

Rexroth IndraDrive MPx-18 Version Notes

R911338658
Edition 03

Release Notes



Title	Rexroth IndraDrive MPx-18 Version Notes
Type of Documentation	Release Notes
Document Typecode	DOK-INDRV*-MP*-18VRS**-RN03-EN-P
Internal File Reference	RS-e957bbc64ed8059e0a6846a5000b847c-3-en-US-4
Purpose of Documentation	This documentation contains an overview of the firmware function or the subject of the section.

Record of Revision

Edition	Release Date	Notes
DOK-INDRV*-MP*-18RS**-RN01-EN-P	2013-04-03	First edition
DOK-INDRV*-MP*-18RS**-RN02-DE-P	2013-12-20	Second edition; not published in English
DOK-INDRV*-MP*-18RS**-RN03-EN-P	2014-02-04	Corrections

Copyright © Bosch Rexroth AG 2014

This document, as well as the data, specifications and other information set forth in it, are the exclusive property of Bosch Rexroth AG. It may not be reproduced or given to third parties without its consent.



sercos is registered trademark of sercos International e.V.



EtherNet /IP™ is a trademark under license of Open DeviceNet Vendor Association, Inc.



ProfiNet® is registered trademark of PROFIBUS Nutzerorganisation e. V.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany



PROFIBUS® is registered trademark of PROFIBUS Nutzerorganisation e. V.



CANopen® is registered trademark of CAN in Automation e.V.

HIPERFACE® is registered trademark of Max Stegmann GmbH

EnDat® is registered trademark of Dr. Johannes Heidenhain GmbH

Liability The specified data is intended for product description purposes only and shall not be deemed to be a guaranteed characteristic unless expressly stipulated in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.

Published by Bosch Rexroth AG ■ Bgm.-Dr.-Nebel-Str. 2 ■ 97816 Lohr a. Main, Germany
Tel. +49 9352 18 0 ■ Fax +49 9352 18 8400 ■ Dept. DC-IA/EDY (TH, BB)
<http://www.boschrexroth.com> ■ dokusupport@boschrexroth.de

Table of Contents

	Page
1 How to Use This Documentation.....	5
1.1 Structure of the Version Notes.....	5
1.2 Markers and Terms.....	6
1.3 Cross References.....	6
1.4 Documentations.....	6
2 Important Directions for Use	7
2.1 Appropriate Use	7
2.1.1 Introduction.....	7
2.1.2 Areas of Use and Application.....	7
2.2 Inappropriate Use.....	8
3 Safety Instructions for Electric Drives and Controls.....	9
3.1 Definitions of Terms.....	9
3.2 General Information.....	10
3.2.1 Using the Safety Instructions and Passing Them on to Others.....	10
3.2.2 Requirements for Safe Use.....	10
3.2.3 Hazards by Improper Use.....	11
3.3 Instructions with Regard to Specific Dangers.....	12
3.3.1 Protection Against Contact with Electrical Parts and Housings.....	12
3.3.2 Protective Extra-Low Voltage as Protection Against Electric Shock	13
3.3.3 Protection Against Dangerous Movements.....	14
3.3.4 Protection Against Magnetic and Electromagnetic Fields During Operation and Mounting.....	15
3.3.5 Protection Against Contact with Hot Parts.....	16
3.3.6 Protection During Handling and Mounting.....	16
3.3.7 Battery Safety.....	16
3.3.8 Protection Against Pressurized Systems.....	17
3.4 Explanation of Signal Words and the Safety Alert Symbol.....	17
4 Changes and Enhancements in Comparison to the Previous Version.....	19
4.1 Definitions of Terms.....	19
4.2 Incompatible new Functions and Functional Changes	19
4.2.1 System Overview.....	19
4.2.2 Master Communication.....	20
4.2.3 Motor, Mechanical Axis System, Measuring Systems.....	21
4.2.4 Drive Control.....	21
4.2.5 Operation Modes.....	21
4.2.6 Extended Axis Functions.....	22
4.2.7 Optional Device Functions.....	22
4.2.8 Handling, Diagnostic and Service Functions.....	28
4.2.9 Engineering/Diagnostic Interfaces.....	29
4.3 Compatible new Functions and Functional Changes	30
4.3.1 System Overview.....	30

Table of Contents

	Page
4.3.2 Master Communication.....	30
4.3.3 Motor, Mechanical Axis System, Measuring Systems.....	31
4.3.4 Drive Control.....	31
4.3.5 Extended Axis Functions.....	33
4.3.6 Optional Device Functions.....	35
4.3.7 Handling, Diagnostic and Service Functions.....	41
4.3.8 Engineering/Diagnostic Interfaces.....	41
4.3.9 Commissioning.....	42
4.4 New, Modified or no Longer Existing Parameters.....	42
4.4.1 New Parameters.....	42
4.4.2 New Alias Parameters	53
4.4.3 Modified Parameters.....	57
4.4.4 Modified Alias Parameters	59
4.4.5 No Longer Existing Parameters.....	66
4.5 New, Modified or no Longer Existing Diagnostic Messages.....	68
4.5.1 New Diagnostic Messages.....	68
4.5.2 Modified Diagnostic Messages.....	71
4.5.3 No Longer Existing Diagnostic Messages.....	71
5 Overview of the Scope of Functions.....	73
5.1 System Overview.....	73
5.1.1 General Information.....	73
5.1.2 IndraDrive Product Range.....	78
5.1.3 Overview of Drive Firmware.....	80
5.1.4 Overview of Master Communication.....	81
5.1.5 Overview of Functions/Functional Packages.....	81
5.1.6 Performance Data.....	93
5.1.7 Drive controllers.....	95
5.1.8 Supported Motors and Measuring Systems.....	102
5.1.9 Documentations.....	103
5.2 Master Communication.....	106
5.2.1 Basic Functions of Master Communication.....	106
5.2.2 Control Options / Additional Functions.....	108
5.2.3 Operating Modes of Master Communication.....	110
5.2.4 Profile Types (with Field Bus Interfaces).....	113
5.2.5 sercos.....	116
5.2.6 EtherCAT®.....	120
5.2.7 EtherNet/IP(TM) Interface.....	123
5.2.8 PROFINET®.....	126
5.2.9 PROFIBUS-DP.....	131
5.2.10 CANopen Interface.....	134
5.2.11 Analog Interface.....	136
5.2.12 RIL_ModbusTCP.....	139
5.3 Motor, Mechanical Axis System, Measuring Systems.....	139
5.3.1 General Information on Operation of Motors with IndraDrive.....	139
5.3.2 Rexroth Motors.....	142

Table of Contents

	Page
5.3.3 Third-Party Motors at IndraDrive Controllers	148
5.3.4 Motor Holding Brake	149
5.3.5 Measuring Systems.....	153
5.3.6 Mechanical Axis System and Arrangement of Measuring Systems.....	169
5.3.7 Scaling of Physical Data.....	173
5.4 Drive Control.....	175
5.4.1 Overview of Drive Control.....	175
5.4.2 Motor Control.....	181
5.4.3 Automatic Setting of Motor Control.....	192
5.4.4 Open-Loop Axis Control (Open-Loop Operation).....	195
5.4.5 Closed-Loop Axis Control (Closed-Loop Operation).....	197
5.4.6 Commutation Setting.....	206
5.4.7 Limitations.....	218
5.4.8 Power Supply.....	223
5.5 Operation Modes.....	226
5.5.1 General Information on the Operation Modes.....	226
5.5.2 Torque/Force Control.....	231
5.5.3 Velocity Control.....	232
5.5.4 Position Control with Cyclic Command Value Input.....	234
5.5.5 Drive-Internal Interpolation.....	236
5.5.6 Drive-Controlled Positioning.....	238
5.5.7 Positioning Block Mode.....	240
5.5.8 Synchronization Modes.....	243
5.6 Extended Axis Functions.....	256
5.6.1 Availability of the Extended Axis Functions.....	256
5.6.2 Drive Halt.....	256
5.6.3 Error Reactions.....	257
5.6.4 E-Stop Function.....	263
5.6.5 Compensation Functions / Corrections.....	263
5.6.6 Measuring Wheel Mode.....	268
5.6.7 Positive Stop Drive Procedure.....	269
5.6.8 Redundant Motor Encoder.....	269
5.6.9 Spindle Positioning.....	270
5.6.10 Parameter Set Switching.....	271
5.6.11 Star-Delta Switching.....	272
5.6.12 Drive-Controlled Oscillation.....	274
5.6.13 Parking Axis.....	275
5.6.14 Integrated Safety Technology.....	275
5.7 Optional Device Functions.....	280
5.7.1 Availability of the Optional Device Functions.....	280
5.7.2 Cross Communication (CCD).....	281
5.7.3 Rexroth IndraMotion MLD (Drive-Integrated PLC).....	288
5.7.4 Digital Inputs/Outputs.....	292
5.7.5 Analog Inputs.....	294
5.7.6 Analog Outputs.....	296
5.7.7 Virtual Master Axis Generator.....	298

Table of Contents

	Page
5.7.8 Drive-Integrated Command Value Generator.....	301
5.7.9 Drive-Internal "Command Value Box".....	303
5.7.10 Encoder Emulation.....	304
5.7.11 Programmable Position Switch.....	307
5.7.12 Probe Function.....	308
5.7.13 Measuring Encoder.....	309
5.8 Handling, Diagnostic and Service Functions.....	311
5.8.1 Parameters, Basics.....	311
5.8.2 Diagnostic System.....	316
5.8.3 Control Panel.....	320
5.8.4 Firmware Replacement.....	322
5.8.5 Optional Memory.....	328
5.8.6 Replacing the Controller.....	329
5.8.7 Enabling of Functional Packages.....	333
5.8.8 Extended Diagnostic Possibilities.....	333
5.8.9 RMS Value Generator in the Drive.....	334
5.8.10 Oscilloscope Function.....	335
5.8.11 Options for Integrated Energy and Power Measurement.....	336
5.9 Engineering/Diagnostic Interfaces.....	339
5.9.1 TCP/IP Communication.....	339
5.9.2 S/IP Protocol.....	340
5.9.3 Firmware Download via TFTP Server	341
5.9.4 File Handling by FTP via Ethernet.....	342
5.10 Commissioning.....	343
5.10.1 Commissioning Motors.....	343
5.10.2 Commissioning Machine Axes.....	347
5.10.3 Axis Simulation.....	349
6 Service and Support.....	351
Index.....	353

1 How to Use This Documentation

1.1 Structure of the Version Notes

Purpose of This Documentation

These Version Notes contain

- the changes in comparison to the previous version MPx-17VRS in [chapter 4 "Changes and Enhancements in Comparison to the Previous Version" on page 19](#) with the following contents:
 - the compatible new functions and functional enhancements
 - the incompatible new functions and functional enhancements
 - the new, modified and no longer existing parameters
 - the new, modified and no longer existing diagnostic messages
- an overview of the firmware function with the pertinent parameters and diagnostic messages in [chapter 5 "Overview of the Scope of Functions" on page 73](#).

The description of a firmware function in the documentation is basically divided into fixed chapters:

- Brief Description
- Functional Description
- Notes on Commissioning
- Diagnostic and Status Messages, Monitoring Functions

This documentation "Rexroth IndraDrive, MPx-18, Version Notes" only contains the "Brief Description" sections of the firmware function. They provide an overview of the firmware function or the subject of the section. The Brief Description can contain, for example, general basics, the most important features of the function, overviews and examples of application.



The detailed description of the firmware function is contained in the Application Manual "Rexroth IndraDrive, MPx-18, Functions" (DOK-INDRV*-MP*-18VRS**-APxx-EN-P, mat. no. R911338673).



The detailed description of the parameters, their function and structure is contained in the separate documentation "Rexroth IndraDrive, Parameters".



The detailed description of the diagnostic messages, their causes and remedies is contained in the separate documentation "Rexroth IndraDrive, Diagnostic Messages".

Your Feedback

Your experience is important for our improvement processes of products and documentations.

If you discover mistakes in this documentation or suggest changes, you can send your feedback to the following e-mail address:

Dokusupport@boschrexroth.de

In order that we can handle your feedback, please send us the number indicated under "Internal File Reference" and the page number.

How to Use This Documentation

1.2 Markers and Terms

The complete functionality of the IndraDrive firmware is divided into functional packages (base packages and optional expansion packages). The scope of the available functions does not only depend on the hardware design, but in the majority of cases also on the variant and characteristic of the firmware.

The descriptions of the drive functions and the operation modes have a marker containing information on the availability of this functionality in the respective functional package of the firmware.

Terms The following terms are used in the Version Notes and in the Functional Description:

- Firmware **range**, e.g. IndraDrive
- Firmware **design**, e.g. single-axis, double-axis
- Firmware **variant**, e.g. MPB, MPE
- Firmware **version**, e.g. MPB-18VRS
- Firmware **characteristic**, e.g. open-loop/closed-loop
- Firmware **performance**, e.g. Basic/Economy/Advanced
- Firmware **type**, complete firmware type designation

Means of Representation in This Documentation

Bold type is used for important facts which are to be highlighted in the body text. "Quotation marks" are used for parameter names, diagnostic message names, function designations.

All important notes (e.g. warning, caution) are highlighted by a symbol. Signal words in accordance with ANSI Z535.6-2006 draw the reader's attention to hazards (see "[Explanation of Signal Words and the Safety Alert Symbol](#)"). In addition, there are the following tips:



This box contains important information that should be taken into consideration.



This symbol highlights useful tips and tricks.

1.3 Cross References

Many basic subfunctions of the firmware, as well as necessary settings and definitions, are of multiple use within the overall functionality or have an effect on neighboring areas of the drive functionality. Descriptions that are part of other IndraDrive documentations (Parameter Description, Description of Diagnostic Messages, Project Planning Manuals ...) are only repeated in detail in exceptional cases. Cross references indicate the source for more detailed information.

1.4 Documentations

For a list of the reference documentations, see [chapter 5.1.9 "Documentations" on page 103](#)

2 Important Directions for Use

2.1 Appropriate Use

2.1.1 Introduction

Rexroth products reflect the state-of-the-art in their development and their manufacture. They are tested prior to delivery to ensure operating safety and reliability.

WARNING

Personal injury and property damage caused by incorrect use of the products!

The products have been designed for use in industrial environments and may only be used in the appropriate way. If they are not used in the appropriate way, situations resulting in property damage and personal injury can occur.



Rexroth as manufacturer is not liable for any damages resulting from inappropriate use. In such cases, the guarantee and the right to payment of damages resulting from inappropriate use are forfeited. The user alone carries all responsibility of the risks.

Before using Rexroth products, the following pre-requisites must be met to ensure appropriate use of the products:

- Personnel that in any way, shape or form uses our products must first read and understand the relevant safety instructions and be familiar with their appropriate use.
- If the products take the form of hardware, then they must remain in their original state, in other words, no structural changes are permitted. It is not permitted to decompile software products or alter source codes.
- Damaged or faulty products may not be installed or put into operation.
- Make sure that the products have been installed in the manner described in the relevant documentation.

2.1.2 Areas of Use and Application

Drive controllers made by Rexroth are designed to control electrical motors and monitor their operation.

Control and monitoring of the Drive controllers may require additional sensors and actors.



The drive controllers may only be used with the accessories and parts specified in this documentation. If a component has not been specifically named, then it may neither be mounted nor connected. The same applies to cables and lines.

Operation is only permitted in the specified configurations and combinations of components using the software and firmware as specified in the relevant Functional Descriptions.

Drive controllers have to be programmed before commissioning to ensure that the motor executes the specific functions of an application.

Drive controllers of the Rexroth IndraDrive line have been developed for use in single- and multi-axis drive and control tasks.

Important Directions for Use

To ensure application-specific use of Drive controllers, device types of different drive power and different interfaces are available.

Typical applications include, for example:

- Handling and mounting systems,
- Packaging and food machines,
- Printing and paper processing machines and
- Machine tools.

Drive controllers may only be operated under the assembly and installation conditions described in this documentation, in the specified position of normal use and under the ambient conditions as described (temperature, degree of protection, humidity, EMC, etc.).

2.2 Inappropriate Use

Using the Drive controllers outside of the operating conditions described in this documentation and outside of the technical data and specifications given is defined as "inappropriate use".

Drive controllers may not be used, if ...

- they are subject to operating conditions that do not meet the specified ambient conditions. This includes, for example, operation under water, under extreme temperature fluctuations or extremely high maximum temperatures.
- Furthermore, Drive controllers may not be used in applications which have not been expressly authorized by Rexroth. Please carefully follow the specifications outlined in the general Safety Instructions!



Components of the Rexroth IndraDrive system are **products of category C3** (with limited availability) according to IEC 61800-3. To ensure that this category (limit values) is maintained, suitable line filters must be used in the drive system.

These components are not provided for use in a public low-voltage network supplying residential areas with power. If these components are used in such a public network, high-frequency interference is to be expected. This can require additional measures of radio interference suppression.

3 Safety Instructions for Electric Drives and Controls

3.1 Definitions of Terms

Application Documentation	Application documentation comprises the entire documentation used to inform the user of the product about the use and safety-relevant features for configuring, integrating, installing, mounting, commissioning, operating, maintaining, repairing and decommissioning the product. The following terms are also used for this kind of documentation: Operating Instructions, Commissioning Manual, Instruction Manual, Project Planning Manual, Application Description, etc.
Component	A component is a combination of elements with a specified function, which are part of a piece of equipment, device or system. Components of the electric drive and control system are, for example, supply units, drive controllers, mains choke, mains filter, motors, cables, etc.
Control System	A control system comprises several interconnected control components placed on the market as a single functional unit.
Device	A device is a finished product with a defined function, intended for users and placed on the market as an individual piece of merchandise.
Electrical Equipment	Electrical equipment encompasses all devices used to generate, convert, transmit, distribute or apply electrical energy, such as electric motors, transformers, switching devices, cables, lines, power-consuming devices, circuit board assemblies, plug-in units, control cabinets, etc.
Electric Drive System	An electric drive system comprises all components from mains supply to motor shaft; this includes, for example, electric motor(s), motor encoder(s), supply units and drive controllers, as well as auxiliary and additional components, such as mains filter, mains choke and the corresponding lines and cables.
Installation	An installation consists of several devices or systems interconnected for a defined purpose and on a defined site which, however, are not intended to be placed on the market as a single functional unit.
Machine	A machine is the entirety of interconnected parts or units at least one of which is movable. Thus, a machine consists of the appropriate machine drive elements, as well as control and power circuits, which have been assembled for a specific application. A machine is, for example, intended for processing, treatment, movement or packaging of a material. The term "machine" also covers a combination of machines which are arranged and controlled in such a way that they function as a unified whole.
Manufacturer	The manufacturer is an individual or legal entity bearing responsibility for the design and manufacture of a product which is placed on the market in the individual's or legal entity's name. The manufacturer can use finished products, finished parts or finished elements, or contract out work to subcontractors. However, the manufacturer must always have overall control and possess the required authority to take responsibility for the product.
Product	Examples of a product: Device, component, part, system, software, firmware, among other things.
Project Planning Manual	A project planning manual is part of the application documentation used to support the sizing and planning of systems, machines or installations.
Qualified Persons	In terms of this application documentation, qualified persons are those persons who are familiar with the installation, mounting, commissioning and operation of the components of the electric drive and control system, as well as with the hazards this implies, and who possess the qualifications their work

Safety Instructions for Electric Drives and Controls

requires. To comply with these qualifications, it is necessary, among other things,

- 1) to be trained, instructed or authorized to switch electric circuits and devices safely on and off, to ground them and to mark them
- 2) to be trained or instructed to maintain and use adequate safety equipment
- 3) to attend a course of instruction in first aid

User A user is a person installing, commissioning or using a product which has been placed on the market.

3.2 General Information

3.2.1 Using the Safety Instructions and Passing Them on to Others

Do not attempt to install and operate the components of the electric drive and control system without first reading all documentation provided with the product. Read and understand these safety instructions and all user documentation prior to working with these components. If you do not have the user documentation for the components, contact your responsible Rexroth sales partner. Ask for these documents to be sent immediately to the person or persons responsible for the safe operation of the components.

If the component is resold, rented and/or passed on to others in any other form, these safety instructions must be delivered with the component in the official language of the user's country.

Improper use of these components, failure to follow the safety instructions in this document or tampering with the product, including disabling of safety devices, could result in property damage, injury, electric shock or even death.

3.2.2 Requirements for Safe Use

Read the following instructions before initial commissioning of the components of the electric drive and control system in order to eliminate the risk of injury and/or property damage. You must follow these safety instructions.

- Rexroth is not liable for damages resulting from failure to observe the safety instructions.
- Read the operating, maintenance and safety instructions in your language before commissioning. If you find that you cannot completely understand the application documentation in the available language, please ask your supplier to clarify.
- Proper and correct transport, storage, mounting and installation, as well as care in operation and maintenance, are prerequisites for optimal and safe operation of the component.
- Only qualified persons may work with components of the electric drive and control system or within its proximity.
- Only use accessories and spare parts approved by Rexroth.
- Follow the safety regulations and requirements of the country in which the components of the electric drive and control system are operated.
- Only use the components of the electric drive and control system in the manner that is defined as appropriate. See chapter "Appropriate Use".
- The ambient and operating conditions given in the available application documentation must be observed.
- Applications for functional safety are only allowed if clearly and explicitly specified in the application documentation "Integrated Safety Technolo-

Safety Instructions for Electric Drives and Controls

gy". If this is not the case, they are excluded. Functional safety is a safety concept in which measures of risk reduction for personal safety depend on electrical, electronic or programmable control systems.

- The information given in the application documentation with regard to the use of the delivered components contains only examples of applications and suggestions.

The machine and installation manufacturers must

- make sure that the delivered components are suited for their individual application and check the information given in this application documentation with regard to the use of the components,
- make sure that their individual application complies with the applicable safety regulations and standards and carry out the required measures, modifications and complements.
- Commissioning of the delivered components is only allowed once it is sure that the machine or installation in which the components are installed complies with the national regulations, safety specifications and standards of the application.
- Operation is only allowed if the national EMC regulations for the application are met.
- The instructions for installation in accordance with EMC requirements can be found in the section on EMC in the respective application documentation.

The machine or installation manufacturer is responsible for compliance with the limit values as prescribed in the national regulations.

- The technical data, connection and installation conditions of the components are specified in the respective application documentations and must be followed at all times.

National regulations which the user must take into account

- European countries: In accordance with European EN standards
- United States of America (USA):
 - National Electrical Code (NEC)
 - National Electrical Manufacturers Association (NEMA), as well as local engineering regulations
 - Regulations of the National Fire Protection Association (NFPA)
- Canada: Canadian Standards Association (CSA)
- Other countries:
 - International Organization for Standardization (ISO)
 - International Electrotechnical Commission (IEC)

3.2.3 Hazards by Improper Use

- High electrical voltage and high working current! Danger to life or serious injury by electric shock!
- High electrical voltage by incorrect connection! Danger to life or injury by electric shock!
- Dangerous movements! Danger to life, serious injury or property damage by unintended motor movements!
- Health hazard for persons with heart pacemakers, metal implants and hearing aids in proximity to electric drive systems!

Safety Instructions for Electric Drives and Controls

- Risk of burns by hot housing surfaces!
- Risk of injury by improper handling! Injury by crushing, shearing, cutting, hitting!
- Risk of injury by improper handling of batteries!
- Risk of injury by improper handling of pressurized lines!

3.3 Instructions with Regard to Specific Dangers

3.3.1 Protection Against Contact with Electrical Parts and Housings



This section concerns components of the electric drive and control system with voltages of **more than 50 volts**.

Contact with parts conducting voltages above 50 volts can cause personal danger and electric shock. When operating components of the electric drive and control system, it is unavoidable that some parts of these components conduct dangerous voltage.

High electrical voltage! Danger to life, risk of injury by electric shock or serious injury!

- Only qualified persons are allowed to operate, maintain and/or repair the components of the electric drive and control system.
- Follow the general installation and safety regulations when working on power installations.
- Before switching on, the equipment grounding conductor must have been permanently connected to all electric components in accordance with the connection diagram.
- Even for brief measurements or tests, operation is only allowed if the equipment grounding conductor has been permanently connected to the points of the components provided for this purpose.
- Before accessing electrical parts with voltage potentials higher than 50 V, you must disconnect electric components from the mains or from the power supply unit. Secure the electric component from reconnection.
- With electric components, observe the following aspects:
Always wait **30 minutes** after switching off power to allow live capacitors to discharge before accessing an electric component. Measure the electrical voltage of live parts before beginning to work to make sure that the equipment is safe to touch.
- Install the covers and guards provided for this purpose before switching on.
- Never touch electrical connection points of the components while power is turned on.
- Do not remove or plug in connectors when the component has been powered.
- Under specific conditions, electric drive systems can be operated at mains protected by residual-current-operated circuit-breakers sensitive to universal current (RCDs/RCMs).

Safety Instructions for Electric Drives and Controls

- Secure built-in devices from penetrating foreign objects and water, as well as from direct contact, by providing an external housing, for example a control cabinet.

High housing voltage and high leakage current! Danger to life, risk of injury by electric shock!

- Before switching on and before commissioning, ground or connect the components of the electric drive and control system to the equipment grounding conductor at the grounding points.
- Connect the equipment grounding conductor of the components of the electric drive and control system permanently to the main power supply at all times. The leakage current is greater than 3.5 mA.
- Establish an equipment grounding connection with a minimum cross section according to the table below. With an outer conductor cross section smaller than 10 mm² (8 AWG), the alternative connection of two equipment grounding conductors is allowed, each having the same cross section as the outer conductors.

Cross section outer conductor	Minimum cross section equipment grounding conductor	
	Leakage current ≥ 3.5 mA	
	1 equipment grounding conductor	2 equipment grounding conductors
1.5 mm ² (16 AWG)	10 mm ² (8 AWG)	2 × 1.5 mm ² (16 AWG)
2.5 mm ² (14 AWG)		2 × 2.5 mm ² (14 AWG)
4 mm ² (12 AWG)		2 × 4 mm ² (12 AWG)
6 mm ² (10 AWG)		2 × 6 mm ² (10 AWG)
10 mm ² (8 AWG)		-
16 mm ² (6 AWG)	16 mm ² (6 AWG)	-
25 mm ² (4 AWG)		-
35 mm ² (2 AWG)		-
50 mm ² (1/0 AWG)	25 mm ² (4 AWG)	-
70 mm ² (2/0 AWG)	35 mm ² (2 AWG)	-
...	...	...

Tab. 3-1: Minimum Cross Section of the Equipment Grounding Connection

3.3.2 Protective Extra-Low Voltage as Protection Against Electric Shock

Protective extra-low voltage is used to allow connecting devices with basic insulation to extra-low voltage circuits.

On components of an electric drive and control system provided by Rexroth, all connections and terminals with voltages up to 50 volts are PELV ("Protective Extra-Low Voltage") systems. It is allowed to connect devices equipped with basic insulation (such as programming devices, PCs, notebooks, display units) to these connections.

Safety Instructions for Electric Drives and Controls

Danger to life, risk of injury by electric shock! High electrical voltage by incorrect connection!

If extra-low voltage circuits of devices containing voltages and circuits of more than 50 volts (e.g., the mains connection) are connected to Rexroth products, the connected extra-low voltage circuits must comply with the requirements for PELV ("Protective Extra-Low Voltage").

3.3.3 Protection Against Dangerous Movements

Dangerous movements can be caused by faulty control of connected motors. Some common examples are:

- Improper or wrong wiring or cable connection
- Operator errors
- Wrong input of parameters before commissioning
- Malfunction of sensors and encoders
- Defective components
- Software or firmware errors

These errors can occur immediately after equipment is switched on or even after an unspecified time of trouble-free operation.

The monitoring functions in the components of the electric drive and control system will normally be sufficient to avoid malfunction in the connected drives. Regarding personal safety, especially the danger of injury and/or property damage, this alone cannot be relied upon to ensure complete safety. Until the integrated monitoring functions become effective, it must be assumed in any case that faulty drive movements will occur. The extent of faulty drive movements depends upon the type of control and the state of operation.

Dangerous movements! Danger to life, risk of injury, serious injury or property damage!

A **risk assessment** must be prepared for the installation or machine, with its specific conditions, in which the components of the electric drive and control system are installed.

As a result of the risk assessment, the user must provide for monitoring functions and higher-level measures on the installation side for personal safety. The safety regulations applicable to the installation or machine must be taken into consideration. Unintended machine movements or other malfunctions are possible if safety devices are disabled, bypassed or not activated.

To avoid accidents, injury and/or property damage:

- Keep free and clear of the machine's range of motion and moving machine parts. Prevent personnel from accidentally entering the machine's range of motion by using, for example:
 - Safety fences
 - Safety guards
 - Protective coverings
 - Light barriers
- Make sure the safety fences and protective coverings are strong enough to resist maximum possible kinetic energy.
- Mount emergency stopping switches in the immediate reach of the operator. Before commissioning, verify that the emergency stopping equip-

Safety Instructions for Electric Drives and Controls

ment works. Do not operate the machine if the emergency stopping switch is not working.

- Prevent unintended start-up. Isolate the drive power connection by means of OFF switches/OFF buttons or use a safe starting lockout.
- Make sure that the drives are brought to safe standstill before accessing or entering the danger zone.
- Additionally secure vertical axes against falling or dropping after switching off the motor power by, for example,
 - mechanically securing the vertical axes,
 - adding an external braking/arrester/clamping mechanism or
 - ensuring sufficient counterbalancing of the vertical axes.
- The standard equipment **motor holding brake** or an external holding brake controlled by the drive controller is **not sufficient to guarantee personal safety!**
- Disconnect electrical power to the components of the electric drive and control system using the master switch and secure them from reconnection ("lock out") for:
 - Maintenance and repair work
 - Cleaning of equipment
 - Long periods of discontinued equipment use
- Prevent the operation of high-frequency, remote control and radio equipment near components of the electric drive and control system and their supply leads. If the use of these devices cannot be avoided, check the machine or installation, at initial commissioning of the electric drive and control system, for possible malfunctions when operating such high-frequency, remote control and radio equipment in its possible positions of normal use. It might possibly be necessary to perform a special electromagnetic compatibility (EMC) test.

3.3.4 Protection Against Magnetic and Electromagnetic Fields During Operation and Mounting

Magnetic and electromagnetic fields generated by current-carrying conductors or permanent magnets of electric motors represent a serious danger to persons with heart pacemakers, metal implants and hearing aids.

Health hazard for persons with heart pacemakers, metal implants and hearing aids in proximity to electric components!

- Persons with heart pacemakers and metal implants are not allowed to enter the following areas:
 - Areas in which components of the electric drive and control systems are mounted, commissioned and operated.
 - Areas in which parts of motors with permanent magnets are stored, repaired or mounted.
- If it is necessary for somebody with a heart pacemaker to enter such an area, a doctor must be consulted prior to doing so. The noise immunity of implanted heart pacemakers differs so greatly that no general rules can be given.
- Those with metal implants or metal pieces, as well as with hearing aids, must consult a doctor before they enter the areas described above.

Safety Instructions for Electric Drives and Controls

3.3.5 Protection Against Contact with Hot Parts

Hot surfaces of components of the electric drive and control system. Risk of burns!

- Do not touch hot surfaces of, for example, braking resistors, heat sinks, supply units and drive controllers, motors, windings and laminated cores!
- According to the operating conditions, temperatures of the surfaces can be **higher than 60 °C (140 °F)** during or after operation.
- Before touching motors after having switched them off, let them cool down for a sufficient period of time. Cooling down can require **up to 140 minutes!** The time required for cooling down is approximately five times the thermal time constant specified in the technical data.
- After switching chokes, supply units and drive controllers off, wait **15 minutes** to allow them to cool down before touching them.
- Wear safety gloves or do not work at hot surfaces.
- For certain applications, and in accordance with the respective safety regulations, the manufacturer of the machine or installation must take measures to avoid injuries caused by burns in the final application. These measures can be, for example: Warnings at the machine or installation, guards (shields or barriers) or safety instructions in the application documentation.

3.3.6 Protection During Handling and Mounting

Risk of injury by improper handling! Injury by crushing, shearing, cutting, hitting!

- Observe the relevant statutory regulations of accident prevention.
- Use suitable equipment for mounting and transport.
- Avoid jamming and crushing by appropriate measures.
- Always use suitable tools. Use special tools if specified.
- Use lifting equipment and tools in the correct manner.
- Use suitable protective equipment (hard hat, safety goggles, safety shoes, safety gloves, for example).
- Do not stand under hanging loads.
- Immediately clean up any spilled liquids from the floor due to the risk of falling!

3.3.7 Battery Safety

Batteries consist of active chemicals in a solid housing. Therefore, improper handling can cause injury or property damage.

Risk of injury by improper handling!

- Do not attempt to reactivate low batteries by heating or other methods (risk of explosion and cauterization).
- Do not attempt to recharge the batteries as this may cause leakage or explosion.
- Do not throw batteries into open flames.
- Do not dismantle batteries.

Safety Instructions for Electric Drives and Controls

- When replacing the battery/batteries, do not damage the electrical parts installed in the devices.
- Only use the battery types specified for the product.



Environmental protection and disposal! The batteries contained in the product are considered dangerous goods during land, air, and sea transport (risk of explosion) in the sense of the legal regulations. Dispose of used batteries separately from other waste. Observe the national regulations of your country.

3.3.8 Protection Against Pressurized Systems

According to the information given in the Project Planning Manuals, motors and components cooled with liquids and compressed air can be partially supplied with externally fed, pressurized media, such as compressed air, hydraulics oil, cooling liquids and cooling lubricants. Improper handling of the connected supply systems, supply lines or connections can cause injuries or property damage.

Risk of injury by improper handling of pressurized lines!

- Do not attempt to disconnect, open or cut pressurized lines (risk of explosion).
- Observe the respective manufacturer's operating instructions.
- Before dismantling lines, relieve pressure and empty medium.
- Use suitable protective equipment (safety goggles, safety shoes, safety gloves, for example).
- Immediately clean up any spilled liquids from the floor due to the risk of falling!



Environmental protection and disposal! The agents (e.g., fluids) used to operate the product might not be environmentally friendly. Dispose of agents harmful to the environment separately from other waste. Observe the national regulations of your country.

3.4 Explanation of Signal Words and the Safety Alert Symbol

The Safety Instructions in the available application documentation contain specific signal words (DANGER, WARNING, CAUTION or NOTICE) and, where required, a safety alert symbol (in accordance with ANSI Z535.6-2011).

The signal word is meant to draw the reader's attention to the safety instruction and identifies the hazard severity.

The safety alert symbol (a triangle with an exclamation point), which precedes the signal words DANGER, WARNING and CAUTION, is used to alert the reader to personal injury hazards.



In case of non-compliance with this safety instruction, death or serious injury will occur.

Safety Instructions for Electric Drives and Controls

WARNING

In case of non-compliance with this safety instruction, death or serious injury **could** occur.

CAUTION

In case of non-compliance with this safety instruction, minor or moderate injury could occur.

NOTICE

In case of non-compliance with this safety instruction, property damage could occur.

4 Changes and Enhancements in Comparison to the Previous Version

4.1 Definitions of Terms

Regarding the changes and enhancements in comparison to the previous version MPx-17VRS, we distinguish between the incompatible and compatible functions and functional enhancements.

Incompatible Functions

Incompatible new functions or incompatible functional enhancements produce an axis behavior which does not correspond to the previous version.

The causes can be, for example:

- Changes in the error behavior
- Change of default values (e.g. inertia)
- Change of filter types and filter degree
- Additional monitoring functions (e.g. in the safety technology) take effect



Before commissioning, you must check whether the new firmware in the application results in a different behavior at the axis, which might possibly cause problems.

If a new function or functional enhancement is incompatible, this means that, for example, a parameter file from a previous version (MPx16VRS, MPx17VRS in this case) **cannot** be used in the new firmware (MPx18V08 in this case).

Maybe the behavior of the previous version can partly be reestablished by parameter adjustment.

Compatible Functions

Compatibility of a new function or functional enhancement means that, for example, a parameter file from a previous version (MPx16VRS, MPx17VRS in this case) can be used in the new firmware (MPx18V08 in this case).

With the standard settings of the new firmware and/or the parameter settings from the previous version, the drive shows the same behavior as before the upgrade; the reaction to a command value input, for example, does not differ in both firmwares. It is not necessary to adjust parameters.

4.2 Incompatible new Functions and Functional Changes

4.2.1 System Overview

Control Sections

CSB02 Control Sections - Basic Plug-in Unit

Modifications to the Basic control section CSB02 in comparison to the CSB01.x control section:

- SERCOS II is no longer supported
- Evaluation of MKD/MHD motors is no longer supported
- The interface assignment at the front panel has changed
- MMC is no longer supported
- Serial interface is no longer supported
- BB relay contact permanently configured

Changes and Enhancements in Comparison to the Previous Version

- MA1 and MD1 options (analog and digital I/O extensions) are not supported
- As of MPx18V10: "DA" option (analog and digital I/O extension) is supported

See also control sections supported by the firmware in the chapter "[Drive Controllers, Control Sections and Optional Modules](#)"

CSH02 Control Sections - Advanced Plug-in Unit

Modifications to the Advanced control section CSH02 in comparison to the CSH01.x control section:

- SERCOS II is no longer supported
- Evaluation of MKD/MHD motors is no longer supported
- The interface assignment at the front panel has changed
- Extension of the analog I/Os
- One slot for optional modules no longer available
- MMC is replaced by μ SD card in the control panel
- Serial interface is no longer supported
- BB relay contact permanently configured
- MA1 and MD1 options (analog and digital I/O extensions) are not supported
- As of MPx18V10: "DA" option (analog and digital I/O extension) is supported

See also control sections supported by the firmware in the chapter "[Drive Controllers, Control Sections and Optional Modules](#)"

CDB02 Control Sections - Double-Axis Plug-in Unit

Modifications to the double-axis control section CDB02 in comparison to the CDB01.1 control section:

- SERCOS II is no longer supported
- Evaluation of MKD/MHD motors is no longer supported
- The interface assignment at the front panel has changed
- Modifications for analog I/Os
- Two slots for optional modules no longer available
- MMC is no longer supported
- Serial interface is no longer supported
- BB relay contact permanently configured
- MA1 and MD1 options (analog and digital I/O extensions) are not supported
- As of MPx18V10: "DA" option (analog and digital I/O extension) is supported

4.2.2 Master Communication

EtherCAT (SoE)

EtherCAT, Synchronization and Timing

Operation via EtherCAT now is possible without synchronization via "Distributed Clocks".

4.2.3 Motor, Mechanical Axis System, Measuring Systems

Motors

Holding Brakes, Brake Check

Safe Break Control (SBC) is impossible with self-releasing brakes. With SBC, the "drive ON delay time" and "drive OFF delay time" are internally extended by the delay of control due to the safety technology option. The actual delay of control can be found in the safety technology documentation. The parameters "S-0-0206, Drive on delay time" and "S-0-0207, Drive off delay time" must be set again for third-party motors due to modified decimal places.

Motors that can be Operated, General

For motors with a winding insulation system which has not been designed for the voltage load of the DC750V bus, the parameter "P-0-0853, Max. DC bus voltage, motor" was implemented. The braking resistor threshold is adjusted to the value of this parameter, the DC bus voltage is limited to this value ("output stage locked").

The parameter P-0-0853 is set in accordance with the version of the data structure of the encoder memory or is otherwise loaded via the DriveBase data of IndraWorks:

- Version 4 (MSK) and 6 (SBC): 950 V
- Version 5 (MSM): 420 V
- IndraWorks (MCP: primary part of MCL motor): 420 V

Operation with utilization of the additional reluctance torque of MSK133 is only possible with MPx18.

With the new control section generation (HCS01), it is not possible to operate MHD and MKD motors with the "plug & play" method. The encoder memory is no longer supported.

4.2.4 Drive Control

Connection Conditions

Power Supply of Converter, Mains Failure and Phase Failure

The parameter "P-0-0810, Minimum mains crest value" was removed. The warning "E2814Undervoltage in mains" is generated, when the mains voltage has fallen below the minimum allowed value (hardware-dependent). It is impossible to individually increase the minimum value.

4.2.5 Operation Modes

Operation Modes, General

The following operation modes no longer exist:

- Cam, encoder 1, virtual master axis 0x8803
- Cam, encoder 2, virtual master axis 0x8804
- Cam lagless, encoder 1, virtual master axis 0x880B
- Cam lagless, encoder 2, virtual master axis 0x880C
- Cam, encoder 1, real master axis 0x8813
- Cam, encoder 2, real master axis 0x8814
- Cam lagless, encoder 1, real master axis 0x881B
- Cam lagless, encoder 2, real master axis 0x881C
- Phase synchronization, encoder 1, virtual master axis 0x9003

Changes and Enhancements in Comparison to the Previous Version

- Phase synchronization, encoder 2, virtual master axis 0x9004
- Phase synchronization lagless, encoder 1, virtual master axis 0x900B
- Phase synchronization lagless, encoder 2, virtual master axis 0x900C
- Phase synchronization, encoder 1, real master axis 0x9013
- Phase synchronization, encoder 2, real master axis 0x9014
- Phase synchronization lagless, encoder 1, real master axis 0x901B
- Phase synchronization lagless, encoder 2, real master axis 0x901C
- Velocity synchronization, virtual master axis 0xA002
- Velocity synchronization, real master axis 0xA012
- MotionProfile, encoder1, virtual master axis 0x9803
- MotionProfile, encoder2, virtual master axis 0x9804
- MotionProfile lagless, encoder1, virtual master axis 0x980B
- MotionProfile lagless, encoder2, virtual master axis 0x980C
- MotionProfile, encoder1, real master axis 0x9813
- MotionProfile, encoder2, real master axis 0x9814
- MotionProfile lagless, encoder1, real master axis 0x981B
- MotionProfile lagless, encoder2, real master axis 0x981C

The following operation mode codings no longer exist - get new operation mode codings:

- Drive-controlled positioning, encoder1 old: 0x0213 new: 0x0123
- Drive-controlled positioning, encoder2 old: 0x0214 new: 0x0124
- Drive-controlled positioning lagless, encoder1 old: 0x021B new: 0x012B
- Drive-controlled positioning lagless, encoder2 old: 0x021C new: 0x012C
- Drive-controlled positioning with ctrl word of axis controller old: 0x0215 new: 325

Operation Mode Handling, Drive State Machine

HW interlock signaled by E-Stop or module bus or safety technology in "P-0-0115, Device control: Status word", bits 14 and 15 (bits are 00, if no enabling by HW)

The error message "F2025Drive not ready for control" is output, if the drive enable signal is set in this case.

4.2.6 Extended Axis Functions

Power Supply

Functions of the Inverter

The automatic clearing of the error "F2026Undervoltage in power section" in case drive enable is removed is no longer supported.

4.2.7 Optional Device Functions

CCD Function (sercos Master)

General

With the MPx18 firmware, the CCD parameterization is entirely changed to EIDNs. The table below helps with the conversion of an existing parameterization or access for diagnostic purposes etc. (before MPx18) to the new parameters.

Changes and Enhancements in Comparison to the Previous Version

No longer existing parameters	Replacement parameters as of MPx-18	Parameter name
P-0-1600	P-0-1800.0.1	CCD: Configuration
P-0-1601	P-0-1801.0.10	CCD: Addresses of projected drives
P-0-1602	P-0-1810.0.3	CCD: Timing settings
P-0-1603	P-0-1801.0.3	CCD: Actual topology addresses
P-0-1604	P-0-1801.0.11	CCD: Addresses of projected I/Os
P-0-1605	P-0-1802.0.3	CCD: Command communication phase
P-0-1606	P-0-1802.0.4	CCD: Actual communication phase
P-0-1607	P-0-1810.0.16	CCD: Axis error
P-0-1608	P-0-1800.0.3	CCD: Control word
P-0-1609	P-0-1810.0.2	CCD: Status word
P-0-1610	P-0-1800.0.10	CCD: Cycle time
P-0-1610.0.3	P-0-1801.0.21	CCD: Actual topology
P-0-1610.0.21	P-0-1801.0.22	CCD: Slave addresses at end of line
P-0-1610.0.30	P-0-1810.0.10	CCD: Diagnostic message text
P-0-1610.0.31	P-0-1810.0.11	CCD: Diagnosis code
P-0-1611	P-0-1804.1.1 - P-0-1804.10.1	CCD: Configuration list signal status word
P-0-1612	P-0-1804.1.2 - P-0-1804.10.2	CCD: Configuration list signal control word
P-0-1613	P-0-1804.1.3 - P-0-1804.10.3	CCD: Assignment list signal status word
P-0-1614	P-0-1804.1.4 - P-0-1804.10.4	CCD: Assignment list signal control word
P-0-1615	P-0-1800.0.30	CCD: Extrapolated cmd value IDN list signal selection
P-0-1616	P-0-1800.0.31	CCD: Extrapolated cmd value signal selection
P-0-1617	P-0-1800.0.32	CCD: Number of extrapolation steps
P-0-1618	P-0-1800.0.33	CCD: Extrapolated command value
P-0-1619	P-0-1801.0.4	CCD: Slave information at topology location
P-0-1620.0.3	P-0-1801.0.20	CCD: Command topology
P-0-1620.0.4	P-0-1801.0.1	CCD: Slave identification
P-0-1620.0.5	P-0-1802.0.1	C7400 CCD: Switching to phase 2
P-0-1620.0.6	P-0-1802.0.2	C7500 CCD: Switching to phase 4
P-0-1620.0.21	P-0-1801.0.23	C7100 CCD: Command Close ring
P-0-1620.0.30	No longer exists	
P-0-1620.0.31	No longer exists	
P-0-1621.x.1	P-0-1803.2.1 - P-0-1803.8.1	CCD: Slave address in high level network

Changes and Enhancements in Comparison to the Previous Version

No longer existing parameters	Replacement parameters as of MPx-18	Parameter name
P-0-1621.x.9	P-0-1803.2.20 - P-0-1803.10.20	CCD: Master comm. C0100 Comm. phase 3 transition check
P-0-1621.x.10	P-0-1803.2.21 - P-0-1803.10.21	CCD: Master comm. C5200 Comm. phase 4 transition check
P-0-1621.x.24	P-0-1803.2.24 - P-0-1803.10.24	CCD: Master communication gateway parameter pool 1
P-0-1621.x.25	P-0-1803.2.25 - P-0-1803.10.25	CCD: Master communication gateway parameter pool 2
P-0-1621.x.35	P-0-1803.2.22 - P-0-1803.10.22	C5300 CCD: sercos SYNC delay measuring procedure command
P-0-1621	P-0-1803.2.11 - P-0-1803.10.11	CCD: Configuration list master communication cmd values
P-0-1622	P-0-1803.2.12 - P-0-1803.10.12	CCD: Configuration list master communication actual values
P-0-1623	P-0-1805.1.1 - P-0-1805.10.1	CCD: Configuration list master cmd values
P-0-1624	P-0-1805.1.2 - P-0-1805.10.2	CCD: Configuration list actual master values
P-0-1625	P-0-1805.1.3 - P-0-1805.10.3	CCD: Configuration list slave cmd values
P-0-1626	P-0-1805.1.4 - P-0-1805.10.4	CCD: Configuration list actual slave values
P-0-1627	No longer exists	
P-0-1628	No longer exists	
P-0-1629	No longer exists	
P-0-1630	P-0-1810.0.10	CCD: Diagnostic message text
P-0-1630.x.1	P-0-1806.1.1 - P-0-1806.14.1	CCD: Slave IP address
P-0-1630.x.2	P-0-1806.1.2 - P-0-1806.14.2	CCD: Device Status (S-Dev)
P-0-1630.x.3	P-0-1806.1.4 - P-0-1806.14.4	CCD: Connection-Control #0 (C-Con)
P-0-1630.x.20	P-0-1806.1.10 - P-0-1806.14.10	CCD: Resource-Status (S-Res)
P-0-1631	P-0-1810.0.15	CCD: AT error counter
P-0-1632	No longer exists	
P-0-1633	No longer exists	
P-0-1634.x.1	No longer exists	
P-0-1635	P-0-1801.0.5	C7000 CCD: Command adjust slave addresses
P-0-1636	P-0-1801.0.2	CCD: Command topology addresses
P-0-1637	P-0-1810.0.12	CCD: Error counter Port-1

Changes and Enhancements in Comparison to the Previous Version

No longer existing parameters	Replacement parameters as of MPx-18	Parameter name
P-0-1638	P-0-1810.0.13	CCD: Error counter Port-2
P-0-1639	P-0-1800.0.5	CCD: Allowed telegram failures
P-0-1640	These IP parameters remain unchanged.	CCD: MAC address
P-0-1641		CCD: IP address
P-0-1642		CCD: Network mask
P-0-1643		CCD: Gateway address
P-0-1644		CCD: Status IP communication
P-0-1645.x.1	P-0-1807.x.1	CCD connection: Configuration
P-0-1645.x.2	P-0-1807.x.2	CCD connection: Connection number
P-0-1645.x.3	P-0-1807.x.3	CCD connection: Telegram assignment
P-0-1645.x.4	P-0-1807.x.4	CCD connection: Max. length of connection
P-0-1645.x.5	P-0-1807.x.5	CCD connection: Current connection length
P-0-1645.x.6	P-0-1807.x.6	CCD connection: Configuration list
P-0-1645.x.7	P-0-1807.x.7	CCD connection: Assigned connection capability
P-0-1645.x.8	P-0-1807.x.8	CCD connection: Connection control (C-Con)
P-0-1645.x.9	P-0-1807.x.9	CCD connection: State
P-0-1645.x.10	P-0-1807.x.10	CCD connection: Producer cycle time
P-0-1645.x.11	P-0-1807.x.11	CCD connection: Allowed losses of producer data
P-0-1645.x.12	P-0-1807.x.12	CCD connection: Error counter data losses
P-0-1645.x.20	P-0-1807.x.20	CCD connection: IDN allocation of real-time bits
P-0-1645.x.21	P-0-1807.x.21	CCD connection: Bit number allocation of real-time bits
P-0-1651 - 59	P-0-1806.1.11 - P-0-1806.14.11	CDD: Resource-Control (C-Res)
P-0-1660.x.2	P-0-1806.1.3 - P-0-1806.14.3	CCD: Device Control (C-Res)
P-0-1660.x.3	P-0-1806.1.5 - P-0-1806.14.5	CCD: Connection-Control #1 (C-Con)
P-0-1660.x.20	P-0-1806.1.11 - P-0-1806.14.11	CDD: Resource-Control (C-Res)
P-0-1661 - 69	P-0-1806.1.10 - P-0-1806.14.10	CCD: Resource-Status (S-Res)
P-0-1670 - 79	P-0-1808.1.10 - P-0-1808.10.10	CCD: Active actual position value
P-0-1680 - 89	P-0-1808.1.11 - P-0-1808.10.11	CCD: Actual velocity value
P-0-1690 - 99	P-0-1808.1.12 - P-0-1808.10.12	CCD: Actual torque/force value
P-0-1701 - 09	P-0-1808.1.1 - P-0-1808.10.1	CCD: Diagnostic message number, slave

Changes and Enhancements in Comparison to the Previous Version

No longer existing parameters	Replacement parameters as of MPx-18	Parameter name
P-0-1710 - 19	P-0-1808.1.2 - P-0-1808.10.2	CCD: Signal status word
P-0-1720 - 29	P-0-1808.1.3 - P-0-1808.10.3	CCD: Signal control word
P-0-1730 - 39	P-0-1808.1.20 - P-0-1808.10.20	CCD: Command value data container 1 4Byte
P-0-1740 - 49	P-0-1808.1.21 - P-0-1808.10.21	CCD: Command value data container 2, 4Byte
P-0-1750 - 59	P-0-1808.1.22 - P-0-1808.10.22	CCD: Command value data container 3, 4Byte
P-0-1760 - 69	P-0-1808.1.23 - P-0-1808.10.23	CCD: Command value data container 4, 4Byte
P-0-1770 - 79	P-0-1808.1.40 - P-0-1808.10.40	CCD: Actual value data container 1, 4Byte
P-0-1780 - 89	P-0-1808.1.41 - P-0-1808.10.41	CCD: Actual value data container 2, 4Byte
P-0-1790 - 99	P-0-1808.1.42 - P-0-1808.10.42	CCD: Actual value data container 3, 4Byte
P-0-1800 - 09	P-0-1808.1.43 - P-0-1808.10.43	CCD: Actual value data container 4, 4Byte
P-0-1810 - 19	P-0-1808.1.13 - P-0-1808.10.13	CCD: Status word synchronous operation modes
P-0-1820 - 29	P-0-1808.1.30 - P-0-1808.10.30	CCD: Command value data container 1, 2Byte
P-0-1830 - 39	P-0-1808.1.31 - P-0-1808.10.31	CCD: Command value data container 2, 2Byte
P-0-1840 - 49	P-0-1808.1.32 - P-0-1808.10.32	CCD: Command value data container 3, 2Byte
P-0-1850 - 59	P-0-1808.1.33 - P-0-1808.10.33	CCD: Command value data container 4, 2Byte
P-0-1860 - 69	P-0-1808.1.50 - P-0-1808.10.50	CCD: Actual value data container 1, 2Byte
P-0-1870 - 79	P-0-1808.1.51 - P-0-1808.10.51	CCD: Actual value data container 2, 2Byte
P-0-1880 - 89	P-0-1808.1.52 - P-0-1808.10.52	CCD: Actual value data container 3, 2Byte
P-0-1890 - 99	P-0-1808.1.53 - P-0-1808.10.53	CCD: Actual value data container 4, 2Byte

Tab. 4-1: Parameter Overview, Assignment of New and no Longer Existing Parameters

CCD: sercos III I/O

All (sercos) I/O slaves are supported by the I/O configurator integrated in IndraWorks (as of IndraWorks MLD 13VRS).

Changes and Enhancements in Comparison to the Previous Version

These I/Os are exclusively configured via this "I/O configurator", only the addressing and setting of the order are still made in the CCD master (CCD dialog in IndraWorks).

The "I/O configurator" is only available with the functional package MLD. Consequently, I/O slaves can only be used with the functional package MLD.

Exception: SLC03 (the safety control) can also be configured and used via parameters in the CCD master, i.e. in this case without the functional package MLD.

CCD: CC Connections

Besides the master-slave connections previously used for cyclic process data, there are "Cross Communication connections (CC)" between the CCD nodes. The cyclic process data, also those of the CC connections, are adjusted in IndraWorks with the "CC configurator".

The (sercos) cycle time of the connections corresponds to the smallest producer cycle time (S-0-1050.x.10, sercos Connection: Producer cycle time).

CCD: Phase Progression

Parameterization has incompatibly changed.

CCD: Diagnostics

Parameterization has incompatibly changed.

CCD: CCD System Mode

The parameters relevant to master communication have changed.

CCD: MLD-M System Mode

Parameterization has incompatibly changed.

CCD: Addressing

The parameter numbers for addressing and identifying the CCD nodes have changed.

CCD: Overview, Features, Modes

The parameter numbers have incompatibly changed. Connection of SIII I/O extensions only in MLD-M system mode and only via IO configurator. See also "CCD: sercos III I/O".

CCD: Basic Mode

The parameter numbers for data exchange and slave control have incompatibly changed.

CCD: Process Data Mapping

The parameter numbers for configuring the cyclic process data have incompatibly changed.

CCD: Error Reaction

The parameter numbers for configuring the error reaction in the CCD group have incompatibly changed.

PLC System

Retain Handling Storage, Organization, Configuration, Commands

Remanent variables can retain their values beyond the usual program run-time. They are declared as "retain variables" or, more strictly, as "persistent variables". In each case, an individual memory range is used for manage-

Changes and Enhancements in Comparison to the Previous Version

ment. The selected type of declaration determines the degree of "resistance" of a remanent variable in the case of reset, download or reboot of the control unit. The size of the memory for retain variables or persistent variables depends on the firmware derivative. There is a common memory for the retain variables and the persistent variables, i.e. the memory required for retain variables and the memory required for persistent variables must not exceed the maximum value.

Maximum value MPB18VRS: 496 bytes

Maximum value MPC18VRS: 31728 bytes

System Behavior of MLD 2G

The system behavior of MLD 2G corresponds to the system behavior of MLD 1G. Some PLC system parameters can no longer be made available in compatibility with MLD 2G. This affects the following parameters:

- "P-0-1362, PLC boot project info"
(parameter no longer exists in MLD 2G)
- "P-0-1363, PLC project info"
(parameter is displayed in modified form in MLD 2G)

4.2.8 Handling, Diagnostic and Service Functions

Diagnostics

Structure and Priority-Based Generation

Generation of diagnostic codes in accordance with sercos specification, i.e. the interpretation bits and source type bits are written in the bits 31-24 of "S-0-0390, Diagnostic message number" (incompatible modification). The parameters "P-0-0007, Display text of diagnostic message" and "P-0-0009, Display text of diagnostic message" no longer exist.

Local Diagnostics and Control

Menu Structure & Handling of Control Panel

- The modifications for safety technology were implemented.
- The old menu (formerly pressing ESC+ENTER for 8 seconds) is no longer available. It is replaced by the standard menu (can be reached via the Enter key).
- It is possible to choose between the edit mode and the view mode of the control panel.
 - "P-0-0680, Control panel: Configuration", bit 14 = 0, Edit Mode, changes can be made via the control panel.
 - "P-0-0680, Control panel: Configuration", bit 14 = 1, View Mode, editing via the control panel is locked. If the modification screen is activated on the display for a datum which basically can be changed, the "Edit disabled" message is generated, it is impossible to change the value.

However, a temporary edit mode can be activated by keeping ESC+ENTER pressed for 8 seconds. If the standard menu is started in this way, parameters can be adjusted as usual.
- Before a value is changed, the additional query "Ok?" is displayed. This query must be confirmed with the ENTER key before a value is actually changed. This is meant to prevent accidental changes.

Changes and Enhancements in Comparison to the Previous Version

- By means of the corresponding setting in "P-0-0680, Control panel: Configuration", the output of diagnostic texts can be deactivated.

4.2.9 Engineering/Diagnostic Interfaces

Digital Inputs/Outputs

Local Real-Time Channel

CDB02:

- 14 digital inputs [4 of which are fast inputs as probe inputs (in steps of μs)]
- 8 digital inputs / outputs, all inputs and outputs can be freely assigned to every axis

CSB02.1C :

- 11 digital inputs (2 probe inputs)
- 5 digital input / output

CSB02.1N :

- 7 digital inputs (2 probe inputs)
- 1 digital input / output

CSA02.1A :

- 12 digital inputs (2 probe inputs)
- 5 digital input / output

CSE02.1 :

- 7 digital inputs (2 probe inputs)
- 1 digital input / output

Generally, the assignment mechanisms were changed.

Analog Inputs/Outputs

Analog Inputs at the Control Section

CDB02:

- 2 analog inputs, both inputs can be switched from $\pm 10\text{ V}$ to current input $\pm 20\text{ mA}$ or $4-20\text{ mA}$.

CSB02.1C and CSH02.1C :

- 3 inputs: Input 1: $\pm 10\text{V}$, inputs 2 and 3 can be switched from $\pm 10\text{ V}$ to current input

CSB02.1N and CSE02.1N:

- 1 input: $\pm 10\text{ V}$

General:

- Up to 3 assignments of parameters
- Changes in the configuration options (current inputs)

Analog Outputs at the Control Section

CDB02, CSB02.1C and CSA02.1C:

- 2 outputs

CSB02.1N and CSE02.1N:

- No outputs

Compared to platform 0, the parameterization was changed.

Changes and Enhancements in Comparison to the Previous Version

4.3 Compatible new Functions and Functional Changes

4.3.1 System Overview

Electric Drive Controllers

Supported Devices, General

Overview of the supported power sections and control sections, see chapter "[Drive Controllers](#)"

IndraDrive Cs

For HCS01.1 drive systems supported by the firmware, see chapter "[Drive Controllers, Power Sections](#)"

HMS IndraDrive Single-Axis Inverters

For HMS01.x power sections supported by the firmware, see chapter "[Drive Controllers, Power Sections](#)"

HMD IndraDrive Double-Axis Inverters

For HMD01.1 power sections supported by the firmware, see chapter "[Drive Controllers, Power Sections](#)"

HCS02 IndraDrive Single-Axis Converters Size 2

For HCS02.1 power sections supported by the firmware, see chapter "[Drive Controllers, Power Sections](#)"

HCS03 IndraDrive Single-Axis Converters Size 3

For HCS03.1 power sections supported by the firmware, see chapter "[Drive Controllers, Power Sections](#)"

HCS04 IndraDrive Single-Axis Converters Size 4

For HCS04.2 power sections supported by the firmware, see chapter "[Drive Controllers, Power Sections](#)"

IndraDrive Mi, Distributed Servo Drive

Option "S3" included

IndraDrive Mi, Distributed Drive Controller

Option "S3" included

Control Sections

CSE02 Control Sections - Economy Plug-in Unit

This is the new control section hardware CSE02.1 for low-performance applications. See also "control sections supported by the firmware", chapter "[Drive Controllers, Control Sections and Optional Modules](#)"

4.3.2 Master Communication

sercos

sercos Connections

The number of supported connections is augmented from 4 to 6. The "New Data Counter" is supported in the connection control (C-CON).

Modbus TCP

Modbus TCP – Client and Server

Changes and Enhancements in Comparison to the Previous Version

The field bus protocol "Modbus TCP" is used to exchange data between Ethernet devices which support the Modbus protocol. With the function blocks of the "RIL_ModubusTCP" library, both a server (master) and a client (slave) can be implemented.

4.3.3 Motor, Mechanical Axis System, Measuring Systems

Measuring Systems

Encoder with EnDat 2.2 Interface

As of MPx18V10:

The firmware can now evaluate EnDat2.2 encoders which are not EnDat2.1-compatible.

Just like the SSI encoder evaluation, the EnDat2.2 encoder evaluation is carried out according to a new method which in the future will allow several drives to evaluate encoders simultaneously. With sercos master communication, the pieces of information immediately made available by the encoder are available on the master communication level and therefore are available to each drive in the sercos ring for evaluation.

4.3.4 Drive Control

Motor Control

Setting Motor Control by "Loading Controller Default Values"

With the "load controller parameters" command, the following holding brake parameters are loaded, where applicable, as of MPx18:

- P-0-2206, Drive On delay time, type plate
- P-0-2207, Drive Off delay time, type plate

Thereby the values are retained after an axis-specific adjustment and are not reset to the motor-specific values from the encoder memory every time the drive is booted. Now this only happens by the "load controller parameters" command, as is the case with the controller parameters.

Axis Control

Automatic Setting of Axis Control

Calculating and Optimizing the Control Loop Parameters

- Calculating the control loop parameters now is also possible in phase 4 (bb: drive ready for operation).
- The type of motion, oscillating motion or motion in one direction, and the direction of motion, positive or negative, are no longer set via "P-0-0165, Drive optimization, control word", but they are derived from
 - the processing format of the position data, absolute format or modulo format ("S-0-0076, Position data scaling type", bit 7) and
 - the Command value mode (S-0-0393) - only with modulo format
- The load inertia is determined with a new method.
- Reduction of the minimum required travel range:
 - For rotary motors from 2 mechanical motor revolutions to 1/4 of an electric motor revolution
 - For linear motors from 100 mm to 1/4 of a pole pair distance

Changes and Enhancements in Comparison to the Previous Version

Commutation Setting

Commutation Setting of Digital Hall Sensors

The best possible performance of a synchronous motor with digital Hall sensors can be achieved by the following measures:

- The value of "P-0-0509, Commutation offset coarse" must refer to the center of the Hall-sensor-detected 60° el. ranges (at least 87% of performance in the case of commutation via the dig. Hall sensors only, directly after the motor has been switched on)
- **The first Hall sensor switching edge is overrun with adjusted velocity, the coarse commutation offset value is thereby automatically adjusted** (approx. 97% of performance, depending on the hysteresis and the relative position precision of the Hall sensor switching edges opposite the respective motor winding).
- Using the "optimum commutation offset with regard to reference point" when operating the motor (100% of performance, according to the result of the initial commissioning).

The adjustment of the coarse commutation offset value when overrunning the first Hall sensor switching edge is only possible with MPx18 and above!

Limitations

Position Limit Values and Travel Range Limit Switches

The travel range limit switches are displayed in the status (S-0-0478, Position/travel range limit status), even if the monitoring function has been switched off.

Implementation of parameters defined in sercos. The previously available parameters are still available as alias parameters.

Parameters defined in sercos	Previous parameters as alias parameters
S-0-0532, Travel range limit parameter	P-0-0090, Travel range limit parameter
S-0-0478, Position/travel range limit status	P-0-0091, Position/travel range limit status

Tab. 4-2: Parameters Defined in sercos and Alias

Parameters Used:

- S-0-0532, Travel range limit parameter
- S-0-0478, Position/travel range limit status
- P-0-0222, Travel range limit switch inputs
- S-0-0049, Positive position limit value
- S-0-0050, Negative position limit value

Diagnostic Messages Used:

- E8029 Positive position limit exceeded
- E8030 Negative position limit exceeded
- E8043 Positive travel range limit switch activated
- E8044 Negative travel range limit switch activated
- F6029 Positive position limit exceeded
- F6030 Negative position limit exceeded
- F6043 Positive travel range limit switch activated
- F6044 Negative travel range limit switch activated

Changes and Enhancements in Comparison to the Previous Version

- E8042 Both travel range limit switches activated
- F6042 Both travel range limit switches activated
- F6028 Position limit value exceeded (overflow)

Components and Additional Devices

Braking Resistor, Internal and External

The parameter "P-0-0858, Data of external braking resistor" no longer contains the switch-on threshold of the braking resistor. The function "automatic setting of the braking resistor threshold" due to the mains voltage no longer exists.

4.3.5 Extended Axis Functions

Compensation Functions / Corrections

Cogging Torque Compensation

The range in which the cogging torque compensation takes effect can cover the **entire travel range** of an axis (default), but can also be restricted to a definable position range. The **restricted position range** can be less than one motor revolution (rotary motor) or one pole pair distance (linear motor).

In the case of cogging torque compensation over the **entire travel range**, the recording range for the cogging torque compensation table(s) is one motor revolution (rotary motor) or one pole pair distance (linear motor). The compensation values take effect "recurrently" within every motor revolution or pole pair distance. This is particularly advantageous for rotary motors, for linear motors it is rather disadvantageous.



In the case of linear synchronous motors, the lined-up pole pairs of the travel distance exemplarily differ from one another, which leads to expect differences in the effectiveness over the travel distance with cogging torque compensation merely related to the pole pair distance.

In the case of cogging torque compensation **between definable limits**, the recording range of the measured values for the cogging torque compensation table(s) is the entire **position range between the limits**. This is particularly advantageous for linear motors, because the lined-up permanent magnet pole pairs are only alike within certain tolerances as regards the magnetic flux density, as well as the mechanical deviations and mounting. Thereby, individual compensation values exist for each pole pair which leads to expect good effectiveness of the cogging torque compensation over the entire, limited position range.



For cogging torque compensation limited in the position range, it is necessary to establish the **position data reference between motor encoder and axis**. Position reference between motor encoder and motor only (see above) is not sufficient in this case!

Error Reactions

Warnings and Error Classes and Reactions, Overview

New diagnostic message numbers F7xxx (safety technology errors) and F83xx (fatal errors of safety technology) are implemented for safety technology, Safe Motion.

The "best possible deceleration" is expanded by the "return motion".

Changes and Enhancements in Comparison to the Previous Version

Position Spindle

Position Spindle

Features:

- Upon the control command "C0900Position spindle command", the drive aligns the spindle independently with regard to the spindle zero position. The command position can be freely set via parameter, it can be preset as the absolute position or travel distance.
- With the parameter "P-0-3219, SMO: Configuration of support functions", an additional velocity limit value for the initial velocity of the operation mode can be activated for an axis with safety technology; see also "Rexroth IndraDrive, Integrated Safety Technology as of MPx-1x (Safe Motion)" (DOK-INDRV*-SI3*SMO-VRS-AP**-EN-P; mat. no. R911338920).

Integrated Safety Technology

With MPx-18, the integrated safety technology of the 2nd generation is comprehensively available (in different characteristics) in all IndraDrive product ranges based on the new Cxx02 control sections:

- IndraDrive Cs
- IndraDrive Mi
- IndraDrive C/IndraDrive M

The optional safety technology modules "Safe Motion" ("S3" and "S4") are supported. These optional modules make available many safety technology functions of the function groups "Safe Motion" and "Safe standstill".

The optional safety technology modules "L3"/"L4" are already supported with the firmware MPx-16 or MPx-17 and above. These optional modules make available safety technology functions of the "Safe standstill" function group.

Overview of safety functions see [chapter 5.6.14 "Integrated Safety Technology" on page 275](#):

Besides a higher safety level for all safety functions independent of an encoder (Cat. 4, PL e, SIL3), the integrated safety technology of the 2nd generation is characterized by integrated safe logic function blocks, as well as by the reduced commissioning effort.

Features

- Comprises all IndraDrive product ranges
- Higher safety level for all safety functions independent of an encoder: Cat. 4, PL e, SIL3
- Integrated safe logic functions
- Simplified installation and zone setup with zone bus cable
- Reduced commissioning effort
- How to select the safety functions:
 - The optional safety technology modules "L3" ("Safe Torque Off") or "L4" ("Safe Torque Off" and "Safe Brake Control") must be controlled directly at the device via safe 24 V signals.
 - The optional safety technology module "S4" can be controlled either by a safety control via the safety bus (CIP Safety on sercos) or via 24 V signals.

If the control takes place via 24 V signals, the signals of all drives of a safety zone must be discretely wired at the HZS01 safety zone module.

Changes and Enhancements in Comparison to the Previous Version

- The optional safety technology module "S3" can be exclusively controlled via the safety bus (CIP Safety on sercos).

4.3.6 Optional Device Functions

Drive-Internal Command Value Box

Drive-Internal Command Value Box

For the command value curve, it is possible, both in velocity control and in position control, to choose between the operation modes "oscillating motion" and "stepper mode". As of MPx18, continuous (periodic) motion or one-time motion can be additionally selected.

Basic Functions of Internal Master Axis Generation

Master Axis Format Converter

The list of the input signals for the master axis format converter of the virtual axis (P-0-0915, Master axis format converter IDN list signal selection) is extended by the parameters "P-0-0457, Position command value generator" and "P-0-0048, Effective velocity command value".

Master Axis Linking

MLD-M Axis Group

In the MLD-M system mode, up to 3 master axes are generated in the CCD master. Generating a master axis in each case means to retrieve the value of a source parameter, convert it to the master axis format, filter it and extrapolate it to compensate transmission times. The resulting master axis positions then are transmitted to the assigned CCD slave axes in order to be used as command values for synchronization modes in the slave axes.

Encoder Emulation

Encoder Emulation

At double-axis devices of the new control section generation, two optional slots (one for each axis) can be equipped with the encoder emulation "EM". For the requirements of the device configuration, see the "Project Planning Manual for Control Sections".

Control section	Project Planning Manual	Material No.
CSE02.1A CSB02.1A CDB02.1B CSB02.1B CSH02.1B	Rexroth IndraDrive Control Sections CSE02, CSB02, CDB02, CSH02	R911338962

Tab. 4-3: Control Section, Project Planning Manual



With double-axis control sections, encoder emulation is simultaneously possible in both axes.

IndraMotion MLD (2G)

Introduction

The IndraWorks MLD 13VRS version makes available the user interface for programming and visualizing MLD-2G in IndraWorks. With the drive firmware

Changes and Enhancements in Comparison to the Previous Version

MPx-18VRS and IndraWorks MLD 13VRS, PLC programs can be created in the IndraLogic 2G environment.

Existing programs that were already developed in MLD-1G can be imported and it is possible to continue using them with MLD-2G.

The following documentations support you when working with IndraMotion MLD (2G) and when switching from IndraMotion MLD (1G) to IndraMotion MLD (2G):

Title	Purpose of Documentation	Document typecode ¹⁾	Material number
Rexroth IndraDrive MPx-16 to MPx-18 Parameters	Apart from the PLC-specific parameters, all other drive parameters are documented in the Reference Book of parameters	DOK-INDRV*-GEN1-PARA**-RExx-EN-P	R911328651
Rexroth IndraDrive MPx-16 to MPx-18 Diagnostic Messages	Apart from the PLC-specific diagnostic messages, all other diagnostic drive messages are documented in the Reference Book of diagnostic messages	DOK-INDRV*-GEN1-DIAG**-RExx-EN-P	R911326738
Rexroth IndraDrive Rexroth IndraMotion MLD (2G) Libraries as of MPx-18	Library for Rexroth IndraMotion MLD-2G - Describes the functions and function blocks especially programmed for "IndraMotion MLD" which are combined in a specific library - Contains references to the system libraries used by several systems - Contains references to the basic libraries used by several systems TIP: Via the Online Help in IndraWorks, you can easily access the descriptions of the system libraries and basic libraries.	DOK-INDRV*-MLD-SYSLIB3-RExx-EN-P	R911338916
Rexroth IndraDrive Rexroth IndraMotion MLD (2G) as of MPx-18	Application Manual for Rexroth IndraMotion MLD-2G Describes the specific functionalities of "IndraMotion MLD" and explains the integration of the PLC in the drive, as well as the technical possibilities and functions	DOK-INDRV*-MLD3-**-VRS*-APxx-EN-P	R911338914
Rexroth IndraDrive Rexroth IndraMotion MLD (2G) as of MPx-18	Rexroth IndraMotion MLD (2G), Commissioning as of MPx-18 Explains how to get started when using Rexroth IndraMotion MLD for the first time (Preparation and Setup, Commissioning, Programming)	DOK-INDRV*-MLD3-F*STEP-COxx-EN-P	R911341708
Rexroth IndraDrive Service Tools IMST/IDST	Describes the Service Tools (IMST and IDST). These are web-based software solutions that have been implemented in the drive firmware. By means of the tools, OEMs, end users and account managers can access drive systems to make remote diagnoses or carry out firmware updates, for example.	DOK-IM*MLD-IMSTIDSTV13-RExx-EN-P	R911342652

Changes and Enhancements in Comparison to the Previous Version

Title	Purpose of Documentation	Document typecode ¹⁾	Material number
Rexroth IndraWorks 13VRS IndraLogic 2G PLC Programming System	Operating and Programming Guide for IndraLogic 2G This documentation specifically describes the programming environment, as well as the programming and creation of PLC programs	DOK-IWORKS-IL2GPRO*V13-APxx-EN-P	R911336876
Rexroth IndraWorks 13VRS IndraLogic 2G Basic Libraries	Describes the system-wide basic PLC libraries	DOK-IL*2G*-BASLIB**V13-LIxx-EN-P	R911336285
Rexroth IndraWorks 11VRS ²⁾ PLC System Libraries IndraLogic 2G	Describes the system-wide PLC system libraries	DOK-IL*2G*-SYSLIB**V11-LIxx-EN-P	R911336157

- 1) In the document typecodes, "xx" is a wild card for the current edition of the documentation (example: RE02 is the second edition of a Reference Book)
- 2) The current Online Help of the **system** libraries is supplied with IndraWorks 13

Tab. 4-4: Documentations – Firmware

Advantages of IndraMotion MLD (2G)

- State-of-the-art editors
- All IOs can be conveniently added to a device (context menu of the sercos branch) and configured via dialogs.
Offline configuration of IOs is possible
- Improved version management of device and libraries
- Object-oriented programming with inheritance, methods and transmission parameters, etc.
- The LREAL and LINT data types are supported
- IndraMotion MLD was further adapted to the behavior of IndraMotion MLC
- Drive controllers of the "IndraDrive" range with the firmware MPx-18 can be configured as PLC peripherals
 - 9 IndraDrive as slaves (CCD slaves)
 - 4 IndraDrive as PLC peripherals via SDDML file

Modified / New Functions

Addressing according to IEC Byte Addressing

- Word addressing is changed to IEC byte addressing
- Access to addresses with %QBxxx / %IBxxx
- Standardization of the systems

Task System / Events

- **Freewheeling Task**
Same behavior as in MLD-1G
- **Event Task**
It is not possible to create event tasks only; at least one cyclic or free-wheeling task must be created.

Changes and Enhancements in Comparison to the Previous Version

- **System Events / PLC Events**

The following system events have been released:

EVENT_START, EVENT_STOP, EVENT_BEFORE_RESET, EVENT_AFTER_RESET

The following PLC events are made available with the "SysCallback23" library (e.g. for callback functions): StartDone, StopDone, PrepareReset.

The following **structures** of "SysCallback23" must not be used: EventParameter23, EVTPARAM_CmpAppException, EVTPARAM_SysExcept, RegContext.

The following **functions** of "SysCallback23" must not be used: EventCallbackFunction, MapException, OpenEvent.

Caution: As little code as possible should be processed!

Local Real-Time Channel RtcR / RtcW

The local real-time channel (RtcR / RtcW) is not made available in MLD-2G; instead, the AxisData interface and synchronized tasks can be used in applications (see also documentation "Rexroth IndraMotion MLD (2G), Commissioning as of MPx-18", index entry "Real-time channel").

It is possible to have 5 freely definable command values and 6 actual values.

OOP – Object-Oriented Programming

Object-oriented programming with inheritance, methods and transmission parameters, etc.

PLC Shell

The "PLC browser" known from MLD-1G was replaced by "PLC shell" in MLD-2G.



With the "?" command, the list of MLD commands can be called.

IO Configurator

- All IOs can be conveniently added to a device (context menu of the sercos branch) and configured via dialogs.
- Offline configuration of IOs is possible

See "Application Manual for Rexroth IndraMotion MLD-2G", chapter "Configuring the Inputs and Outputs (I/O Configuration of MLD)"

Libraries

General modification: The libraries now have the "library" extension instead of the "lib" extension (MLD-1G).

- The "RIL_LoopControl" library is supported.
- The library for communication via "Modbus TCP" is supported ("RIL_ModbusTCP").
- In the "MX_Base" library, only cyclic parameters are now defined as direct variables, data types and structures. The functions and function blocks made available in MLD-1G with "MX_Base" can be found in "MX_PLCOpen" with MLD-2G and above.

The "Atan2()" function is contained in the free library "Oscat"; it can simply be mapped to "TAN()".

- The real-time channel is no longer available, the "MX_DSP" library therefore cannot be used any more; instead, the AxisData interface and synchronized tasks can be used in applications (see also documentation "Rexroth IndraMotion MLD (2G), Commissioning as of MPx-18", index entry "Real-time channel").

Changes and Enhancements in Comparison to the Previous Version

- The "SysSockets" library is incompatible with the "SysLibSockets" library of IndraMotion MLD-1G.

Although the "SysSockets23" library provides the programming interface of the "SysLibSockets" library of IndraMotion MLD-1G, the entire functionality is not covered. **Therefore, the "SysSockets23" library must not be used!**

- The "SysFile" and "SysDir" libraries are new. As with MLD-1G, they allow carrying out file and directory operations (e.g. open, close, ...). Besides, it is possible with MLD-2G to read out the current position in the file, change it and check whether it is at the end of the file.

For asynchronous file and directory operations, it is recommended to use the "SysFileAsync23" or "SysDirAsync23" libraries.

All functions / function blocks of the libraries now return a status message of the "RTS_IEC_RESULT" type (cf. "Errors" constants in the "CmpErrors" library).

- When an MLD-1G project is ported that uses one of the "MX_SysLibDir", "MX_SysLibFile" or "MX_SysLibFileAsync" libraries, it is sufficient to replace these by the "SysDir23", "SysFile23" and "SysFileAsync23" libraries.

The following differences have to be taken into account:

- If an error occurs when a file is opened, it is not the value "0" that is returned (as in the case of MLD-1G), but "SYSFILE_INVALID_HANDLE".
- The Error output of the function blocks of the "SysFileAsync23" library assumes the value "TRUE" in the case of error, without the Done output becoming "TRUE". [Behavior compliant with "Behaviour and interface model of function POU's" (see "Guidelines for Library Design")].
- The "SyslecTasks23" library replaces the "MX_SysLiblecTasks" library. Only the "SysIECTaskGetConfig" function is supported by "SyslecTasks23".

Differences between MLD-1G and MLD-2G:

- MLD-2G: The tasks are listed according to their priorities.
- MLD-2G: The cycle time is displayed in milliseconds.
- The "MX_SysLiblecTasks" library is replaced by the libraries "SysMem23" (to port MLD-1G projects) and "SysMem" (to be preferred for new projects).

Functions of "SysMem23" that must not be used:

- SysMemFree
- SysMemAlloc
- SysMemCmp30
- SysMemCpy30
- SysMemMove30
- SysMemSet30
- SysMemSwap30
- SysMemFreeData30
- SysMemAllocData30

Changes and Enhancements in Comparison to the Previous Version

Functions of "SysMem" that must not be used:

- SysMemAllocArea
- SysMemAllocCode
- SysMemAllocData
- SysMemForceSwap
- SysMemFreeArea
- SysMemFreeCode
- SysMemFreeData
- SysMemIsValidPointer
- SysMemReallocData
- The "SysCallback23" library replaces the "SysLibCallback" library.
- The "SysLibSem" library is replaced by the libraries "SysSem23" (to port MLD-1G projects) and "SysMem" (to be preferred for new projects).



In contrast to MLD-1G, semaphores in MLD-2G are not automatically deallocated in the case of PLC reset.

⇒ For programming in MLD-2G it is necessary to make sure that the semaphores are deallocated (e.g. in an fb_Exit method).

Project Conversion

To transfer an existing project from MLD-1G to MLD-2G, proceed as follows (for a detailed description, see "Application Manual for Rexroth IndraMotion MLD-2G", chapter "Project Conversion"):

1. The prerequisites must be checked and preset in MLD-1G.
2. Then the project can be transferred from MLD-1G to MLD-2G.
3. The compilation errors after the project conversion must be removed.
4. After the program has been imported, adjustments must be made in MLD-2G.

Power / Performance of IndraMotion MLD MPx-18

Required Memory

The memory required for MLD-2G is greater than for MLD-1G.

The required initial memory (basic requirement) is clearly (by approx. the 4-fold) above the one of MLD-1G. The reason for this is that the syntax of the direct variables is different; there are more characters required.

(See "Application Manual for Rexroth IndraMotion MLD-2G", chapter "Compilation Errors after Project Conversion", marginal note "Syntax of the Direct Variables".)

With larger projects, the additionally required memory is decreasing.

The memory required for the program code itself is less in MLD-2G.

Determining the Performance

IndraMotion MLD-2G requires more calculating time than IndraMotion MLD-1G. With small projects, the performance of IndraMotion MLD-2G is lesser than the performance of IndraMotion MLD-1G. With big projects, the lesser performance is normally compensated by the more compact program code.

The easiest way to check the calculating time is by means of P-0-1364. The parameter is available in both versions and shows the unused calculating time. The "MX_IECTaskGetLoad" function block provides a more precise analysis of the available time.

Changes and Enhancements in Comparison to the Previous Version

(See "Application Manual for Rexroth IndraMotion MLD-2G", chapter "Basic Functions of Rexroth IndraMotion MLD"→"Task System"→"Runtime Measurements".)

4.3.7 Handling, Diagnostic and Service Functions

Parameters

Reset to Default Values

The "load defaults procedure " function was expanded by the selective reset of the SMO default values (command C0720). Furthermore, it is possible to exclude, by means of masking, the reset of the safety technology parameters during the execution of the command "C0750Load defaults procedure command (factory settings)".

Oscilloscope Function

Trend Mode

It is possible to switch from a single measurement (Single Shot) to a continuous measurement (trend mode).

- Recording of up to 4 channels in a cyclic mode
- Signal selection via the previous parameters
- Values are administrated in a buffer memory and cyclically called
- IndraWorks can read this buffer memory and display it continuously
- Setting of time resolution and signal selection only in trend mode that has been switched off
- Allowed time resolutions must be a multiple of 2 ms
- Single Shot mode cannot be used in parallel

4.3.8 Engineering/Diagnostic Interfaces

IndraMotion Service Tool (IMST) and IndraDrive Service Tool (IDST)

By means of IndraMotion Service Tool (IMST) or IndraMotion Diagnostic Tool (IDST), it is possible to access the drive system, e.g. for remote diagnostics. Besides, authorized users can handle different service cases with IMST or IDST, such as:

- Replacing drive components
- Loading parameters
- Updating/upgrading the drive firmware

IndraMotion Service Tool (IMST) additionally analyzes drive systems connected via cross communication (CCD). Further information on IndraMotion Service Tool (IMST) and IndraDrive Service Tool (IDST) is described in the separate documentation "Rexroth IndraDrive Service Tools IMST/IDST" (DOK-IM*MLD-IMSTIDSTV13-RE**-EN-P; mat. no. R911342652).

IndraMotion Service Tool

The „IndraMotion Service Tool (IMST)“ is a tool for several devices, i.e. IMST can communicate with additional drive systems via cross communication (CCD). The program code of IMST is stored on the µSD card in the Tools directory. It is not required to install the tool. The IndraMotion Service Tool is made available in German and English.

IndraDrive Service Tool

The „IndraDrive Service Tool (IDST)“ is a tool for one device. IDST communicates with a drive system. The program code of IDST has been integrated in the firmware. It is not required to install the tool. The IndraDrive Service Tool is made available in English.

Changes and Enhancements in Comparison to the Previous Version

Diagnostics and Control

Web Server

Web server service to display web pages of the optional memory card of IndraDrive Cs Advanced. This is the basic service required to use the web application IndraMotion Service Tool.

HMI

BRWS Protocol Server

The data server allows accessing drive parameters via IMST/IDST (IndraMotion ServiceTool, IndraDrive ServiceTool) and web servers. Accessing drive parameters is possible for all drive derivatives and independent of the sundry drive configuration. MLD must have been enabled in order that PLC variables can be accessed.

4.3.9 Commissioning

Offline Mode

Offline Mode

Features of the offline mode

- The offline simulation allows commissioning Rexroth drives "at the desk"; this means that the commissioning engineers do not need to work directly at the real machine. With this head start, the installation can already be parameterized while the machine is mounted.
- Offline simulation behavior of the Integrated Safety Technology as of MPx-1x (Safe Motion) is not supported, the existing SMO parameterization is not modified.

4.4 New, Modified or no Longer Existing Parameters

4.4.1 New Parameters

- P-0-0002, SPI flash aging counter
- P-0-0005, SPI flash aging counter (onboard)
- P-0-0006, Diagnostic message configuration
- P-0-0139, Analog output 1
- P-0-0140, Analog output 2
- P-0-0161, Drive optimization: Periodic time
- P-0-0181, Drive optimization: Antiresonance frequency
- P-0-0182, Drive optimization: Resonance frequency
- P-0-0184, Motor password
- P-0-0189, Debug output: IDN list of parameters last saved
- P-0-0208, DA: Analog input 2
- P-0-0211, Analog input 2
- P-0-0228, Analog input 3
- P-0-0229, DA: Analog input 1
- P-0-0231, Analog input 2, time constant input filter
- P-0-0232, Analog input 3, time constant input filter
- P-0-0245, Analog input, assignment C, target parameter
- P-0-0246, Analog input, assignment C, scaling

Changes and Enhancements in Comparison to the Previous Version

- P-0-0247, Analog input, assignment C, signal value at 0
- P-0-0248, Analog input, assignment C, dead zone
- P-0-0255, Analog input; hardware configuration
- P-0-0279, Oscilloscope:Trend mode, time resolution
- P-0-0280, Oscilloscope:Trend mode, list of measured values
- P-0-0414, DA: Analog output 1
- P-0-0415, DA: Analog output 2
- P-0-0418, Analog output, assignment A, signal value at 0V
- P-0-0418, Analog output 1, signal value at 0V
- P-0-0419, Analog output, assignment B, signal value at 0V
- P-0-0419, Analog output 2, signal value at 0V
- P-0-0420, Analog output, assignment A, signal selection
- P-0-0420, Analog output 1, signal selection
- P-0-0422, Analog output, assignment A, scaling [1/V]
- P-0-0422, Analog output 1, scaling [1/V]
- P-0-0423, Analog output, assignment B, signal selection
- P-0-0423, Analog output 2, signal selection
- P-0-0425, Analog output, assignment B, scaling [1/V]
- P-0-0425, Analog output 2, scaling [1/V]
- P-0-0426, Analog output IDN list of assignable parameters
- P-0-0427, Control parameter of analog output
- P-0-0428, DA: Analog output 1, signal value at 0V
- P-0-0429, DA: Analog output 2, signal value at 0V
- P-0-0459, DA: Analog output 1, signal selection
- P-0-0462, DA: Analog output 2, signal selection
- P-0-0463, DA: Analog output 1, scaling [1/V]
- P-0-0464, DA: Analog output 2, scaling [1/V]
- P-0-0476, Logbook configuration word
- P-0-0516, Commutation speed smoothing time constant
- P-0-0593, FXC: Total flux loop proportional gain
- P-0-0660.000.128, Compact parameter diagnostics
- P-0-0660.000.129, Instance parameter diagnostics
- P-0-0853, Max. DC bus voltage, motor
- P-0-0901.x.001, Encoder emulation signal selection
- P-0-0901.x.002, Encoder emulation control parameter
- P-0-0901.x.003, Encoder emulation resolution
- P-0-0901.x.004, Encoder emulation zero pulse offset
- P-0-0901.x.005, Encoder emulation zero pulse distance
- P-0-0901.x.006, Encoder emulation assignment
- P-0-1118, Velocity controller command filter
- P-0-1145, Cogging torque compensation: Lower position limit
- P-0-1146, Cogging torque compensation: Upper position limit
- P-0-1147, Cogging torque compensation: Offset positive

Changes and Enhancements in Comparison to the Previous Version

- P-0-1148, Cogging torque compensation: Offset negative
- P-0-1467, PLC/setting-up mode, torque/force ramp time
- P-0-1800.000.001, CCD: Configuration
- P-0-1800.000.003, CCD: Control word
- P-0-1800.000.005, CCD: Allowed telegram failures
- P-0-1800.000.010, CCD: Cycle time
- P-0-1800.000.020, CCD: Application connection configuration, incremental
- P-0-1800.000.021, CCD: Application connection configuration, overall
- P-0-1800.000.022, CCD: Current connection configuration
- P-0-1800.000.030, CCD: Extrapolated command value IDN list signal selection
- P-0-1800.000.031, CCD: Extrapolated cmd value signal selection
- P-0-1800.000.032, CCD: Number of extrapolation steps
- P-0-1800.000.033, CCD: Extrapolated command value
- P-0-1801.000.001, CCD: Slave identification
- P-0-1801.000.002, CCD: Command typology addresses
- P-0-1801.000.003, CCD: Actual topology addresses
- P-0-1801.000.004, CCD: Slave information at topology location
- P-0-1801.000.005, C7000 CCD: Command Adjust slave addresses
- P-0-1801.000.010, CCD: Addresses of projected drives
- P-0-1801.000.011, CCD: Addresses of projected I/Os
- P-0-1801.000.020, CCD: Command typology
- P-0-1801.000.021, CCD: Actual topology
- P-0-1801.000.022, CCD: Slave addresses at end of line
- P-0-1801.000.023, C7100 CCD: Command Close ring
- P-0-1802.000.001, C7400 CCD: Switching to phase 2
- P-0-1802.000.002, C7500 CCD: Switching to phase 4
- P-0-1802.000.003, CCD: Command communication phase
- P-0-1802.000.004, CCD: Actual communication phase
- P-0-1803.x.001, CCD: Slave address in high level network
- P-0-1803.x.011, CCD: Configuration list master communication cmd values
- P-0-1803.x.012, CCD: Configuration list master communication actual values
- P-0-1803.x.020, CCD: Master comm. C0100 Comm. phase 3 transition check
- P-0-1803.x.021, CCD: Master comm. C5200 Comm. phase 4 transition check
- P-0-1803.x.022, C5300 CCD: sercos SYNC delay measuring procedure command
- P-0-1803.x.024, CCD: Master communication gateway parameter pool 1
- P-0-1803.x.025, CCD: Master communication gateway parameter pool 2
- P-0-1804.x.001, CCD: Configuration list signal status word
- P-0-1804.x.002, CCD: Configuration list signal control word

Changes and Enhancements in Comparison to the Previous Version

- P-0-1804.x.003, CCD: Assignment list signal status word
- P-0-1804.x.004, CCD: Assignment list signal control word
- P-0-1804.x.130, Assignment signal status/control word, compact
- P-0-1805.x.001, CCD: Configuration list master cmd values
- P-0-1805.x.002, CCD: Configuration list actual master values
- P-0-1805.x.003, CCD: Configuration list slave cmd values
- P-0-1805.x.004, CCD: Configuration list actual slave values
- P-0-1805.x.130, Configuration master/slave command/actual values, compact
- P-0-1806.x.001, CCD: Slave IP address
- P-0-1806.x.002, CCD: Device Status (S-Dev)
- P-0-1806.x.003, CCD: Device Control (C-Res)
- P-0-1806.x.004, CCD: Connection-Control #0 (C-Con)
- P-0-1806.x.005, CCD: Connection-Control #1 (C-Con)
- P-0-1806.x.010, CCD: Resource-Status (S-Res)
- P-0-1806.x.011, CDD: Resource-Control (C-Res)
- P-0-1807.x.001, CCD connection: Configuration
- P-0-1807.x.002, CCD connection: Connection number
- P-0-1807.x.003, CCD connection: Telegram assignment
- P-0-1807.x.004, CCD connection: Max. length of connection
- P-0-1807.x.005, CCD connection: Current connection length
- P-0-1807.x.006, CCD connection: Configuration list
- P-0-1807.x.007, CCD connection: Connection class
- P-0-1807.x.008, CCD connection: Connection control (C-Con)
- P-0-1807.x.009, CCD connection: State
- P-0-1807.x.010, CCD connection: Producer cycle time
- P-0-1807.x.011, CCD connection: Allowed losses of producer data
- P-0-1807.x.012, CCD connection: Error counter data losses
- P-0-1807.x.020, CCD connection IDN allocation of real-time bits
- P-0-1807.x.021, CCD connection: Bit number allocation of real-time bits
- P-0-1808.x.001, CCD: Diagnostic message number, slave
- P-0-1808.x.002, CCD: Signal status word
- P-0-1808.x.003, CCD: Signal control word
- P-0-1808.x.010, CCD: Active actual position value
- P-0-1808.x.011, CCD: Velocity feedback value
- P-0-1808.x.012, CCD: Torque/force feedback value
- P-0-1808.x.013, CCD: Status word synchronous operation modes
- P-0-1808.x.020, CCD: Command value data container 1, 4Byte
- P-0-1808.x.021, CCD: Command value data container 2, 4Byte
- P-0-1808.x.022, CCD: Command value data container 3, 4Byte
- P-0-1808.x.023, CCD: Command value data container 4, 4Byte
- P-0-1808.x.024, CCD: Command value data container 5, 4Byte
- P-0-1808.x.030, CCD: Command value data container 1, 2Byte

Changes and Enhancements in Comparison to the Previous Version

- P-0-1808.x.031, CCD: Command value data container 2, 2Byte
- P-0-1808.x.032, CCD: Command value data container 3, 2Byte
- P-0-1808.x.033, CCD: Command value data container 4, 2Byte
- P-0-1808.x.034, CCD: Command value data container 5, 2Byte
- P-0-1808.x.040, CCD: Actual value data container 1, 4Byte
- P-0-1808.x.041, CCD: Actual value data container 2, 4Byte
- P-0-1808.x.042, CCD: Actual value data container 3, 4Byte
- P-0-1808.x.043, CCD: Actual value data container 4, 4Byte
- P-0-1808.x.044, CCD: Actual value data container 5, 4Byte
- P-0-1808.x.045, CCD: Actual value data container 6, 4Byte
- P-0-1808.x.050, CCD: Actual value data container 1, 2Byte
- P-0-1808.x.051, CCD: Actual value data container 2, 2Byte
- P-0-1808.x.052, CCD: Actual value data container 3, 2Byte
- P-0-1808.x.053, CCD: Actual value data container 4, 2Byte
- P-0-1808.x.054, CCD: Actual value data container 5, 2Byte
- P-0-1808.x.055, CCD: Actual value data container 6, 2Byte
- P-0-1809.000.001, CCD: SLc, diagnostic information
- P-0-1809.000.002, CCD: SLc, states of safety inputs
- P-0-1809.000.003, CCD: SLc, states of safety outputs
- P-0-1809.000.004, CCD: SLc, group status and control words
- P-0-1809.000.006, CCD: SLc user data (inputs)
- P-0-1809.000.010, CCD: User data of SLc (outputs)
- P-0-1810.000.001, CCD: Version
- P-0-1810.000.002, CCD: Status word
- P-0-1810.000.003, CCD: Timing settings
- P-0-1810.000.004, CCD: FPGA version
- P-0-1810.000.010, CCD: Diagnostic text
- P-0-1810.000.011, CCD: Diagnostic code
- P-0-1810.000.012, CCD: Error counter Port-1
- P-0-1810.000.013, CCD: Error counter Port-2
- P-0-1810.000.015, CCD: AT error counter
- P-0-1810.000.016, CCD: Axis error
- P-0-1815.x.001, CCD: Master communication, synchronization input value
- P-0-1815.x.002, CCD: Master communication, synchronization output value
- P-0-1816.000.001, CCD: Master communication, synchronization counter
- P-0-1816.000.002, CCD: Master communication, synchronization P-gain
- P-0-1816.000.003, CCD: Master communication, synchronization I-gain
- P-0-1816.000.004, CCD: Master communication, synchronization error window
- P-0-1816.000.005, CCD: Master communication, synchronization delay
- P-0-1820.000.001, CCD: Master axes configuration list

Changes and Enhancements in Comparison to the Previous Version

- P-0-1820.000.002, CCD: Source of measuring encoder position feedback value
- P-0-1820.000.003, CCD: Actual position value of measuring encoder
- P-0-1820.000.004, CCD: Axis position selection
- P-0-1821.x.001, CCD: Position command value for master axis n
- P-0-1821.x.002, CCD: Master axis n, filter type
- P-0-1821.x.003, CCD: Master axis n, filter corner frequency
- P-0-1821.x.004, CCD: Master axis n, number of extrapolation steps
- P-0-1821.x.005, CCD: Master axis n, master axis position
- P-0-1822.000.001, CCD: Default master axis selection for the IndraDrive axes
- P-0-1822.000.002, CCD: Master axis selection for the IndraDrive axes
- P-0-1823.x.001, CCD: Default synchronization mode for axis n
- P-0-1823.x.002, CCD: Master axis position for axis n
- P-0-3044, Motor torque at nominal current with reluctance, type plate
- P-0-3045, Motor torque at maximum current with reluctance, type plate
- P-0-3046, Reluctance angle at nominal motor current, type plate
- P-0-3047, Reluctance angle at maximum motor current, type plate
- P-0-3048, Motor control configuration, type plate
- P-0-3200, SMO: Manufacturer version
- P-0-3200.000.001, SMO: Certificate information
- P-0-3200.000.005, SMO: Module code
- P-0-3200.000.006, SMO: Circuit board code
- P-0-3200.000.020, SMO: Service password
- P-0-3201, SMO: Configuration of functional commissioning
- P-0-3210, C8600 SMO: Command Measure position difference
- P-0-3210.000.001, SMO: Measured position difference
- P-0-3210.000.002, SMO: Axis validation status
- P-0-3211, SMO: Error reaction validation assistance
- P-0-3212, SMO: Code words for tests
- P-0-3218, SMO: Scaling factor for velocity limit value
- P-0-3219, SMO: Configuration of support functions
- P-0-3220, C8000 SMO: Command Apply scaling
- P-0-3221.000.001, SMO: Polarity
- P-0-3221.000.002, SMO: Input revolutions of load gearbox
- P-0-3221.000.003, SMO: Output revolutions of load gearbox
- P-0-3221.000.004, SMO: Feed constant
- P-0-3221.000.006, SMO: Modulo value
- P-0-3221.000.007, SMO: Maximum travel range
- P-0-3221.000.130, SMO: Basic scaling, compact
- P-0-3222.000.001, SMO: Position data scaling type
- P-0-3222.000.002, SMO: Linear position data scaling exponent
- P-0-3222.000.003, SMO: Rotational position resolution

Changes and Enhancements in Comparison to the Previous Version

- P-0-3222.000.130, SMO: Position scaling, compact
- P-0-3223.000.001, SMO: Velocity data scaling type
- P-0-3223.000.002, SMO: Velocity data scaling exponent
- P-0-3223.000.130, SMO: Velocity scaling, compact
- P-0-3224.000.001, SMO: Acceleration data scaling type
- P-0-3224.000.002, SMO: Acceleration data scaling exponent
- P-0-3224.000.003, SMO: Ramp reference velocity for acceleration data
- P-0-3224.000.130, SMO: Acceleration scaling, compact
- P-0-3230, SMO: Password level
- P-0-3230.000.001, SMO: Password
- P-0-3231, SMO: Operating status
- P-0-3231.000.001, C8100 SMO: Command Activate configuration mode
- P-0-3231.000.002, C8200 SMO: Command Exit configuration mode
- P-0-3231.000.003, C8300 SMO: Command Activate parameter image
- P-0-3231.000.004, SMO: System configuration
- P-0-3232, SMO: Parameter image
- P-0-3233, SMO: List of non-verified parameters
- P-0-3234.000.001, SMO: Configuration checksum
- P-0-3234.000.002, SMO: Operating hours at last change of configuration
- P-0-3234.000.003, SMO: Configuration change counter
- P-0-3234.000.004, SMO: Parameterization checksum
- P-0-3234.000.005, SMO: Operating hours at last change of parameterization
- P-0-3234.000.006, SMO: Parameterization change counter
- P-0-3234.000.130, SMO: Image information, compact
- P-0-3235.000.001, SMO: Active axis identifier
- P-0-3235.000.002, SMO: Proposed axis identifier
- P-0-3235.000.003, C8500 SMO: Command Apply identification data
- P-0-3235.000.004, SMO: Axis identification: Control word
- P-0-3235.000.005, SMO: Identification data image
- P-0-3236.000.001, SMO: Verification interface, configuration
- P-0-3236.000.002, SMO: Verification interface, data
- P-0-3236.000.003, SMO: Verification interface, acknowledgment
- P-0-3236.000.004, SMO: Verification interface, axis ID
- P-0-3236.000.005, SMO: Verification interface, commissioning identifier
- P-0-3237, SMO: Status word
- P-0-3238, SMO: Active velocity threshold
- P-0-3242.x.001, SMO: Phys. encoder type
- P-0-3242.x.002, SMO: Phys. encoder properties
- P-0-3242.x.003, SMO: Phys. encoder resolution (incremental)
- P-0-3242.x.130, SMO: Phys. encoder configuration, compact
- P-0-3245.x.131, SMO: Phys. encoder configuration, standard firmware

Changes and Enhancements in Comparison to the Previous Version

- P-0-3252.x.002, SMO: Mounting position
- P-0-3252.x.003, SMO: Gearbox input revolutions
- P-0-3252.x.004, SMO: Gearbox output revolutions
- P-0-3252.x.130, SMO: Encoder mechanics, compact
- P-0-3254, C8400 SMO: Command Apply encoder configuration
- P-0-3255, SMO: Velocity threshold for safe standstill
- P-0-3256, SMO: Encoder evaluation status
- P-0-3257, SMO: Position feedback value
- P-0-3258, SMO: Velocity feedback value
- P-0-3261, SMO: State machine control word
- P-0-3261.000.001, SMO: State machine control word, functional
- P-0-3262, SMO: Selected operating status
- P-0-3263.000.001, SMO: Configuration of stopping process
- P-0-3263.000.002, SMO: Oscillation velocity window of SMD-E
- P-0-3263.000.003, SMO: SMD-E reaction time
- P-0-3263.000.004, SMO: Velocity window of SMD-E
- P-0-3263.000.005, SMO: SMD-E delay
- P-0-3263.000.006, SMO: Error reaction F3 tolerance time
- P-0-3263.000.007, SMO: Error reaction F7 tolerance time
- P-0-3263.000.130, SMO: Stopping process, compact
- P-0-3264, SMO: Safety function selection
- P-0-3264.000.001, SMO: Safety function status
- P-0-3265, SMO: Status word of safe braking and holding function
- P-0-3265.000.001, SMO: Configuration of safe braking and holding function
- P-0-3265.000.002, SMO: Control word of safe braking and holding function
- P-0-3266, SMO: Safety zone status word
- P-0-3266.000.001, SMO: Safety zone control word
- P-0-3266.000.002, SMO: Safety zone configuration
- P-0-3266.000.003, SMO: Control word of safe door locking
- P-0-3270.000.001, SMO: Configuration of global safety functions
- P-0-3270.000.002, SMO: Safe maximum speed
- P-0-3270.000.003, SMO: Standstill window for safe direction of motion
- P-0-3270.000.130, SMO: Global safety functions, compact
- P-0-3277.000.001, SMO: Configuration in normal operation
- P-0-3280.000.001, SMO: Configuration of operation mode transitions
- P-0-3280.000.002, SMO: Max. transition time normal oper. to safe standstill
- P-0-3280.000.003, SMO: Max. transition time between safe operating states
- P-0-3280.000.004, SMO: Max. transition time normal oper. to safe motion
- P-0-3280.000.005, SMO: Max. tolerance time for different selection

Changes and Enhancements in Comparison to the Previous Version

- P-0-3280.000.006, SMO: Oscillation velocity window of SMD
- P-0-3280.000.007, SMO: SMD reaction time
- P-0-3280.000.008, SMO: Velocity window of SMD
- P-0-3280.000.009, SMO: SMD delay
- P-0-3280.000.130, SMO: Operation mode transitions, compact
- P-0-3285.000.001, SMO: Configuration of safe standstill
- P-0-3285.000.002, SMO: Monitoring window for safe operational stop
- P-0-3285.000.130, SMO: Safe standstill, compact
- P-0-3290.x.001, SMO: Configuration of safe motion
- P-0-3290.x.002, SMO: Safely-limited speed
- P-0-3290.x.003, SMO: Safely-limited increment
- P-0-3290.x.006, SMO: Maximum activation time of enabling control
- P-0-3290.x.007, SMO: Tolerance time for overshooting
- P-0-3290.x.008, SMO: Safely-reduced speed
- P-0-3290.x.130, SMO: Safe motion, compact
- P-0-3320, SMO: Safe input signals, safety zone module
- P-0-3320.000.002, SMO: Configuration of input signals, safety zone module
- P-0-3321, SMO: Safe output signals, safety zone module
- P-0-3322.000.001, SMO: Functional input signals, local
- P-0-3323, SMO: Safe output signals, local
- P-0-3329, SMO: Functional input signals, drive
- P-0-3330.x.001, SMO: IO mapper inputs, type
- P-0-3330.x.002, SMO: IO mapper inputs, IDN source
- P-0-3330.x.003, SMO: IO mapper inputs, bit source
- P-0-3330.x.004, SMO: IO mapper inputs, IDN target
- P-0-3330.x.005, SMO: IO mapper inputs, bit target
- P-0-3330.x.130, SMO: IO mapper inputs, compact
- P-0-3331.x.130, SMO: IO mapper block type, compact
- P-0-3332.000.001, SMO: IO mapper inputs, minimum pulse duration
- P-0-3335.000.001, SMO: Signal control for discrete outputs, IDN assignment
- P-0-3335.000.002, SMO: Signal control for discrete outputs, bit number
- P-0-3335.000.003, SMO: Signal ctrl for discrete outputs, possible source IDNs
- P-0-3335.000.004, SMO: Signal ctrl for discrete outputs, possible source bits
- P-0-3336.000.001, SMO: Signal control, status, safety bus, IDN assignment
- P-0-3336.000.002, SMO: Signal control, status, safety bus, bit number
- P-0-3336.000.003, SMO: Signal control, status, safety bus, possible source IDNs
- P-0-3336.000.004, SMO: Signal control, status, safety bus, possible source bits

Changes and Enhancements in Comparison to the Previous Version

- P-0-3336.000.005, SMO: Signal control, status, safety bus, SMMx coding
- P-0-3340, SMO: Safety bus control word
- P-0-3340.000.001, SMO: Mask of control word, safety bus
- P-0-3341, SMO: Safety bus status word
- P-0-3342, SMO: Status of consuming connection, safety bus
- P-0-3342.000.001, SMO: Configuration of consuming connection, safety bus
- P-0-3342.000.002, SMO: Consuming connection configuration list, safety bus
- P-0-3343, SMO: Status of producing connection, safety bus
- P-0-3343.000.001, SMO: Configuration of producing connection, safety bus
- P-0-3343.000.002, SMO: Producing connection configuration list, safety bus
- P-0-3345, SMO: Safety bus configuration
- P-0-3908.000.130, Circuit board management data, compact
- P-0-3908.000.151, Circuit board adjustment values
- P-0-3908.000.152, Circuit board type data 0
- P-0-3909, Boot Control word
- P-0-3933.000.001, Web server: Configuration
- P-0-3940, Motor torque/force at nominal current when using reluctance
- P-0-3941, Motor torque/force at maximum current when using reluctance
- P-0-3942, Reluctance angle at nominal motor current
- P-0-3943, Reluctance angle at maximum motor current
- P-0-4056, Thermal coefficients HCS04
- P-0-4089.000.006, Sync failures monitoring threshold
- S-0-0478, Position/travel range limit status
- S-0-0532, Travel range limit parameter
- S-0-0600.x.001, Encoder status
- S-0-0600.x.002, Position unscaled
- S-0-0600.x.020, Encoder data out container
- S-0-0601.x.001, Encoder data out configuration
- S-0-0601.x.001, Physical encoder position
- S-0-0601.x.002, Resolution of position
- S-0-0601.x.006, Absolute position range
- S-0-0601.x.010, Resolution of physical encoder position
- S-0-0601.x.010, Overflow threshold position
- S-0-0601.x.011, Encoder available data out
- S-0-0601.x.012, Encoder refresh time data out
- S-0-0601.x.130, Basic encoder evaluation configuration, compact
- S-0-0602.x.001, Phys. encoder type
- S-0-0602.x.002, Phys. encoder properties

Changes and Enhancements in Comparison to the Previous Version

- S-0-0602.x.003, Phys. encoder resolution (incremental)
- S-0-0602.x.004, Phys. encoder resolution (absolute)
- S-0-0602.x.007, Phys. Encoder protocol configuration
- S-0-0602.x.130, Basic encoder evaluation phys. configuration, compact
- S-0-1032, sercos: Communication control
- S-0-1050.x.001, sercos Connection: Configuration
- S-0-1050.x.002, sercos Connection: Connection number
- S-0-1050.x.003, sercos Connection: Telegram assignment
- S-0-1050.x.004, sercos Connection: Max. length of connection
- S-0-1050.x.005, sercos Connection: Current connection length
- S-0-1050.x.006, sercos Connection: Configuration list
- S-0-1050.x.007, sercos Connection: Connection class
- S-0-1050.x.007, sercos Connection: Connection class
- S-0-1050.x.008, sercos Connection: Connection control (C-Con)
- S-0-1050.x.009, sercos Connection: State
- S-0-1050.x.010, sercos Connection: Producer cycle time
- S-0-1050.x.011, sercos Connection: Allowed losses of producer data
- S-0-1050.x.012, sercos Connection: Error counter data losses
- S-0-1050.x.020, sercos Connection: IDN allocation of real-time bits
- S-0-1050.x.021, sercos Connection: Bit number allocation of real-time bits
- S-0-1300.x.001, Component Name
- S-0-1300.x.001, Component Name
- S-0-1300.x.003, Vendor Code
- S-0-1300.x.004, Device Name
- S-0-1300.x.004, Device Name
- S-0-1300.x.005, Vendor Device ID
- S-0-1300.x.008, Hardware version
- S-0-1300.x.008, Hardware version
- S-0-1300.x.009, Software version
- S-0-1300.x.009, Software version
- S-0-1300.x.011, Order Number
- S-0-1300.x.011, Order Number
- S-0-1300.x.012, Serial Number
- S-0-1300.x.130, Type plate, compact
- S-0-1300.x.150, Firmware identifier
- S-0-1302.000.003, Application type
- S-0-1305.000.003, sercos: Current coarse time
- S-0-1601, List of FSP Drive classes
- S-0-1800.000.001, List of applications
- S-0-1800.000.002, List of validator objects
- S-0-1800.000.004, SV Safety connection fault count
- S-0-1800.000.010, SSO Device Status

Changes and Enhancements in Comparison to the Previous Version

- S-0-1800.000.015, SSO Safety Configuration Identifier
- S-0-1800.000.016, SSO Configuration Lock
- S-0-1800.000.017, SSO Configuration UNID
- S-0-1800.000.018, SSO Proposed TUNID
- S-0-1800.000.019, SSO Target UNID
- S-0-1801.000.001, CIP Vendor ID
- S-0-1801.000.002, CIP Device Type
- S-0-1801.000.003, CIP Product Code
- S-0-1801.000.004, CIP Revision
- S-0-1801.000.005, CIP Status
- S-0-1801.000.006, CIP serial number
- S-0-1801.000.007, CIP Product Name
- S-0-1810.x.001, SV Max data age
- S-0-1810.x.002, Safety Validator State
- S-0-1810.x.003, SV Error code
- S-0-1810.x.004, Safety Validator type
- S-0-1810.x.005, SV Time coord msg min multiplier
- S-0-1810.x.006, SV Max consumer number
- S-0-1810.x.007, SV Timeout multiplier
- S-0-1810.x.008, SV Ping interval EPI multiplier
- S-0-1810.x.009, SV Network time expectation multiplier
- S-0-1820.x.001, CIP assembly instance number
- S-0-1820.x.002, Safety Validator instance number
- S-0-1820.x.003, Safety application type
- S-0-1820.x.004, Safety application data size
- S-0-1830.x.001, List of cyclic SMP container (out)
- S-0-1830.x.002, List of cyclic SMP Session ID (out)
- S-0-1830.x.003, List of cyclic SMP containers (in)
- S-0-1830.x.004, List of cyclic SMP Session IDs (in)
- S-0-1830.x.005, List of UCM SMP containers (in)
- S-0-1830.x.006, List of UCM SMP Session IDs (in)
- S-0-1830.x.007, List of UCM SMP containers (out)
- S-0-1830.x.008, List of UCM SMP Session IDs (out)
- S-0-1830.x.009, List of consumer numbers

4.4.2 New Alias Parameters

- P-0-1700, CCD: Diagnostic message number, slave
- P-0-2307, CCD: Application connection configuration, incremental
- P-0-2308, CCD: Application connection configuration, overall
- P-0-2309, CCD: Current connection configuration
- P-0-2319, CCD: Slave identification
- P-0-2322, CCD: Command typology
- P-0-2324, CCD: Actual topology

Changes and Enhancements in Comparison to the Previous Version

- P-0-2326, CCD: Slave addresses at end of line
- P-0-2328, C7100 CCD: Command Close ring
- P-0-2330, CCD: Slave information at topology location
- P-0-2332, C7000 CCD: Command Adjust slave addresses
- P-0-2334, C7400 CCD: Switching to phase 2
- P-0-2335, C7500 CCD: Switching to phase 4
- P-0-2336, CCD: Resource-Status (S-Res)
- P-0-2337, CDD: Resource-Control (C-Res)
- P-0-2338, CCD: Resource-Status (S-Res)
- P-0-2347, CDD: Resource-Control (C-Res)
- P-0-2355, CCD: Resource-Status (S-Res)
- P-0-2363, CDD: Resource-Control (C-Res)
- P-0-2371, CCD: Resource-Status (S-Res)
- P-0-2379, CDD: Resource-Control (C-Res)
- P-0-2387, CCD: Resource-Status (S-Res)
- P-0-2389, Basic encoder evaluation phys. configuration, compact
- P-0-2390, Basic encoder evaluation phys. configuration, compact
- P-0-2392, Basic encoder evaluation phys. configuration, compact
- P-0-2395, CDD: Resource-Control (C-Res)
- P-0-2397, CCD: SLc, diagnostic information
- P-0-2398, CCD: User data of SLc (outputs)
- P-0-2399, CCD: SLc, states of safety inputs
- P-0-2400, CCD: SLc, states of safety outputs
- P-0-2401, CCD: SLc, group status and control words
- P-0-2402, CCD: SLc user data (inputs)
- P-0-2403, CCD: Diagnostic code
- P-0-2406, Assignment signal status/control word, compact
- P-0-2407, Assignment signal status/control word, compact
- P-0-2408, Assignment signal status/control word, compact
- P-0-2409, Assignment signal status/control word, compact
- P-0-2410, Assignment signal status/control word, compact
- P-0-2411, Configurable factory default values, diagnostics
- P-0-2412, Instance parameter diagnostics
- P-0-2440, SMO: Basic scaling, compact
- P-0-2441, SMO: Position scaling, compact
- P-0-2442, SMO: Velocity scaling, compact
- P-0-2443, SMO: Acceleration scaling, compact
- P-0-2445, SMO: Global safety functions, compact
- P-0-2446, SMO: Safe motion, compact
- P-0-2447, SMO: Safe motion, compact
- P-0-2448, SMO: Safe motion, compact
- P-0-2449, SMO: Safe motion, compact
- P-0-2450, SMO: Safe motion, compact

Changes and Enhancements in Comparison to the Previous Version

- P-0-2451, SMO: Safe motion, compact
- P-0-2452, SMO: Safe motion, compact
- P-0-2453, SMO: Safe motion, compact
- P-0-2454, SMO: Safe motion, compact
- P-0-2455, SMO: Safe motion, compact
- P-0-2456, SMO: Safe motion, compact
- P-0-2457, SMO: Safe motion, compact
- P-0-2458, SMO: Safe motion, compact
- P-0-2459, SMO: Safe motion, compact
- P-0-2460, SMO: Safe motion, compact
- P-0-2461, SMO: Safe motion, compact
- P-0-2462, SMO: Safety function status
- P-0-2463, SMO: State machine control word, functional
- P-0-2464, SMO: Configuration in normal operation
- P-0-2465, C8100 SMO: Command Activate configuration mode
- P-0-2466, C8200 SMO: Command Exit configuration mode
- P-0-2467, C8300 SMO: Command Activate parameter image
- P-0-2468, SMO: Password
- P-0-2469, SMO: System configuration
- P-0-2474, SMO: Phys. encoder configuration, compact
- P-0-2486, SMO: Encoder mechanics, compact
- P-0-2492, SMO: IO mapper inputs, compact
- P-0-2493, SMO: IO mapper inputs, compact
- P-0-2494, SMO: IO mapper inputs, compact
- P-0-2495, SMO: IO mapper inputs, compact
- P-0-2496, SMO: IO mapper inputs, compact
- P-0-2497, SMO: IO mapper inputs, compact
- P-0-2498, SMO: IO mapper inputs, compact
- P-0-2499, SMO: IO mapper inputs, compact
- P-0-2500, SMO: IO mapper inputs, compact
- P-0-2501, SMO: IO mapper inputs, compact
- P-0-2502, SMO: IO mapper inputs, compact
- P-0-2503, SMO: IO mapper inputs, compact
- P-0-2504, SMO: IO mapper inputs, compact
- P-0-2505, SMO: IO mapper inputs, compact
- P-0-2506, SMO: IO mapper inputs, compact
- P-0-2507, SMO: IO mapper inputs, compact
- P-0-2508, SMO: IO mapper block type, compact
- P-0-2509, SMO: IO mapper block type, compact
- P-0-2510, SMO: IO mapper block type, compact
- P-0-2511, SMO: IO mapper block type, compact
- P-0-2512, SMO: IO mapper block type, compact
- P-0-2513, SMO: IO mapper block type, compact

Changes and Enhancements in Comparison to the Previous Version

- P-0-2514, SMO: IO mapper block type, compact
- P-0-2515, SMO: Signal control for discrete outputs, IDN assignment
- P-0-2516, SMO: Signal control for discrete outputs, bit number
- P-0-2517, SMO: Signal ctrl for discrete outputs, possible source IDNs
- P-0-2518, SMO: Signal ctrl for discrete outputs, possible source bits
- P-0-2519, SMO: Signal control, status, safety bus, IDN assignment
- P-0-2520, SMO: Signal control, status, safety bus, bit number
- P-0-2521, SMO: Signal control, status, safety bus, possible source IDNs
- P-0-2522, SMO: Signal control, status, safety bus, possible source bits
- P-0-2523, SMO: Operation mode transitions, compact
- P-0-2524, SMO: Safe standstill, compact
- P-0-2525, SMO: Image information, compact
- P-0-2526, SMO: Functional input signals, local
- P-0-2527, SMO: IO mapper inputs, minimum pulse duration
- P-0-2528, SMO: Mask of control word, safety bus
- P-0-2529, SMO: Signal control, status, safety bus, SMMx coding
- P-0-2530, SMO: Certificate information
- P-0-2531, SMO: Stopping process, compact
- P-0-2532, SMO: Configuration of input signals, safety zone module
- P-0-2533, SMO: Active axis identifier
- P-0-2534, SMO: Proposed axis identifier
- P-0-2535, C8500 SMO: Command Apply identification data
- P-0-2536, SMO: Axis identification: Control word
- P-0-2537, SMO: Verification interface, configuration
- P-0-2538, SMO: Verification interface, data
- P-0-2539, SMO: Verification interface, acknowledgment
- P-0-2540, SMO: Verification interface, axis ID
- P-0-2541, SMO: Verification interface, commissioning identifier
- P-0-2542, SMO: Measured position difference
- P-0-2543, SMO: Axis validation status
- P-0-2544, SMO: Configuration of safe braking and holding function
- P-0-2545, SMO: Control word of safe braking and holding function
- P-0-2546, SMO: Safety zone control word
- P-0-2547, SMO: Safety zone configuration
- P-0-2548, SMO: Control word of safe door locking
- P-0-2549, SMO: Configuration of consuming connection, safety bus
- P-0-2550, SMO: Consuming connection configuration list, safety bus
- P-0-2551, SMO: Configuration of producing connection, safety bus
- P-0-2552, SMO: Producing connection configuration list, safety bus
- P-0-2553, SMO: Identification data image
- P-0-2554, SMO: Module code
- P-0-2555, Assignment signal status/control word, compact
- P-0-2556, Assignment signal status/control word, compact

Changes and Enhancements in Comparison to the Previous Version

- P-0-2557, Assignment signal status/control word, compact
- P-0-2558, Assignment signal status/control word, compact
- P-0-2559, Assignment signal status/control word, compact
- P-0-2560, Configuration master/slave command/actual values, compact
- P-0-2561, Configuration master/slave command/actual values, compact
- P-0-2562, Configuration master/slave command/actual values, compact
- P-0-2563, Configuration master/slave command/actual values, compact
- P-0-2564, Configuration master/slave command/actual values, compact
- P-0-2565, Configuration master/slave command/actual values, compact
- P-0-2566, Configuration master/slave command/actual values, compact
- P-0-2567, Configuration master/slave command/actual values, compact
- P-0-2568, Configuration master/slave command/actual values, compact
- P-0-2569, Configuration master/slave command/actual values, compact
- P-0-2570, SMO: Circuit board code
- P-0-2571, Circuit board management data, compact
- P-0-2572, Basic encoder evaluation configuration, compact
- P-0-2573, Basic encoder evaluation configuration, compact
- P-0-2575, Basic encoder evaluation configuration, compact
- P-0-2578, Type plate, compact
- P-0-2579, Type plate, compact
- P-0-2580, Type plate, compact
- P-0-2584, Serial number
- P-0-2585, Serial number
- P-0-2586, Serial number
- P-0-2587, Serial number
- P-0-2722, Circuit board adjustment values
- P-0-2724, Circuit board adjustment values
- P-0-2725, Circuit board adjustment values
- P-0-2726, Circuit board adjustment values
- P-0-2727, Circuit board adjustment values
- P-0-2728, Sync failures monitoring threshold

4.4.3 Modified Parameters

- P-0-0013, List of all IDNs not corresponding to default value
- P-0-0020, Oscilloscope: Operation mode
- P-0-0088, Control word for synchronous operation modes
- P-0-0165, Drive optimization, control word
- P-0-0166, Drive optimization, end position negative
- P-0-0167, Drive optimization, end position positive
- P-0-0168, Maximum acceleration to be parameterized
- P-0-0165, Drive optimization, travel distance
- P-0-0210, Analog input 1
- P-0-0214, Analog input, assignment A, scaling

Changes and Enhancements in Comparison to the Previous Version

- P-0-0214, Analog input, assignment A, scaling per 10V full scale
- P-0-0215, Analog input, assignment A, signal value at 0
- P-0-0215, Analog input, assignment A, signal value at 0V
- P-0-0216, Analog input, assignment A, dead zone
- P-0-0217, Analog input 1, time constant input filter
- P-0-0218, Analog input, control parameter
- P-0-0226, Probe, extended control word
- P-0-0237, Analog input, assignment B, scaling
- P-0-0237, Analog input, assignment B, scaling per 10V full scale
- P-0-0238, Analog input, assignment B, signal value at 0
- P-0-0238, Analog input, assignment B, signal value at 0V
- P-0-0239, Analog input, assignment B, dead zone
- P-0-0481, Patch function 1, attribute
- P-0-0487, Patch function 2, attribute
- P-0-0492, PLC patch function 1, data source
- P-0-0492, Symbol-based patch function 1, data source
- P-0-0493, PLC patch function 1, display
- P-0-0493, Symbol-based patch function 1, display
- P-0-0494, PLC patch function 2, data source
- P-0-0494, Symbol-based patch function 2, data source
- P-0-0495, PLC patch function 2, display
- P-0-0495, Symbol-based patch function 2, display
- P-0-0496, PLC patch function 3, data source
- P-0-0496, Symbol-based patch function 3, data source
- P-0-0497, PLC patch function 3, display
- P-0-0497, Symbol-based patch function 3, display
- P-0-0498, PLC patch function 4, data source
- P-0-0498, Symbol-based patch function 4, data source
- P-0-0499, PLC patch function 4, display
- P-0-0499, Symbol-based patch function 4, display
- P-0-0519, Commutation status word
- P-0-0522, Control word for commutation setting
- P-0-0525, Holding brake control word
- P-0-0539, Holding brake status word
- P-0-0680, Control panel: Configuration
- P-0-0680.000.001, Control panel: Config. list of changeable app. parameters
- P-0-0680.000.002, Control panel: Config. list of app. parameters to be displayed
- P-0-0806, Current mains voltage crest value
- P-0-0815, Nominal mains voltage crest value
- P-0-0833, Braking resistor threshold
- P-0-0858, Data of external braking resistor

Changes and Enhancements in Comparison to the Previous Version

- P-0-0860, Converter configuration
- P-0-0901.x.006, Encoder emulation assignment
- P-0-1131, Control word of cogging torque compensation
- P-0-1466, PLC Torque/force ramp
- P-0-2003, Selection of functional packages
- P-0-4014, Type of construction of motor
- S-0-0206, Drive on delay time
- S-0-0207, Drive off delay time
- S-0-0262, C07_x Load defaults procedure command
- S-0-0262, C07_x Load defaults procedure command
- S-0-0375, List of diagnostic numbers
- S-0-0390, Diagnostic message number
- S-0-0524, Dead time compensation, positive edge, probe 1
- S-0-0525, Dead time compensation, negative edge, probe 1
- S-0-0526, Dead time compensation, positive edge, probe 2
- S-0-0527, Dead time compensation, negative edge, probe 2
- S-0-0600.x.020, Encoder data out container
- S-0-0601.x.001, Encoder data out configuration
- S-0-0601.x.001, Physical encoder position
- S-0-0601.x.002, Resolution of position
- S-0-0601.x.006, Absolute position range
- S-0-0601.x.010, Resolution of physical encoder position
- S-0-0601.x.010, Overflow threshold position
- S-0-0601.x.011, Encoder available data out
- S-0-0601.x.012, Encoder refresh time data out
- S-0-0602.x.002, Phys. encoder properties
- S-0-0602.x.003, Phys. encoder resolution (incremental)
- S-0-0602.x.004, Phys. encoder resolution (absolute)
- S-0-0602.x.007, Phys. Encoder protocol configuration

4.4.4 Modified Alias Parameters

- P-0-0090, Travel range limit parameter
- P-0-0091, Position/travel range limit status
- P-0-1600, CCD: Configuration
- P-0-1601, CCD: Addresses of projected drives
- P-0-1602, CCD: Timing settings
- P-0-1603, CCD: Actual topology addresses
- P-0-1604, CCD: Addresses of projected I/Os
- P-0-1605, CCD: Command communication phase
- P-0-1606, CCD: Actual communication phase
- P-0-1607, CCD: Axis error
- P-0-1608, CCD: Control word
- P-0-1609, CCD: Status word

Changes and Enhancements in Comparison to the Previous Version

- P-0-1610, CCD: Cycle time
- P-0-1615, CCD: Extrapolated command value IDN list signal selection
- P-0-1616, CCD: Extrapolated cmd value signal selection
- P-0-1617, CCD: Number of extrapolation steps
- P-0-1618, CCD: Extrapolated command value
- P-0-1630, CCD: Diagnostics
- P-0-1631, CCD: AT error counter
- P-0-1636, CCD: Command typology addresses
- P-0-1637, CCD: Error counter Port-1
- P-0-1638, CCD: Error counter Port-2
- P-0-1639, CCD: Allowed telegram failures
- P-0-1651, CCD: Master control word, slave 1
- P-0-1652, CCD: Master control word, slave 2
- P-0-1653, CCD: Master control word, slave 3
- P-0-1654, CCD: Master control word, slave 4
- P-0-1655, CCD: Master control word, slave 5
- P-0-1656, CCD: Master control word, slave 6
- P-0-1657, CCD: Master control word, slave 7
- P-0-1658, CCD: Master control word, slave 8
- P-0-1659, CCD: Master control word, slave 9
- P-0-1661, CCD: Drive status word, slave 1
- P-0-1662, CCD: Drive status word, slave 2
- P-0-1663, CCD: Drive status word, slave 3
- P-0-1664, CCD: Drive status word, slave 4
- P-0-1665, CCD: Drive status word, slave 5
- P-0-1666, CCD: Drive status word, slave 6
- P-0-1667, CCD: Drive status word, slave 7
- P-0-1668, CCD: Drive status word, slave 8
- P-0-1669, CCD: Drive status word, slave 9
- P-0-1670, CCD: Active actual position value, master
- P-0-1671, CCD: Active actual position value, slave 1
- P-0-1672, CCD: Active actual position value, slave 2
- P-0-1673, CCD: Active actual position value, slave 3
- P-0-1674, CCD: Active actual position value, slave 4
- P-0-1675, CCD: Active actual position value, slave 5
- P-0-1676, CCD: Active actual position value, slave 6
- P-0-1677, CCD: Active actual position value, slave 7
- P-0-1678, CCD: Active actual position value, slave 8
- P-0-1679, CCD: Active actual position value, slave 9
- P-0-1680, CCD: Actual velocity value, master
- P-0-1681, CCD: Actual velocity value, slave 1
- P-0-1682, CCD: Actual velocity value, slave 2
- P-0-1683, CCD: Actual velocity value, slave 3

Changes and Enhancements in Comparison to the Previous Version

- P-0-1684, CCD: Actual velocity value, slave 4
- P-0-1685, CCD: Actual velocity value, slave 5
- P-0-1686, CCD: Actual velocity value, slave 6
- P-0-1687, CCD: Actual velocity value, slave 7
- P-0-1688, CCD: Actual velocity value, slave 8
- P-0-1689, CCD: Actual velocity value, slave 9
- P-0-1690, CCD: Actual torque/force value, master
- P-0-1691, CCD: Actual torque/force value, slave 1
- P-0-1692, CCD: Actual torque/force value, slave 2
- P-0-1693, CCD: Actual torque/force value, slave 3
- P-0-1694, CCD: Actual torque/force value, slave 4
- P-0-1695, CCD: Actual torque/force value, slave 5
- P-0-1696, CCD: Actual torque/force value, slave 6
- P-0-1697, CCD: Actual torque/force value, slave 7
- P-0-1698, CCD: Actual torque/force value, slave 8
- P-0-1699, CCD: Actual torque/force value, slave 9
- P-0-1701, CCD: Diagnostic message number slave 1
- P-0-1702, CCD: Diagnostic message number slave 2
- P-0-1703, CCD: Diagnostic message number slave 3
- P-0-1704, CCD: Diagnostic message number slave 4
- P-0-1705, CCD: Diagnostic message number slave 5
- P-0-1706, CCD: Diagnostic message number slave 6
- P-0-1707, CCD: Diagnostic message number slave 7
- P-0-1708, CCD: Diagnostic message number slave 8
- P-0-1709, CCD: Diagnostic message number slave 9
- P-0-1710, CCD: Signal status word, master
- P-0-1711, CCD: Signal status word, slave 1
- P-0-1712, CCD: Signal status word, slave 2
- P-0-1713, CCD: Signal status word, slave 3
- P-0-1714, CCD: Signal status word, slave 4
- P-0-1715, CCD: Signal status word, slave 5
- P-0-1716, CCD: Signal status word, slave 6
- P-0-1717, CCD: Signal status word, slave 7
- P-0-1718, CCD: Signal status word, slave 8
- P-0-1719, CCD: Signal status word, slave 9
- P-0-1720, CCD: Signal control word, master
- P-0-1721, CCD: Signal control word, slave 1
- P-0-1722, CCD: Signal control word, slave 2
- P-0-1723, CCD: Signal control word, slave 3
- P-0-1724, CCD: Signal control word, slave 4
- P-0-1725, CCD: Signal control word, slave 5
- P-0-1726, CCD: Signal control word, slave 6
- P-0-1727, CCD: Signal control word, slave 7

Changes and Enhancements in Comparison to the Previous Version

- P-0-1728, CCD: Signal control word, slave 8
- P-0-1729, CCD: Signal control word, slave 9
- P-0-1730, CCD: Command value data container 1, Master 4Byte
- P-0-1731, CCD: Command value data container 1, Slave 1 4Byte
- P-0-1732, CCD: Command value data container 1, Slave 2 4Byte
- P-0-1733, CCD: Command value data container 1, Slave 3 4Byte
- P-0-1734, CCD: Command value data container 1, Slave 4 4Byte
- P-0-1735, CCD: Command value data container 1, Slave 5 4Byte
- P-0-1736, CCD: Command value data container 1, Slave 6 4Byte
- P-0-1737, CCD: Command value data container 1, Slave 7 4Byte
- P-0-1738, CCD: Command value data container 1, Slave 8 4Byte
- P-0-1739, CCD: Command value data container 1, Slave 9 4Byte
- P-0-1740, CCD: Command value data container 2, Master 4Byte
- P-0-1741, CCD: Command value data container 2, Slave 1 4Byte
- P-0-1742, CCD: Command value data container 2, Slave 2 4Byte
- P-0-1743, CCD: Command value data container 2, Slave 3 4Byte
- P-0-1744, CCD: Command value data container 2, Slave 4 4Byte
- P-0-1745, CCD: Command value data container 2, Slave 5 4Byte
- P-0-1746, CCD: Command value data container 2, Slave 6 4Byte
- P-0-1747, CCD: Command value data container 2, Slave 7 4Byte
- P-0-1748, CCD: Command value data container 2, Slave 8 4Byte
- P-0-1749, CCD: Command value data container 2, Slave 9 4Byte
- P-0-1750, CCD: Command value data container 3, Master 4Byte
- P-0-1751, CCD: Command value data container 3, Slave 1 4Byte
- P-0-1752, CCD: Command value data container 3, Slave 2 4Byte
- P-0-1753, CCD: Command value data container 3, Slave 3 4Byte
- P-0-1754, CCD: Command value data container 3, Slave 4 4Byte
- P-0-1755, CCD: Command value data container 3, Slave 5 4Byte
- P-0-1756, CCD: Command value data container 3, Slave 6 4Byte
- P-0-1757, CCD: Command value data container 3, Slave 7 4Byte
- P-0-1758, CCD: Command value data container 3, Slave 8 4Byte
- P-0-1759, CCD: Command value data container 3, Slave 9 4Byte
- P-0-1760, CCD: Command value data container 4, Master 4Byte
- P-0-1761, CCD: Command value data container 4, Slave 1 4Byte
- P-0-1762, CCD: Command value data container 4, Slave 2 4Byte
- P-0-1763, CCD: Command value data container 4, Slave 3 4Byte
- P-0-1764, CCD: Command value data container 4, Slave 4 4Byte
- P-0-1765, CCD: Command value data container 4, Slave 5 4Byte
- P-0-1766, CCD: Command value data container 4, Slave 6 4Byte
- P-0-1767, CCD: Command value data container 4, Slave 7 4Byte
- P-0-1768, CCD: Command value data container 4, Slave 8 4Byte
- P-0-1769, CCD: Command value data container 4, Slave 9 4Byte
- P-0-1770, CCD: Actual value data container 1, Master 4Byte

Changes and Enhancements in Comparison to the Previous Version

- P-0-1771, CCD: Actual value data container 1, Slave 1 4Byte
- P-0-1772, CCD: Actual value data container 1, Slave 2 4Byte
- P-0-1773, CCD: Actual value data container 1, Slave 3 4Byte
- P-0-1774, CCD: Actual value data container 1, Slave 4 4Byte
- P-0-1775, CCD: Actual value data container 1, Slave 5 4Byte
- P-0-1776, CCD: Actual value data container 1, Slave 6 4Byte
- P-0-1777, CCD: Actual value data container 1, Slave 7 4Byte
- P-0-1778, CCD: Actual value data container 1, Slave 8 4Byte
- P-0-1779, CCD: Actual value data container 1, Slave 9 4Byte
- P-0-1780, CCD: Actual value data container 2, Master 4Byte
- P-0-1781, CCD: Actual value data container 2, Slave 1 4Byte
- P-0-1782, CCD: Actual value data container 2, Slave 2 4Byte
- P-0-1783, CCD: Actual value data container 2, Slave 3 4Byte
- P-0-1784, CCD: Actual value data container 2, Slave 4 4Byte
- P-0-1785, CCD: Actual value data container 2, Slave 5 4Byte
- P-0-1786, CCD: Actual value data container 2, Slave 6 4Byte
- P-0-1787, CCD: Actual value data container 2, Slave 7 4Byte
- P-0-1788, CCD: Actual value data container 2, Slave 8 4Byte
- P-0-1789, CCD: Actual value data container 2, Slave 9 4Byte
- P-0-1790, CCD: Actual value data container 3, Master 4Byte
- P-0-1791, CCD: Actual value data container 3, Slave 1 4Byte
- P-0-1792, CCD: Actual value data container 3, Slave 2 4Byte
- P-0-1793, CCD: Actual value data container 3, Slave 3 4Byte
- P-0-1794, CCD: Actual value data container 3, Slave 4 4Byte
- P-0-1795, CCD: Actual value data container 3, Slave 5 4Byte
- P-0-1796, CCD: Actual value data container 3, Slave 6 4Byte
- P-0-1797, CCD: Actual value data container 3, Slave 7 4Byte
- P-0-1798, CCD: Actual value data container 3, Slave 8 4Byte
- P-0-1799, CCD: Actual value data container 3, Slave 9 4Byte
- P-0-1800, CCD: Actual value data container 4, Master 4Byte
- P-0-1801, CCD: Actual value data container 4, Slave 1 4Byte
- P-0-1802, CCD: Actual value data container 4, Slave 2 4Byte
- P-0-1803, CCD: Actual value data container 4, Slave 3 4Byte
- P-0-1804, CCD: Actual value data container 4, Slave 4 4Byte
- P-0-1805, CCD: Actual value data container 4, Slave 5 4Byte
- P-0-1806, CCD: Actual value data container 4, Slave 6 4Byte
- P-0-1807, CCD: Actual value data container 4, Slave 7 4Byte
- P-0-1808, CCD: Actual value data container 4, Slave 8 4Byte
- P-0-1809, CCD: Actual value data container 4, Slave 9 4Byte
- P-0-1810, CCD: Status word synchronous operation modes, master
- P-0-1811, CCD: Status word synchronous operation modes, slave 1
- P-0-1812, CCD: Status word synchronous operation modes, slave 2
- P-0-1813, CCD: Status word synchronous operation modes, slave 3

Changes and Enhancements in Comparison to the Previous Version

- P-0-1814, CCD: Status word synchronous operation modes, slave 4
- P-0-1815, CCD: Status word synchronous operation modes, slave 5
- P-0-1816, CCD: Status word synchronous operation modes, slave 6
- P-0-1817, CCD: Status word synchronous operation modes, slave 7
- P-0-1818, CCD: Status word synchronous operation modes, slave 8
- P-0-1819, CCD: Status word synchronous operation modes, slave 9
- P-0-1820, CCD: Command value data container 1, Master 2Byte
- P-0-1821, CCD: Command value data container 1, Slave 1 2Byte
- P-0-1822, CCD: Command value data container 1, Slave 2 2Byte
- P-0-1823, CCD: Command value data container 1, Slave 3 2Byte
- P-0-1824, CCD: Command value data container 1, Slave 4 2Byte
- P-0-1825, CCD: Command value data container 1, Slave 5 2Byte
- P-0-1826, CCD: Command value data container 1, Slave 6 2Byte
- P-0-1827, CCD: Command value data container 1, Slave 7 2Byte
- P-0-1828, CCD: Command value data container 1, Slave 8 2Byte
- P-0-1829, CCD: Command value data container 1, Slave 9 2Byte
- P-0-1830, CCD: Command value data container 2, Master 2Byte
- P-0-1831, CCD: Command value data container 2, Slave 1 2Byte
- P-0-1832, CCD: Command value data container 2, Slave 2 2Byte
- P-0-1833, CCD: Command value data container 2, Slave 3 2Byte
- P-0-1834, CCD: Command value data container 2, Slave 4 2Byte
- P-0-1835, CCD: Command value data container 2, Slave 5 2Byte
- P-0-1836, CCD: Command value data container 2, Slave 6 2Byte
- P-0-1837, CCD: Command value data container 2, Slave 7 2Byte
- P-0-1838, CCD: Command value data container 2, Slave 8 2Byte
- P-0-1839, CCD: Command value data container 2, Slave 9 2Byte
- P-0-1840, CCD: Command value data container 3, Master 2Byte
- P-0-1841, CCD: Command value data container 3, Slave 1 2Byte
- P-0-1842, CCD: Command value data container 3, Slave 2 2Byte
- P-0-1843, CCD: Command value data container 3, Slave 3 2Byte
- P-0-1844, CCD: Command value data container 3, Slave 4 2Byte
- P-0-1845, CCD: Command value data container 3, Slave 5 2Byte
- P-0-1846, CCD: Command value data container 3, Slave 6 2Byte
- P-0-1847, CCD: Command value data container 3, Slave 7 2Byte
- P-0-1848, CCD: Command value data container 3, Slave 8 2Byte
- P-0-1849, CCD: Command value data container 3, Slave 9 2Byte
- P-0-1850, CCD: Command value data container 4, Master 2Byte
- P-0-1851, CCD: Command value data container 4, Slave 1 2Byte
- P-0-1852, CCD: Command value data container 4, Slave 2 2Byte
- P-0-1853, CCD: Command value data container 4, Slave 3 2Byte
- P-0-1854, CCD: Command value data container 4, Slave 4 2Byte
- P-0-1855, CCD: Command value data container 4, Slave 5 2Byte
- P-0-1856, CCD: Command value data container 4, Slave 6 2Byte

Changes and Enhancements in Comparison to the Previous Version

- P-0-1857, CCD: Command value data container 4, Slave 7 2Byte
- P-0-1858, CCD: Command value data container 4, Slave 8 2Byte
- P-0-1859, CCD: Command value data container 4, Slave 9 2Byte
- P-0-1860, CCD: Actual value data container 1, Master 2Byte
- P-0-1861, CCD: Actual value data container 1, Slave 1 2Byte
- P-0-1862, CCD: Actual value data container 1, Slave 2 2Byte
- P-0-1863, CCD: Actual value data container 1, Slave 3 2Byte
- P-0-1864, CCD: Actual value data container 1, Slave 4 2Byte
- P-0-1865, CCD: Actual value data container 1, Slave 5 2Byte
- P-0-1866, CCD: Actual value data container 1, Slave 6 2Byte
- P-0-1867, CCD: Actual value data container 1, Slave 7 2Byte
- P-0-1868, CCD: Actual value data container 1, Slave 8 2Byte
- P-0-1869, CCD: Actual value data container 1, Slave 9 2Byte
- P-0-1870, CCD: Actual value data container 2, Master 2Byte
- P-0-1871, CCD: Actual value data container 2, Slave 1 2Byte
- P-0-1872, CCD: Actual value data container 2, Slave 2 2Byte
- P-0-1873, CCD: Actual value data container 2, Slave 3 2Byte
- P-0-1874, CCD: Actual value data container 2, Slave 4 2Byte
- P-0-1875, CCD: Actual value data container 2, Slave 5 2Byte
- P-0-1876, CCD: Actual value data container 2, Slave 6 2Byte
- P-0-1877, CCD: Actual value data container 2, Slave 7 2Byte
- P-0-1878, CCD: Actual value data container 2, Slave 8 2Byte
- P-0-1879, CCD: Actual value data container 2, Slave 9 2Byte
- P-0-1880, CCD: Actual value data container 3, Master 2Byte
- P-0-1881, CCD: Actual value data container 3, Slave 1 2Byte
- P-0-1882, CCD: Actual value data container 3, Slave 2 2Byte
- P-0-1883, CCD: Actual value data container 3, Slave 3 2Byte
- P-0-1884, CCD: Actual value data container 3, Slave 4 2Byte
- P-0-1885, CCD: Actual value data container 3, Slave 5 2Byte
- P-0-1886, CCD: Actual value data container 3, Slave 6 2Byte
- P-0-1887, CCD: Actual value data container 3, Slave 7 2Byte
- P-0-1888, CCD: Actual value data container 3, Slave 8 2Byte
- P-0-1889, CCD: Actual value data container 3, Slave 9 2Byte
- P-0-1890, CCD: Actual value data container 4, Master 2Byte
- P-0-1891, CCD: Actual value data container 4, Slave 1 2Byte
- P-0-1892, CCD: Actual value data container 4, Slave 2 2Byte
- P-0-1893, CCD: Actual value data container 4, Slave 3 2Byte
- P-0-1894, CCD: Actual value data container 4, Slave 4 2Byte
- P-0-1895, CCD: Actual value data container 4, Slave 5 2Byte
- P-0-1896, CCD: Actual value data container 4, Slave 6 2Byte
- P-0-1897, CCD: Actual value data container 4, Slave 7 2Byte
- P-0-1898, CCD: Actual value data container 4, Slave 8 2Byte
- P-0-1899, CCD: Actual value data container 4, Slave 9 2Byte

Changes and Enhancements in Comparison to the Previous Version

- S-0-0142, Application type

4.4.5 No Longer Existing Parameters

- P-0-0007, Display text of diagnostic message
- P-0-0009, Error number
- P-0-1362, PLC boot project info
- P-0-1470.000.001, PLC inputs area AT %IB1000 - %IB1199
- P-0-1470.000.002, PLC inputs area AT %IB1200 - %IB1399
- P-0-1470.000.003, PLC inputs area AT %IB1400 - %IB1599
- P-0-1470.000.004, PLC inputs area AT %IB1600 - %IB1799
- P-0-1471.000.001, PLC outputs area AT %QB1000 - %QB1199
- P-0-1471.000.002, PLC outputs area AT %QB1200 - %QB1399
- P-0-1471.000.003, PLC outputs area AT %QB1400 - %QB1599
- P-0-1471.000.004, PLC outputs area AT %QB1600 - %QB1799
- P-0-1610.000.003, CCD: Actual topology
- P-0-1610.000.021, CCD: Slave addresses at end of line
- P-0-1610.000.030, CCD: Diagnostic text
- P-0-1610.000.031, CCD: Diagnostic code
- P-0-1611, CCD: Configuration list signal status word
- P-0-1612, CCD: Configuration list signal control word
- P-0-1613, CCD: Assignment list signal status word
- P-0-1614, CCD: Assignment list signal control word
- P-0-1619, CCD: Slave information at topology location
- P-0-1620.000.003, CCD: Command typology
- P-0-1620.000.004, CCD: Slave identification
- P-0-1620.000.005, C7400 CCD: Switching to phase 2
- P-0-1620.000.006, C7500 CCD: Switching to phase 4
- P-0-1620.000.021, C7100 CCD: Command Close ring
- P-0-1620.000.030, CCD: I/O selection for command C72
- P-0-1620.000.031, C7200 CCD: Command Apply I/O configuration
- P-0-1621, CCD: Configuration list master communication cmd values
- P-0-1621.x.001, CCD: Slave address in high level network
- P-0-1621.x.009, CCD: Master comm. C0100 Comm. phase 3 transition check
- P-0-1621.x.010, CCD: Master comm. C5200 Comm. phase 4 transition check
- P-0-1621.x.024, CCD: Master communication gateway parameter pool 1
- P-0-1621.x.025, CCD: Master communication gateway parameter pool 2
- P-0-1621.x.035, C5300 CCD: sercos SYNC delay measuring procedure command
- P-0-1622, CCD: Configuration list master communication actual values
- P-0-1623, CCD: Configuration list master cmd values
- P-0-1624, CCD: Configuration list actual master values
- P-0-1625, CCD: Configuration list slave cmd values

Changes and Enhancements in Comparison to the Previous Version

- P-0-1626, CCD: Configuration list actual slave values
- P-0-1627, CCD: Configuration list master cmd values I/Os
- P-0-1628, CCD: Configuration list act. master values I/Os
- P-0-1629, CCD: Configuration compact I/Os
- P-0-1630.x.001, CCD: Slave IP address
- P-0-1630.x.002, CCD: Device Status (S-Dev)
- P-0-1630.x.003, CCD: Connection-Control #0 (C-Con)
- P-0-1630.x.020, CCD: Resource-Status (S-Res)
- P-0-1632, CCD: System data 2 bytes
- P-0-1633, CCD: System data 4 bytes
- P-0-1634.x.001, CCD: Module type codes of the modular I/Os
- P-0-1635, C7000 CCD: Command Adjust slave addresses
- P-0-1645.x.001, CCD connection: Configuration
- P-0-1645.x.002, CCD connection: Connection number
- P-0-1645.x.003, CCD connection: Telegram assignment
- P-0-1645.x.004, CCD connection: Max. length of connection
- P-0-1645.x.005, CCD connection: Current connection length
- P-0-1645.x.006, CCD connection: Configuration list
- P-0-1645.x.007, CCD connection: Connection class
- P-0-1645.x.008, CCD connection: Connection control (C-Con)
- P-0-1645.x.009, CCD connection: State
- P-0-1645.x.010, CCD connection: Producer cycle time
- P-0-1645.x.011, CCD connection: Allowed losses of producer data
- P-0-1645.x.012, CCD connection: Error counter data losses
- P-0-1645.x.020, CCD connection IDN allocation of real-time bits
- P-0-1645.x.021, CCD connection: Bit number allocation of real-time bits
- P-0-1660.x.002, CCD: Device Control (C-Res)
- P-0-1660.x.003, CCD: Connection-Control #1 (C-Con)
- P-0-1660.x.020, CDD: Resource-Control (C-Res)
- P-0-4065, Non-volatile memory active
- S-0-0600.x.020, Encoder data out container
- S-0-0601.x.001, Encoder data out configuration
- S-0-0601.x.001, Physical encoder position
- S-0-0601.x.002, Resolution of position
- S-0-0601.x.006, Absolute position range
- S-0-0601.x.010, Resolution of physical encoder position
- S-0-0601.x.010, Overflow threshold position
- S-0-0601.x.011, Encoder available data out
- S-0-0601.x.012, Encoder refresh time data out
- S-0-0602.x.001, Phys. encoder type
- S-0-0602.x.002, Phys. encoder properties
- S-0-0602.x.003, Phys. encoder resolution (incremental)
- S-0-0602.x.004, Phys. encoder resolution (absolute)

Changes and Enhancements in Comparison to the Previous Version

- S-0-0602.x.007, Phys. Encoder protocol configuration

4.5 New, Modified or no Longer Existing Diagnostic Messages

4.5.1 New Diagnostic Messages

The following new diagnostic messages were implemented in firmware version **MPx17V08**:

- A0004 Initialization
- A0005 Pre-Operational
- A0006 Safe-Operational
- A0023 WAIT_CFG
- A0024 Connection established

The following new diagnostic messages were implemented in firmware version **MPx18**:

- A0300 Condition as supplied SMO: Output stage locked
- A0301 Special mode Safe motion 1 active
- A0302 Special mode Safe motion 2 active
- A0303 Special mode Safe motion 3 active
- A0304 Special mode Safe motion 4 active
- A0305 Special mode Safe motion 5 active
- A0306 Special mode Safe motion 6 active
- A0307 Special mode Safe motion 7 active
- A0308 Special mode Safe motion 8 active
- A0309 Special mode Safe motion 9 active
- A0310 Special mode Safe motion 10 active
- A0311 Special mode Safe motion 11 active
- A0312 Special mode Safe motion 12 active
- A0313 Special mode Safe motion 13 active
- A0314 Special mode Safe motion 14 active
- A0315 Special mode Safe motion 15 active
- A0316 Special mode Safe motion 16 active
- A0320 EMERGENCY STOP active
- A0321 Special mode Safe standstill active with STO
- A0322 Special mode Safe standstill active with SOS
- A0323 SMO configuration mode active
- C0213 SMO: Incorrect parameterization
- C0214 SMO: Incorrect configuration
- C0215 SMO: Error in encoder initialization
- C0216 SMO: SCM-OM switching not allowed
- C0297 Encoder type not possible for selected constr. type of motor
- C0404 SMO: Incorrect change of system state
- C0720 SMO: Load defaults procedure command
- C0721 SMO: Load defaults procedure not possible
- C0723 SMO: Error in deactivation

Changes and Enhancements in Comparison to the Previous Version

- C0743 Error in activation of field bus profile settings
- C4806 Cogging torque compensation: Measuring range invalid
- C8000 SMO: Command Apply scaling
- C8001 SMO: Invalid scaling parameters ->S-0-0423
- C8002 SMO: Not allowed to apply scaling
- C8100 SMO: Command Activate configuration mode
- C8101 SMO: Command execution impossible
- C8200 SMO: Command Exit configuration mode
- C8213 SMO: Incorrect parameterization
- C8214 SMO: Incorrect configuration
- C8215 SMO: Error in encoder initialization
- C8300 SMO: Command Activate parameter image
- C8301 SMO: Incorrect parameter image
- C8302 SMO: Parameter image presently cannot be applied
- C8400 SMO: Command Apply encoder configuration
- C8401 SMO: Impossible to apply encoder type
- C8402 SMO: Impossible to apply encoder configuration
- C8403 SMO: Parameter for applying encoder configuration invalid
- C8500 SMO: Command Apply identification data
- C8501 SMO: Impossible to apply axis identification
- C8502 SMO: Impossible to apply TUNID
- C8600 SMO: Command Measure position difference
- C8601 SMO: Encoder evaluation is inactive
- E8300 SMO: Error within the safety zone
- E8399 Error in processing of diagnostic message
- F2270 Analog input, wire break
- F3010 SMO: IO mapper inputs error
- F3100 F3 test error during machine acceptance test
- F3101 Axis validation missing
- F3115 Brake check time interval exceeded
- F3119 Error in initialization of P-0-3212
- F3131 Control error, safe inputs of HSZ
- F3132 SDL validation error
- F3141 Operating status selection validation error
- F3142 Activation time of enabling control exceeded
- F3150 Safety zone module: Temperature monitoring error
- F3151 Safety zone module: 24 volt error
- F3152 Safety zone module: DYN error
- F3153 Safety zone module: SZE/SZA error
- F3304 SMO: System error
- F3360 SMO: Local I/O system error
- F3450 CSS stack error
- F4141 CCD: IO configuration changed

Changes and Enhancements in Comparison to the Previous Version

- F4142 CCD: Ring buffer overflow
- F4150 CSAL error
- F6200 Velocity command value > standstill window in SOS
- F7010 Safely-limited increment exceeded
- F7013 Velocity threshold exceeded
- F7014 Timeout in safely-monitored transient oscillation
- F7020 Safe maximum speed exceeded
- F7030 Position window for safe operating stop exceeded
- F7031 Incorrect direction of motion
- F7032 Forced zone safety
- F7033 Safety zone module: Hardware error
- F7034 Safety zone module: SDL error
- F7035 Zone bus error
- F7050 Maximum transition time exceeded
- F7051 Safely-monitored deceleration exceeded
- F7052 Selected target velocity exceeded
- F7100 F7 test error during machine acceptance test
- F8018 Device overtemperature shutdown
- F8304 SMO: System error
- F8313 SMO: Incorrect parameterization
- F8314 SMO: Incorrect configuration
- F8315 SMO: Error in encoder initialization
- F8316 SMO: Incorrect change of system state
- F8319 SMO: INIT system error
- F8320 SMO: Invalid module/firmware combination
- F8321 SMO: Invalid circuit board/firmware combination
- F8323 SMO: Error in deactivation
- F8324 SMO: Error in activation
- F8330 SMO: Configuration data record has not been activated
- F8350 Maximum transition time exceeded
- F8351 Safely-monitored deceleration exceeded
- F8352 Drive enable set in STO
- F8353 SBC system error
- F8354 Error when checking interrupting circuits
- F8355 Incorrect processing of diagnostic message
- F8356 SMO: Incorrect parameter processing
- F8380
- F8381
- F8382
- F8383
- F8395 SMO: Drive system configuration error

Changes and Enhancements in Comparison to the Previous Version

4.5.2 Modified Diagnostic Messages

The following diagnostic messages were extended or modified in firmware version MPx18:

- C0722 SMO: Error in load defaults procedure
- C1217 Setting only possible in 'Ab'
- C1802 No useful motor data
- C1803 Inertia detection failed
- C1804 Automatic controller setting failed
- C1805 Travel range invalid
- C1806 Travel range exceeded
- C2001 Command not enabled
- C3612 Command execution impossible
- F2825 Switch-on threshold braking resistor too low
- F6010 PLC runtime error
- F8069 Error in device-internal power supply
- F8118 Invalid power section/firmware combination

4.5.3 No Longer Existing Diagnostic Messages

Compared to the firmware version MPx17, the following diagnostic messages no longer exist or were replaced by other diagnostic messages:

- "C7200CCD: Command Apply I/O configuration" and "C7201CCD: Impossible to apply I/O configuration"¹⁾

¹⁾ The command / the command error is only required for IndraMotion MLD 1G (MPx-17)

5 Overview of the Scope of Functions

5.1 System Overview

5.1.1 General Information

Terms, Basic Principles

Parameters

Communication between master and drive takes place, with a few exceptions, by means of parameters.

Parameters are used for:

- Determining the configuration
- Parameterizing the control loop
- Triggering and controlling drive functions and commands
- Transmitting command values and actual values (according to requirements, cyclically or acyclically)

All operating data are mapped to parameters!

The operating data stored in parameters can be identified by means of the IDN. They can be read and transferred, if required. The user write access to parameters depends on the properties of the respective parameter and the current communication phase. The drive firmware checks specific parameter values (operating data) for validity.

Data Storage and Parameter Handling

Data Memory

Several non-volatile data memories are available in an IndraDrive device:

- In the controller
- In the motor encoder (depending on motor type)
- In the programming module / control panel

In addition, a volatile data memory (working memory) is available in the controller.

Condition as Supplied

Condition as supplied of the Rexroth drive components:

- The controller memory contains controller-specific parameter values.
- The programming module / control panel contains the firmware.
- The motor encoder memory contains the encoder-specific and, depending on the motor type, the motor-specific parameter values.
- The application-specific parameter values are stored in the programming module / control panel. Due to the limited number of writing cycles of non-volatile storage media, application-specific parameter values can also be stored in the working memory (volatile memory) of the controller.
- With the "IMST" or "IDST" service tool (as of MPx18V10), parameter values can be saved on an external data carrier.

Storing the Application-Specific Parameter Values

Saving Parameter Values

Saving application-specific parameter values is required in the following cases:

- After initial commissioning of the machine axis or the motor
- Before replacing the controller for servicing (if possible)

Application-specific parameter values can be saved via:

- "IndraWorks Ds/D/MLD" commissioning tool
→ Saving parameter values on external data carrier

Overview of the Scope of Functions

	- Control master → Saving parameter values on master-side data carrier
Parameter IDN Lists	The drive supports master-side saving of parameter values by listing parameter identification numbers (IDNs). Using these lists guarantees complete storage of the application-specific parameter values. It is also possible to determine IDN lists defined by the customer.
Loading Parameter Values	Loading parameter values is required in the following cases: - Initial commissioning of the motor → Loading default values (factory settings) and the motor-specific parameter values - Serial commissioning of machine axes on series machines → Loading the parameter values saved after initial commissioning - Reestablishing a defined initial state → Reloading the parameter values saved after initial commissioning - Replacing the controller for servicing → Loading the parameter values currently saved before servicing Possibilities of loading parameter values to the controller: - Motor encoder data memory → Loading the parameter values by command or via the control panel during initial motor commissioning "IndraWorks Ds/D/MLD" commissioning tool → Loading the parameter values from an external data carrier "IMST" or "IDST" service tool as of MPx18V10 → Loading the parameter values from an external data carrier - Control master → Loading the parameter values from a master-side data carrier
Checksum of Parameter Values	By means of checksum comparison, the control master can determine whether the values of the application-specific parameter values currently active in the drive correspond to the values saved on the master side. Password IndraDrive controllers provide the possibility to protect parameter values against accidental or unauthorized change by means of a password. With regard to write protection, there are 3 groups of writable parameters: - Parameters that are generally write-protected, such as motor parameters, hardware code parameters, encoder parameters, error memories, etc. ("administration parameters"). The values of these parameters ensure correct function and performance of the drive. - Parameters the customer can combine in groups and protect them with a so-called customer password. This allows protecting parameter values, that are used for adjusting the drive to the axis, after having determined them. - All other writable parameters and are not contained in the above-mentioned groups. They are not write-protected. Types of Passwords The drive firmware allows activating and deactivating the write protection for parameter values by means of three hierarchically different passwords: Customer password

Overview of the Scope of Functions

The parameter values of a parameter group combined by the customer can be protected.

- **Control password**

Parameters protected by a customer password are writable; "administration parameters" remain read-only.

- **Master password**

All writable parameters, including "administration parameters" and parameters protected by a customer password, can be changed.

Commands

Commands are used to activate and control complex functions or monitoring features in the drive. The higher-level master can start, interrupt and clear commands.

Each command is assigned to a parameter by means of which the execution of the command can be controlled. While the command is executed, the display of the control panel reads "Cx", "C" representing the diagnostic command message and "x" representing the number of the command.



Each command that was started must be actively cleared again.

All commands available in the drive are stored in parameter "S-0-0025, IDN-list of all procedure commands".

Types of Commands

There are 3 different types of commands:

- **Drive control commands**
 - can cause automatic drive motion,
 - can be started only when drive enable has been set,
 - deactivate the active operation mode while they are executed.
- **Monitor commands**
 - activate or deactivate monitoring features or functions in the drive.
- **Administration commands**
 - carry out administration tasks,
 - cannot be interrupted.

See also section "Command Processing"

Operation Modes

The selection of operation modes defines which command values will be processed in which way, in order to lead to the desired drive motion. The operation mode does not determine how these command values are transmitted from the master to the slave.

One of the eight operation modes that are defined in parameters is always active if the conditions below are fulfilled:

- Control section and power section are ready for operation
- Drive enable signal sees a positive edge
- Drive follows command value input
- "Drive Halt" function has not been activated
- No drive control command is active
- No error reaction is carried out

The display of the control panel reads "AF" when an operation mode was activated.

Overview of the Scope of Functions



All implemented operation modes are stored in parameter "S-0-0292, List of supported operation modes".

See also chapter "[Operation Modes](#)"

Warnings

Depending on the active operation mode and the parameter settings, many monitoring functions are carried out. If a state is detected that permits correct operation, but if continued results in the occurrence of an error and the automatic shutdown of the drive, the drive firmware generates an error message.



Warnings do not cause automatic shutdown (exception: fatal warning).

Warning Classes

Warnings are classified in different warning classes which determine whether or not the drive carries out an automatic reaction when the warning is generated.



The warning class can be recognized by the diagnostic message.

We distinguish the following warning classes:

- **Without** drive reaction → diagnostic message number **E2xxx**, **E3xxx**, **E4xxx**
- **With** drive reaction → diagnostic message number **E8xxx**



Warnings cannot be cleared. They persist until the condition that activated the warning is no longer fulfilled.

Errors

Depending on the active operation mode and the parameter settings, many monitoring functions are carried out. If a state is detected that affects or prevents correct operation, the drive firmware generates an error message.

Error Classes

Errors are assigned to various error classes that differ based on the different error reactions of the drive.



The error class can be recognized by the diagnostic message number.

Diagnostic message number	Error class
F2xxx	Non-fatal error
F3xxx	Non-fatal safety technology error
F4xxx	Interface error
F6xxx	Travel range error
F7xxx	Safety technology error
F8xxx	Fatal error
F83xx	Fatal error of safety technology
F9xxx	Fatal system error

Tab. 5-1: Overview of Error Classes

Overview of the Scope of Functions



Apart from the mentioned error classes that can occur during operation, errors can occur when the devices are booted and during firmware download. These errors are displayed on the control panel with a short diagnostic text rather than with a diagnostic message number of the "Fxxx" pattern. Boot and firmware download errors are described in the separate "Troubleshooting Guide" documentation (description of diagnostic messages).

Error Reactions of the Drive

If the drive controller is in control and an error state is detected, the execution of a drive error reaction is automatically started. The diagnostic message number "Fxxx" flashes on the display of the control panel.

The drive reaction in the case of F2xxx, F3xxx, F4xxx, F6xxx, F7xxx and F8xxx errors is defined in parameter "P-0-0119, Best possible deceleration". At the end of each error reaction, the drive goes torque-free.

See also "[Error Reactions](#)".

Clearing an Error Message

Error messages are not automatically cleared; instead, there is a procedure for this depending on the severity of the error; see the separate "Troubleshooting Guide" documentation (description of diagnostic messages).

For example, if the error state persists, the error message is immediately generated again.

Clearing Error Messages when Drive Enable Was Set

If a drive error occurs while operating with drive enable having been set, the drive carries out an error reaction. The drive automatically deactivates itself at the end of each error reaction; in other words, the output stage is switched off and the drive switches from an energized to a de-energized state.

To reactivate the drive,

- clear the error message and
- set a positive edge for drive enable again.

Error Memory

The diagnostic message numbers of occurring errors are written to an error memory. This memory contains the diagnostic message numbers of the last 50 errors that occurred and the time when they occurred. Errors caused by a shutdown of the control voltage (e.g. "F8070Control voltage failure") are not stored in the error memory.

The diagnostic message numbers in the error memory are mapped to parameter "P-0-0192, Error memory of diagnostic numbers" and can be displayed by means of the control panel. The "IndraWorks Ds/D/MLD" commissioning tool allows displaying the diagnostic message numbers and the respective times at which the errors occurred.

Reconfigure an Error as a Warning

In some cases, the user can reconfigure an error as a warning. After an error has been reconfigured, it is not an error reaction that takes place when such an error occurs, but only a warning is output. The list of axis errors that can be reconfigured can be found in "P-0-0173, List of configurable axis-specific monitoring functions"; the reconfiguration takes place in this parameter, too.



When an error has been reconfigured, only a warning is output instead of the error message; the warning shows the control master that there is a problem. It then is the user's responsibility to react to the diagnostic warning messages in an appropriate way. If this is not the case, the machine or installation can be damaged.

The reconfiguration of errors as warnings can be used in application-related form in the following cases:


Overview of the Scope of Functions

- Use of an external encoder as a redundant motor encoder, see chapter "[Redundant Motor Encoder](#)"
- Use of a measuring encoder, see "[Measuring Encoder](#)"
- Position control with cyclic command value input, see chapter of the same name, "[Position Control with Cyclic Command Value Input](#)" under "[Operation Modes](#)"

5.1.2 IndraDrive Product Range

The figure below shows the relations between control sections and power sections, firmware derivatives and possible technology modules.

Overview of the Scope of Functions



*)

**)

Fig. 5-1:

As of MPx18V12

Hardware-dependent, see type code

IndraDrive Product Range - Version 18

Overview of the Scope of Functions

5.1.3 Overview of Drive Firmware

Firmware Variants

For the IndraDrive range, there are different application-related firmware types available that are characterized by their scope of functions and their performance:

- **MPx**: Drives for general automation (including machine tool applications) with a MultiEthernet interface (sercos, EtherCAT®, PROFINET®, EtherNet/IP™), field bus interface (e.g. PROFIBUS-DP) and analog interface (design versions include **MPB**, **MPC**, **MPE** and **MPM**; see below)



The **first two letters** of the firmware designation identify the application and profile of the firmware:

- **MP**: "Multi Purpose" → Drives for general automation (including machine tool applications) with a MultiEthernet interface (sercos, EtherCAT®, PROFINET®, EtherNet/IP™), field bus interface (e.g. PROFIBUS-DP, CANopen) and analog interface.

The **third letter** of the firmware designation identifies the hardware, as well as the performance and functionality of the firmware (x contains **B**, **C**, **E** and **M**):

- **B**: **Single-axis** firmware with **BASIC** performance and functionality plus MLD-S functions
- **C**: **Single-axis** firmware with **ADVANCED** performance and functionality plus CCD + MLD-M functions
- **E**: **Single-axis** firmware with **ECONOMY** performance and functionality
- **M**: **Double-axis/multi-axis** firmware with **BASIC** performance and functionality

This documentation describes the functionality of the following firmware types:

- FWA-INDRV*-MPB-18VRS-D5
- FWA-INDRV*-MPC-18VRS-D5
- FWA-INDRV*-MPE-18VRS-D5
- FWA-INDRV*-MPM-18VRS-D5

The "IndraWorks Ds/D/MLD" commissioning tool is available for commissioning these firmware variants.

Organization of the Firmware

For the application-specific definition of the drive functionality, the firmware functions are divided into different "functional packages". There are a **generally available base package** and various **additional functional packages** (e.g. main spindle, IndraMotion MLD) that can be optionally activated.



The scope of functions of the functional packages and their possible combinations are described in the section "[Overview of Functions/Functional Packages](#)".

5.1.4 Overview of Master Communication

The **MPx-18VRS** firmware supports the following interfaces for master communication:

Master Communication	Firmware variant			
	MPB	MPC	MPE	MPM
sercos	■	■	■	■
PROFIBUS-DP	■	■	-	■
EtherNet/IP interface	■	■	-	-
PROFINET	■	■	-	-
Analog interface	■	■	■	■
EtherCAT®	■	■	-	■
CANopen	■	■	-	-

Tab. 5-2: Supported Interfaces for Master Communication

5.1.5 Overview of Functions/Functional Packages

Overview

General Information

The application-specific scope of usable functions of the **FWA-INDRV*-MP*-18VRS** drive firmware depends on

- the existing device configuration
- and -
- the licensed functional firmware packages.



Depending on the hardware design, the scope of firmware functionality can be determined according to the respective application (scalability of the firmware functionality). The scope of corresponding parameters depends on the available functions.

Scaling the Drive Functionality

Firmware Scaling by Control Section Configuration

IndraDrive drive controllers have slots for optional cards. Depending on the available optional cards, it is possible to activate certain functions (incl. corresponding parameters), e.g.:

- **Master Communication**
- **Safety technology**
- **Encoder emulation**
- **Optional encoders**
- **I/O extension**

Controller or control section	Number of Optional Card Slots
CSE02.1, KMS02.1, KSM02.1	1
HCS01, HCQ02.1, HCT02.1, CSB02.1A	2

Overview of the Scope of Functions

Controller or control section	Number of Optional Card Slots
CSB02.1B, CSH02.1	3
CDB02.1	4

Tab. 5-3: Number of Optional Card Slots



The functions and parameters for the evaluation of the measuring systems as control encoders do not depend on the device configuration, since their functions can be freely assigned to the various optional encoder modules.

See also the section "[Drive Controllers](#)"

Firmware Scaling by Functional Packages

The firmware functionality is divided into the following package groups:

- **Base packages** (open-loop or closed-loop)
- **Optional expansion packages:**
 - Alternative functional packages (expansion packages for servo function, main spindle function, synchronization)
 - Additive functional package "IndraMotion MLD" (drive-integrated PLC and technology functions)

Depending on the hardware configuration, the base packages are available without any access enable. Using the optional expansion packages, however, requires licensing.



The desired scope of firmware functions should preferably be defined when the firmware is ordered. This guarantees that the required functional packages have been enabled when the firmware is delivered. In individual cases, it is possible to provide access enable subsequently (additional licensing) or to reduce the activated scope of functions.


This procedure is described in the section "[Enabling of Functional Packages](#)".



The **drive-integrated safety technology** is a functionality only scalable by means of the hardware and does not require any additional enabling of functions!

The figure below contains an overview of the possibilities of firmware scaling by functional packages:

Overview of the Scope of Functions



- * IndraMotion MLD, only MLD-S functionality, single-axis motion, not with MPM firmware
- ** IndraMotion MLD-M functionality, multi-axis motion

Fig. 5-2: Functional Packages of IndraDrive Firmware MPx18 Depending on Control Performance

Brief Description of the Functional Packages

The overall functionality of an IndraDrive device is divided into groups of functions, the so-called "functional packages". The **FWA-INDRV*-MP*-18VRS** firmware supports the functional packages listed below.



Each of the listed packages is available in **Basic**, **Economy** or **Advanced** design which differ with regard to their performance and functionality.

Base Packages

The following base packages are available:

- **Base package "open-loop"** (open-loop motor control)
→ No position evaluation and functions depending thereof and no position control modes are possible
- **Base package "closed-loop"** (closed-loop motor control)
→ Position evaluation and functions and operation modes depending thereof are possible

Alternative functional packages

The following alternative functional packages are available:

- **Servo functions** ¹⁾
This package makes available all specific expansions for servo applications, such as compensations and correction functions (e.g. axis error correction, quadrant error correction).
- **Synchronization** ¹⁾
With this package, the possibilities of synchronization of the drive can be used (support of synchronization modes, measuring encoder function, probe function, ...).
- **Main spindle functions** ¹⁾

Overview of the Scope of Functions

This package contains the specific functions for the use of main spindles (e.g. spindle positioning, parameter set switching).



¹⁾...These functional packages cannot be activated simultaneously (only individually)!

Additive Functional Packages

There is also an additional functional package available:

- **IndraMotion MLD**



For single-axis devices (ADVANCED and BASIC) the expansion package "IndraMotion MLD" can be activated in addition to a possibly available alternative package.

Firmware Types

Structure of the Firmware Type Designation

The type designation of the IndraDrive firmware consists of the following type code elements:

	IndraDrive firmware	Base package of variant (depending on control section)	Version	Release	Language	OL/CL	Alternative expansion packages	Additive expansion packages
Basic single-axis	FWA-INDRV*	-MPB-	18	VRS-	D5-	x-	xxx-	xx
Advanced single-axis	FWA-INDRV*	-MPC-	18	VRS-	D5-	x-	xxx-	xx
Economy single-axis	FWA-INDRV*	-MPE-	18	VRS-	D5-	x-	xxx-	xx
Basic multi-axis	FWA-INDRV*	-MPM-	18	VRS-	D5-	x-	xxx-	xx

OL

Open-loop characteristic

CL

Closed-loop characteristic

Tab. 5-4: Basic Structure of the Firmware Type Designation

Function-Specific Abbreviations in Type Designation of IndraDrive Firmware

Base package (application and performance):

- **MPB** → Single-axis firmware with Basic performance
- **MPC** → Single-axis firmware with Advanced performance
- **MPE** → Single-axis firmware with Economy performance
- **MPM** → Multi-axis firmware with Basic performance

Firmware characteristic:

- **0** → Open-loop
- **1** → Closed-loop

Alternative expansion packages:

- **NNN** → Without alternative expansion package
- **SRV** → Functional package "Servo function"
- **SNC** → Functional package "Synchronization"
- **MSP** → Functional package "Main spindle"
- **ALL** → All alternative expansion packages

Additive expansion packages:

Overview of the Scope of Functions

- **NN** → Without additive expansion package
- **ML** → IndraMotion MLD for free programming; incl. use of technology functions (for MPB, MPC firmware)
- **MA** → IndraMotion MLD Advanced (only for MPB, MPC firmware)



The sales representative in charge will help you with the current status of available firmware types.

Base Packages

General Information

In the base packages of the firmware, the minimum scope of functionalities is available depending on the respective firmware characteristic ("open-loop" or "closed-loop"). They contain the basic functions of a drive firmware and a number of other fundamental functions.

Basic Functions

The following basic functions are available for every drive and contain the fundamental basic functions of a digital drive (available in the firmware characteristics "open-loop" and "closed-loop"):

- Extensive diagnostic functions:
 - Drive-internal generation of diagnostic messages
 - Monitoring function
 - Patch Function
 - Status displays, status classes
 - Oscilloscope Function
 - Code of optional card
 - Parameter value check
 - Operating hours counter, logbook function, error memory
- Undervoltage monitor
- Output of control signals
- Limitations that can be parameterized

Scope of Functions

Motor Control Modes

	MPB	MPC	MPE*	MPM
V/Hz (U/f)	CL/OL	CL/OL	CL/OL	CL/OL
FXC	CL/OL	CL/OL	-	CL/OL

Overview of the Scope of Functions

	MPB	MPC	MPE*	MPM
FOC	CL	CL	CL	CL
FOCsl	CL	CL	CL	CL

V/Hz (U/f)	Frequency-controlled operation of sensorless asynchronous three-phase a.c. motors
FXC	Flux-controlled, sensorless operation of three-phase a.c. motors
FOC	Current-controlled operation of three-phase a.c. motors (with motor encoder)
FOCsl	Current-controlled operation of sensorless three-phase a.c. motors
OL	Open-loop characteristic
CL	Closed-loop characteristic
*	MPE has an expanded closed-loop base package (CL). It includes the parameter set switching.

Tab. 5-5: Motor Control Mode Depending on Firmware Variant

Supported Operation Modes



The operation modes supported by the firmware depend on the hardware and firmware and are contained in parameter "S-0-0292, List of supported operation modes".

The following overview illustrates with which base or functional package the respective operation mode is supported and it applies to all firmware variants.

Operation mode	In base package (characteristic)	In functional package ... (on the basis of a base package with the following characteristic)		
		Servo function	Synchronization	Main spindle
Standard operation modes:				
- Torque/force control	CL	+	+	+
- Velocity control	OL/CL	+	+	+
- Position control	CL	+	+	+
- Drive-internal interpolation	CL	+	+	+
- Drive-controlled positioning	CL	+	+	+
- Positioning block mode	CL	+	+	+
Synchronization modes:				
- Velocity synchronization	–	–	OL/CL	–
- Phase synchronization	–	–	CL	–

Overview of the Scope of Functions

Operation mode	In base package (characteristic)	In functional package ... (on the basis of a base package with the following characteristic)		
		Servo function	Synchronization	Main spindle
- Electronic cam	–	–	CL	–
- Electronic motion profile	–	–	CL	–

+ Operation mode already contained in base package (for characteristic see base package)

- Operation mode not possible

OL Open-loop characteristic

CL Closed-loop characteristic

Tab. 5-6: Supported Operation Modes

To use a functional package, it must have been activated (enabled). The currently enabled functional packages are displayed in parameter "P-0-2004, Active functional packages".

See also "[Enabling of Functional Packages](#)"

Availability of the Extended Axis Functions

The following overview illustrates in which base or functional packages the respective extended axis function is available (if not stated otherwise, this applies to all firmware versions MPB, MPC, MPE and MPM).

Extended axis function	In base package (characteristic)	In functional package ... (on the basis of a base package with the following characteristic)		
		Servo function	Synchronization	Main spindle
Drive Halt	OL/CL	+	+	+
v _{cmd} reset (emergency stop)	OL/CL	+	+	+
v _{cmd} reset with ramp and filter (quick stop)	OL/CL	+	+	+
v _{cmd} reset with ramp and filter (emergency stop)	OL/CL	+	+	+
Torque disable	OL/CL	+	+	+
Return motion	-	CL	–	–
Package reaction on error	OL/CL	+	+	+
NC reaction on error	OL/CL	+	+	+
MLD reaction on error	OL/CL ^{1) 2)}	+ ^{1) 2)}	+ ^{1) 2)}	+ ^{1) 2)}
E-Stop function	OL/CL	+	+	+
Friction torque compensation	CL	+	+	+
Encoder error correction	CL	+	+	+
Backlash on reversal correction	CL ¹⁾	+ ¹⁾	+ ¹⁾	+ ¹⁾
Precision axis error correction	–	CL ¹⁾	–	–
Control-side axis error correction	–	CL ¹⁾	–	–

Overview of the Scope of Functions

Extended axis function	In base package (characteristic)	In functional package ... (on the basis of a base package with the following characteristic)		
		Servo function	Synchronization	Main spindle
Temperature error correction	–	CL ¹⁾	–	–
Quadrant error correction	–	CL ¹⁾	–	–
Cogging torque compensation	–	CL ¹⁾	CL ¹⁾	–
Measuring wheel mode	–	–	CL ¹⁾	–
Positive stop drive procedure	OL/CL	+	+	+
Redundant motor encoder	CL ¹⁾	+ ¹⁾	+ ¹⁾	+ ¹⁾
Spindle positioning	–	–	–	CL ¹⁾
Parameter set switching	CL ³⁾	–	–	OL/CL
Drive-controlled oscillation	–	–	–	OL/CL ¹⁾
Parking axis	OL/CL	+	+	+
Programmable position switch	–	CL ¹⁾²⁾	CL ¹⁾²⁾	–
Set/shift coordinate system	–	CL ¹⁾	CL ¹⁾	CL ¹⁾
Integrated safety technology (STO/SBC)	Only available with the corresponding hardware configuration			

- + Extended axis function already contained in base package (for characteristic see base package)
 – Extended axis function not possible
 OL Open-loop characteristic
 CL Closed-loop characteristic
 1) Not for the MPE firmware variant
 2) Not for the MPM firmware variant
 3) Only the MPE firmware variant has an expanded closed-loop base package (CL). It includes the parameter set switching.

Tab. 5-7: Availability of the Extended Axis Functions

To use a functional package, it must have been activated (enabled). The currently enabled functional packages are displayed in parameter "P-0-2004, Active functional packages".

See also "[Enabling of Functional Packages](#)"

Availability of the Optional Device Functions

The following overview illustrates in which base or functional packages the respective optional device function is available (if not stated otherwise, this applies to all firmware versions MPB, MPE, MPC and MPM).

Optional device function	In base package (characteristic)	In functional package ...		
		Servo function	Synchronization	Main spindle
Cross communication (CCD)	Only possible with HCS01 in conjunction with MPC-17VRS or MPC-18VRS, or with CSH02.1 in conjunction with MPC-18VRS			
IndraMotion MLD	Independent expansion packages (ML, MA) ^{2) 3)}			
Digital inputs/outputs ¹⁾	OL/CL	+	+	+
Analog inputs ¹⁾	OL/CL	+	+	+

Overview of the Scope of Functions

Optional device function	In base package (characteristic)	In functional package ...		
		Servo function	Synchronization	Main spindle
Virtual master axis generator	OL/CL	-	+	-
Command value generator	OL/CL	+	+	+
Command value box	CL	+	+	+
Encoder emulation	OL/CL	+	+	+
Programmable position switch	-	CL ²⁾	CL ²⁾	-
Probe	CL	+	+	+
Measuring encoder ¹⁾	-	OL/CL ²⁾	OL/CL ²⁾	-

+ Optional device function already contained in base package

(for characteristic see base package)

- Optional device function not possible

OL Can be used in open-loop operation

CL Can be used in closed-loop operation

1) Depending on hardware configuration

2) Not for the firmware version MPE

3) Not for the firmware version MPM

Tab. 5-8: Availability of the Optional Device Functions

To use a functional package, it must have been activated (enabled). The currently enabled functional packages are displayed in parameter "P-0-2004, Active functional packages".

See also "[Enabling of Functional Packages](#)"

Alternative Functional Packages

General Information

In addition to the base packages that are always available, the alternative functional packages are provided as optional expansion packages. When these functional packages are used, only one package can be activated (alternative activation).

The following expansion packages are available:

- Expanded Servo Function
- Synchronization
- Main spindle function

Servo function

Depending on the firmware variant and characteristic, the "servo function" expansion package has the following scope of functions:

	MPB	MPC	MPE	MPM
Relative return motion	CL	CL	-	-
Precision axis error correction	CL	CL	-	-
Temperature error correction	CL	CL	-	CL
Quadrant error correction	CL	CL	-	CL
Cogging torque compensation	CL	CL	-	CL
Programmable position switch	CL	CL	-	-

Overview of the Scope of Functions

	MPB	MPC	MPE	MPM
Set/shift coordinate system	CL	CL	–	–
Parameter set switching (without motor / gearbox switching)	CL/OL	CL/OL	Contained in base package	–

OL Open-loop characteristic (not with "servo function" expansion package)

CL Closed-loop characteristic

Tab. 5-9: Overview of the "Servo Function" Expansion Package

Synchronization

Depending on the firmware variant and characteristic, the "synchronization" expansion package has the following scope of functions:

	MPB	MPC	MPE	MPM
Velocity synchronization	OL, CL	OL, CL	–	OL, CL
Phase synchronization	CL	CL	–	CL
Electronic cam	CL	CL	–	CL
Electronic motion profile	CL	CL	–	CL
Cogging torque compensation	CL	CL	–	CL
Measuring wheel mode	CL	CL	–	CL
Programmable position switch	CL	CL	–	–
Measuring encoder	OL, CL	OL, CL	–	CL

OL Open-loop characteristic

CL Closed-loop characteristic

Tab. 5-10: Overview of the "Synchronization" Expansion Package

Main spindle function

Depending on the firmware variant and characteristic, the "main spindle" expansion package has the following scope of functions:

	MPB	MPC	MPE	MPM
Spindle positioning	CL	CL	–	CL
Parameter set switching	OL, CL	OL, CL	CL ¹⁾	OL, CL
Drive-controlled oscillation	OL, CL	OL, CL	–	OL, CL

OL Open-loop characteristic

CL Closed-loop characteristic

¹⁾ Contained in the expanded base package for MPE

Tab. 5-11: Overview of the "Main Spindle" Expansion Package

Additive Functional Packages

General Information

So-called additive functional packages are part of the optional expansion packages. Additive functional packages can be used in addition to the basic function and one of the alternative functional packages (additive activation).

At present, **IndraMotion MLD** (drive-integrated PLC and technology functions) is available as an additive functional package (in different designs).

Overview of the Scope of Functions

IndraMotion MLD (Drive-Integrated PLC)



As of the MPB-18V08 firmware, using the performance level "Advanced performance" (P-0-0556, bit 2) is impossible when "IndraMotion MLD" is active (expansion packages "ML" or "MA").

Optional Expansion Package "IndraMotion MLD"

The following designs of the optional expansion package "IndraMotion MLD" are available:

- The **"ML"** design allows:
 - Loading and using self-contained PLC programs (technology functions) by Rexroth (see "Technology Functions")
 - Freely programming Rexroth IndraMotion MLD-S / MLD-M using the function block libraries made available by Rexroth and supported by "IndraMotion MLD" (see "Library Description IndraMotion MLD (2G)")
- The **"MA"** design allows using a freely programmable "Advanced" PLC for complex tasks.



The technology functions can be loaded via IndraWorks (see also MLD Application Manual: "Using Technology Functions").

Examples of technology functions: Following-on cutting devices, pick&place, process controller (register controller, winding computation, ...), preventive maintenance, ...



See documentation "Rexroth IndraDrive, Rexroth IndraMotion MLD (2G) as of MPx-18, Application Manual" (DOK-INDRV*-MLD3-**-VRS*-AP; mat. no.: R911338914) and "Rexroth IndraMotion MLD (2G) Libraries as of MPx18, Reference Book" (DOK-INDRV*-MLD-SYSLIB3-RE; mat. no.: R911338916).

Integrated Safety Technology



The **drive-integrated safety technology** is a functionality only scalable by means of the hardware and does not require any additional enabling of functions! The requirement for using this function is the availability of the optional safety technology modules "L3"/"L4" or "S3"/"S4".

In conjunction with the optional safety technology modules **L3** and **L4**, the safety function "Safe torque off" (STO) is supported.

When the safety function "Safe torque off" (STO) is selected, the safe brake control (SBC) is automatically activated with **L4**.



See documentation "Rexroth IndraDrive Integrated Safety Technology as of MPx-1x (Safe Torque Off), Application Manual" (DOK-INDRV*-SI3-**-VRS*-AP; mat. no.: R911332634).

The following safety functions can be implemented by using the optional safety technology modules "Safe Motion" (S3/S4):

IndraDrive Mi

The IndraDrive Mi drive systems with the motor-integrated servo drive KSM02 and the near motor servo drive KMS02 can be equipped with the optional safety technology module "S3". In this configuration, the systems provide universally programmable safe motion and standstill monitoring. The following safety technology functions are supported:

Overview of the Scope of Functions

SDI	Safe direction	SIL2
SLI	Safely-limited increment	SIL2
SLS	Safely-limited speed	SIL2
SLS-LT	Safely-monitored transient oscillation	SIL2
SMD	Safely-monitored deceleration	SIL2
SMS	Safe maximum speed	SIL2
SOS	Safe operating stop	SIL2
SS1	Safe stop 1 (time-monitored)	SIL3
SS1	Safe stop 1 (monitored deceleration)	SIL2
SS2	Safe stop 2	SIL2
STO	Safe torque off	SIL3

Tab. 5-12: Safety Functions of the Optional Safety Technology Module "S3"

IndraDrive Cs and IndraDrive M /
IndraDrive C

The control sections of the IndraDrive Cs drive system, as well as the Cxx02 control sections of the IndraDrive M / IndraDrive C drive systems, can be equipped with the optional safety technology module "S4". In this configuration, the systems provide universally programmable safe motion and stand-still monitoring. The following safety technology functions are supported:

SBC	Safe brake control ¹⁾	SIL3
SDI	Safe direction	SIL2
SDL	Safe door locking ²⁾	SIL3
SLI	Safely-limited increment	SIL2
SLS	Safely-limited speed	SIL2
SLS-LT	Safely-monitored transient oscillation	SIL2
SMD	Safely-monitored deceleration	SIL2
SMS	Safe maximum speed	SIL2
SOS	Safe operating stop	SIL2
SS1	Safe stop 1 (time-monitored)	SIL3
SS1	Safe stop 1 (monitored deceleration)	SIL2
SS2	Safe stop 2	SIL2
STO	Safe torque off	SIL3
SZA	Safety zone acknowledge ²⁾	SIL3
SZE	Safe zone error ²⁾	SIL3

1) Function presently only available with Indradrive Cs (in preparation for Cxx02)

2) Only in conjunction with safety zone module (HSZ01)

Tab. 5-13: Safety Functions of the Optional Safety Technology Module "S4"



See documentation "Rexroth IndraDrive Integrated Safety Technology as of MPx-1x (Safe Motion), Application Manual" (DOK-INDRV*-SI3*SMO-VRS**-AP; mat. no.: R911338920).

5.1.6 Performance Data

Overview

Levels of Control Performance

For the control performance of the IndraDrive range, we basically distinguish three levels with regard to the clock rates (cycle times):

- **Advanced** performance
→ High control performance by shorter clock rates for the control loops and the signal processing of inputs and outputs or drive-integrated PLC (IndraMotion MLD).
- **Basic** performance
→ Standard control performance by medium internal clock rates for the control loops and the signal processing of inputs/outputs or drive-integrated PLC (IndraMotion MLD)
- **Economy** performance
→ Low control performance due to reduced clock rates (cycle times) for the control loops and signal processing of inputs/outputs.



Basic control section and "Advanced performance" setting are not possible when functional package "MLD" is active.

Performance and Clock Rates

In this documentation the clock rate data refer to the following characteristic values:

- Current controller clock $T_{A_current}$
- Velocity controller clock $T_{A_velocity}$
- Position controller clock $T_{A_position}$
- Cycle time of PLC (IndraMotion MLD) T_{MLD}
- Cycle time of master communication $T_{MastCom}$

The table below contains an overview of the clock rates depending on the respective control performance. The detailed assignment of clock rate to control section design, performance level and parameter setting is contained in the table "Performance Depending on the Control Section Design" in the section "[Control Section Design and Performance](#)" (see below).



The control performance is not synonymous with the control section design, because it is determined by several factors.

The available performance depends on the following requirements and parameter settings:

- **Device configuration** and the associated drive **firmware** (MPB, MPC, MPM and MPE)
- **Activation of functional packages** (cf. P-0-2004)
- Performance level in "P-0-0556, Config word of axis controller"
- Switching frequency in "P-0-0001, Switching frequency of the power output stage"

See also "[Overview of Drive Control](#)"

Overview of the Scope of Functions

Control Section Design and Performance

The control section design differs with regard to the performance levels that can be reached (cycle times or switching frequencies).

The table below contains an overview of the performance levels and clock rates that can be reached depending on the control section design.

Drive system or Control section/Firmware	Functional packages	Perform. level	$f_{\text{PWM}}^{1)}$	PWM switching ²⁾	$T_{\text{A_current}}$	$T_{\text{A_velocity}}$	$T_{\text{A_position}}$	T_{MLD}	T_{MastCom}
HCS01.1 / MPB CSB02.1 / MPB KSM02.1 / MPB KMS02.1 / MPB CDB02.1 / MPM	All ⁷⁾	Basic	2 kHz	No	250 μs	250 μs	500 μs	1000 μs (not avail- able with MPM)	As for ($T_{\text{A_position}}^{3)}$ 1000 μs ⁴⁾ 2000 μs ⁵⁾ 500 μs ⁶⁾
			4 kHz	Yes	125 μs				
			8 kHz	Yes	125 μs				
			12 kHz	Yes	83.3 μs				
			16 kHz	Yes	62.5 μs				
	All ⁷⁾ , ex- cept MLD	Advanced	4 kHz	No	125 μs	125 μs	250 μs	Not availa- ble	
			8 kHz	Yes	62.5 μs				
			16 kHz	Yes	62.5 μs				
HCS01.1 / MPC CSH02.1 / MPC	All ⁷⁾	Basic	2 kHz	No	250 μs	250 μs	500 μs	1000 μs	
			4 kHz	Yes	125 μs				
			8 kHz	Yes	125 μs				
			12 kHz	Yes	83.3 μs				
			16 kHz	Yes	62.5 μs				
		Advanced	4 kHz	No	125 μs	125 μs	250 μs		
			8 kHz	Yes	62.5 μs				
			16 kHz	Yes	62.5 μs				
HCS01.1 / MPE CSE02.1 / MPE	All ⁷⁾	Economy	4 kHz	No	125 μs	500 μs	1000 μs	Not availa- ble	2000 μs
			8 kHz	No	125 μs				

Overview of the Scope of Functions

Drive system or Control section/Firmware	Functional packages	Perform. level	$f_{\text{PWM}}^{1)}$	PWM switching ²⁾	$T_{\text{A_current}}$	$T_{\text{A_velocity}}$	$T_{\text{A_position}}$	T_{MLD}	T_{MastCom}
HCQ02.1 / MPM HCT02.1 / MPM	All ⁷⁾	Basic	4 kHz	No	125 μs	250 μs	500 μs	Not available	500 μs
			8 kHz	No	125 μs				

- 1) Switching frequency of the power output stage, device-dependent (can be set via P-0-0001)
- 2) Reduction of the PWM frequency depending on velocity or load (can be set via P-0-0045)
- 3) With sercos
- 4) With PROFIBUS®
- 5) With PROFINET® and EtherNet/IP™
- 6) With EtherCAT®
- 7) The selection of functional packages depends on the drive system and on the control section/firmware

Tab. 5-14: Performance Depending on the Control Section Design

Performance at Reduced Switching Frequency

At switching frequencies of 4 kHz, 8 kHz, 12 kHz or 16 kHz and the corresponding setting in parameter "P-0-0045, Control word of current controller" (type of PWM clocking), the switching frequency is automatically reduced by half in order to increase the ability of the controller to withstand thermal loads:

- Depending on the thermal load of the controller
- Depending on the velocity

When the reduction of the PWM frequency is used, the switching frequency of the power output stage is changed, but not the cycle times! The performance is not reduced!

See "Current Limitation: Principles of Current Limitation"

For the automatic PWM adjustment, see chapter "Dynamic Current Limitation", section "Continuous Current of Controller Depending on Work Load at PWM of 12 kHz or 16 kHz"

5.1.7 Drive controllers

Standard Design of the IndraDrive Controllers

Design of the IndraDrive Controllers

Overview of the Scope of Functions




Fig. 5-3: Standard Design of the IndraDrive Controllers

Power Section

The following are connected to the power section:

- Power supply or DC bus voltage
- 24 V control voltage
- Motor



The design versions of the power sections are described, respectively, in separate documentations (see "[Reference Documentations](#)").

Control section

The control section additionally makes available connections for:

- Encoder
- Master Communication
- Optional Ethernet engineering
- Safety technology
- Optional memories for user data
- Digital / analog inputs / outputs

The control section is a separate part of the IndraDrive controller and is plugged in the power section. The drive controller is supplied ex works complete with control section. The control section may only be replaced by a qualified service engineer.



The available control sections are described in the separate documentation "Control Sections for Drive Controllers, Project Planning Manual" (DOK-INDRV*-CSH*****-PR**-EN-P; mat. no.: R911295012).

Special Design of the IndraDrive Controllers




Fig. 5-4: Special Design of the IndraDrive Controllers

Compact Converters, Special Design

- IndraDrive Cs (HCS01), compact single-axis converter
In contrast to the usual device design with power sections and control sections that can be explicitly ordered, the control section and power section of the HCS01 controller (IndraDrive Cs) are inseparably integrated in one device.
For information on the functional and performance features of HCS01 controllers, see "Rexroth IndraDrive Cs, Drive Systems with HCS01", Project Planning Manual, mat. no. R911322210, DOK-INDRV*-HCS01*****-PR02-EN-P.
- IndraDrive C (HCQ, HCT), compact multi-axis converter
Also in contrast to the usual device design, each of the compact HCT and HCQ controllers can operate 3 - 4 axes. The control section and power section are inseparably integrated in one device.
For information on the functional and performance features, see "Rexroth IndraDrive, Drive Controllers HCQ02, HCT02", Project Planning Manual, mat. no. R911324185, DOK-INDRV*-HCQ-T+HMQ-TPRxx-EN-P.

Inverters for Cabinet-Free Drive Technology

- IndraDrive Mi (KSM01.2-B, motor-integrated servo drive)
⇒ Synchronous servo motors with integrated inverter
In KSM (distributed servo drive), the control section and the power section are integrated in the motor (synchronous servo motor), it is not possible to configure the control section. KSM can be operated with the IndraDrive firmware of version **FWA-INDRV*-MPB-17VRS and above**.
See also separate documentations:
 - "Rexroth IndraDrive Mi, Drive Systems with KCU01, KSM01, KMS01" (DOK-INDRV*-KCU+KSM****-PR04-EN-P; mat. no.: R911320924)
 - "Rexroth IndraDrive Mi, Distributed Servo Drive KSM01" (DOK-INDRV*-KSM01*****-IT01-EN-P; mat. no.: R911339088).

Overview of the Scope of Functions

- IndraDrive Mi (KMS01.2-B, near motor servo drive)

⇒ Compact inverter with control section

In KMS (distributed drive controller), the control section and the power section are integrated and separated from the motor, and due to the high degree of protection can be mounted as near as possible to the motor. It is not possible to configure the control section. This variant of IndraDrive Mi does not have a HIPERFACE® encoder interface. The converter can be operated with the IndraDrive firmware of version **FWA-INDRV*-MPB-17VRS and above**.

See also separate documentations:

- "Rexroth IndraDrive Mi, Distributed Drive Controller KMS01" (DOK-INDRV*-KMS01*****-IT01-EN-P; mat. no.: R911339094).
- "Rexroth IndraDrive Mi, Drive Systems with KCU01, KSM01, KMS01" (DOK-INDRV*-KCU+KSM****-PR04-EN-P; mat. no.: R911320924)

Power Sections, Drive Systems

All HMS01, HMD01, HCS02, HCS03 and HCS04.2 power sections from the table below with the production date **FD: 07W01** and above are supported (07W01 means production year 2007, week 01).

Power Sections

Power Sections
HMS01.1N-W0020-A-07-NNNN
HMS01.1N-W0036-A-07-NNNN
HMS01.1N-W0054-A-07-NNNN
HMS01.1N-W0070-A-07-NNNN
HMS01.1N-W0110-A-07-NNNN
HMS01.1N-W0150-A-07-NNNN
HMS01.1N-W0210-A-07-NNNN
HMS01.1N-W0350-A-07-NNNN
HMD01.1N-W0012-A-07-NNNN
HMD01.1N-W0020-A-07-NNNN
HMD01.1N-W0036-A-07-NNNN
HMS02.1N-W0028-A-07-NNNN
HMS02.1N-W0054-A-07-NNNN
HCS02.1E-W0012-A-03-xNNx
HCS02.1E-W0028-A-03-xNNx
HCS02.1E-W0054-A-03-xNNx ¹⁾
HCS02.1E-W0070-A-03-xNNx ¹⁾

Overview of the Scope of Functions

Power Sections
HCS03.1E-W0070-A-05-xNxx
HCS03.1E-W0100-A-05-xNxx
HCS03.1E-W0150-A-05-xNxx
HCS03.1E-W0210-A-05-xNxx
HCS04.2E-W0290-N-0x-xNxN ²⁾
HCS04.2E-W0350-N-0x-xNxN ²⁾
HCS04.2E-W0520-N-0x-xNxN ²⁾
HCS04.2E-W0640-N-0x-xNxN ²⁾
HCS04.2E-W0790-N-0x-xNxN ²⁾
HCS04.2E-W1010-N-0x-xNxN ²⁾
HCS04.2E-W1240-N-0x-xNxN ²⁾
HCS04.2E-W1540-N-0x-xNxN ²⁾

1) As of week 30/2007

2) As of MPx18V12

Tab. 5-15: Power Sections



For devices of an older production date, the message "F8118Invalid power section/firmware combination" is output.

Drive Systems

For HCS01, HCQ, HCT, KMS and KSM, there are no restrictions as regards the production period.

Drive Systems
HCS01.1E-W00xx-A-0x-x-xx-EC-xx-xx-NN-FW
KMS02.1B-A0xx-P-D7-ET-xxx-xx-xx-FW
KSM02.1B-0xxC-xxN-xx-Hxx-ET-xx-D7-xx-FW
HCQ02.1E-W-00xx-A-03-B-L8-1S-xx-xx-NN-xx
HCT02.1E-W00xx-A-03-B-xx-xx-xx-xx-NN-xx

Tab. 5-16: Drive Systems

Control Sections and Optional Modules

Control sections supported by the MPx18VRS firmware, as well as the possible combinations of optional modules.



Our sales representative will help you with the current status of available control section card types.

Control section types →	CSE02.1	CSB02.1	CDB02.1	CSH02.1
	ECONOMY "Single-axis"	BASIC "Single-axis"	BASIC "Multi-axis"	ADVANCED "Single-axis"
Firmware variant →	MPE-18VRS	MPB-18VRS	MPM-18VRS	MPC-18VRS
Optional modules for master communication				

Overview of the Scope of Functions

Control section types →		CSE02.1	CSB02.1	CDB02.1	CSH02.1
ET	MultiEthernet	-	■	-	■
PB	PROFIBUS-DP	-	■	■	■
CN	CANopen	-	■	-	■
Optional modules for encoder evaluation					
EC	Encoder interface for EnDat2.1, 1Vpp sine and TTL signals, HIPER-FACE®	-	■	■	■
EM	Encoder emulation	-	■	■	■
Optional modules for safety technology					
L3	Safe Torque Off	■	■	■	■
L4	Safe Torque Off / Safe Brake Control	-	-	-	-
S3	Safe Motion SIL 2 (without SBC)	-	-	-	-
S4	Safe Motion SIL 2	-	■	■	■
Optional modules for I/O extension					
DA*)	I/O extension digital/analog	-	■	■	■
Optional module MultiEthernet					
ET	MultiEthernet option	-	-	-	■

*) As of MPx18V10
 Tab. 5-17: Supported Control Section Configurations

Device		HCS01.1		
		ECONOMY "Single-axis"	BASIC "Single-axis"	ADVANCED "Single-axis"
Firmware variant →		MPE-18VRS	MPB-18VRS	MPC-18VRS
Optional modules for master communication				
ET	MultiEthernet	-	■	■
PB	PROFIBUS-DP	-	■	■
CN	CANopen	-	■	■
Optional modules for encoder evaluation				
EC	Encoder interface for EnDat2.1, 1Vpp sine and TTL signals, HIPER-FACE®	-	■	■
EM	Encoder emulation	-	■	■
Optional modules for safety technology				
L3	Safe Torque Off	■	■	■
L4	Safe Torque Off / Safe Brake Control	■	■	■
S3	Safe Motion SIL 2 (without SBC)	-	-	-

Overview of the Scope of Functions

Device		HCS01.1		
S4	Safe Motion SIL 2	-	■	■
Optional modules for I/O extension				
DA ^{*)}	I/O extension digital/analog	-	■	■
Optional module MultiEthernet				
ET	MultiEthernet option	-	-	■

^{*)} As of MPx18V10
Tab. 5-18: Supported Control Section Configurations

Device		KSM02.1	KMS02.1
		BASIC "Single-axis"	BASIC "Single-axis"
Firmware variant →		MPB-18VRS	MPB-18VRS
Optional modules for master communication			
ET	MultiEthernet	■	■
PB	PROFIBUS-DP	-	-
CN	CANopen	-	-
Optional modules for encoder evaluation			
ENH	HIPERFACE®	-	■
Optional modules for safety technology			
L3	Safe Torque Off	■	■
L4	Safe Torque Off / Safe Brake Control	-	-
S3	Safe Motion SIL 2 (without SBC)	■	■
S4	Safe Motion SIL 2	-	-
Optional module MultiEthernet			
TO	MultiEthernet output coupling	■	■

Tab. 5-19: Supported Control Section Configurations

Device		HCT02.1	HCQ02.1
		BASIC "Single-axis"	BASIC "Single-axis"
Firmware variant →		MPB-18VRS	MPB-18VRS
Optional modules for master communication			
ET	MultiEthernet	■	-
PB	PROFIBUS-DP	■	-
CN	CANopen	-	-
L8	Embedded PC, LX 800	■	■
Optional modules for encoder evaluation			
Number of encoder evaluations in basic device		4	5

Overview of the Scope of Functions

Device		HCT02.1	HCQ02.1
Optional modules for I/O extension			
D1	Digital I/O extension (DEA40.1)	■	■

Tab. 5-20: Supported Control Section Configurations

5.1.8 Supported Motors and Measuring Systems

Supported Motors

The following table provides an overview of the Rexroth motors that are supported by this firmware:

Rexroth housing motors		Rexroth kit motors	
Synchronous	Asynchronous	Synchronous	Asynchronous
MSK (IndraDyn S) MSM	MAD (IndraDyn A) MAF (IndraDyn A) MAL	MLF (IndraDyn L) MBS (IndraDyn H) MCL MBT (IndraDyn T)	1MB

Tab. 5-21: Appropriate Rexroth Motors for IndraDrive

In addition to the Rexroth motors, it is basically possible to operate three-phase third-party motors (synchronous and asynchronous motors) at IndraDrive controllers. However, it is necessary to check whether the specific motor type can be controlled (see chapter "Third-Party Motors" in "Rexroth IndraDrive, Drive System, R911309636, DOK-INDRV*-SYSTEM*****-PR0x-.....").



The operation of SBC motors of the manufacturer Parker is directly supported by motor-type-specific parameters made available in the encoder data memory!

Supported Measuring Systems

Supported Encoder Systems Encoder systems with a supply voltage of **5 and 12 volt**:

- MSM motor encoder (with HCS01 only)
- MSK motor encoder
- Sin-cos encoder 1 V_{pp}; HIPERFACE®
- Sin-cos encoder 1 V_{pp}; EnDat2.1
- Sin-cos encoder 1 V_{pp}; with reference track
- 5V-TTL square-wave encoder; with reference track
- Sin-cos encoder 1 V_{pp} and SSI encoder (combined encoder for SSI)
- SSI encoder
- Resolver
- Sin-cos encoder 1 V_{pp}; with Hall sensor box SHL02.1
- EnDat 2.2 (as of MPx18V10)

5.1.9 Documentations

Drive Systems, System Components

Drive Systems with Single-Axis or Double-Axis Drive Controllers

Title Rexroth IndraDrive ...	Kind of documentation	Document typecode ¹⁾ DOK-INDRV*-...	Material number R911...
Cs Drive Systems with HCS01	Project Planning Manual	HCS01*****-PRxx-EN-P	322210
Mi Drive Systems with KCU02, KSM02, KMS02	Project Planning Manual	KCU02+KSM02-PRxx-EN-P	335703
Drive Systems with HMV01/02 HMS01/02, HMD01, HCS02/03	Project Planning Manual	SYSTEM*****-PRxx-EN-P	309636
Supply Units, Power Sections HMS, HMD, HCS02, HCS03	Project Planning Manual	HMS-S-D+HCS-PRxx-EN-P	318790
Control Sections CSE02, CSB02, CDB02, CSH02	Project Planning Manual	Cxx02*****-PRxx-EN-P	338962
Additional Components and Accessories	Project Planning Manual	ADDCOMP****-PRxx-EN-P	306140

1) In the document typecodes, "xx" is a wild card for the current edition of the documentation (example: PR01 is the first edition of a Project Planning Manual)

Tab. 5-22: Documentations – Drive Systems, System Components

Drive Systems with Multi-Axis Drive Controllers

Title	Kind of documentation	Document typecode ¹⁾	Material number R911...
Rexroth IndraDrive Drive Controllers HCQ02, HCT02	Project Planning Manual	DOK-INDRV*-HCQ-T+HMQ-T- PRxx-EN-P	324185
Rexroth IndraDrive Additional Components and Accessories	Project Planning Manual	DOK-INDRV*-ADDCOMP****- PRxx-EN-P	306140
Rexroth IndraControl VDP 80.1 Machine Operator Panel Operator Display	Project Planning Manual	DOK-SUPPL*-VDP*80.1***-PRxx- EN-P	329156

1) In the document typecodes, "xx" is a wild card for the current edition of the documentation (example: PR01 is the first edition of a Project Planning Manual)

Tab. 5-23: Documentations – Drive Systems, System Components

Overview of the Scope of Functions

Motors

Title Rexroth IndraDyn ...	Kind of documentation	Document typecode ¹⁾ DOK-MOTOR*-...	Material number R911...
A Asynchronous Motors MAD / MAF	Project Planning Manual	MAD/MAF****-PRxx-EN-P	295781
H Synchronous Kit Spindle Motors	Project Planning Manual	MBS-H*****-PRxx-EN-P	297895
L Synchronous Linear Motors	Project Planning Manual	MLF*****-PRxx-EN-P	293635
L Ironless Linear Motors MCL	Project Planning Manual	MCL*****-PRxx-EN-P	330592
S Synchronous Motors MKE	Project Planning Manual	MKE*GEN2***-PRxx-EN-P	297663
S Synchronous Motors MSK	Project Planning Manual	MSK*****-PRxx-EN-P	296289
S Synchronous Motors MSM	Data Sheet	MSM*****-DAxx-EN-P	329338
S Synchronous Motors QSK	Project Planning Manual	QSK*****-PRxx-EN-P	330321
T Synchronous Torque Motors	Project Planning Manual	MBT*****-PRxx-EN-P	298798

1) In the document typecodes, "xx" is a wild card for the current edition of the documentation (example: PR01 is the first edition of a Project Planning Manual)

Tab. 5-24: Documentations – Motors

Cables

Title	Kind of documentation	Document typecode ¹⁾ DOK-CONNEC-...	Material number R911...
Rexroth Connection Cables IndraDrive and IndraDyn	Selection Data	CABLE*INDRV-CAxx-EN-P	322949

1) In the document typecodes, "xx" is a wild card for the current edition of the documentation (example: CA02 is the second edition of the documentation "Selection Data")

Tab. 5-25: Documentations – Cables

Firmware

Title Rexroth IndraDrive ...	Kind of documentation	Document typecode ¹⁾ DOK-INDRV*-...	Material number R911...
MPx-18 Functions	Application Manual	MP*-18VRS**-APxx-EN-P	338673
MPx-18 Version Notes	Release Notes	MP*-18VRS**-RNxx-EN-P	338658
MPx-17 Functions	Application Manual	MP*-17VRS**-APxx-EN-P	331236
MPx-17 Version Notes	Release Notes	MP*-17VRS**-RNxx-EN-P	331588
MPx-16 Functions	Application Manual	MP*-16VRS**-APxx-EN-P	326767
MPx-16 Version Notes	Release Notes	MP*-16VRS**-RNxx-EN-P	329272

Overview of the Scope of Functions

Title Rexroth IndraDrive ...	Kind of documentation	Document typecode¹⁾ DOK-INDRV*-...-	Material number R911...
MPx-16 to MPx-18 Parameters	Reference Book	GEN1-PARA**-RExx-EN-P	328651
MPx-16 to MPx-18 Diagnostic Messages	Reference Book	GEN1-DIAG**-RExx-EN-P	326738
Integrated Safety Technology as of MPx-1x	Application Manual	SI3-**VRS**-APxx-EN-P	332634
Integrated Safety Technology as of MPx-1x (Safe Motion)	Application Manual	SI3*SMO-VRS-APxx-EN-P	338920
Rexroth IndraMotion MLD Libraries as of MPx-17	Reference Book	MLD-SYSLIB2-RExx-EN-P	332627
Rexroth IndraMotion MLD Libraries as of MPx-18	Reference Book	MLD-SYSLIB3-RExx-EN-P	338916
Rexroth IndraMotion MLD as of MPx-17	Application Manual	MLD2-**VRS*-APxx-EN-P	334351
Rexroth IndraMotion MLD as of MPx-18	Application Manual	MLD3-**VRS*-APRS-EN-P	338914

1) In the document typecodes, "xx" is a wild card for the current edition of the documentation (example: RE02 is the second edition of a Reference Book)

Tab. 5-26: Documentations – Firmware

Control Unit

Title Rexroth IndraMotion MTX micro	Kind of documentation	Document typecode¹⁾ DOK-MTXMIC-...-	Material number R911...
Easy setup for Standard Turning and Milling Machines	Commissioning Manual	EASY*****-COxx-EN-P	332281
12VRS System Description	Manual	SYS*DES*V12-RExx-EN-P	334369
12VRS Functional Description	Manual	NC*FUNC*V12-APxx-EN-P	334357
12VRS Machine Parameters	Reference Book	MA*PAR**V12-RExx-EN-P	334365
12VRS Programming Manual	Manual	NC**PRO*V12-RExx-EN-P	334361

1) In the document typecodes, "xx" is a wild card for the current edition of the documentation (example: RE02 is the second edition of a Reference Book)

Tab. 5-27: Documentations – Control Unit

Overview of the Scope of Functions

5.2 Master Communication

5.2.1 Basic Functions of Master Communication

Brief Description

General Information

The same basic functions of master communication for IndraDrive devices apply to:

- MultiEthernet interface with
 - sercos
 - EtherCAT®
 - PROFINET®
 - EtherNet/IP™
- Field bus interface
- Analog interface

The protocol is selected and deactivated via "P-0-4089.0.1, Master communication: Protocol".

IP engineering can also be carried out via the MultiEthernet interface. This function is maintained after the master communication has been switched off. When the EtherCAT® protocol has been activated, IP engineering cannot be carried out, because it is not supported by EtherCAT®; EoE (Ethernet over EtherCAT) can be used for EtherCAT® instead.

Notes on Parameter Access

The following mechanisms are available for control units that cannot access 4-byte EIDN parameters:

- 4-byte EIDNs with sercos element and sercos instance = 0, which are available in the drive, can be accessed as 2-byte IDNs. Example: Parameter P-0-4006.0.0 via P-0-4006
- The below-mentioned 4-byte EIDNs with sercos element or sercos instance unequal 0 are mapped to the assigned 2-byte IDN parameters

4-byte EIDN parameter	2-byte IDN parameter
P-0-4089.0.1, Master communication: Protocol	P-0-2310, Master communication: Protocol
P-0-4089.0.2, Master communication: Device name	P-0-2311, Master communication: Device name
P-0-4089.0.3, Device Address	P-0-2303, Device Address
P-0-4089.0.4, Active Device Address	P-0-2304, Active Device Address
P-0-4089.0.10, Master communication: MAC address device	P-0-2312, Master communication: MAC address device
P-0-4089.0.11, Master communication: MAC address Port1	P-0-2313, Master communication: MAC address Port1
P-0-4089.0.12, Master communication: MAC address Port2	P-0-2314, Master communication: MAC address Port2
P-0-4089.0.13, Master communication: IP address	P-0-2315, Master communication: IP address
P-0-4089.0.14, Master communication: Network mask	P-0-2316, Master communication: Network mask
P-0-4089.0.15, Master communication: Gateway address	P-0-2317, Master communication: Gateway address

Tab. 5-28: Parameters for Configuring the Master Communication



By means of the above-mentioned mechanisms, all parameters can thus be accessed via 2-byte IDNs. The CCD configuration parameters represent the only exception.

Overview of the Scope of Functions

Features



When the field bus card (PROFIBUS® and CANopen) has been plugged in, it is only possible to change between inactive master communication and PROFIBUS® or CANopen master communication. Switching to sercos®, EtherCAT®, EtherNet/IP™ or PROFINET® is impossible.

Without the field bus card, only sercos is possible as the master communication for IndraDrive Cs with the MPE-18VRS (Economy) firmware.

- Protocol selection via the control panel or "P-0-4089.0.1, Master communication: Protocol"
 - IP engineering is supported depending on the protocol
 - Master communication engineering is supported depending on the protocol
 - **Command processing**
 - Drive commands to be externally activated (via master communication, "Engineering over IP" or control panel)
 - **Device control** (state machine)
 - Individual state machines for master communication and device
 - According to the variant of master communication, the master communication state machine has different functionality and complexity. The communication-specific states are distinguished and mapped to the status words of the corresponding master communication (e.g. for sercos: "S-0-0135, Drive status word"; "S-0-1045, ").
 - The device state machine is independent of the variant of master communication and maps the device-specific states to parameter "S-0-0424, Status parameterization level". We always distinguish between the operating mode (OM) and the parameter mode (PM).
 - **Extended control options**
 - Signal control word (S-0-0145) and signal status word (S-0-0144)
 - Multiplex channel
- See chapter "[Control Options / Additional Functions](#)".



The state machine of the master communications is briefly outlined in this section; it will be described in detail, i.e. including the individual status transitions, in the main chapter of the respective master communication.

Pertinent Parameters

The following parameters are used independent of the variant of master communication:

Parameters for State Machine and Phase Switch

- S-0-0011, Class 1 diagnostics
- S-0-0012, Class 2 diagnostics
- S-0-0013, Class 3 diagnostics
- S-0-0014, Interface status
- S-0-0420, C0400 Activate parameterization level procedure command
- S-0-0422, C0200 Exit parameterization level procedure command

Overview of the Scope of Functions

	• S-0-0423, IDN-list of invalid data for parameterization levels • S-0-0424, Status parameterization level • P-0-4086, Master communication status • P-0-4088, Master communication: Drive configuration
Operation Mode Parameters	• S-0-0032, Primary operation mode • S-0-0033, Secondary operation mode 1 • S-0-0034, Secondary operation mode 2 • S-0-0035, Secondary operation mode 3 • S-0-0284, Secondary operation mode 4 • S-0-0285, Secondary operation mode 5 • S-0-0286, Secondary operation mode 6 • S-0-0287, Secondary operation mode 7
Control and Status Words Specific to sercos	For the "sercos" interface, the following additional parameters are used: • S-0-0134, Master control word • S-0-0135, Drive status word • S-0-1044, sercos: Device Control (C-Dev) • S-0-1045,
Field-Bus-Specific Parameters	The following additional parameters are used for field buses: • P-0-4068, Field bus: Control word IO • P-0-4077, Field bus: Control word • P-0-4078, Field bus: Status word
Specific Parameters for Analog Interface	For the analog interface, the following additional parameters are used: • P-0-4028, Device control word • P-0-0115, Device control: Status word Pertinent Diagnostic Messages • C0100 Communication phase 3 transition check • C5200 Communication phase 4 transition check • C0200 Exit parameterization level procedure command • C0400 Activate parameterization level 1 procedure command

5.2.2 Control Options / Additional Functions

Configurable Signal Control Word

Brief Description

The signal control word allows writing individual control bits, that are available in different parameters, by a freely configurable collective parameter. The configurable signal control word is used to accept a maximum of 16 copies of bits from other drive parameters.

Examples of Use

This functionality can be used, for example,

- for setting bits in drive parameters and for starting commands via the cyclic channel (master communication)
- for defining an application-specific combination of 16-bit wide control and status words which can then be transmitted in the cyclic data channel.

Overview of the Scope of Functions



For sercos and field bus interfaces the parameter "S-0-0145, Signal control word" must be accordingly configured in the cyclic data so that the configured control bits are evaluated.

Pertinent Parameters

- S-0-0027, Configuration list for signal control word
- S-0-0145, Signal control word
- S-0-0329, Assign list signal control word
- S-0-0399, IDN-list of configurable data in signal control word

Configurable Signal Status Word

Brief Description

The configurable signal status word is used to accept a maximum of 16 copies of bits from other drive parameters. The user can thereby freely configure a bit list with status bits. This allows defining a bit list which contains all the important pieces of status information of the drive for the control unit.

Pertinent Parameters

- S-0-0026, Configuration list for signal status word
- S-0-0144, Signal status word
- S-0-0328, Assign list signal status word
- S-0-0398, IDN-list of configurable data in signal status word

Multiplex Channel

Brief Description

The multiplex channel is an expansion of the cyclic data channel. By means of index assignment and switching, cyclic access to list elements is possible for the multiplex channel, too.



The "multiplex channel" mechanism cannot be used with the analog interface.

Features

- 8 multiplex containers with 4 bytes each are available for cyclic command value data (MDT) and cyclic actual value data (AT)
- Multiplex data to be transmitted is addressed via parameter "S-0-0368, Data container A: Addressing" (L-byte for MDT; H-byte for AT)
- Individual elements from list parameters can be addressed via parameters S-0-0362 and S-0-0366
- Multiplex data are transmitted in communication cycle

Possible Applications

By means of the multiplex channel it is possible:

- To increase the number of transmittable bytes in the cyclic real-time channel (command and actual values) by multiplexing data
- To transmit the multiplex data in every cycle with a cycle time of " $T_{scyc} \times$ quantity of multiplex data" by incrementing the addressing index (S-0-0368)
- To achieve operation mode dependent configuration of the cyclic data by index switching in case the operation mode is changed



When IndraMotion MLC and IndraDrive MLD-M are used, the multiplex channel is used for communication between MLC and MLD-M and drive and can therefore no longer be used freely.

Pertinent Parameters

Parameters for command value channel:

Overview of the Scope of Functions

- S-0-0362, Data container A: List index command values
- S-0-0368, Data container A: Addressing
- S-0-0360, Data container A: Command value 1
- S-0-0450, Data container A: Command value 2
- to -
- S-0-0456, Data container A: Command value 8

Parameters for actual value channel:

- S-0-0366, Data container A: List index feedback values
- S-0-0364, Data container A: Feedback value 1
- S-0-0480, Data container A: Feedback value 2
- to -
- S-0-0486, Data container A: Feedback value 8

Configuration lists of the command value data containers:

- S-0-0370, Data container A: Configuration list command value-1
- S-0-0490, Data container A: Configuration list command value 2
- to -
- S-0-0496, Data container A: Configuration list command value 8

Configuration lists of the actual value data containers:

- S-0-0371, Data container A: Configuration list feedback value-1
- S-0-0500, Data container A: Configuration list feedback value 2
- to -
- S-0-0506, Data container A: Configuration list feedback value 8

Pertinent Diagnostic Messages

- C0151 IDN for command value data container not allowed
- C0152 IDN for actual value data container not allowed
- C0238 Order of cyclic command value configuration incorrect
- E4008 Invalid addressing command value data container A
- E4009 Invalid addressing actual value data container A

5.2.3 Operating Modes of Master Communication


Introduction and Overview

Overview of Operating Modes and Possibilities of Command Triggering

Command triggering for the drive can take place by an external control master (remote mode) or internally via IndraMotion MLD or the inputs/outputs which are available (local mode).

The figure below contains an overview of the possibilities of drive command triggering.

Overview of the Scope of Functions



* MultiEthernet is not available for PROFIBUS, interfaces can be used for engineering

** Only as of MPx17 and not possible for EtherCAT

Fig. 5-5: Overview of Possibilities of Command Triggering for an IndraDrive Device

Operating Modes and Changes of States

The overview below shows the basically possible operating states and the actions required for change/transition from one operating mode to the other.

Overview of the Scope of Functions




Fig. 5-6: Operating States and Operating Modes of Master Communication

Device Control and State Machine

According to the type of master communication or setting of the device control, different control words take effect. Internally, however, all relevant control bits are always displayed in parameter "P-0-0116, Device control: Control word".



The actual state machines of master communication are described in the section "Device Control and State Machines"!

Normal Operation (via Internal or External Control Unit)

In the so-called normal operation, the command triggering for the drive takes place via an internal (IndraMotion MLD) or external control unit (e.g. IndraMotion MTX or MLC); we distinguish the following cases:

- **Remote mode** with active master communication (standard case)
Command triggering for the axis takes place via the master communication (sercos, field bus, analog interface).
- **Special case** (respective configuration via "P-0-4089.0.1, Master communication: Protocol"):
 - **Analog mode** for sercos or field bus devices (master communication has been deactivated and a device with sercos or field bus interface is permanently operated via the digital/analog inputs/outputs)

See also "Special Cases of Operation with External Control Unit"

Overview of the Scope of Functions

- **MLD mode** (stand-alone "Motion Control")
 - The PLC integrated in the drive (IndraMotion MLD) takes over command triggering of the axis or, in conjunction with cross communication (CCD), of an entire axis group.
 - Configuration via parameter P-0-1367 (see also "Stand-alone motion control" in the separate documentation "IndraMotion MLD, Application Manual")

Local Setting-Up Mode/Emergency Mode (Easy Startup Mode)

During operation, the drive can, **due to the situation**, change to a local mode for setting-up or to remedy an emergency (e.g. bus failure). We distinguish the following operating modes:

- **Setting-up mode** (easy startup mode)

For commissioning or the setting-up procedure, the drive can temporarily be moved via the inputs/outputs (digital and analog), independently of the external master (e.g. field bus interfaced PLC or NC) or the the internal control (IndraMotion MLD).
- **Emergency mode** in the case of bus failure (freezing the last command values)

Even if the master communication fails, it is possible to continue operating the drive in an emergency mode via the (local) inputs/outputs at the device.



Using the emergency mode requires the corresponding configuration in the parameter "P-0-4088, Master communication: Drive configuration"; the automatic activation of the easy startup mode can be set in this parameter.

5.2.4 Profile Types (with Field Bus Interfaces)

Brief Description

Supported Profile Types, Overview

When a field bus interface is used for master communication, IndraDrive controllers support the following profile types (modes):

- "No profile"
- I/O mode positioning
- I/O mode preset velocity
- Freely configurable mode (IndraDrive profile type)

The tables below contain an overview of the most important properties and features of these 4 profile types:

Overview of the Scope of Functions

Profile type: "No profile"			
Content of "P-0-4084, Field bus: Profile type"	Master Communication	Field bus or drive operation mode	Features
0x0000	PROFIBUS® CANopen PROFINET® EtherNet/IP™	- With the profile type "No profile", all settings relevant to the profile type are deactivated - The profile type "No profile" is intended for MLD applications with "permanent control"	- Field bus control word and field bus status word are not available in the cyclic data - Field bus control word and field bus status word are deactivated and cannot be written via acyclic services - Real-time data can be freely configured - Drive is controlled via MLD

Tab. 5-29: Profile Type "No Profile"

I/O mode positioning			
Content of "P-0-4084, Field bus: Profile type"	Master Communication	Field bus or drive operation mode	Features
0xFF82	PROFIBUS® CANopen PROFINET® EtherNet/IP™	I/O mode positioning (positioning block mode, encoder 1, lagless)	- Up to 64 positioning blocks can be controlled via field bus - Apart from control word and status word, other real-time data can be configured (in P-0-4080 and P-0-4081) - Bits can be freely defined in signal status word via "configurable signal status word" function

Tab. 5-30: Profile Type "I/O Mode Positioning"

I/O mode preset velocity			
Content of "P-0-4084, Field bus: Profile type"	Master Communication	Field bus or drive operation mode	Features
0xFF92	PROFIBUS® CANopen PROFINET® EtherNet/IP™	I/O mode preset velocity	- Fixed velocity command values can be controlled and ramp-function generator can be operated via field bus - Apart from control word and status word, other real-time data can be configured (in P-0-4080 and P-0-4081) - Bits can be freely defined in signal status word via "configurable signal status word" function

Tab. 5-31: Profile Type "I/O Mode Preset Velocity"

Overview of the Scope of Functions

Freely configurable mode			
Content of "P-0-4084, Field bus: Profile type"	Master Communication	Field bus or drive operation mode	Features
0xFFFE	PROFIBUS® CANopen PROFINET® EtherNet/IP™	Freely configurable mode (Default assignment is "drive-controlled positioning" with corresponding required cyclic data)	- Possible use of complete drive functionality by free configuration of real-time data and operation mode selection - Control word and status word have a Rexroth-specific structure - Selection suited for operation with analog command values in commissioning phase
0xFFFD	As for profile 0xFFFE, but reduced field bus control word		

Tab. 5-32: Profile Type "Freely Configurable Mode"

- Pertinent Parameters**
- S-0-0026, Configuration list for signal status word
 - S-0-0144, Signal status word
 - S-0-0328, Assign list signal status word
 - P-0-4068, Field bus: Control word IO
 - P-0-4071, Field bus: Length of cyclic command value data channel
 - P-0-4074, Field bus: Data format
 - P-0-4077, Field bus: Control word
 - P-0-4078, Field bus: Status word
 - P-0-4080, Field bus: Config. list of cyclic actual value data ch.
 - P-0-4081, Field bus: Config. list of cyclic command value data ch.
 - P-0-4082, Field bus: Length of cyclic actual value data channel
 - P-0-4083, Parameter channel: Length
 - P-0-4084, Field bus: Profile type

Supported Profile Types, Basic Principles and Terms

- Drive Profile** The drive profile defines
- the structure of the field bus control word (P-0-4077) and of the field bus status word (P-0-4078),
 - the structure and content of real-time channel (P-0-4080, P-0-4081),
 - the active operation mode (S-0-0032, S-0-0033, S-0-0034, S-0-0035),
 - the drive states and their transitions (state machine of IndraDrive profile type or I/O mode).

By selecting a profile type, the commissioning of field bus drives becomes very easy for the user. The advantage of the profile selection is that all important basic settings for the desired drive function are thereby made automatically in the drive. As the profile types are defined independently of the bus, the transfer of applications from one field bus to the other is also facilitated.

- State Machine** A state (e.g. Drive Halt, drive error, ...) represents a specific internal and external behavior. The state can be exited by defined events (e.g. drive commands, switching of operation modes, ...). Corresponding state transitions are assigned to the events. The interaction of control and status bits and the state transitions are called state machine.

- Abbreviations**
- **i16**: Signed 16-bit variable (1 word) in Intel format


Overview of the Scope of Functions

- **i32**: Signed 32-bit variable (2 words) in Intel format
- **u16**: Unsigned 16-bit variable (1 word) in Intel format
- **u32**: Unsigned 32-bit variable (2 words) in Intel format
- **ZKL1**: Class 1 diagnostics
- **ZKL2**: Class 2 diagnostics

5.2.5 **sercos**

Brief Description

Topology



- 1 Engineering via inactive sercos port of a node at the bus
- 2 Engineering via optional sercos netSWITCH
- 3 Engineering via IndraWorks on sercos control
- 4 Engineering via routing using control unit (if routing control is available)

Fig. 5-7: Engineering Options via sercos

It is possible to operate IndraDrive controllers with a MultiEthernet interface (ET) or the optional module "sercos" as sercos master communication. Via these modules it is possible to exchange real-time data with a sercos master.

The following communication channels are distinguished:

- **Cyclic data channel**
→ Channel for cyclic transmission of useful data (**process data**) in real time
- **Acyclic data channel** (service channel)
→ Channel for acyclic transmission of useful data (**service data**)
- **Non-real time channel (NRT channel)**
→ Defined time slot within the cycle time for transmission of standard Ethernet telegrams

General Features

- Transmission rate 100 Mbit/s

Overview of the Scope of Functions

- Cyclical data exchange of command values and actual values in equal time intervals
- Data transmission via Ethernet cable (CAT5e-copper)
- Service channel for parameterization and diagnostics
- Free configuration of telegram contents
- Synchronization between time command value takes effect and measurement starting time of the actual values for all devices on a ring
- Overall synchronization of all connected devices

			BASIC MPB-18VRS	ECONOMY MPE-18VRS	ADVANCED MPC-18VRS	MULTIAXIS MPM-18VRS
Position controller cycle	T_{position}	μs	250/500	1000	250	500
Master communication cycle time	min	μs	250/500	2000	250	500
	max	ms	65	65	65	65
Motion data for MDT/AT respectively [excl. 2 byte connection control word (C_Con)]	$T_{\text{sercos}} = T_{\text{position}}$	Byte	26	26	26	26
		IDN	12	12	12	12
	$T_{\text{sercos}} > T_{\text{position}}$	Byte	50	50	50	50
		IDN	16	16	16	16
CC connections [excl. 2 byte connection control word (C_Con)]			Byte	12	12	12
			IDN	2	2	2
Safety connections			Byte	10	10	10
			IDN	SMP container	SMP container	SMP container

Tab. 5-33: *sercos Key Data*

- IndraDrive supports 6 connections, 2 between control unit and drive and 4 CC connections for direct communication with one or several other nodes



In this firmware version, CC connections or connections for exchanging safety data have been implemented according to the status of the sercos specification (SCP V1.1.2). Regarding use and configuration, see Technical Note "TN_332_CC-Verbindungen_SERCOS3_EIDN.pdf"



The number of configurable bytes in consumer/producer connections depends on the relation of the position cycle time (P-0-0556, bit 2) to the sercos cycle time:

- sercos cycle time = position cycle time → max. length 26 bytes / 12 IDNs
- sercos cycle time > position cycle time → max. length 50 bytes / 16 IDNs

The NRT channel is only possible, if a time slot of more than 125 μs is available.

Hardware Requirements

Overview of the Scope of Functions

Optional Module with sercos Communication

IndraDrive Cs	
ECONOMY	HCS01.1E-W00xx-A-0x-E-S3-EC-NN-xx-NN-FW
IndraDrive control section	
ECONOMY	CSE02.1A-S3-EC-NN-xx-NN-FW

Tab. 5-34: Control Section Design for "sercos interface"

Optional Module with MultiEthernet Communication

IndraDrive Cs	
ADVANCED	HCS01.1E-W00xx-A-0x-A-CC-EC-xx-xx-NN-FW
IndraDrive Mi	
Distributed servo drive	KSM02.1B-xxxC-xxN-xx-Hxx-ET-NN-D7-xx-FW
Distributed drive controller	KMS02.1B-Axxx-P-D7-ET-xxx-xx-xx-FW
Drive connection box	KCU02.1N-ET-ET*-025-NN-N-NN-NN
IndraDrive control sections	
BASIC single-axis	CSB02.1x-ET-EC-xx-xx-xx-NN-FW
BASIC double-axis	CDB02.1B-ET-EC-EC-xx-xx-xx-xx-NN-FW
ADVANCED single-axis	CSH02.1B-CC-EC-xx-xx-xx-NN-FW

* See central standard ZN 41001-021

Tab. 5-35: Control Section Design for MultiEthernet

Axis Addressing

The axis address can be set directly using the control panel of the drive. This can be done using the so-called Easy Menu (see also "Standard Control Panel").




Fig. 5-8: Submenu for "Slave__" "Address"

Alternatively, the address can be directly changed or displayed using the parameter "S-0-1040, Drive address of master communication". With sercos the address can be set remotely and automatically via the master using remote address assignment. This function must be supported by the master, e.g. the CCD master. On this topic, see chapter "Cross Communication (CCD)". The topology address of the drive determined in communication phase 0 (CP0) is displayed in parameter "S-0-1042, sercos: Topology index".

Overview of the Scope of Functions

The axis address is always displayed in the left side of the standard display of the control panel.

Pertinent Parameters

Specific parameters for sercos communication:

- S-0-1000, sercos: SCP Type & Version
- S-0-1002, sercos: Communication Cycle time (tScyc)
- S-0-1003, sercos: Allowed MST losses
- S-0-1005, sercos: Minimum feedback processing time (t5)
- S-0-1006, sercos: AT0 transmission starting time (t1)
- S-0-1007, sercos: Feedback acquisition capture point (t4)
- S-0-1008, sercos: Command value valid time (t3)
- S-0-1009, sercos: Device Control (C-Dev) offset in MDT
- S-0-1010, sercos: Lengths of MDTs
- S-0-1011, sercos: Device Status (S-Dev) offset in AT
- S-0-1012, sercos: Length of ATs
- S-0-1013, sercos: SVC offset in MDT
- S-0-1014, sercos: SVC offset in AT
- S-0-1015, sercos: Ring delay
- S-0-1016, sercos: Slave delay (P/S)
- S-0-1017, sercos: NRT transmission time
- S-0-1019, Master comm. engineering over IP: MAC address
- S-0-1020, Master comm. engineering over IP: IP address
- S-0-1021, Master comm. engineering over IP: Network mask
- S-0-1022, Master comm. engineering over IP: Gateway address
- S-0-1023, sercos: SYNC jitter
- S-0-1024, C5300 sercos: SYNC delay measuring procedure command
- S-0-1026, sercos: Version of communication hardware
- S-0-1027.0.1, sercos: Requested MTU
- S-0-1027.0.2, sercos: Effective MTU
- S-0-1028, sercos: Error counter MST-P/S
- S-0-1031, sercos: Signal assignment TSx
- S-0-1034, sercos: PHY error counter Port1 and Port2
- S-0-1035, sercos: Error counter Port1 & Port2
- S-0-1035.0.1, sercos: Error counter P&S
- S-0-1036, sercos: Inter Frame Gap
- S-0-1037, sercos: Slave Jitter
- S-0-1040, Drive address of master communication
- S-0-1041, sercos: AT Command value valid time (t9)
- S-0-1042, sercos: Topology index
- S-0-1044, sercos: Device Control (C-Dev)
- S-0-1045,
- S-0-1046, sercos: Slave addresses of the device
- S-0-1047, sercos: Maximum Consumer Activation Time
- S-0-1050.x.1, sercos Connection: Connection setup

Overview of the Scope of Functions

- S-0-1050.x.2, sercos Connection: Connection number
- S-0-1050.x.3, sercos Connection: Telegram assignment
- S-0-1050.x.4, sercos Connection: Max. length of connection
- S-0-1050.x.5, sercos Connection: Current length of connection
- S-0-1050.x.6, sercos Connection: Configuration list
- S-0-1050.x.7, sercos Connection: Connection class
- S-0-1050.x.8, sercos Connection: Connection control (C-Con)
- S-0-1050.x.9, sercos Connection: State
- S-0-1050.x.10, sercos Connection: Producer cycle time
- S-0-1050.x.11, sercos Connection: Allowed data losses
- S-0-1050.x.12, sercos Connection: Error counter data losses
- S-0-1050.x.20, sercos Connection: IDN allocation of real-time bit
- S-0-1050.x.21, sercos Connection: Bit allocation of real-time bit
- S-0-1051, sercos Connection: Image of connection setups
- S-0-1060.x.1, sercos Connectiontype: Default configuration
- S-0-1060.x.2, sercos Connectiontype: Configuration mask
- S-0-1060.x.3, sercos Connectiontype: Max. quantity of conn. Capability
- S-0-1060.x.4, sercos Connectiontype: Max. Length of Connection
- S-0-1060.x.6, sercos Connectiontype: Configurable IDNs
- S-0-1060.x.7, sercos Connectiontype: Min. processing time
- S-0-1060.x.10, sercos Connectiontype: Minimum producer cycle time

Pertinent Diagnostic Messages


- A0000 Communication phase 0
- A0001 Communication phase 1
- A0002 Communication phase 2
- A0003 Communication phase 3
- A0008 sercos: NRT-Mode
- E4020 sercos: Ring interruption (FF to LF)
- F4001Sync telegram failure
- F4002RTD telegram failure
- F4003Invalid communication phase shutdown
- F4004Error during phase progression
- F4005Error during phase regression
- F4006Phase switching without ready signal
- F4017sercos: Incorrect sequence during phase switch
- F4020sercos: Cable break (L+F to NRT)

5.2.6 EtherCAT®

Brief Description

Topology

Overview of the Scope of Functions



- 1 Engineering using EoE via optional Ethernet switch port
- 2 Engineering using EoE via optional Ethernet switch port
- 3 Engineering using ADS interface via third-party control or Engineering using EoE (control includes switch port)

Fig. 5-9: Engineering Options with EtherCAT®

IndraDrive controllers with MultiEthernet interface (ET) can be operated as EtherCAT® master communication. Via these modules it is possible to exchange real-time data with an EtherCAT® master. The "Servo Drive Profile over EtherCAT® (SoE)", which is based on the drive profile from the SERCOS II specification, is supported.

The following communication channels are distinguished:

- **Cyclic data channel** (process data)
→ Data container for cyclic transmission of useful data (**process data**) in real time
- **Acyclic data channel** (service channel)
→ EtherCAT® mailbox method for acyclic transmission of useful data (**service data**)
- **Non-real time channel** [Ethernet over EtherCAT® (EoE)]
→ Transmission of Ethernet telegrams via an EtherCAT® mailbox method [Ethernet over EtherCAT® (EoE)]

General Features

- Transmission rate 100 Mbit/s
- Data transmission via Ethernet cable (CAT5e-copper)
- Topology: "Line"
- Access to 16 bit sercos parameters of the drive via "SoE" protocol ("Servo Drive Profile over EtherCAT®" protocol)
- EtherCAT® mailbox method for parameterization and diagnostics
- Cyclic data exchange of command values and actual values

Overview of the Scope of Functions

- Free configuration of telegram contents
- Max. length of the configurable MDT/AT data, 15 IDNs with max. 48 bytes; if bus clock = position clock, the max. length is reduced by half to 24 bytes
- Cycle time: Min. 500 µs (multiples of the position clock can be set)
- Optional synchronization via "distributed clock synchronization" (exact adjustment of distributed clocks)
- Synchronization between time command value takes effect and measurement starting time of the actual values for all drives on a ring when using Distributed Clocks
- Overall synchronization of all connected drives to the master when using Distributed Clocks
- Non-synchronous operation without synchronization via "Distributed Clock" is possible
- "CAN over EtherCAT®" (CoE) is not supported
- Only released in conjunction with "Beckhoff-TwinCAT"

Hardware Requirements

The master communication "EtherCAT®" requires the following control section design:

IndraDrive Cs	
BASIC	HCS01.1E-W00xx-A-0x-B-ET-EC-xx-xx-NN-FW
ADVANCED	HCS01.1E-W00xx-A-0x-A-CC-EC-ET-xx-NN-FW
IndraDrive Mi	
Distributed servo drive	KSM02.1B-xxxC-xxN-xx-Hxx-ET-NN-D7-xx-FW
Distributed drive controller	KMS02.1B-Axxx-P-D7-ET-xxx-xx-xx-FW
Electronic control system	KCU02.1N-ET-ET*-025-NN-N-NN-NN
IndraDrive control sections	
Basic control section - single-axis	CSB02.1x-ET-EC-xx-xx-xx-NN-FW
Basic control section - double-axis	CDB02.1B-ET-EC-EC-xx-xx-xx-xx-NN-FW
Advanced control section - single-axis	CSH02.1B-CC-ET-xx-xx-NN-FW

* See central standard ZN 41001-021

Tab. 5-36: Control Section Design for MultiEthernet

Axis Addressing

The axis address can be set directly using the control panel of the drive. This can be done using the so-called Easy Menu, see also "[Standard Control Panel](#)". Alternatively, the address can be directly changed or displayed using the parameter "P-0-4089.0.3, Device Address". The topology address of the drive is assigned by the master and displayed in parameter "P-0-4089.0.4, Active Device Address", and cannot be changed. With EtherCAT®, this address is used as the "Device Identification Value / 2nd Address".

Pertinent Parameters

- P-0-4089.0.3, Device Address
- P-0-4089.0.4, Active Device Address
- S-0-0001, NC cycle time (TNcyc)

Overview of the Scope of Functions

- S-0-0002, sercos cycle time (TScyc)
- S-0-0005, Minimum feedback acquisition time (T4min)
- S-0-0007, Feedback acquisition starting time (T4)
- S-0-0014, Interface status
- S-0-0015, Telegram type parameter
- S-0-0016, Configuration list of AT
- S-0-0024, Configuration list of MDT
- S-0-0029, MDT error counter
- S-0-0097, Mask class 2 diagnostics
- S-0-0098, Mask class 3 diagnostics
- S-0-0134, Master control word
- S-0-0135, Drive status word
- S-0-0185, Length of the configurable data record in the AT
- S-0-0186, Length of the configurable data record in the MDT
- S-0-0187, List of configurable data in the AT
- S-0-0188, List of configurable data in the MDT
- S-0-0301, Allocation of real-time control bit 1
- S-0-0303, Allocation of real-time control bit 2
- S-0-0305, Allocation of real-time status bit 1
- S-0-0307, Allocation of real-time status bit 2
- S-0-0413, Bit number allocation of real-time control bit 1
- S-0-0414, Bit number allocation of real-time control bit 2
- S-0-0415, Bit number allocation of real-time status bit 1
- S-0-0416, Bit number allocation of real-time status bit 2

Pertinent Diagnostic Messages


- C0101 Invalid parameters (-> S-0-0021)
- C0104 Config. IDN for MDT not configurable
- C0105 Maximum length for MDT exceeded
- C0106 Config. IDNs for AT not configurable
- C0107 Maximum length for AT exceeded
- C0108 Time slot parameter > sercos cycle time
- C0112 TNcyc (S-0-0001) or TScyc (S-0-0002) error
- C0113 Relation TNcyc (S-0-0001) to TScyc (S-0-0002) error
- C0114 T4 > TScyc (S-0-0002) - T4min (S-0-0005)
- C0201 Invalid parameters (->S-0-0423)
- C0299 Configuration changed. Restart
- E4005 No command value input via master communication
- F4002RTD telegram failure
- F4009Bus failure

5.2.7 EtherNet/IP(TM) Interface

Brief Description

Topology

Overview of the Scope of Functions



- 1 Engineering via inactive EtherNet/IP™ port of a node at the bus
- 2 Engineering using optional industrial Ethernet switch
- 3 Engineering using third-party control is not possible

Fig. 5-10: EtherNet/IP(TM) Topology

IndraDrive controllers with MultiEthernet interface can be operated as EtherNet/IP™ master communication. This module can be used to exchange real-time data with an EtherNet/IP™ scanner.

Real-time data can be transmitted via this interface using an I/O connection (Class 1 connection).

To achieve high system flexibility, all data are accessible via objects. With Ethernet/IP™ interfaces, these objects can be addressed via class, instance and attribute. Some of these objects can be assigned to the I/O connection as real-time data and thus be cyclically transmitted. There is also the option of transmitting via "Explicit Message", but no objects defined in the real-time channel (P-0-4081) may be written by the master via "Explicit Message".

Features

- Transmission rate 100 Mbit/s (full duplex)
- Data transmission via Ethernet cable (CAT5e-copper)
- Topologies: "Star", "line" (with integrated cut through switch)
- Autonegotiation is supported; the transmission rate listed above is required
- Profile type is "Generic Device", specified in ODVA 2.0 (Open Device-Net Vendors Association)
- EtherNet/IP™ Level 2 server
- Cyclic exchange via "Ethernet/IP™ I/O messaging" (Class 1)

Overview of the Scope of Functions

- Acyclic data exchange via "Ethernet/IP™ Unconnected Explicit Messaging" and "Explicit Messaging" (Class 3)
- The smallest supported cycle time (API → Actual Packet Interval) is 2 ms.
- Configurable cyclic data up to 15 parameters (incl. field bus control word and field bus status word) in both data directions (max. 48 bytes or 24 words)



- It is recommended that the industrial Ethernet network not be coupled with a company network (office communications). (Alternatively, a Level 3 router can be used to connect the industrial Ethernet network to a company network.)
- It is recommended that only switches with cut through method be used for industrial Ethernet communication.
- It is recommended that a star topology with cable type AWG22 or shielded cables be used, particularly for cables that exit the control cabinet and for cables longer than 10 meters.

- Supported field bus profiles:
 - 0x0000: "No profile"
 - 0xFF82: I/O mode "positioning" with configurable real-time data
 - 0xFF92: I/O mode "preset velocity" with configurable real-time data
 - 0xFFFFD: Freely configurable mode "Neutral operation modes"
 - 0xFFFFE: Freely configurable mode

Hardware Requirements

The master communication "EtherNet/IP™" requires the following control section design:

IndraDrive Cs	
BASIC	HCS01.1E-W00xx-A-0x-B-ET-EC-xx-xx-NN-FW
ADVANCED	HCS01.1E-W00xx-A-0x-A-CC-EC-ET-xx-NN-FW
IndraDrive Mi	
Distributed servo drive	KSM02.1B-xxx-C-xxN-xx-Hxx-ET-NN-D7-xx-FW
Distributed drive controller	KMS02.1B-Axxx-P-D7-ET-xxx-xx-xx-FW
Electronic control system	KCU02.1N-ET-ET*-025-NN-N-NN-NN
IndraDrive control sections	
Basic control section - single-axis	CSB02.1x-ET-EC-xx-xx-xx-NN-FW
Basic control section - double-axis	CDB02.1B-ET-EC-EC-xx-xx-xx-xx-NN-FW
Advanced control section - single-axis	CSH02.1B-CC-ET-xx-xx-NN-FW

* See central standard ZN 41001-021

Tab. 5-37: Control Section Design for MultiEthernet

Axis Addressing

With EtherNet/IP the master communication address is an IP address. It is set in "P-0-4089.0.13, Master communication: IP address".

Overview of the Scope of Functions



The device address set in "P-0-4089.0.3, Device Address" is applied to the parameter "P-0-4089.0.4, Active Device Address" after the device has been restarted. This address is shown on the display and is irrelevant for the EtherNet/IP communication!

Pertinent Parameters

- P-0-4073, Field bus: Diagnostic message
- P-0-4074, Field bus: Data format
- P-0-4075, Field bus: Watchdog
- P-0-4076, Field bus: Process data - updating clock
- P-0-4079, Field bus: Baud rate
- P-0-4088, Master communication: Drive configuration
- P-0-4089.0.2, Master communication: Device name
- P-0-4089.0.10, Master communication: MAC address device
- P-0-4089.0.13, Master communication: IP address
- P-0-4089.0.14, Master communication: Network mask
- P-0-4089.0.15, Master communication: Gateway address

Profile type parameters

Apart from mere communication parameters, we use parameters in conjunction with the profile types.

In this regard, see "[Profile Types \(with Field Bus Interfaces\)](#)"

Parameters for extended communication

We use additional parameters for extended communication.

See the following sections:

- "[Configurable Signal Control Word](#)"
- "[Configurable Signal Status Word](#)"
- "[Multiplex channel](#)"

Pertinent Diagnostic Messages


- C0229 Field bus: IDN for cycl. command val. not configurable
- C0230 Field bus: Max. length for cycl. command val. exceeded
- C0231 Field bus: IDN for cycl. actual val. not configurable
- C0232 Field bus: Length for cycl. actual values exceeded
- C0233 Field bus: Tcyc (P-0-4076) incorrect
- C0234 Field bus: P-0-4077 missing for cycl. command values
- C0299 Configuration changed. Restart
- E4005 No command value input via master communication
- E4006 Communication module overload
- E4011 Communication watchdog: Overload of cyclic communication
- F4009 Bus failure
- F4011 Communication watchdog: Overload of cyclic communication

5.2.8 PROFINET®

Brief Description

Topology

Overview of the Scope of Functions



- 1 Engineering via inactive PROFINET® port of a node at the bus
- 2 Engineering using optional industrial Ethernet switch
- 3 Engineering using third-party control via TCI is not possible

Fig. 5-11: Engineering Options with PROFINET®

IndraDrive controllers with MultiEthernet interface (ET) can be operated as PROFINET® master communication. Via this module it is possible to exchange real-time data with a PROFINET® controller.

The field bus provides data containers in which useful data can be cyclically transmitted. This section is referred to as **cyclic data channel** (PROFINET®).

The cyclic data channel is divided as follows:

- One (optional) **device-specific parameter channel** for reading and writing of all parameters via PROFINET®.



The **device-specific parameter channel** does not fulfill any "real-time properties"!

- One (optional) **safe, axis-specific process data channel** (PROFIsafe).



The **safe, axis-specific process data channel** is not available in MPx18VRS. For configuration, however, the module "F-Module not used" must be integrated!

- One **axis-specific process data channel** (real-time channel) which contains specified information that can be directly interpreted by the receiver.

Overview of the Scope of Functions




Fig. 5-12: Overview of Cyclic Data Channel



To simplify field bus communication, PLC function blocks are available for different programmable logic controllers (PLCs). The function blocks support the basic functionalities of the axis-specific process data channel and device-specific parameter channel. The principles applied can be easily used for other PROFINET® controllers.

Features

The PROFINET® device circuit with MultiEthernet interface has the following features:

- Ethernet in accordance with IEEE 802.3 and prioritization in accordance with IEEE 802.1Q
- Transmission rate 100 Mbit/s
- Data transmission via Ethernet cable (CAT5e-copper)
- Topologies: "Star", "line" (with integrated cut through switch)
- Assignment of the IP addresses via DCP protocol (Discovery and Basic Configuration)
- The lowest supported cycle time (IO cycle update time) is 2 ms.



The IO cycle update time is written by the control unit and is the time cycle in which the process data from the PROFINET network are applied to the MultiEthernet interface and written in the other direction.

- Configurable cyclic data up to 15 parameters (incl. field bus control word and field bus status word) in both data directions (max. 48 bytes or 24 words)
- Setting options via "P-0-4076, Field bus: Process data - updating clock", min. 2 ms, max. 65 ms (can be set in steps of 1 ms).



The parameter "P-0-4076, Field bus: Process data - updating clock" is used to set the update cycle with which the process data from the MultiEthernet interface are applied to the drive and vice versa.

Overview of the Scope of Functions



In the planning, assembly and commissioning of an installation, the following guidelines are referred to (designation: PROFINET trilogy):

- Planning guideline
- Assembly guideline
- Commissioning guideline

The guidelines are made available by the administrative office of the PNO (PROFIBUS Nutzerorganisation e. V.).



It is recommended that

- the industrial Ethernet network not be coupled with a company network (office communications). (Alternatively, a Level 3 router can be used to connect the industrial Ethernet network to a company network.)
- only switches with cut through method be used for industrial Ethernet communication
- a star topology with cable type AWG22 or shielded cables be used, particularly for cables that exit the control cabinet and for cables longer than 10 meters

- Additional optional parameter channel in the cyclic channel with up to 16 bytes (8 words)
- LED for diagnosing PROFINET® status (network status)
- LEDs for displaying link/activity status
- Support for CCA and RT_CLASS_1
- Diagnostic messages and alarms are not used due to reasons of compatibility with IndraDrive controllers with the PROFIBUS® master communication module.
- PROFINET® IRT is not supported.
- Operation in PROFINET® IRT networks is not possible.
- Supported field bus profiles:
 - 0x0000: "No profile" selected
 - 0xFF82: I/O mode "positioning" with configurable real-time data
 - 0xFF92: I/O mode "preset velocity" with configurable real-time data
 - 0xFFFFD: Freely configurable mode "Neutral operation modes"
 - 0xFFFFE: Freely configurable mode

Hardware Requirements

The master communication "PROFINET®" requires the following control section design:

IndraDrive Cs	
BASIC	HCS01.1E-W00xx-A-0x-B-ET-EC-xx-xx-NN-FW
ADVANCED	HCS01.1E-W00xx-A-0x-A-CC-EC-ET-xx-NN-FW
IndraDrive Mi	
Distributed servo drive	KSM02.1B-xxxC-xxN-xx-Hxx-ET-NN-D7-xx-FW
Distributed drive controller	KMS02.1B-Axxx-P-D7-ET-xxx-xx-xx-FW
Electronic control system	KCU02.1N-ET-ET*-025-NN-N-NN-NN

Overview of the Scope of Functions

IndraDrive control sections	
Basic control section - single-axis	CSB02.1x-ET-EC-xx-xx-xx-NN-FW
Basic control section - double-axis	CDB02.1B-ET-EC-EC-xx-xx-xx-xx-NN-FW
Advanced control section - single-axis	CSH02.1B-CC-ET-xx-xx-NN-FW

* See central standard ZN 41001-021

Tab. 5-38: Control Section Design for MultiEthernet

Axis Addressing

A node in PROFINET is addressed using the so-called device name. This name is saved in P-0-4089.0.2 and can be changed there.



The device address set in "P-0-4089.0.3, Device Address" is applied to the parameter "P-0-4089.0.4, Active Device Address" after the device has been restarted. This address is shown on the display and is irrelevant for the PROFINET communication!

Pertinent Parameters**Communication parameters**

Specific parameters for communication via PROFINET®:

- P-0-4089.0.11, Master communication: MAC address Port1
- P-0-4089.0.12, Master communication: MAC address Port2

Parameters for general communication via field bus interfaces:

- P-0-4073, Field bus: Diagnostic message
- P-0-4074, Field bus: Data format
- P-0-4075, Field bus: Watchdog
- P-0-4076, Field bus: Process data - updating clock
- P-0-4079, Field bus: Baud rate
- P-0-4083, Parameter channel: Length
- P-0-4083.0.1, Parameter channel: Configuration
- P-0-4088, Master communication: Drive configuration
- P-0-4089.0.2, Master communication: Device name
- P-0-4089.0.10, Master communication: MAC address device
- P-0-4089.0.13, Master communication: IP address
- P-0-4089.0.14, Master communication: Network mask
- P-0-4089.0.15, Master communication: Gateway address

Profile type parameters

Apart from mere communication parameters, we use parameters in conjunction with the profile types.

In this regard, see "[Profile Types \(with Field Bus Interfaces\)](#)"

In this regard, see "[Engineering/Diagnostic Interfaces](#)"

Parameters for extended communication

We use additional parameters for extended communication.

See the following sections:

- "[Configurable Signal Control Word](#)"
- "[Configurable Signal Status Word](#)"

Overview of the Scope of Functions

- "Multiplex channel"
- Pertinent Diagnostic Messages**
- C0229 Field bus: IDN for cycl. command val. not configurable
 - C0230 Field bus: Max. length for cycl. command val. exceeded
 - C0231 Field bus: IDN for cycl. actual val. not configurable
 - C0232 Field bus: Length for cycl. actual values exceeded
 - C0233 Field bus: Tcyc (P-0-4076) incorrect
 - C0234 Field bus: P-0-4077 missing for cycl. command values
 - C0299 Configuration changed. Restart
 - E4005 No command value input via master communication
 - E4006 Communication module overload
 - E4011 Communication watchdog: Overload of cyclic communication
 - F4009Bus failure
 - F4011Communication watchdog: Overload of cyclic communication
 - F4012Incorrect I/O length

5.2.9 PROFIBUS-DP

Brief Description

IndraDrive controllers with PROFIBUS interface (PB) can be operated as PROFIBUS slaves in a PROFIBUS installation. Via these PROFIBUS components, it is possible to exchange real-time data with a PROFIBUS-DP master.

Cyclic data channel (PROFIBUS-DP)

The field bus provides data containers in which useful data can be cyclically transmitted. This section is referred to as cyclic data channel.

The cyclic data channel is divided as follows:

- One (optional) **device-specific parameter channel** for reading and writing of all IndraDrive parameters via PROFIBUS-DP.



The **device-specific parameter channel** does not fulfill any "real-time properties"!

- One (optional) **safe, axis-specific process data channel** (PROFIsafe).



The **safe, axis-specific process data channel** is not available in MPx18VRS. For configuration, however, the module "F-Module not used" must be integrated!

- One **axis-specific process data channel** (real-time channel) which contains specified information that can be directly interpreted by the receiver.




Fig. 5-13: Overview of Cyclic Data Channel

Overview of the Scope of Functions



To simplify field bus communication, Rexroth PLC function blocks are available for different programmable logic controllers (PLCs). The function blocks support the basic functionalities of the axis-specific process data channel and device-specific parameter channel. The principles applied can be easily used for other field bus masters.

Features

The slave PROFIBUS-DP circuit with master communication module PROFIBUS interface (PB) has the following functional features:

- Support of **RS485 interfaces according to IEC 61158-2**
- Support of all **data rates according to IEC 61158-2**, with exclusive use of PROFIBUS-DP (9.6 kBaud, 19.2 kBaud, 45.45 kBaud, 93.75 kBaud, 187.5 kBaud, 500 kBaud, 1.5 MBaud, 3 MBaud, 6 MBaud, 12 MBaud)
- Automatic baud rate detection
- Configurable cyclic data up to 15 parameters (incl. field bus control word and field bus status word) in both data directions (max. 48 bytes or 24 words)
- Setting options for P-0-4076: Min. 2 ms, max. 65 ms (can be set in steps of 1 ms)



The parameter "P-0-4076, Field bus: Process data - updating clock" is used to set the update cycle with which the process data from the PROFIBUS interface are applied to the drive and from the drive.

- Additional optional parameter channel in the cyclic channel with up to 16 bytes (8 words)
- Monitoring of the cyclic data exchange (watchdog function)
- LED for diagnosing the PROFIBUS interface
- Supported DPV0 services:
 - Slave_Diag (read diagnostic data)
 - Get_Cfg (read configuration data)
 - Set_Prm (send parameterization data)
 - Chk_Cfg (check configuration data)
 - Data Exchange (transfer I/O data)
 - Global Control (synchronization)
 - RD_Outp (read output data)
 - RD_Inp (read input data)
- Supported DPV1 Class 1 services
 - DDLM_Initiate (establishment of connection)
 - DDLM_Read (acyclic read access)
 - DDLM_Write (acyclic write access)
 - DDLM_Abort (abortion of connection)
 - DDLM_Idle (connection monitoring)
- Support of up to two DPV1 Class 2 connections
- TCI (Tool Calling Interface) support

Overview of the Scope of Functions

- Supported field bus profiles:
 - 0x0000: "No profile selected"
 - 0xFF82: I/O mode "positioning" with configurable real-time data
 - 0xFF92: I/O mode "preset velocity" with configurable real-time data
 - 0xFFFD: Freely configurable mode "Neutral operation modes"
 - 0xFFFE: Freely configurable mode

Hardware Requirements

The master communication "PROFIBUS-DP" requires the following device design:

IndraDrive Cs	
BASIC	HCS01.1E-W00xx-A-0x-B-ET-EC-PB-xx-NN-FW
ADVANCED	HCS01.1E-W00xx-A-0x-A-CC-EC-PB-xx-NN-FW
IndraDrive control sections	
Basic control section - single-axis	CSB02.1x-ET-EC-PB-xx-xx-NN-FW
Basic control section - double-axis	CDB02.1B-ET-EC-EC-PB-xx-xx-xx-NN-FW
Advanced control section - single-axis	CSH02.1B-CC-EC-PB-xx-xx-NN-FW

Tab. 5-39: Control Section Design for PROFIBUS



In the case of devices with PROFIBUS option, it is only possible to change between inactive master communication and PROFIBUS master communication. Switching to sercos, EtherCAT, EtherNet/IP or PROFINET is impossible.

Axis Addressing

The axis address can be set directly using the display of the drive. This can be done using the so-called Easy menu.




Fig. 5-14: Submenu for "Slave__" "Address"

Alternatively, the address can be directly changed or displayed using the parameter "S-0-1040, Drive address of master communication".

Overview of the Scope of Functions

The axis address is always displayed in the left side of the standard display of the control panel.

Pertinent Parameters**Communication parameters**

Specific parameters for communication via PROFIBUS-DP:

- P-0-4069, Field bus: Module diagnosis

Parameters for general communication via field bus interfaces:

- P-0-4073, Field bus: Diagnostic message
- P-0-4074, Field bus: Data format
- P-0-4075, Field bus: Watchdog
- P-0-4076, Field bus: Process data - updating clock
- P-0-4079, Field bus: Baud rate
- P-0-4083, Parameter channel: Length
- P-0-4083.0.1, Parameter channel: Configuration

Profile type parameters

Apart from mere communication parameters, we use parameters in conjunction with the profile types.

In this regard, see "[Profile Types \(with Field Bus Interfaces\)](#)"

Parameters for extended communication

We use additional parameters for extended communication.

See the following sections:

- "[Configurable Signal Control Word](#)"
- "[Configurable Signal Status Word](#)"
- "[Multiplex channel](#)"

Pertinent Diagnostic Messages

- C0229 Field bus: IDN for cycl. command val. not configurable
- C0230 Field bus: Max. length for cycl. command val. exceeded
- C0231 Field bus: IDN for cycl. actual val. not configurable
- C0232 Field bus: Length for cycl. actual values exceeded
- C0233 Field bus: Tcyc (P-0-4076) incorrect
- C0234 Field bus: P-0-4077 missing for cycl. command values
- E4005 No command value input via master communication
- F4009 Bus failure
- F4012 Incorrect I/O length

5.2.10 CANopen Interface

Brief Description

It is possible to operate IndraDrive controllers with a CANopen interface as master communication module. This requires the control section design with the optional module "CANopen" (CN). Via this optional module, it is possible to exchange real-time data with a CANopen master. The "CANopen" protocol (according to Draft Standard DS301, version 4.0.2) has been implemented in the drive controller.

Communication Channels

We distinguish the following communication channels:

- **Cyclic data channel** (process data objects → PDO)

Overview of the Scope of Functions

The field bus provides data containers in which useful data can be cyclically transmitted in real time (process data objects).

- **Acyclic data channel** (service data objects → SDO)

The field bus provides data containers in which useful data (service data objects) can be acyclically transmitted.



The process data are always transmitted via PDOs.

Features

- Simple configuration through use of "Predefined Connection Set" and "Minimal Boot-Up" according to DS301
- Baud rates of 20, 50, 125, 250, 500, 800 and 1000 kbit/s specified by CANopen according to DS301 are supported
- Configurable cyclic data up to 15 parameters (incl. field bus control word and field bus status word) in both data directions (max. 32 bytes or 16 words)
- Functional compatibility with EcoDrive functions through profile selection (I/O mode)
- Node monitoring (heartbeat function and node guard function)
- LED displays at the front panel of the master communication module for simple diagnosis of bus functions and most important communication relationships between drive and field bus (2 LEDs: "Run" status and "Error" status)
- All parameters of the drive can be directly read via SDO and, if permitted, can be written
- Upload/download function for all parameters of the drive possible with SDO services
- Event-controlled or synchronous transmission of process data
- CANopen Device profile DSP402 is not supported; field bus profiles according to DSP402 are partly supported (see ["Profile Types \(with Field Bus Interfaces\)"](#))

Hardware Requirements

The optional module with CANopen interface is available for the following configurable control sections:

IndraDrive Cs	
BASIC	HCS01.1E-W00xx-A-0x-B-ET-EC-CN-xx-NN-FW
ADVANCED	HCS01.1E-W00xx-A-0x-A-CC-EC-EN-xx-NN-FW
IndraDrive control sections	
Basic control section - single-axis	CSB02.1x-ET-EC-CN-xx-xx-NN-FW
Advanced control section - single-axis	CSH02.1B-CC-EC-CN-xx-xx-NN-FW

Tab. 5-40: Control Section Design for CANopen Communication

Pertinent Parameters

Communication parameters

Specific parameters for CANopen communication:

- P-0-3610, CANopen: Heartbeat/NodeGuard Configuration
- P-0-3611, CANopen: COB-IDs
- P-0-3612, CANopen: Transmission Types

Overview of the Scope of Functions

- P-0-3613, CANopen: List of the Event Parameters

Parameters for general field bus communication:

- P-0-4025, Drive address of master communication
- P-0-4073, Field bus: Diagnostic message
- P-0-4074, Field bus: Data format
- P-0-4075, Field bus: Watchdog
- P-0-4076, Field bus: Process data - updating clock
- P-0-4079, Field bus: Baud rate

Profile type parameters

Apart from mere communication parameters, we use parameters in conjunction with the profile types.

In this regard, see "[Profile Types \(with Field Bus Interfaces\)](#)"

Parameters for extended communication

We use additional parameters for extended communication.

See the following sections:

- "[Configurable Signal Control Word](#)"
- "[Configurable Signal Status Word](#)"

Pertinent Diagnostic Messages

- C0229 Field bus: IDN for cycl. command val. not configurable
- C0230 Field bus: Max. length for cycl. command val. exceeded
- C0231 Field bus: IDN for cycl. actual val. not configurable
- C0232 Field bus: Length for cycl. actual values exceeded
- C0233 Field bus: Tcyc (P-0-4076) incorrect
- C0234 Field bus: P-0-4077 missing for cycl. command values
- F4001 Sync telegram failure
- F4002 RTD telegram failure
- F4009 Bus failure
- F4012 Incorrect I/O length

5.2.11 Analog Interface

Brief Description

Overview Apart from the digital master communication interfaces (sercos, PROFIBUS...), the drive controllers of the IndraDrive range provide an interface for analog master communication (analog interface). This allows assigning an analog command value to a drive parameter (e.g. "S-0-0036, Velocity command value").

The figures below illustrate the structure of drive solutions with analog interface and open-loop or closed-loop operation.

Overview of the Scope of Functions




Fig. 5-15: Open-Loop Operation with Analog Interface (with Optional Position Feedback to Open-Loop Control)




Fig. 5-16: Closed-Loop Operation with Analog Interface (with Analog Command Value Input and SSI Emulation)

This section describes the basic functions of the analog interface and contains notes on commissioning and parameterization. The single function used, "Analog inputs", is described separately.

See also "[Analog Inputs](#)"

Features

The analog interface is an interface for master communication with analog command values and digital inputs/outputs (drive enable, Drive Halt, ...).

Features of the **analog inputs**:

- Analog inputs (14 bit) which can be assigned to parameters, with smoothing to be set (number of analog inputs depending on control section design)
- Sampling of the analog inputs in the position controller clock T_{position} (see "[Performance Data](#)")

Features of the **analog assignment**:

- Two assignments to parameters are possible; offset and scaling of the analog input can be set for each assignment
- Sampling rates for analog input assignment:
 - Assignment channel A → assignment in position controller clock T_{position}
 - Assignment channel B → assignment in clock of 2 ms

Overview of the Scope of Functions

Features of the **digital inputs/outputs**:

- Digital control and status information determined via configuration of the digital inputs of the control section:
 - **Digital control inputs** for analog master communication:
 - "Drive enable" and "Drive Halt" signals
 - Zero switch, limit switch (+/-); clearing errors and E-Stop
 - **Digital status outputs** for analog master communication:
 - Ready and warning output
 - Relay output for readiness for operation

Availability All drive controllers except for KSM02.1 and KMS02.1 provide the possibility of analog operation. For this purpose, the master communication must be deactivated by means of "P-0-4089.0.1, Master communication: Protocol".

The Multi-Ethernet interface can still be used for engineering and diagnostic purposes.

Pertinent Parameters Control and status parameters:

- P-0-0115, Device control: Status word
- P-0-0116, Device control: Control word
- P-0-4028, Device control word

Digital inputs/outputs:

- P-0-0300, Digital inputs, assignment list
- P-0-0301, Digital inputs, bit numbers
- P-0-0303, Digital inputs, input image of device
- P-0-0304, Digital outputs, output image of device
- P-0-0306, Digital inputs, assignment connector and pin
- P-0-0307, Digital inputs, input image sub-device
- P-0-0310, Digital outputs, assignment list
- P-0-0311, Digital outputs, bit numbers
- P-0-0312, Digital outputs, assignment sub-device
- P-0-0313, Digital outputs, output image sub-device
- P-0-0316, Digital outputs, assignment connector and pin

Analog inputs:

- P-0-0210, Analog input 1
- P-0-0212, Analog input, list of assignable parameters
- P-0-0213,
- P-0-0214, Analog input, assignment A, scaling
- P-0-0215, Analog input, assignment A, signal value at 0
- P-0-0216, Analog input, assignment A, dead zone
- P-0-0217, Analog input 1, time constant input filter
- P-0-0218, Analog input, control parameter
- P-0-0219,
- P-0-0220,
- P-0-0236,
- P-0-0237, Analog input, assignment B, scaling

Overview of the Scope of Functions

- P-0-0238, Analog input, assignment B, signal value at 0
- P-0-0239, Analog input, assignment B, dead zone
- P-0-3901, Adjustment values of control section

Encoder emulation:

- P-0-0900, Encoder emulation signal selection list
- P-0-0901.x.1, Encoder emulation signal selection
- P-0-0901.x.2, Encoder emulation control parameter
- P-0-0901.x.3, Encoder emulation resolution
- P-0-0901.x.4, Encoder emulation zero pulse offset

5.2.12 RIL_ModbusTCP

The field bus protocol "Modbus TCP" is used to exchange data between Ethernet devices which support the Modbus protocol.

In this case, the drive-internal PLC assumes the role of the "Modbus TCP" server (master) to which the "Modbus TCP" clients (slaves) can connect.

By means of the function blocks contained in the "RIL_ModbusTCP" library, both a "Modbus TCP" server and a "Modbus TCP" client can be implemented.

The library is supported by several targets and therefore is described in the documentation "Basic Libraries, IndraLogic 2G".

5.3 Motor, Mechanical Axis System, Measuring Systems

5.3.1 General Information on Operation of Motors with IndraDrive

Basics on the Motors to be Controlled

Brief Description

With the controllers of the IndraDrive range it is possible to control both synchronous motors and asynchronous motors.

Types of Construction

The following types of construction are possible:

- Rotary motors
- Linear motors

Both types can be used in housing design (motor with an output shaft that includes the bearing) or in kit design (stator and rotor as individual components).

Thermal Monitoring

When IndraDrive is used, the controlled motors are protected against thermal damage when they are provided with a temperature sensor connected to the controller. The controllers are equipped for evaluating the following temperature sensors:

- NTC thermistor K227 (manufacturer: Siemens)
- PTC thermistor KTY84 (manufacturer: Siemens)
- Thermal switch SNM150DK (manufacturer: Thermik)

In addition, it is possible to evaluate temperature sensors not listed above, but their specific resistance characteristics have to be entered manually!

Diagnostic Data for Motor Operation

The firmware provides the option to collect dynamic operating data of the motor and store them (operating hours counter, thermal and mechanical operating data, operational performance).

Overview of the Scope of Functions

Adjusting Mains Voltage / Motor	Motors the winding insulation of which is not suited for the maximum nominal DC bus voltage of DC750V, can be protected against inadmissibly high voltage by specifying the maximum DC bus voltage allowed for these motor types. The braking resistor threshold is adjusted to the value of this parameter and the DC bus voltage is limited to this value ("output stage locked"). If the DC bus voltage to be expected is higher than the one allowed for the motor, you must check whether the DC bus voltage can be dropped to a value allowed for the motor by reducing the mains voltage.
Adjusting Motor/Controller	The IndraDrive controllers are adjusted to the motor to be controlled by providing or inputting the motor-specific data. • In the case of Rexroth motors, this can be done without any problem, because the manufacturer provides a specific data set for adjusting each motor type. The data are documented by the manufacturer as parameter values, stored and made available in motor-specific parameters. • In the case of third-party motors, it is necessary to check, by means of the motor data and the data of the possibly available motor encoder, whether they are basically suited for operation with IndraDrive. The parameter values for adjusting the controller have to be specifically determined for each motor.  Rexroth motors, by motor-specific parameter values made available and temperature evaluation adjusted in an optimum way, guarantee easy commissioning, full drive performance and a high degree of operational safety!
Motor Holding Brakes	IndraDrive allows controlling and monitoring holding brakes that are mechanically connected to the motor: • Electrically releasing brakes (self-holding) • Electrically holding brakes (self-releasing)
Hardware Data	For the electrical connection of the motors to the controller, see the Project Planning Manuals for the IndraDrive controllers. A complete connection diagram for the use of Rexroth motors is contained in the respective Project Planning Manual.
Pertinent Parameters	Motor parameters: • S-0-0109, Motor peak current • S-0-0111, Motor current at standstill • S-0-0113, Maximum motor speed • S-0-0141, Motor type • P-0-0018, Number of pole pairs/pole pair distance • P-0-0051, Torque/force constant • P-0-0510, Rotor inertia • P-0-0640, Cooling type • P-0-0853, Max. DC bus voltage, motor • P-0-4014, Type of construction of motor • P-0-4048, Stator resistance Synchronous motor parameters: • P-0-4016, Direct-axis inductance of motor • P-0-4002, Charact. of quadrature-axis induct. of motor, inductances

Overview of the Scope of Functions

- P-0-4003, Charact. of quadrature-axis inductance of motor, currents
- P-0-4005, Flux-generating current, limit value
- P-0-4013, Current limit value of demagnetization

Asynchronous motor parameters:

- P-0-0532, Premagnetization factor
- P-0-4004, Magnetizing current
- P-0-0529, Scaling of stall current limit
- P-0-0530, Slip increase
- P-0-4039, Stator leakage inductance
- P-0-4040, Rotor leakage inductance
- P-0-4041, Motor magnetizing inductance
- P-0-4042, Characteristic of motor magnetizing inductance
- P-0-4043, Rotor time constant

Field-weakening range parameters:

- P-0-0533,
- P-0-0534, Voltage loop integral action time
- P-0-0535, Motor voltage at no load
- P-0-0536, Maximum motor voltage

Other Motor-Relevant Parameters

In connection with the motor, there are other important parameters of the following parameter groups:

- Measuring system parameters
- Motor holding brake parameters
- Temperature sensor parameters
- Motor temperature model parameters
- Default control loop parameters

Motor Temperature Monitoring

Brief Description

See "[Basics on the Motors to be Controlled](#)"

Pertinent Parameters

- S-0-0201, Motor warning temperature
- S-0-0204, Motor shutdown temperature
- S-0-0383, Motor temperature
- P-0-0512, Temperature sensor
- P-0-0513,

Pertinent Diagnostic Messages

- E2021 Motor temperature outside of measuring range
- E2051 Motor overtemp. prewarning
- F2019 Motor overtemperature shutdown
- F2021 Motor temperature monitor defective

Overview of the Scope of Functions

5.3.2 Rexroth Motors

Basics on the Rexroth Motors

Brief Description

Classification In the "Electric Drives and Controls" technology field, Rexroth offers a wide range of motors for equipping machines and installations with drives.

Due to their types of construction, Rexroth electric motors can be divided into:

- Housing motors with output shaft and flange or mounting supports
- Kit motors to be installed in machines and installations; consisting of individual components that are mounted to a moving and a static part of the mechanical system

Adjusting Motor/Controller The controllers can be adjusted to Rexroth motors without any problem because the manufacturer provides the respective data set for each motor type. These data are available as parameter values.

- In the case of housing motors with data memory in the motor encoder, the parameter values are delivered as an integral part of the motor. At the initial commissioning they are automatically loaded to the controller.
- In the case of kit motors (individual components) and housing motors without data memory in the motor encoder, the respective motor parameters are not supplied with the motor. They can be easily loaded to the controller, however, from a database in the "IndraWorks Ds/D/MLD" commissioning tool.

The motor parameter values determined by the manufacturer guarantee that the motor can be loaded in accordance with its operating characteristic, if the required current and the corresponding power are provided by controller and supply unit.

The motor-specific parameter values of Rexroth motors can be loaded to the controller in different ways:

- Automatically for housing motors with encoder data memory
- Supported by a database for kit motors when using the commissioning tool "IndraWorks Ds/D/MLD"
- File-supported by loading a drive parameter set
- Manually by entering the parameter values based on a motor-specific data list

For automatic, database-supported and file-supported loading procedures, the motor-specific parameter values are written to a memory range of the controller that maintains the data unchanged, similar to a conventional "type plate". The data, which if applicable are converted depending on the scaling, are copied from this "type plate" memory range to the parameters active for control. In the case of manual data input, the parameters of the "type plate" memory range should be written.

Thermal Motor Monitoring Rexroth motors are thermally monitored by the controller and protected against overheating. For this purpose, the current motor temperature is determined by thermo sensors installed in the motor winding. Depending on temperature thresholds that can be set, the controller generates a warning or switches the motor off.

Overview of the Scope of Functions



Due to the availability of motor parameters and perfectly adjusted temperature evaluation, Rexroth motors guarantee easy commissioning, full drive performance and a high degree of operational safety!

Measuring system

As a standard, Rexroth housing motors are equipped with a position measurement system. The individual motor series have different measuring systems which allows providing cost-efficient motors depending on the application.

The following measuring systems of Rexroth housing motors are supported by this firmware

- Encoders with sine signal and HIPERFACE® interface (1 Vpp)
- Encoders with sine signals (1 Vpp) and EnDat2.1 interface
- Encoders with sine signals (1 Vpp)
- Encoders of MSM motors with digital interfaces

Various encoder systems can be used together with Rexroth kit motors:

- Encoders with sine signals (1 Vpp) and EnDat2.1 interface, Heidenhain standard
- Encoders with sine signals (1 Vpp) and HIPERFACE® interface (IndraDrive-compatible HIPERFACE® encoders (DE_EN_FAQ_IndraDrive_unterstützte_Geber...) and HIPERFACE® encoders with "0xFF" type ID)
- Encoder with sine signals, 1Vpp, Heidenhain standard
- Encoder with square-wave signals, TTL, Heidenhain standard

Pertinent Parameters

The "type plate" memory range contains the parameters listed below, among others. The parameters, which if applicable are converted depending on the scaling, are automatically copied to the parameters active for control (see "Pertinent Parameters" under "Basics on the Motors to be Controlled").

General motor parameters:

- P-0-2109, Motor peak current, type plate
- P-0-2111, Motor current at standstill, type plate
- P-0-2113, Maximum velocity of motor, type plate
- P-0-2141, Motor type, type plate
- P-0-3000, Module code of motor, type plate
- P-0-3002, Number of pole pairs/pole pair distance, type plate
- P-0-3003, Rotor inertia, type plate
- P-0-3005, Torque/force constant, type plate
- P-0-3007, Stator resistance, type plate
- P-0-3008, Commutation offset, type plate

Synchronous motor parameters

- P-0-3008, Commutation offset, type plate
- P-0-3015, Flux-generating current, limit value, type plate
- P-0-3016, Direct-axis inductance of motor, type plate
- P-0-3017, Quadrature-axis inductance of motor, type plate
- P-0-3018, Charact. quadr.-axis induct. of motor, induct., type plate
- P-0-3019, Charact. quadr.-axis induct. of motor, currents, type plate
- P-0-3023, Current limit value of demagnetization, type plate

Overview of the Scope of Functions

- P-0-3044, Motor torque at nominal current with reluctance, type plate
- P-0-3045, Motor torque at maximum current with reluctance, type plate
- P-0-3046, Reluctance angle at nominal motor current, type plate
- P-0-3047, Reluctance angle at maximum motor current, type plate
- P-0-3048, Motor control configuration, type plate

Asynchronous motor parameters

- P-0-3032, Premagnetization factor, type plate
- P-0-3014, Magnetizing current, type plate
- P-0-3029, Scaling of stall current limit, type plate
- P-0-3039, Stator leakage inductance, type plate
- P-0-3040, Rotor leakage inductance, type plate
- P-0-3041, Motor magnetizing inductance, type plate
- P-0-3042, Characteristic of motor magnetizing inductance, type plate
- P-0-3043, Rotor time constant, type plate

Field weakening range parameters

- P-0-3033, Voltage loop proportional gain, type plate
- P-0-3034, Voltage loop intergral action time, type plate
- P-0-3035, Motor voltage at no load, type plate
- P-0-3036, Maximum motor voltage, type plate

Parameters for measuring system:

- P-0-1000, Kind of encoder 1, encoder memory
- P-0-1001, Encoder 1 resolution, encoder memory

Only for absolute encoders (multi-turn):

- P-0-1002, Absolute encoder offset 1, encoder memory

Parameter for motor holding brake (if available):

- P-0-3010, Torque of motor holding brake, type plate
- P-0-3011, Holding brake current, type plate
- P-0-2206, Drive On delay time, type plate
- P-0-2207, Drive Off delay time, type plate

Default control loop parameters:

- P-0-2100, Velocity loop proportional gain, type plate
- P-0-2101, Velocity loop integral-action time, type plate
- P-0-2104, Position loop Kv-factor, type plate
- P-0-2106, Current loop proportional gain 1, type plate
- P-0-2107, Current loop integral-action time 1, type plate
- P-0-3004, Speed controller smoothing time constant, type plate



At a command, the default control loop parameters and, where required, the delay times for the holding brake (P-0-2206, P-0-2207) can be loaded to the drive controller. They are useful start values for further optimization.

Pertinent Diagnostic Messages

- C0700 Load defaults proced. command (motor-spec. controller val.)
- C0702 Default parameters not available

Overview of the Scope of Functions

- C0703 Default parameters invalid
- C0704 Parameters not copyable
- C0706 Error when reading the controller parameters
- F2008RL The motor type has changed.
- F2104Commutation offset invalid

Rexroth Housing Motors

Rexroth Housing Motors with Encoder Data Memory

Motor Series

The following Rexroth housing motors that are supported by this firmware are equipped with an encoder data memory:

- MSK, MSM
- MAD, MAF

Brief Description

See section "[Basics on the Rexroth Motors](#)"

Pertinent Parameters

See "Pertinent Parameters" in the section "Basics on the Rexroth Motors"

In addition to the parameters listed above there are other parameters for the data transfer from the encoder data memory to the parameter memory of the controller (administration parameters that users cannot interpret, the number of which depends on the number of encoder interfaces present):

- P-0-1031, Content of encoder memory optional slot 1
- P-0-1032, Content of encoder memory optional slot 2
- P-0-1033, Content of encoder memory optional slot 3
- P-0-1034, Content of encoder memory optional slot 4
- P-0-1035, Content of encoder memory optional slot 5
- P-0-1036, Content of encoder memory optional slot 6

Pertinent Diagnostic Messages

See "Pertinent Diagnostic Messages" in the section "Basics on the Rexroth Motors"

Notes on Commissioning

Initial Commissioning

In the case of Rexroth housing motors with encoder data memory, the values for the motor parameters stored in the encoder, the measuring system parameters and, where required, the motor holding brake parameters are automatically loaded to the "type plate" parameters of the controller when the drive is switched on.

When a drive is commissioned for the first time, first the error message "F2008RL The motor type has changed." appears. This message only means that this motor has not yet been connected to the controller.

By clearing this error message (reset via control panel or command "S-0-0099, C0500 Reset class 1 diagnostics"), the command "S-0-0262, C07_x Load defaults procedure command" is automatically started. In this way, default control loop parameter values for this motor are loaded from the "type plate" parameters to the active parameters of the controller.

Overview of the Scope of Functions

	 With the command "C07_x Load defaults procedure command" (S-0-0262), depending on the setting in "P-0-4090, Configuration for loading default values", the following parameter values are loaded: • Default control loop parameter values (default setting) • Default values of the firmware (factory settings) • MLD default values • SMO default values • Field bus profile settings
	In the case of motors with integrated holding brake, the brake type and the activation of brake control is automatically set in "P-0-0525, Holding brake control word". In the case of motors with several cooling type variants (MSK), the load data can be referred to the realized cooling type by entering the corresponding value in "P-0-0640, Cooling type".
Recommissioning	During servicing the motor can be replaced by a motor of the same type without any problem. The adjustment to the controller does not need to be repeated. In the case of an absolute motor encoder, it is only necessary to make an adjustment to the machine axis by establishing the position data reference. If the motor type connected to the controller has changed, the controller signals this with "F2008RL The motor type has changed." and requests the default values of the control loop parameters and the motor-specific parameters to be loaded. In the case of a desired motor change, initial commissioning of the new axis motor is necessary. Otherwise, there is an assembly error that has to be corrected!
Diagnostic Messages	In conjunction with the loading and verifying of parameter values from the encoder data memory, the following messages might possibly be generated: • When the default control loop parameter values and the motor-specific parameters are loaded → C07_0 Command for loading default values • If the parameter values in the encoder data memory cannot be read → C0706 Error when reading the controller parameters • If the motor type connected to the controller has changed → F2008 RL The motor type has changed. • If an invalid value for the commutation offset is contained in the encoder memory → F2104 Commutation offset invalid Rexroth Housing Motors without Encoder Data Memory Motor Series The following Rexroth housing motor supported by this firmware does not have an encoder data memory: • MAL Brief Description See section "Basics on the Rexroth Motors"
Pertinent Parameters	See "Pertinent Parameters" in the section "Basics on the Rexroth Motors"

Overview of the Scope of Functions

Pertinent Diagnostic Messages

See "Pertinent Diagnostic Messages" in the section "Basics on the Rexroth Motors"

For further information, see section "Basics on the Rexroth Motors"

Rexroth Kit Motors

General Information

Kit motors consist of individual components that are mounted to a moving and as static part of the machine's mechanical system and functionally put together to form a motor.

A kit motor consists of the following components:

- Electrically active part with thermo sensor
- Electrically passive part
- Measuring system
- Storage

The electrical parts of the kit motor are supplied by Rexroth, the measuring system and the bearing are provided on the machine side.

Rexroth kit motors are built according to the functional principles associated with "asynchronous motors" or "synchronous motors". With regard to control, the functional principles have different requirements:

- In the case of synchronous motors, the current in the windings of the stator must have a fixed allocation to the permanent magnetic field of the rotor so that the maximum torque or the maximum force is generated.
- In the case of asynchronous motors there is no fixed allocation between stator and rotor required in order to generate the maximum torque or the maximum force.

Rexroth Kit Motors, Synchronous

Brief Description

The following Rexroth kit motors are manufactured according to the functional principle "synchronous motor":

- Linear motors MLF and MCL
- Rotary motors MBS and MBT

As the motor is assembled in the machine, stator, rotor and measuring system can only be put together on site. The electric-magnetic-mechanical allocation of the synchronous motor is therefore only to be made on site. This is done by determining and setting the commutation offset.



The measuring system should be realized with high resolution and as a motor encoder to be evaluated in absolute form (see also "[Absolute Measuring Systems](#)"). If it is necessary to use an incremental measuring system, using encoders with square-wave signals should be avoided!

Determining the Commutation Offset

The commutation offset can be determined with different methods. The method is chosen in accordance with the axis geometry, the practicability and the chances of success of the respective method depending on the mechanical axis system:

- **Measuring method** for motor encoders that can be evaluated in absolute form

Overview of the Scope of Functions

→ Distance measurement, currentless (only possible for linear Rexroth kit motors)

- **Saturation method** (axis needs to be blocked or at standstill)
 - With current (possible with all types of construction in combination with motor encoders that can be evaluated in absolute form or with relative motor encoders)
- **Sine-wave method** (requires unrestricted movement of axis)
 - With current (possible with all types of construction in combination with motor encoders that can be evaluated in absolute form or with relative motor encoders)



In the case of absolute measuring systems, the commutation offset only has to be determined once (at initial commissioning), in the case of incremental measuring systems this has to be done each time the drive is switched on again!

For the description of the methods for commutation setting, see "Drive Control: [Commutation Setting](#)"

Pertinent Parameters

See "Pertinent Parameters" in the section "[Basics on the Rexroth Motors](#)"

Pertinent Diagnostic Messages

See "Pertinent Diagnostic Messages" in the section "[Basics on the Rexroth Motors](#)"

For further information, see section [Basics on the Rexroth Motors](#)

Rexroth Kit Motors, Asynchronous

Brief Description

The following Rexroth kit motors are manufactured according to the functional principle "asynchronous motor":

- Rotary motors 1 MB

As the motor is assembled in the machine, stator, rotor and measuring system can only be put together on site. After loading the specific parameter values for motor and measuring system the assembled motor can be put into operation independent of rotor position and allocation of the measuring system.



The measuring system should be realized with high resolution! Avoid using encoders with square-wave signals!

Pertinent Parameters

See "Pertinent Parameters" in the section "[Basics on the Rexroth Motors](#)"

Pertinent Diagnostic Messages

See "Pertinent Diagnostic Messages" in the section "[Basics on the Rexroth Motors](#)"

For further information, see section "[Basics on the Rexroth Motors](#)"

5.3.3 Third-Party Motors at IndraDrive Controllers

General Information on Third-Party Motors

Special Requirements

Today, machine axes are mainly moved with electric drives. Motors of standard design are used in most cases, as this is the most cost-efficient solution.

Due to special requirements at machine axes, constructional or safety-related aspects, it may be necessary for the machine manufacturer to use a motor construction diverging from the standard.

Overview of the Scope of Functions

Motor Designs not Included in Product Range	For these cases there is the demand on the drive supplier to realize, apart from the deliverable standard drive consisting of (standard) motor, controller, cable and, if required, machine control unit, drives with motors that are not included in his own product range due to the special design. With Rexroth controllers of the IndraDrive range, it is also possible to control third-party motors.
Checking Whether Third-Party Motors Can be Controlled	For successfully and fail-safely controlling a third-party motor, it is necessary to check beforehand • whether the third-party motor to be controlled meets the requirements of the controller, • whether the third-party motor has the required minimum inductance, • whether the mounted position measuring system can be evaluated by the controller or which position measuring system can be selected for kit motors, • whether the motor can be protected against inadmissible temperature rise in the case of overload, • which controller, including supply, is suitable due to the motor power to be delivered.
How to do Project Planning?	The requirements relevant in the system combination are documented in the Project Planning Manual of the drive system. The filled out "Forms for Required Manufacturer-Side Motor Data" are to be made available for the motor suitability test!  See the documentation "Rexroth IndraDrive Drive System, Project Planning Manual" (DOK-INDRV*-SYSTEM*****-PR**-EN-P; mat. no.: R911309636)!
How to Commission?	First, the motor parameter values must be determined (see the section "Determining the Parameter Values for Motor and Motor Control"). The parameter values of motor control are calculated by command internally in the firmware. The determined motor parameter values are to be documented in the forms included in the section "Forms for Parameter Values".

5.3.4 Motor Holding Brake

Brief Description

Motor holding brakes are used to hold axes with drive enable having been switched off. This is particularly important for non-equilibrated, vertical axes. With IndraDrive controllers it is possible to control and monitor motor holding brakes in a wear-resistant way.

The following motor holding brake types are possible:

- Electrically releasing brakes (self-holding) for servo drives
- Electrically holding brakes (self-releasing) for main drives

The motor holding brake can be directly mounted on the motor shaft, e.g. in the case of Rexroth housing motors, or directly connected to the mechanical axis system, e.g. in the case of linear kit motors.

IndraDrive controllers include application-specific control of the holding brake in order to minimize wear of the brake in the case of error. The following two functional principles of holding brake control are supported:

- Control of holding brake for **servo drives**
- Control of holding brake for **main drives**

Overview of the Scope of Functions

Monitoring the Brake Current

Brief Description

Fields of Application



Base package of all firmware variants in **open-loop and closed-loop** characteristic



Monitoring for wire break, brake current and short circuit is only available with HCS01 devices!

Background

Particularly with vertical servo axes, the reliable function of a holding brake is fundamentally important to the operational safety of a machine. The "Function Check of Motor Holding Brake" can be used to check the holding brake for wear and corrosion; however, the use of this function check is left to the user.

Even with a cyclical function check, wire break occurring in the meantime would cause the brake to be accidentally applied and possibly destroyed before the malfunction could be recognized by the next function check. Between the function check intervals, the monitoring of the brake current, which is always active, detects faults with the holding brake control and signals them immediately.

Overview of Functions

Operating Principle

The controller monitors the current that flows through the terminals on the controller side to operate the brake. The brake current monitoring recognizes these states:

- Wire break (brake current less than 100 mA)
- Brake current ok
- Short circuit

In case of "wire break" or "short circuit", the error message "F2068, Brake error" is generated. The monitoring is active as soon as an existing holding brake is entered in "P-0-0525, Holding brake control word".



The wire break monitoring can be deactivated, e.g. due to brake control via relays.

The status of the monitoring of the holding brake current is displayed in "P-0-0539, Holding brake status word"; for IndraDrive Cs, the measured holding brake current is displayed in "P-0-0527, Actual holding brake current".



For HCQ, holding break current output is not possible!

Hardware Requirements

The "brake current monitoring" function does not require any specific hardware!

For Rexroth motors with encoder data memory, the presence of a motor holding brake is automatically recognized; brake current monitoring is automatically activated. To activate the function for third-party motors and motors with external holding brakes, the presence of a holding brake must be entered in the holding brake control word.

Pertinent Parameters

- P-0-0525, Holding brake control word
- P-0-0539, Holding brake status word
- P-0-0527, Actual holding brake current

Pertinent Diagnostic Messages

- F2068 Brake error

Operating Behavior of the Motor Holding Brake

Brief Description

Motor holding brakes are used to hold axes with drive enable having been switched off. This is particularly important for non-equilibrated vertical axes. With IndraDrive controllers it is possible to control and monitor motor holding brakes in a wear-resistant way.

NOTICE

Holding brakes at Rexroth motors normally aren't designed for decelerating when in operation. Increased wear caused by deceleration in operation can destroy the holding brake at an early stage!

The following motor holding brake types are possible:

- Electrically releasing brakes (self-holding) for servo drives
- Electrically holding brakes (self-releasing) for main drives

The motor holding brake can be directly mounted on the motor shaft, e.g. in the case of Rexroth housing motors, or directly connected to the mechanical axis system, e.g. in the case of linear kit motors.

IndraDrive controllers include application-specific control of the holding brake in order to minimize wear of the brake in the case of error. The following two functional principles of holding brake control are supported:

- Control of holding brake **for servo drives**
- Control of holding brake **for main drives**

Control of the holding brake is linked with drive enable, considering clamping and releasing delays. In special cases it may be appropriate to avoid this programmed link and release or apply the holding brake independently. This, too, is possible with IndraDrive!

Hardware Requirements

The motor holding brake is controlled via a controller-internal relay contact. Power supply is realized by the controller via the 24V control voltage. The holding brake must be suited for the voltage that is output, the holding brake current is not permitted to exceed the allowed maximum value of the respective device (see documentation "Supply Units and Power Sections; Project Planning Manual for Controllers"); if necessary the holding brake must be controlled separately.



The optionally available holding brakes for Rexroth motors can be directly controlled via the drive controller!

Pertinent Parameters

- S-0-0206, Drive on delay time
- S-0-0207, Drive off delay time

Overview of the Scope of Functions

- S-0-0273, Maximum drive off delay time
 - P-0-0525, Holding brake control word
 - P-0-0539, Holding brake status word
 - P-0-0540, Torque of holding brake
 - P-0-0542, C2000 Command Release holding brake
 - P-0-0543, C3800 Command Apply holding brake
- Pertinent Diagnostic Messages**
- C2000Command Release motor holding brake
 - C2001Command not enabled
 - C3800Command Apply motor holding brake
 - F6024Maximum braking time exceeded

Function Check of Motor Holding Brake, Drive-Controlled

Brief Description

If the braking torque of holding brakes is too low due to wear and corrosion, this can interrupt the service and endanger safety in machines and installations. IndraDrive controllers have the advantage of monitoring the effectiveness of the holding brake upon a command of the control master and recording the monitoring intervals.

This allows cyclic brake check according to EN-954-1, cat. 2 or dynamization/check of one of two redundant holding systems according to EN-954-1, cat. 3.

Requirements The function check is only possible in the case of motor control with motor encoder, not for sensorless motors! The holding brake must be controlled by the drive controller (if necessary via relay, if the required brake current cannot be supplied via the drive controller).

Application The function check can also be carried out for an axis-side, external braking device, if it is controlled by the drive controller. The measuring system used for the function check (motor encoder or external encoder) must be connected stiffly and in a backlash-free way to the holding brake. Tolerated motion range with the holding brake applied:

- Rotary motor: Max. 2° of a motor revolution (360°)
- Linear motor: Max. 1/180 of a pole pair distance (in mm)

In the case of corrosion, the effectiveness of the holding brake can be reestablished by a drive-controlled "resurfacing procedure".

- Pertinent Parameters**
- P-0-0525, Holding brake control word
 - P-0-0539, Holding brake status word
 - P-0-0540, Torque of holding brake
 - P-0-0541, C2100 Holding system check command
 - P-0-0544, C3900 Command Holding brake resurfacing
 - P-0-0545, Test torque for releasing holding system
 - P-0-0546, Starting torque for releasing holding system
 - P-0-0547, Nominal load of holding system
 - P-0-0549, Oper. hours control sec. at last succ. holding system check
 - P-0-0550, Time interval holding system check
 - P-0-0554, Current torque value of the motor holding brake
 - S-0-0084, Torque/force feedback value

Overview of the Scope of Functions

- | | |
|--------------------------------------|---|
| Pertinent Diagnostic Messages | <ul style="list-style-type: none"> • S-0-0135, Drive status word • C2100Command Holding system check • C2101Holding system check only possible with drive enable • C2103Holding brake: Torque too low • C2104Command execution impossible • C2105Load of holding system greater than test torque • C2106Test torque of holding system not reached • C3900Command Holding brake resurfacing • C3901Resurfacing of holding brake only possible with drive enable • C3902Error during resurfacing of holding brake • C3903Command execution impossible • E3115 Prewarning, end of brake check time interval • F3115Brake check time interval exceeded |
|--------------------------------------|---|

5.3.5 Measuring Systems

Basics on Measuring Systems, Resolution

- | | |
|--|---|
| Control Loops and Measuring Systems | <p>Brief Description</p> <p>Operating drives in the closed control loop requires measuring systems in order to metrologically acquire the current state of the physical value to be controlled, the so-called actual value.</p> <p>The following drive control loops are distinguished:</p> <ul style="list-style-type: none"> • Torque/force control loop <ul style="list-style-type: none"> → Actual value by evaluating the current measuring system and converting the value • Velocity control loop <ul style="list-style-type: none"> → Actual value by evaluating the position measurement system and time-derivation • Position control loop <ul style="list-style-type: none"> → Actual value by evaluating the position measurement system <p>The actual value of the torque/force control loop is generated by means of the internal current measurement. The measuring system is inaccessible for the user and has a fixed configuration.</p> |
| Possibilities of Position Measurement | <p>For acquiring the actual values of the velocity and position control loop there are position measurement systems available that provide the user possibilities of configuration. Position measurement can be carried out:</p> <ul style="list-style-type: none"> • At the motor only (measurement via motor encoder) - or - • Both at the motor and at the mechanical axis system (measurement via motor encoder and "external" or "optional" encoder). |



Position measurement via motor encoder is always required, measurement at the mechanical axis system is optional, the encoder at the mechanical axis system is therefore called "optional encoder". It is also called "external encoder" because this encoder is not installed internally at the motor, but externally at the axis.

Overview of the Scope of Functions

Types of Position Measurement Systems	Position measurement systems are available for the different kinds of motion in adapted types of construction: • Rotary encoders • Linear encoders With the appropriate signal specification, encoders in both types of construction can be evaluated by IndraDrive controllers.
Evaluating Position Measurement	Depending on their design and the mechanical arrangement at the axis, the position encoders can be evaluated as • relative encoders (incremental encoders) • Absolute encoders (absolute value encoders). The position information of the encoder can be represented as • two analog voltage signals with sinusoidal profile at constant velocity and a 90° phase offset ("analog encoder") • digital encoder signal with defined number of increments per encoder revolution ("digital encoder")
Relative Position Measurement	In the case of relative position measurement, only position differences can be evaluated by means of the measuring system. The actual position values signaled by the measuring system refer to the (mostly undefined) position at the time the drive is switched on. To operate the drive within a limited travel range, a position reference must be established ("homing") each time after the drive has been switched on again.
Absolute Position Measurement	In the case of absolute position measurement, the encoder signals actual position values with a fixed encoder-dependent reference point to the controller. After the drive is switched on, the correct actual position value is immediately available for each axis position. Due to the mostly undefined mounting situation of the encoder to motor or mechanical axis system, it is necessary to determine the position offset ("setting the absolute value") once at the initial commissioning.
Precision, Resolution	The precision of the position measurement depends on: • The resolution of the measuring system (division periods (DP) for analog encoders; increments/revolution for digital encoders) • The absolute encoder precision • The digitalization quality of analog encoder signals • The dimension of the travel range of the axis
Monitoring Functions	Correct position information is of fundamental importance for reliable drive behavior and motion according to contour. The encoder signals are therefore monitored for validity and compliance with the allowed tolerances. In addition, it is possible to monitor drives with an encoder that can be evaluated in absolute form for compliance with the position when switching on compared to the last time the drive was switched off. It is also possible to monitor the difference between the actual position values of motor encoder and external encoder. See also "Monitoring the Measuring Systems"
Hardware Requirements	For connecting the measuring systems to the controller there are two optional interfaces available. The parameters "P-0-0077, Assignment motor encoder->optional slot" and "P-0-0078, Assignment optional encoder->optional slot" define the interface to which the respective encoder is connected.

Overview of the Scope of Functions



See also the documentation "Rexroth IndraDrive Cs, Drive Systems" and "Rexroth IndraDrive HCQ, Drive Systems"



The following points apply to the parameters P-0-0077 and P-0-0078:

- For motors with motor encoder data memory, the value for parameter P-0-0077 is automatically set correctly.
- For motors without motor encoder data memory (e.g. Rexroth kit motors), the value for parameter P-0-0077 must be set manually.
- In the case of optional encoders, the value for parameter P-0-0078 must be set manually, too.

Pertinent Parameters

- S-0-0051, Position feedback value 1
- S-0-0053, Position feedback value 2
- S-0-0115, Position feedback 2 type
- S-0-0116, Resolution of feedback 1
- S-0-0117, Resolution of feedback 2
- S-0-0256, Multiplication 1 (motor encoder)
- S-0-0257, Multiplication 2 (optional encoder)
- S-0-0277, Position feedback 1 type
- S-0-0278, Maximum travel range
- P-0-0074, Encoder type 1 (motor encoder)
- P-0-0075, Encoder type 2 (optional encoder)
- P-0-0129, Internal position data format

Monitoring the Measuring Systems

Brief Description

Monitoring the Encoder Signals

Correct position information is the prerequisite for reliable drive behavior and motion according to contour. In order to guarantee best possible position evaluation the encoder signals are therefore monitored for validity and compliance with the allowed tolerances.

Monitoring the encoder signals allows detecting faulty states, such as:

- Encoder is dirty
- Noise injection in the case of inappropriate wire routing or wire design
- Exceeding the max. allowed encoder velocity (limit frequency of the encoder signals)
- Wire break or short circuit on wire

Monitoring the Axis Position when Switching On

In addition it is possible to monitor drives with an encoder that can be evaluated in absolute form for compliance with the position when switching on compared to the last time the drive was switched off. This allows detecting, for example, whether a vertical axis moved down after the machine was switched off or whether an axis was moved away from the position it had when the machine stopped.

Monitoring Mechanical Transfer Elements

It is also possible to monitor the difference between the actual position values of motor encoder and external encoder, as well as the percentage of slip. This allows, for example, detecting elasticity or slip due to wear in mechanical transfer elements between motor and axis at an early stage.

Overview of the Scope of Functions

Monitoring the Position Data Reference	If the loss of the position data reference of absolute encoders (motor encoder or optional encoder) is detected due to changes in parameter values, e.g. of the mechanical drive system, the drive will signal this faulty state.
Pertinent Parameters	• S-0-0391, Monitoring window feedback 2 • P-0-0095, Absolute encoder monitoring window for motor encoder • P-0-0096, Absolute encoder monitoring window for opt. encoder • P-0-0177, Absolute encoder buffer 1 (motor encoder) • P-0-0178, Absolute encoder buffer 2 (optional encoder) • P-0-0185, Control word of encoder 2 (optional encoder) • P-0-0391, Actual position value difference encoder1 - encoder2
Pertinent Diagnostic Messages	• E2074 Encoder 1: Encoder signals disturbed • E2075 Encoder 2: Encoder signals disturbed • F2036 Excessive position feedback difference • F2042 Encoder 2: Encoder signals incorrect • F2048 Low battery voltage • F2074 Actual pos. value 1 outside absolute encoder window • F2075 Actual pos. value 2 outside absolute encoder window • F2174 Loss of motor encoder reference • F2175 Loss of optional encoder reference • F8022 Enc. 1: Enc. signals incorr. (can be cleared in ph. 2)

Absolute Measuring Systems

Brief Description

Evaluating Position Measurement	Depending on their design and the mechanical arrangement at the axis, position encoders can be evaluated by IndraDrive controllers as • relative encoders (incremental encoders) or as • absolute encoders (absolute value encoders) if they have the required signal specification. Both Rexroth position encoders and motor encoders of Rexroth housing motors are available in one of the two designs: • Single-turn encoders (absolute actual position values over one encoder shaft revolution) • Multi-turn encoders (absolute actual position values over 4096 encoder shaft revolutions). These encoders can be evaluated as absolute encoders if the travel range of the axis can be represented within the absolute actual position value range of the encoder: • In the case of single-turn encoders within one encoder shaft revolution • In the case of multi-turn encoders within 4096 encoder shaft revolutions
Encoders of Rexroth Housing Motors	As a standard, Rexroth housing motors are equipped with a position measurement system. The individual motor series have different measuring systems which allows offering cost-efficient motors depending on the application. The following measuring systems are supported by this firmware:

Overview of the Scope of Functions

	• Motor encoder option S1 or M1: HIPERFACE® encoder, single- or multi-turn type • Motor encoder option S2 or M2: EnDat2.1 encoder, single- or multi-turn type
Absolute Encoders for Kit Motors and External Encoders	For kit motors or directly at the mechanical axis system, the following measuring systems, that can be evaluated in absolute form, can be used: • EnDat2.1 linear encoder (Heidenhain) or HIPERFACE® linear encoder [Stegmannn, IndraDrive-compatible types (DE_EN_FAQ_IndraDrive_unterstützte_Geber...) or encoders with "FF" type ID] for linear motors or linear axes • Rotary EnDat2.1 encoder (Heidenhain) or rotary HIPERFACE® [Stegmannn, IndraDrive-compatible types (DE_EN_FAQ_IndraDrive_unterstützte_Geber...) or encoders with "FF" type ID] for rotary kit motors or rotary axes
Establishing Axis-Related Absolute Distance	The actual position values of an absolute encoder first only relate to the encoder itself. Due to the mostly undefined mounting situation of the encoder at the motor or mechanical axis system, it is necessary to determine the position offset between encoder and axis zero point once at the initial commissioning (see also "Establishing the Position Data Reference: Establishing Position Data Reference for Absolute Measuring Systems").
Hardware Requirements	The signal specification of third-party encoders for position and homing signals with regard to amplitude and phase angle can be found in the documentation "Control Sections for Drive Controllers; Project Planning Manual".



Rexroth encoders comply with the required signal specification!

Pertinent Parameters	• S-0-0115, Position feedback 2 type • S-0-0277, Position feedback 1 type • S-0-0278, Maximum travel range • S-0-0378, Absolute encoder range of motor encoder • S-0-0379, Absolute encoder range of optional encoder • P-0-0019, Initial position value
-----------------------------	---

Relative Measuring Systems

Brief Description

Evaluating Position Measurement	IndraDrive controllers can evaluate the signals of both absolute and relative measuring systems, if the encoder signals correspond to the specification. The disadvantages of relative encoders as opposed to encoders that can be evaluated in absolute form are as follows: • Axes with relative position encoder must go through a homing procedure after switching on so that they can be operated in position control. • Relative encoders are unsuitable as motor encoders for synchronous motors because each time the drive is restarted it has to go through a procedure for setting the commutation offset. Therefore, the immediate readiness for operation is not guaranteed for synchronous motors! The advantages of relative encoders as opposed to encoders that can be evaluated in absolute form are as follows: • Longer travel distances are possible for linear encoders. • The costs of the encoder are mostly lower given equal absolute precision and number of lines or division period length.
--	---

Overview of the Scope of Functions

Aspects of Use	Due to the above disadvantages, relative measuring systems are not used as motor encoders for synchronous Rexroth housing motors. For asynchronous motors there aren't any disadvantages when using relative motor encoders. For kit motors it can be necessary, however, to use relative encoders as motor encoders if absolute encoders of the required design are not available: • Great encoder lengths for long travel distances in the case of linear motors • Hollow-shaft encoders with special drill diameters or encoders for high maximum speeds in the case of rotary kit motors
Establishing Axis-Related Absolute Distance	The actual position values of relative encoders first do not have any position reference. In any axis position the actual position value of the respective relative encoder, when switching the drive on, is written with the so-called initial position value, if no other encoder being in reference has been connected. There are two ways to establish the axis-related absolute distance: • Moving to a defined axis position with reproducible precision. - or - • Detecting a defined axis position by "passing" two distance-coded reference marks of the encoder. At a defined position, the actual position value of the encoder to be homed is written with the corresponding absolute value of the axis (see "Establishing the Position Data Reference: Establishing Position Data Reference for Relative Measuring Systems").
Hardware Requirements	The signal specification for position and homing signals with regard to amplitude and phase angle can be found in the documentation "Control Sections for Drive Controllers; Project Planning Manual".
Pertinent Parameters	• S-0-0115, Position feedback 2 type • S-0-0116, Resolution of feedback 1 • S-0-0117, Resolution of feedback 2 • S-0-0165, Distance-coded reference offset A • S-0-0166, Distance-coded reference offset B • S-0-0277, Position feedback 1 type • S-0-0440, Marker position feedback 1 • S-0-0441, Marker position feedback 2 • S-0-0442, Counter marker position feedback 1 • S-0-0443, Counter marker position feedback 2 • P-0-0019, Initial position value

Digital Encoders and Combined Encoders

Brief Description

Fields of Application

Digital encoders provide absolute position information within the absolute measuring range of the respective encoder. The signal transmission is serial. The main field of application of serial encoders in the electric drive technology is the position control loop; the advantage of the absolute position information outweighs the possible disadvantage of greater time intervals required to make actual values available due to the serial transmission of the absolute position. In many applications, particularly with master-side cycle times in the range of milliseconds, the quality of the actual position values made available by serial encoders is perfectly sufficient.

Overview of the Scope of Functions

For high quality motor control, the encoders that function serially are only suitable in certain cases because the provided position information must be as up-to-date as possible, i.e. it must be provided as quickly as possible.

For synchronous motors, however, the absolute serial encoder information is advantageous, because it allows the drive controller to unequivocally determine the commutation angle for motor control when the drive is switched on again. Therefore, the combination of a serial encoder with an incremental measuring system with analog encoder tracks (e.g. 1 Vpp) is the cost-efficient solution for an absolute measuring system (e.g. "combined encoder for SSI") for motor control, which uses standardized components. In this case, the absolute value of the SSI encoder is used for the commutation angle, the analog signals (e.g. sine encoder, 1 Vpp) are used for motor control.

SSI encoders cannot be evaluated as measuring encoders!

Features

The encoder signals are evaluated in accordance with an innovative encoder evaluation concept. This concept includes two levels for making available the actual position values of the encoder to be evaluated:

- Interface-related actual values of the encoder without function-related scaling or conversion. The index of the corresponding parameters (after the first point of the IDN) is the number of the device interface ("Basic evaluation").
- Function-related actual values, e.g. for motor control, such as motor velocity, actual position values of the motor shaft taking a possibly available encoder gearbox etc. into account. The corresponding parameters correspond to the parameters previously used, like for example "S-0-0040, Velocity feedback value", "S-0-0051, Position feedback value 1" etc. ("Extended evaluation").

Hardware Requirements

Both the serial encoder and the combined encoder require only one encoder interface at the device ["EC" for interface 1 (X4) or interface 2 (X8)]. It is possible to evaluate encoders with DC5V and DC12V supply.

Pertinent Parameters

Physical encoder data (for Basic evaluation)

IDN	Name
S-0-0602.x.01	Phys. Encoder type
S-0-0602.x.02	Phys. Encoder properties
S-0-0602.x.03	Phys. Encoder resolution (incremental)
S-0-0602.x.04	Phys. Encoder resolution (absolute)

Overview of the Scope of Functions

IDN	Name
S-0-0602.x.07	Phys. Encoder protocol configuration
The wild card "x" (structure index) is the number of the device interface to which the encoder is connected: 1: X4 (single-axis device), X4.1 (double-axis and multi-axis device) 2: X8 (single-axis device), X4.2 (double-axis and multi-axis device) 3: X10 (single-axis device), X8.1 (double-axis device), X4.3 (multi-axis device) 4: X4.4 (multi-axis device) 5: X8 (multi-axis device) 6: X8.2 (double-axis device)	

Parameters of encoder evaluation on Basic level

IDN	Name
S-0-0600.x.20	Encoder data out container
S-0-0601.x.01	Encoder data out configuration
S-0-0601.x.02	Resolution of position
S-0-0601.x.06	Absolute position range
S-0-0601.x.08	Command value set position
S-0-0601.x.09	Position zero point offset
S-0-0601.x.10	Overflow threshold position
S-0-0601.x.11	Encoder available data out
S-0-0601.x.12	Encoder refresh time data out
The wild card "x" (structure index) is the number of the device interface to which the encoder is connected: 1: X4 (single-axis device), X4.1 (double-axis and multi-axis device) 2: X8 (single-axis device), X4.2 (double-axis and multi-axis device) 3: X10 (single-axis device), X8.1 (double-axis device), X4.3 (multi-axis device) 4: X4.4 (multi-axis device) 5: X8 (multi-axis device) 6: X8.2 (double-axis device)	

Parameters for Extended encoder evaluation

IDN	Name
S-0-0610.x.2	Position unscaled (input)
S-0-0610.x.20	Encoder data out container (input)
S-0-0611.x.01	Encoder data out configuration (input)
S-0-0611.x.02	Resolution position (input)
S-0-0611.x.06	Absolute position range (input)
S-0-0611.x.10	Overflow threshold position (input)
S-0-0611.x.11	Encoder available data out (input)

Overview of the Scope of Functions

IDN	Name
S-0-0611.x.12	Encoder refresh time data out (input)
The number of the function is assigned to the wild card "x" (structure index) (motor encoder: "0"; optional encoder: "1")	

Establishing the Position Data Reference

General Information on Establishing the Position Data Reference

Brief Description

During the initial commissioning of a drive the actual position values transmitted by the measuring systems do not yet have any reference to the machine axis. This applies to

- Relative measuring systems and
- Absolute measuring systems

For more detailed information on relative and absolute evaluation of measuring systems, see "[Absolute Measuring Systems](#)"

Relative Measuring Systems

The position data reference of a relative measuring system to the axis has to be reestablished after each time the drive is switched on or after the position data reference is lost. For this purpose, it is necessary to move to a defined axis position and set the actual position value to an axis-related value at a defined position (exception: For relative encoders with distance-coded reference marks, movement is only required over two marks!)

Absolute Measuring Systems

The position data reference of an absolute measuring system to the axis has to be established once during initial commissioning after replacing the motor or encoder (motor encoder or external encoder) and changes in the mechanical axis system. The position data reference still is maintained and the actual position values are axis-related immediately after the drive is switched on.

Establishing the Position Data Reference, Drive-Controlled

For establishing the position data reference in a drive-controlled way, the position data reference is automatically established by the drive by master-side triggering of a command. The procedure depends on the kind of measuring system:

- In the case of a relative measuring system without distance-coded reference marks, the axis moves to the reference point or to a dedicated point and then automatically switches to axis-related actual position values.
- In the case of a relative measuring system with distance-coded reference marks, the axis moves between two reference marks and then automatically switches to axis-related actual position values.
- In the case of an absolute measuring system, the automatic switching to the axis-related actual position value is carried out with the axis in standstill.

The presettings for establishing the position data reference are made via assigned parameters.

Establishing the Position Data Reference, NC-Controlled

For establishing the position data reference in an NC-controlled way, the drive makes available three commands to the master. The master has to generate the travel motion for searching the mark:

- The master starts the "NC-controlled homing" command and, for searching the reference point or dedicated point, must move the axis by inputting command values.

Overview of the Scope of Functions

	To calculate the offset and switch to axis-related actual position values it is necessary to start further commands. The presettings for establishing the position data reference are made via assigned parameters.
Displaying the Position Data Reference	A position status parameter shows whether the position data reference of a measuring system evaluated by the controller has been established.
Motor Encoder and External Encoders	In addition to the motor encoder an external (optional) encoder can be available. Both encoders, in any combination of relative and absolute measuring systems, can - have position data reference to the axis independently of each other (both encoders have different actual position values) - or - - have position data reference to the axis depending on each other (both encoders have the same actual position values). This is configured via parameters and realized with the commands for establishing the position data reference.
Actual Position Value Offset	The difference of the actual position value before and after establishing the position data reference is displayed, related to the motor encoder or external encoder, in one parameter respectively. See also the following sections: "Establishing Position Data Reference for Absolute Measuring Systems" "Establishing Position Data Reference for Relative Measuring Systems"
Pertinent Parameters	- S-0-0115, Position feedback 2 type - S-0-0175, Offset parameter 1 - S-0-0176, Offset parameter 2 - S-0-0277, Position feedback 1 type - S-0-0403, Position feedback value status - P-0-0074, Encoder type 1 (motor encoder) - P-0-0075, Encoder type 2 (optional encoder) Establishing Position Data Reference for Absolute Measuring Systems Brief Description  Base package of all variants in closed-loop characteristic. See also the section "General Information on Establishing the Position Data Reference" The position data reference of an absolute measuring system to the axis has to be established once during initial commissioning, after replacing the motor or encoder (motor encoder or external encoder) and changes in the mechanical axis system.
Establishing Position Data Reference via Drive Commands	In the case of measuring systems to be evaluated in absolute form, the position data reference can be automatically established by the drive by starting the command "C0300Set absolute position procedure command" - or -

Overview of the Scope of Functions

Motor Encoder and External Encoder	• "C0600Drive-controlled homing procedure command". The position data reference once established is maintained until one of the two commands is started again. The actual position values therefore are axis-related ("homed") immediately after the drive is switched on. If two absolute measuring systems have been connected to the controller, the position data reference can be separately established for both measuring systems. If the position data reference was only set for one of the measuring systems, both actual position values are equal at the position at which the position data reference was established.
	 If the position data reference was only set for one encoder, the actual position values of both encoders remain equal as long as mechanical axis system and encoder systems are mechanically connected without slip (slip control is possible!).
"Set Absolute Position" Command	It is recommended to start the "set absolute position" command when the axis is in standstill without drive enable. In the cases in which the axis, for establishing the position data reference, is to be brought to a defined position on the master side and be held in this position by the drive, "set absolute position" can also be executed with the active drive.
"Drive-Controlled Homing Procedure" Command	When the command "C0600Drive-controlled homing procedure command" is started without an existing reference, the drive moves the axis independently as defined in parameter "S-0-0147, Homing parameter" and establishes the position data reference. If the drive's position system already has a reference when the command "C0600Drive-controlled homing procedure command" is started, the reference point already determined is approached and the commanded is acknowledged positively. For absolute encoders, the "drive-controlled homing procedure" command can be advantageously used after loss of position data reference after: • Encoder replacement in conjunction with a home switch or • Encoder error with peripheral causes in the case of modulo-scaled axes (e.g. encoder cable damage).
	 "Active drive" means the drive that is in control. Drive enable (AF) has been set.
Assigning the Axis-Related Actual Position Value with "Set Absolute Position"	By starting the "set absolute position" command, the previous actual position value of an encoder at a dedicated position of the axis is set to a new value. This value is the current axis position related to the coordinate system of the machine. The dedicated position is defined by: • the current axis position - or - • the positioning of the axis at a "striking" axis position (e.g. value "0"). The required assignments and configurations for "setting absolute position" are made via parameter settings.
Assigning the Axis-Related Actual Position Value with "Drive-Controlled Homing Procedure"	By starting the "drive-controlled homing procedure" command, the previous actual position value of an encoder at a dedicated position of the axis is set to a new value. This value is the current axis position related to the coordinate system of the machine. The required assignments and configurations for the "drive-controlled homing procedure" are made using parameter settings (see the information regarding

Overview of the Scope of Functions

- Pertinent Parameters**
- "[Drive-Controlled Homing Procedure](#)" in the section "Establishing Position Data Reference for Relative Measuring Systems").
- S-0-0052, Reference distance 1
 - S-0-0054, Reference distance 2
 - S-0-0148, C0600 Drive-controlled homing procedure command
 - S-0-0447, C0300 Set absolute position procedure command
 - S-0-0448, Set absolute position control
 - P-0-0177, Absolute encoder buffer 1 (motor encoder)
 - P-0-0178, Absolute encoder buffer 2 (optional encoder)
 - P-0-1002, Absolute encoder offset 1, encoder memory
 - P-0-1012, Absolute encoder offset 2, encoder memory

- Pertinent Diagnostic Messages**
- C0300 Set absolute position procedure command
 - C0301 Measuring system unavailable
 - C0302 Absolute evaluation of measuring system impossible
 - C0303 Absolute encoder offset cannot be saved
 - C0304 Command cannot be executed under drive enable
 - C0600 Drive-controlled homing procedure command
 - C0601 Homing only possible with drive enable
 - C0602 Distance home switch - reference mark erroneous
 - C0603 Homing impossible with optional encoder
 - C0606 Reference mark not detected
 - C0607 Reference cam input not assigned
 - C0608 Pos. stop a. HW lim. switch not allowed f. modulo axes
 - C0609 Different travel directions parameterized
 - C0610 Absolute encoder offset could not be saved

Establishing Position Data Reference for Relative Measuring Systems (Homing)**Brief Description**

Base package of all firmware variants in **closed loop** characteristic.

Actual Position Value of Relative Measuring Systems when Switching On

See also the section "[General Information on Establishing the Position Data Reference](#)"

After the drive is switched on the actual position values signaled by relative measuring systems do not yet have any reference to the machine axis. Measuring systems can be installed at the motor (motor encoder) and directly at the mechanical axis system (external or optional encoder).

For information on encoder arrangement and mechanical axis system see also "[Mechanical Axis System and Arrangement of Measuring Systems](#)"

The position data reference of relative measuring systems to the axis has to be established again each time after the drive was switched on or after all procedures that cause the position data reference to get lost (homing procedure).

Overview of the Scope of Functions

Establishing the Position Data Reference, Drive-Controlled	After start of the respective command by the master, the drive can automatically establish the position data reference. To do this, the drive moves the axis until the controller can detect a dedicated point. The actual position values then are automatically switched to axis reference. The presettings for the sequence for establishing the position data reference are made via assigned parameters.
Establishing the Position Data Reference, NC-Controlled	As an alternative to establishing the position data reference in a drive-controlled way, the NC ("master") can control the homing procedure. In this case, the master inputs the command values for moving the axis to the dedicated point and controls the homing procedure via commands and assigned parameters. The NC-controlled homing procedure can be advantageous for drives with a rigid mechanical connection (e.g. for Gantry axes), because the master can input coordinated command values for the drives for the homing motion.
Dedicated Point for Establishing the Position Data Reference	The dedicated point for establishing the position data reference, in the case of linear axes, is at one end of the travel range. This allows finding the dedicated point from any axis position (situation when switched on) by moving in a defined direction. Rotary axes do not have an axis end position, the dedicated point is at a defined position within the travel range.
Reference Mark for Relative Measuring Systems	The precision with which this dedicated point is detected considerably influences the absolute precision of the axis. Apart from the signals for position detection, relative measuring systems therefore also provide a signal for exact determination of a dedicated point. This signal is called "reference mark". Depending on their type, relative measuring systems have one or several reference marks over the range of measurement.
Reference Mark and Home Switch	Especially in the case of rotary measuring systems (e.g. motor encoder) at axes moved in a linear way, the reference mark of the encoder can occur several times over the entire travel range. In this case it is required, by axis-side activation of a switch contact at the end of the travel range, to identify one reference mark signal. This defines an unequivocal dedicated point that can be found with reproducible precision. This switch contact is called "home switch". A possibly available travel range limit switch can be used like a home switch, too. In addition, a reference mark signal can be identified by detecting axis blocking when positive stop at the end of the axis has been reached. Independent of the number of reference marks over the travel range, an axis-side additional device (home switch or travel range limit switches or positive stop), is indispensable for linear axes for detecting the axis end position! If only one reference mark occurs over the travel range in the case of rotary axes, the home switch in most cases is not required!
Dedicated Point and Reference Point of an Axis	The dedicated point identified by an encoder reference mark and, if necessary, by a home switch, in most cases is not identical to the reference point of the axis. The distance between reference point and zero point normally is determined on the machine side. Especially in the case of serial machines, this distance should be equal for axes of the same kind. The position of the dedicated point, however, is influenced by the kind of encoder arrangement and therefore differs from axis to axis.
Reference Offset	The position difference between dedicated point and reference point of the axis can be compensated by an offset value (reference offset). See also the section "General Information on Establishing the Position Data Reference"
Pertinent Parameters	Parameters for relative measuring systems:

Overview of the Scope of Functions

- S-0-0041, Homing velocity
- S-0-0042, Homing acceleration
- S-0-0052, Reference distance 1
- S-0-0054, Reference distance 2
- S-0-0108, Feedrate override
- S-0-0147, Homing parameter
- S-0-0148, C0600 Drive-controlled homing procedure command
- S-0-0150, Reference offset 1
- S-0-0151, Reference offset 2
- S-0-0173, Marker position A
- S-0-0174, Marker position B
- S-0-0191, C1500 Cancel reference point procedure command
- S-0-0298, Reference cam shift
- S-0-0299, Home switch offset
- S-0-0349, Bipolar jerk limit
- S-0-0400, Home switch
- S-0-0403, Position feedback value status
- P-0-0153, Optimum distance home switch-reference mark

Parameters for NC-controlled homing:

- S-0-0146 C4300 NC-controlled homing procedure command
- S-0-0171, C4400 Calculate displacement procedure command
- S-0-0172, C4500 Displacement to referenced system procedure command
- S-0-0175, Offset parameter 1
- S-0-0176, Offset parameter 2
- S-0-0404, Position command value status
- S-0-0407, Homing enable
- S-0-0408, Reference marker pulse registered

Parameters for relative measuring systems, distance-coded:

- S-0-0165, Distance-coded reference offset A
- S-0-0166, Distance-coded reference offset B
- S-0-0177, Absolute offset 1
- S-0-0178, Absolute offset 2

Parameters for homing at travel range limit switches:

- S-0-0532, Travel range limit parameter (alias: P-0-0090, Travel range limit parameter)
- P-0-0222, Travel range limit switch inputs

Parameters for homing at positive stop:

- S-0-0082, Torque/force limit value positive
- S-0-0083, Torque/force limit value negative
- S-0-0092, Bipolar torque/force limit value
- S-0-0124, Standstill window

Overview of the Scope of Functions

- S-0-0331, Status "n_feedback = 0"
- S-0-0333, Status "T >= Tx"

Pertinent Diagnostic Messages

Diagnostic messages for drive-controlled homing:

- C0600 Drive-controlled homing procedure command
- C0601 Homing only possible with drive enable
- C0602 Distance home switch - reference mark erroneous
- C0606 Reference mark not detected
- C0607 Reference cam input not assigned

Diagnostic messages for NC-controlled homing:

- C4302Distance home switch - reference mark erroneous
- C4304Homing impossible with absolute encoder
- C4306Reference mark not detected
- C4307Reference cam input not assigned
- C4308Pos. stop a. HW lim. switch not allowed f. modulo axes
- C4400Calculate displacement procedure command

Establishing Position Data Reference for Relative Measuring Systems, Drive-controlled Homing Procedure

Brief Description

Basic Sequence of "Search for Dedicated Point"

After "S-0-0148, C0600 Drive-controlled homing procedure command" has been activated, the drive for searching the dedicated point moves the axis according to the reference travel direction set in "S-0-0147, Homing parameter". When the controller has detected the position of the dedicated point, e.g. by reference mark detection of the encoder selected in S-0-0147, the position data reference of the actual position values to the axis can be established.

Determining the homing appropriate procedure for the existing axis type (settings in S-0-0147) ensures that during the search for the dedicated point the axis only moves within the allowed travel range!

For information on the actual position value after establishing the position data reference for motor encoder and external encoder, see the section "[General Information on Establishing the Position Data Reference](#)".

Establishing Position Data Reference for Relative Measuring Systems, NC-controlled Homing

Brief Description

Sequence of NC-Controlled Homing

For NC-controlled homing the master (NC control unit) controls the homing motion for searching the dedicated point of the axis. To do this, the master activates the parameter

- S-0-0146, C4300 NC-controlled homing procedure command

and presets the command value for axis motion, according to the active operation mode.

When the drive has detected the dedicated point, it informs the master of this fact and stores the position of the dedicated point. The master then completes the execution of command C4300 and afterwards activates the parameter

- S-0-0171, C4400 Calculate displacement procedure command.

Overview of the Scope of Functions

The required displacement of the actual position values is now calculated in the drive controller, in order to establish the reference of the actual position value to the axis zero point.

When the displacement required for establishing the position data reference has been determined, the master completes the execution of command C4400 and then activates the parameter

- S-0-0172, C4500 Displacement to referenced system procedure command.

Drive-internally the actual position value now is changed by the calculated absolute displacement value and thereby the reference of the actual position value to the axis zero point is established. The master has to adjust its command value input to the changed actual position value, before it completes the NC-controlled homing procedure by deactivating command C4500.

Shifting the Position Data Reference for Absolute/Relative Measuring Systems (Shift Coordinate System Procedure)

Brief Description

Fields of Application



Base package of all firmware variants in **open-loop** and **closed-loop** characteristic

The existing position data reference of the measuring systems to the axis can be shifted if the respective command was activated by the master. It is possible to shift the data reference in standstill or while the axis is moving. This does not affect the position reference of the axis because it is only the actual position values output for the master that are displayed in "shifted" form. Internally the original ("non-shifted") position data reference is maintained.

Shifting the position data reference affects the motor encoder and, if available, the external encoder, independent of which encoder is the active encoder for position control. If different actual position values are valid for the encoders (both encoders possibly have position data reference independent of each other), the actual position values of both measuring systems are shifted by the same difference.

Pertinent Parameters

- S-0-0197, C3300 Set coordinate system procedure command
- S-0-0198, Initial coordinate value
- S-0-0199, C3400 Shift coordinate system procedure command
- S-0-0275, Coordinate offset value
- S-0-0283, Current coordinate offset

Pertinent Diagnostic Messages

- C3300 Set coordinate system procedure command
- C3400 Shift coordinate system procedure command
- C0600 Drive-controlled homing procedure command

Detecting the Marker Position

Brief Description



Base package of all firmware variants in **closed loop** characteristic.

Overview of the Scope of Functions

With the "detect marker position" function, which is activated via the corresponding command, it is possible to check whether the reference mark of an incremental measuring system is detected without error.



A possibly available home switch is not evaluated with this function!

- | | |
|--------------------------------------|--|
| Pertinent Parameters | <ul style="list-style-type: none"> • S-0-0173, Marker position A • P-0-0014, C1400 Command Get marker position |
| Pertinent Diagnostic Messages | <ul style="list-style-type: none"> • C1400Command Get marker position |

5.3.6 Mechanical Axis System and Arrangement of Measuring Systems

Brief Description

Motor Encoder Controlled motor activation requires a position measurement system that measures the current rotor position or the position of the moving part as opposed to the static part of the motor.

This position measurement is required for the

- Current control loop
- Velocity control loop
- Position control loop, if applicable

The precision and resolution of the position measurement is decisive for the quality of the actual values, especially in the velocity and position control loop.

External Encoders Depending on the mechanical properties of the mechanical system between motor output shaft and machine axis, it might be required to carry out the position control by means of an external position encoder (not integrated in the motor) directly at the moving part of the axis, e.g. in the case of

- mechanical system with slip,
- gear backlash or a low degree of stiffness of the mechanical system, etc.

The external (optional) encoder can also be used as a measuring wheel encoder (frictionally engaged on transported material).

See "[Measuring Wheel Mode](#)"

For information on encoder evaluation and encoder monitoring see also "[Basics on Measuring Systems, Resolution](#)" and "[Monitoring the Measuring Systems](#)"

Motor Encoders of Rexroth Housing Motors

Rexroth housing motors have integrated position measuring systems:

- EnDat2.1 encoder with 2048 increments for high precision requirements
- HIPERFACE® encoder with 128 increments for lower precision requirements

They are optionally available as

- relative measuring system ("single-turn motor encoder")

or

- absolute measuring system ("multi-turn motor encoder", range of values ± 4096 motor revolutions).

The measuring systems of Rexroth housing motors support the commissioning, because the data for encoder type and resolution are stored in the encoder. They are loaded to the controller when the controller is switched on.

Overview of the Scope of Functions

Motor Encoders for Rexroth Kit Motors and Third-Party Motors

Rexroth kit motors are supplied as individual components and assembled in the machine to form the motor. It consists of a moving and a static part, the bearing and the motor encoder.

The following measuring systems can be used as a motor encoder:

- Incremental encoders with sine signals (compatible with signal specification of Heidenhain)
- Encoders with EnDat2.1 interface from Heidenhain
- Encoders with HIPERFACE® interface by Stegmann, [IndraDrive-compatible HIPERFACE® encoders (DE_EN_FAQ_IndraDrive_unterstützte_Geber...) or HIPERFACE® encoders with "0xFF" type ID].
- Incremental encoders with square-wave signals (compatible with signal specification of Heidenhain)



Do not use incremental encoders with square-wave signals as motor encoders. Bad drive characteristics are to be expected.

The mentioned measuring systems can be used as motor encoders for third-party kit motors and third-party housing motors.



For synchronous kit motors or synchronous third-party motors, it is recommended that the measuring system used as a motor encoder can be evaluated in absolute form so that the commutation offset of the motor must be determined only once (during initial commissioning) (see also "[Absolute Measuring Systems](#)").

Motor Encoders with Gearbox

Especially with rotary kit motors it is sometimes impossible to connect the motor encoder directly to the motor shaft. IndraDrive provides the possibility to evaluate a motor encoder connected via a gear.



For synchronous motors in combination with a motor encoder which can be evaluated in absolute form, the advantage of setting the commutation offset only once (see above) can only be used with an encoder gear with $i = 1$ or when there is no encoder gear available.

As of MPx16V04:

In two special cases, however, for synchronous motors with encoder gear and a motor that can be evaluated in absolute form (rotary encoders only) the commutation setting is performed only during initial commissioning. Then, when the drive is switched on again, it is immediately ready for operation; automatic commutation setting for initial drive enabling (AF) is not required, so it is not performed in the following cases:

Case 1, Single-turn (or multi-turn) encoder:

- if an n -fold motor revolution (n is an integer) yields exactly one encoder revolution

Case 2, Multi-turn encoder:

- if exactly one motor revolution yields an m -fold encoder revolution (m is an integer)

External Encoders at Machine Axes

IndraDrive controllers can evaluate the following measuring systems as external encoders:


Overview of the Scope of Functions

- Incremental encoders with sine signals (compatible with signal specification of Heidenhain)
- Encoders with EnDat2.1 interface from Heidenhain
- Encoders with HIPERFACE® interface by Stegmann, [IndraDrive-compatible HIPERFACE® encoders (DE_EN_FAQ_IndraDrive_unterstützte_Geber...) or HIPERFACE® encoders with "0xFF" type ID].
- Incremental encoders with square-wave signals (compatible with signal specification of Heidenhain)

Possibilities of Arranging Measuring Systems

The figure below shows an overview of arrangement possibilities of mechanical drive system and measuring systems.

Overview of the Scope of Functions



- 1) S-0-0051 or S-0-0053, depending on scaling (S-0-0076)
- S-0-0051 Position feedback 1 value
 - S-0-0053 Position feedback 2 value
 - S-0-0076 Position data scaling type
 - S-0-0115 Position feedback 2 type
 - S-0-0116 Resolution of feedback 1
 - S-0-0117 Resolution of feedback 2
 - S-0-0121 Input revolutions of load gear
 - S-0-0122 Output revolutions of load gear
 - S-0-0123 Feed constant
 - S-0-0277 Position feedback 1 type
 - P-0-0074 Encoder type 1 (motor encoder)
 - P-0-0075 Encoder type 2 (optional encoder)
 - P-0-0121 Gear 1 motor-side (motor encoder)
 - P-0-0122 Gear 1 encoder-side (motor encoder)
 - P-0-0124 Gear 2 load-side (optional encoder)
 - P-0-0125 Gear 2 encoder-side (optional encoder)
 - P-0-0123 Feed constant 2 (optional encoder)
 - P-0-0185 Control word of encoder 2 (optional encoder)

Fig. 5-17: Overview of Arrangement Possibilities of Mechanical Drive System and Measuring Systems

Hardware Requirements

For connecting the measuring systems to the controller there are 2 optional interfaces available. The parameters "P-0-0077, Assignment motor encoder->optional slot" and "P-0-0078, Assignment optional encoder->optional slot" define the interface to which the respective encoder is connected.

Pertinent Parameters

- S-0-0115, Position feedback 2 type
- S-0-0121, Input revolutions of load gear

Overview of the Scope of Functions

- S-0-0122, Output revolutions of load gear
- S-0-0123, Feed constant
- S-0-0277, Position feedback 1 type
- P-0-0121, Gear 1 motor-side (motor encoder)
- P-0-0122, Gear 1 encoder-side (motor encoder)
- P-0-0123, Feed constant 2 (optional encoder)
- P-0-0124, Gear 2 load-side (optional encoder)
- P-0-0125, Gear 2 encoder-side (optional encoder)
- P-0-0185, Control word of encoder 2 (optional encoder)

5.3.7 Scaling of Physical Data

Brief Description

The controller via data maps the drive to an internal mathematical model. The status variables of the drive are determined on the basis of the following measurements:

- Position measurement
- Current measurement
- Temperature measurement

The measured values collected in this way are converted into physical data:

- Position, velocity, acceleration and jerk data
- Current data, torque and force data
- Temperature data and load data

The master transmits command values to the drive that are used by the controller for transforming them at the motor output shaft or mechanical axis system. The drive in return registers and transmits actual values, signals operating and command states and, if necessary, generates error messages and warnings.

Communication between drive and master also takes place by exchanging data.

Scaling An operating data (numeric value) can only be evaluated as a physical value, when the numeric value is connected to a physical unit and the position of the decimal point (decimal places). The data thereby is "scaled" in a qualitative and quantitative way.

Parameters All data are stored in parameters and transmitted as parameter values (for explanations regarding parameters see "[Parameters, Basics](#)"). The scaling of the parameters containing data of the following physical values can be defined by the customer:

- Position
- Velocity
- Acceleration
- Torque/force
- Temperature

Preferred Scaling/Parameter Scaling

To simplify the scaling definition so-called "preferred scalings" were predefined. Physical data, however, can also be exchanged in the control-internal format, i.e. without specific reference to physical units. For this purpose, the scaling for certain data can be freely set ("parameter scaling").

Overview of the Scope of Functions

Linear and Rotary Data Depending on the kind of motion of motor or load, the data can be displayed as follows:

- In linear form (linear axis or motor motion)

- or -

- In rotary form (rotary axis or motor motion)

Motor Reference/Load Reference In the drive firmware there are mechanical transfer elements between motor and load mapped by means of mathematical models. The physical data can thereby be referred to

- the point where the load takes effect (load-side data reference)

- or -

- the point where the force is input (motor-side data reference).

Absolute/Modulo Evaluation For technical reasons, the value range of the position data the controller can display is limited.

For axes with limited travel range (e.g. linear axes), the current axis position within the controller-side value range can be unambiguously displayed (see ["Basics on Measuring Systems, Resolution"](#)).

For axes with an unlimited travel range (e.g. rotary axes), it is useful to limit the infinite value range of the position data to a finite value. With continuous motion, the value range is recurrently run from minimum to maximum value ("modulo" evaluation of the actual position value).

- Pertinent Parameters**
- S-0-0043, Velocity polarity parameter
 - S-0-0044, Velocity data scaling type
 - S-0-0045, Velocity data scaling factor
 - S-0-0046, Velocity data scaling exponent
 - S-0-0055, Position polarities
 - S-0-0076, Position data scaling type
 - S-0-0077, Linear position data scaling factor
 - S-0-0078, Linear position data scaling exponent
 - S-0-0079, Rotational position resolution
 - S-0-0085, Torque/force polarity parameter
 - S-0-0086, Torque/force data scaling type
 - S-0-0093, Torque/force data scaling factor
 - S-0-0094, Torque/force data scaling exponent
 - S-0-0103, Modulo value
 - S-0-0121, Input revolutions of load gear
 - S-0-0122, Output revolutions of load gear
 - S-0-0123, Feed constant
 - S-0-0160, Acceleration data scaling type
 - S-0-0161, Acceleration data scaling factor
 - S-0-0162, Acceleration data scaling exponent
 - S-0-0208, Temperature data scaling type

5.4 Drive Control

5.4.1 Overview of Drive Control

Brief Description

Basic Principles and Terms

The IndraDrive firmware supports the following two basic principles of drive control:

- **Open-loop axis control** (V/Hz [U/f] control)
 - Open-loop-controlled operation without encoder information
- **Closed-loop axis control** (various methods of control)
 - **With** encoder feedback
 - Closed-loop-controlled operation (position, velocity and current)
 - **Without** encoder feedback
 - Closed-loop-controlled operation with motor model (velocity and current)



When selecting the functional packages, take the desired method of control into account as you have to choose between open-loop and closed-loop base package!

Operation mode / command value adjustment	Control mode	Functional principle of motor	Encoder available	Required base package	Method of control
V/Hz (U/f) control with command value adjustment of the velocity control	Voltage-controlled operation	Asynchronous	Yes	Closed-loop	Not relevant
			No	Open-loop	V/Hz (U/f) control
Torque/force control	Field-oriented current control	Asynchronous	Yes	Closed-loop	FOC control
			No	--	No method available
		Synchronous	Yes	Closed-loop	FOC control
			No	--	No method available
Velocity control / velocity synchronization	Velocity Control	Asynchronous	Yes	Closed-loop	FOC control
			No	Open-loop	FXC control ¹⁾
		Synchronous	Yes	Closed-loop	FOC control
			No	Closed-loop	FOCsl control

Overview of the Scope of Functions

Operation mode / command value adjustment	Control mode	Functional principle of motor	Encoder available	Required base package	Method of control
Position control, drive-controlled positioning, positioning block mode, phase synchronization, electronic Cam	Position Control	Asynchronous	Yes	Closed-loop	FOC control
			No	Closed-loop	FXC control ²⁾
		Synchronous	Yes	Closed-loop	FOC control
			No	Closed-loop	FOCsl control

- 1)
- Although the „Open-Loop“ functional base package of the firm-ware is required, the drive control works in closed-loop operation.
- 2)
- Only with external encoder

Tab. 5-41: Overview: Operation Modes and Available Control Methods

See also the section ["Overview of Functions/Functional Packages"](#)

Principles of Drive Control

Overview of Open-Loop Axis Control

Open-loop axis control (or "open-loop operation") allows open-loop-controlled operation of the drive without motor encoder (V/Hz [U/f] control).

The primary operation mode "velocity control" is configured, but only the command value processing specific to this operation mode takes effect. Closed-loop control (position and velocity) and functions and operation modes depending thereof are not possible.

See ["Voltage-Controlled Open-Loop Operation \(V/Hz \[U/f\] Control\)"](#)




Fig. 5-18: Principle of Open-Loop Drive Control (Open-Loop Operation)

See also the section ["Closed-Loop Axis Control \(Closed-Loop Operation\)"](#)

See also the section ["Overview of Functions/Functional Packages"](#)

Overview of Closed-Loop Axis Control



The base package "Closed-Loop" also contains the functions of the base package "Open-Loop".

Closed-loop axis control (or "closed-loop operation") allows closed-loop-controlled operation of the drive; two principles of drive control are distinguished:

Overview of the Scope of Functions

- **Operation with encoder**

The velocity control loop and the position control loop are closed by means of the encoder feedback so that the following operation modes are supported by field-oriented current control with encoder feedback:

- Velocity Control
- Position control with cyclic command value input
- [Positioning modes](#) (drive-controlled positioning, positioning block mode)
- Synchronization modes

- **Sensorless operation**

The velocity control loop is closed by means of a motor model (monitor) so that field-oriented current control without encoder feedback supports velocity control without encoder.

See the section "[Field-Oriented Current Control](#)"




Fig. 5-19: Principle of Closed-Loop Drive Control (Closed-Loop Operation)

See also the section "[Open-Loop Axis Control \(Open-Loop Operation\)](#)"

See also the section "[Overview of Functions/Functional Packages](#)"

Control Loop Structure

General Information

The drive controller has a so-called cascade structure, i.e. the individual controllers (position, velocity and current) are interconnected in cascaded form. Depending on the active operation mode, only the torque/force control loop, the torque/force control loop and the velocity control loop or, in addition to these two control loops, the position control loop are closed in the drive.

Torque/force control The "torque/force control" mode actually isn't torque or force control but current control. Therefore, only the current control loop is closed in the drive.

See also "[Torque/Force Control](#)"

Velocity Control In the "velocity control" mode, the velocity control loop, apart from the current control loop, is closed in the drive, too.

See also "[Velocity Control](#)"

Position Control For the following position control modes, the position control loop, apart from the current and velocity control loops, is closed internally (in the drive):

- [Position control with cyclic command value input](#)
- [Drive-internal interpolation](#)


Overview of the Scope of Functions

- Positioning modes (drive-controlled positioning, positioning block mode)

See also description of the respective operation mode

The figures in the following two paragraphs contain an overview of the structure and the interaction of the control loops (distinguished according to the illustration of the setting parameters and the display parameters).

Control Loop Structure with Setting Parameters




T_A Sampling times (see table in the section "Features of the Control Loops")

Fig. 5-20: Overall Structure of the Control Loops with Points at which the Setting Parameters Take Effect (Example for Field-Oriented Control with Encoder)

Overview of the Scope of Functions

Control Loop Structure with Display Parameters



T_A Sampling times (see table in the section "Features of the Control Loops")

Fig. 5-21: Overall Structure of the Control Loops with Display Parameters (Example)

Features of the Control Loops

Performance (Controller Cycle Times)

The internal controller cycle times (current, velocity and position) depend on the following conditions and parameters:

- Activation of the functional packages
- P-0-0001, Switching frequency of the power output stage
- P-0-0556, Config word of axis controller (bit 2)

Depending on these factors, the following cycle and switching times can be achieved:

	MPE	MPB	MPM
PWM switching frequency	Max. 8 kHz	Max. 16 kHz	Max. 8 kHz
Position controller clock ($T_{A_position}$)	1000 μ s	250 μ s	500 μ s

Overview of the Scope of Functions

	MPE	MPB	MPM
Velocity controller clock ($T_{A_velocity}$)	500 μ s	125 μ s	250 μ s
Current controller clock ($T_{A_current}$)	125 μ s	62.5 μ s	125 μ s

Tab. 5-42: Cycle and Switching Times to be Achieved with IndraDrive



All performance data are summarized under "System Overview: [Performance Data](#)".

Current controller

The current controller is characterized by the following features:

- PI controller for d-axis and q-axis of the field-oriented d-q coordinate system (S-0-0106, S-0-0107)
- Inductance feedforward for decoupling d-axis and q-axis (P-0-4017, P-0-4016) for synchronous motors
- Inductance characteristic for adjusting the current loop parameters in the case of saturation phenomena
- Precontrol of e.m.f.

Velocity controller

The velocity controller is characterized by the following features:

- PI controller that can be set via the following parameters: "S-0-0100, Velocity loop proportional gain", S-0-0101, Velocity loop integral action time
- Standardization of the output value at the velocity controller to Newton (N) or Newton meter (Nm); therefore, depending on the motor type, the following unit results for the parameter "S-0-0100, Velocity loop proportional gain":
 - Rotary motor $\rightarrow$ Nm * s/rad
 - Linear motor $\rightarrow$ N * min/mm
- Filter options for filtering encoder noise and resonance frequencies are available
 - A first order filter (first order low-pass), can be parameterized via P-0-0004
 - Four second order filters (second order low-pass, band-stop filter, second order filter), can be activated via P-0-1120 with the setting parameters (P-0-1121), P-0-1122, P-0-1123, P-0-1140, P-0-1141, P-0-1143



In firmware variant MPE, only two second order filters are available.

- Acceleration feedforward can be set in parameter "P-0-1126Velocity control loop: Acceleration feedforward"
- Option to mix the actual velocity value used for control from the actual value of the motor-side and load-side encoder using a "mix factor" "P-0-1119Velocity mix factor feedback 1 & 2"
- Limitation of command acceleration (velocity command value modification) in velocity control by setting in parameter "S-0-0138, Bipolar acceleration limit value"

Overview of the Scope of Functions

- Limitation of the command velocity using parameters
 - S-0-0113, Maximum motor speed
 - S-0-0038, Positive velocity limit value
 - S-0-0039, Negative velocity limit value
 - S-0-0091, Bipolar velocity limit value
 - P-0-0113, Bipolar velocity limit value of motor

See also "[Velocity Controller \(with the Respective Filters\)](#)"

Position Controller

The position controller is characterized by the following features:

- P controller, can be set using "S-0-0104Position loop Kv-factor"
- Velocity feedforward (degree of feedforward) can be set in parameter "P-0-0040, Velocity feedforward evaluation" (0 %...100 %)
- Acceleration feedforward can be set in parameter S-0-0348
- For control, the actual value of the motor encoder or of the optional encoder can be used as the actual position value. It is possible, however, to use both actual position values for position control ("hybrid actual position value").

See also "[Position Controller \(with Respective Feedforward Functions and Actual Value Adjustment\)](#)"

5.4.2 Motor Control

General Information on Motor Control

Overview of Motor Control Methods

Classification of Motor Control Methods

There are different methods available to control the motor; the main difference between these methods is the fact whether a motor encoder is required or not.

Motor Control with Motor Encoder

Motor control with position feedback via a motor encoder (field-oriented current control → FOC) is the highest-quality method of motor control providing the best control performance. It can be used for synchronous and asynchronous motors and, within the precision and performance of motor and controller determined by the hardware, allows unrestricted motor operation in the following operation modes:

- Position control modes
- Velocity Control
- Torque/force control

Motor Control without Motor Encoder

For sensorless motor control, there are different model-based methods available for synchronous and asynchronous motors.

- For asynchronous motors:
 - Voltage-Controlled Open-Loop Operation (V/Hz [U/f] Control)
 - Flux-Controlled Operation (FXC)
- For synchronous motors
 - Flux-Controlled Operation (FXC)

Regarding the possible operation modes when using these methods, observe the following restrictions:

Overview of the Scope of Functions

- Position control modes (positioning) are possible with sensorless synchronous and asynchronous motors in flux-controlled operation (FXC) in connection with an external encoder. In these cases, generally take the performance losses into account!
- Velocity control, too, can only be used with performance losses!



Torque/force control cannot be used for motor control without motor encoder!

Motor Control Method and Functional Principle of Motor

Make sure that the requirements regarding functional principle of motor and motor encoder have been fulfilled for specified motor control mode. The table below contains an overview for selecting the method.

Motor encoder?	Functional principle of motor	Motor control method	Specific information for use	Possible operation modes
With Motor Encoder	Synchronous motor Asynchronous motor	FOC	Parallel operation of linear motors MLF is possible!	Position control modes Velocity Control Torque/force control
Without Motor Encoder	Asynchronous motor	FXC	Only single-motor operation!	Position control modes Velocity Control
		V/Hz (U/f) control	Parallel operation of motors is possible!	Velocity Control
Without Motor Encoder	Synchronous motor	FXC	Only single-motor operation!	Position control modes Velocity Control

Tab. 5-43: Overview of Motor Operation with and without Motor Encoder

See also "[Overview of Drive Control](#)"

Field-Oriented Current Control with Motor Encoder (FOC)

Features and Use

Field-oriented current control with position feedback via motor encoder (FOC) is characterized by the following features:

- Highest-quality method of motor control
→ To be used when there are high demands on the quality of control and the dynamic response!
- Can be used for synchronous and asynchronous motors

Operation Modes with FOC

Within the hardware-side precision and performance of motor and controller, field-oriented current control with position feedback via motor encoder allows unrestricted motor operation in the following operation modes:

- Position control modes
- Velocity Control
- Torque/force control

See the main section "[Field-Oriented Current Control \(FOC Control\)](#)"

Model-Based Current Control without Motor Encoder (FXC)

Features and Use

Model-based current control without motor encoder is characterized by the following features:

- Cost-saving motors, compared to the FOC method, can be used, as no motor encoder is required (however, performance losses)

Overview of the Scope of Functions

	Flux-controlled method (FXC) can be used without motor-specific restrictions
Operation Modes with FXC	Current control without motor encoder allows using the following operation modes: - Velocity control (only suited for single motors, parallel operation of motors is not possible) - Position control modes possible with external encoder  Torque/force control cannot be used for sensorless (model-based) motor control! See the main section "Sensorless Motor Operation, Flux-Controlled (FXC Control)"
	Voltage-Controlled Open-Loop Operation (V/Hz [U/f] Control)
Features and Use	Voltage-controlled motor operation without motor encoder is characterized by the following features: - Cost-saving motors, compared to the FOC method, can be used, as no motor encoder is required (however, performance losses) - Can only be used for asynchronous motors - Linear or square V/Hz (U/f) characteristic can be selected
Operation Mode with V/Hz (U/f) Control	For voltage-controlled operation without motor encoder, only the "velocity control" mode with the following features can be used: - Parallel operation of motors is possible - Adjustment of motor control to velocity-proportional increase in load (e.g. with fans) by adjusted ("square") V/Hz (U/f) characteristic to reduce the motor losses - Performance losses compared to velocity control with motor encoder  Torque/force control and position control modes cannot be used for voltage-controlled operation without motor encoder! See the main section "Voltage-Controlled Open-Loop Operation (V/Hz [U/f] Control)"
	Notes on Selection of Motor Control Method
Motor Control Performance	The performance of motor control significantly depends on the type of control section including the corresponding firmware, as well as on the PWM frequency of the power output stage which has been set.  An overview of the performance to be achieved and the clock rates depending on control section design and parameter settings is contained in the section "Performance Data".
Selection Criteria	The following criteria have to be taken into account when selecting the appropriate motor control method:

Overview of the Scope of Functions

Motor type	Motor encoder available?	Parallel connection of motors?	Motor control method	Notes on use
Synchronous motor	No	No	FOC	For standard applications with medium demands on quality of control and dynamic response
	Yes	Rotary: No Linear: Yes ¹⁾		For standard applications with high demands on quality of control and dynamic response
Asynchronous motor	No	No	FXC	For standard applications with medium demands on quality of control and dynamic response
		Yes	V/Hz (U/f) control	For standard applications with low demands on quality of control and dynamic response
	Yes	No	FOC	For standard applications with high demands on quality of control and dynamic response

1) Observe mechanical orientation according to motor data

Tab. 5-44: Basic Selection Criteria for the Motor Control Method

See also "[Overview of Drive Control](#)"

Operating Properties for Control of Synchronous Motors

Observe the following differences for controlling synchronous motors in operation with and without motor encoder:

Motor characteristic		FOC	FXC
Speed working ranges	Basic speed range	Yes	Yes
	Field weakening range	Yes	Yes
Supported operation modes	Torque/force control	Yes	No
	Velocity control (incl. synchronization)	Yes	Yes (with restrictions)
	Position control/positioning (incl. synchronization)	Yes	Yes (with restrictions, external encoder required)
Torque limitation		Yes	Yes
Maximum torque		High	Medium
Dynamic response		High	Medium to high
Running smoothness/speed quality		High (depending on measuring system, motor type, mechanical system)	Medium to high
Torque ripple		Low (< ± 5%)	Medium to high
Required accuracy of the motor parameters		Low	Medium to high

Overview of the Scope of Functions

Motor characteristic	FOC	FXC
Robustness	High	Medium
Sensitivity against disturbances	Low	Medium
Validity (availability) of the position information	Absolute encoder: in PM + OM	Depending on load-side encoder type used
	Relative encoder: in OM	

PM
OM

Parameter mode
Operating mode

Tab. 5-45:

Comparison of Motor Control without Encoder and with Encoder for Synchronous Motors

Operating Properties for Control of Asynchronous Motors

Observe the following differences for controlling asynchronous motors as regards operation with and without encoder:

Motor characteristic		FOC	FXC	V/Hz (U/f) control
Speed working ranges	Basic speed range	Yes	Yes	Yes
	Field weakening range	Yes	Yes	Yes
Supported operation modes	Torque/force control	Yes	No	No
	Velocity control (incl. syn- chronization)	Yes	Yes (with restrictions)	Yes (with restrictions)
	Position control/positioning (incl. synchronization)	Yes	Only with external position encoder	No
Torque limitation		Yes	Yes	No (only stall protection controller)
Maximum torque		High	Medium	Low
Dynamic response		High	Medium	Low
Running smoothness/speed quality		High (depending on measur- ing system, motor type, mechanical system)	Medium	Low
Torque ripple		Low (< ± 5%)	High	High
Required accuracy of the motor parameters		Low	Low	High, if high perform- ance must be reached
Robustness		High	Medium	Low
Sensitivity against disturbances		Low	High	High
Validity (availability) of the position information		Absolute encoder: in PM + OM	Depending on load-side encoder type used	Not available
		Relative encoder: on- ly in OM		

PM
OM

Parameter mode
Operating mode

Tab. 5-46:

Comparison of Motor Control without Encoder and with Encoder for Asynchronous Motors

Overview of the Scope of Functions

Motor Control Frequency

Brief Description

General Information

The speed of three-phase a.c. motors depends on the frequency of the voltage applied at the motor. The maximum possible frequency of the motor voltage provided by the controller depends on the PWM frequency with which the power output stage is controlled (clocked).

PWM frequency in Hz	Max. motor control frequency in Hz	
Value in P-0-0001	Static PWM ^{*)}	Dynamic PWM
2000	200	--
4000	400	665
8000	800	1330
12000	1200	2000
16000	1600	2660

^{*)} See also "Supply Units and Power Sections, Project Planning Manual"

Tab. 5-47: PWM Frequency Settings and Maximum Motor Control Frequency with Static and Dynamic PWM

Note on Dimensioning



The required PWM frequency must be observed when selecting the controller because the continuous controller current is affected by the PWM frequency setting:

- Due to continuous controller current, select the lowest possible PWM frequency
- Due to motor control frequency, select a PWM frequency that is only as high as necessary

Advantageous Behavior

Due to the continuous current reduction with PWM frequencies greater than 4 kHz, the controller can set the most advantageous PWM frequency automatically depending on the required motor control frequency.

Availability

Depending on the control section design, the following PWM frequencies are available:

Device/firmware or Control section/Firmware	Available PWM frequencies / Hz	Programmable PWM or vel.-dep. most advantageous PWM
IndraDrive-Cs with MPE firmware	4000	No
CDB02.1 with MPM FWA	8000	No
IndraDrive-Cs with MPB/MPC firmware	2000	No
	4000	Yes ^{*)}
CSB02.1 with MPB FWA	8000	Yes
CSH02.x with MPC FWA	12000	Yes
	16000	Yes

^{*)} Not for MPB with "Advanced" performance

Tab. 5-48: Hardware and Firmware Dependencies of the PWM Frequency

Pertinent Parameters

- P-0-0001, Switching frequency of the power output stage

Overview of the Scope of Functions

- P-0-0045, Control word of current controller
- Pertinent Diagnostic Messages** The switching of the PWM frequency is displayed in the respective bit of "P-0-0046, Status word of current controller".

Voltage-Controlled Open-Loop Operation (V/Hz [U/f] Control)

Brief Description

The drive function "voltage-controlled open-loop operation of asynchronous motors without encoder in V/Hz (U/f) control" is made available in the "open-loop" base package in the "velocity control" mode. When the expansion package "synchronization" has been enabled, the operation mode "velocity synchronization with real/virtual master axis" is additionally available.




Fig. 5-22: Principle of V/Hz (U/f) Control

V/Hz (U/f) motor control is characterized by the following features or core functions:

- Features**
- Monitoring and **limitation** of the maximum **stator frequency slope** that results from the command velocity change
 - **Stall protection controller** (PI controller that can be optionally activated to prevent breakdown of the machine when the torque limits are attained)
 - **Slip compensation** (feedforward of estimated slip of the machine by means of slip compensation factor)
 - Calculation of output voltage by means of **V/Hz (U/f) characteristic** based on motor model data
 - Subsequent trimming of magnetization via premagnetization factor, as well as linear or square characteristic to be selected
 - **IxR boost** (adjustable load-dependent feedforward of the output voltage due to the voltage drop on the motor winding resistance)
 - **Oscillation damping** (adjustable load-dependent feedforward to prevent velocity oscillations in the partial load and idling ranges)
 - **D.C. braking** to reach standstill more quickly
 - User-side **torque/force limitation** via enabled stall protection controller
 - **Velocity search mode** of a coasting machine after switching drive enable on (can be set for the preset rotational direction or both rotational directions)

- Pertinent Parameters**
- S-0-0040, Velocity feedback value

Overview of the Scope of Functions

- S-0-0106, Current loop proportional gain 1
- S-0-0107, Current loop integral action time 1
- P-0-0043, Torque-generating current, actual value
- P-0-0044, Flux-generating current, actual value
- P-0-0045, Control word of current controller
- P-0-0046, Status word of current controller
- P-0-0048, Effective velocity command value
- P-0-0063, Torque-generating voltage, actual value
- P-0-0064, Flux-generating voltage, actual value
- P-0-0065, Absolute voltage value, actual value
- P-0-0440, Actual output current value (absolute value)
- P-0-0442, Actual value torque limit positive (stationary)
- P-0-0443, Actual value torque limit negative (stationary)
- P-0-0532, Premagnetization factor
- P-0-0556, Config word of axis controller
- P-0-0568, Voltage boost
- P-0-0569, Maximum stator frequency slope
- P-0-0570, Stall protection loop proportional gain
- P-0-0571, Stall protection loop integral action time
- P-0-0572, Slip compensation factor
- P-0-0573, IxR boost factor
- P-0-0574, Oscillation damping factor
- P-0-0575, Search mode: Search current factor
- P-0-0576, Search mode: Finding point slip factor
- P-0-0577, Square characteristic: Lowering factor
- P-0-0578, Current for deceleration, absolute value
- P-0-0579, Current for deceleration, time period
- P-0-4036, Rated motor speed
- P-0-4046, Effective peak current

Pertinent Diagnostic Messages

- E8040 Torque/force actual value limit active
- E8041 Current limit active
- E8260 Torque/force command value limit active

Field-Oriented Current Control (FOC Control)

Brief Description



Base package of all firmware variants in **closed-loop** characteristic

Overview of the Scope of Functions



The current controller was preset for all Rexroth motors and the parameter values have been stored in the motor encoder data memory or in the commissioning tool ("IndraWorks Ds/D/MLD", "DriveTop").


For information regarding the commissioning of the current controller for third-party motors, see "[Third-Party Motors at IndraDrive Controllers](#)".

Principle of Field-Oriented Current Control

In the case of field-oriented current control, the internal control task consists in generating the transformed currents I_d and I_q in controlled form:

- I_d (flux-generating current) → PI controller for I_d
- I_q (torque-generating current) → PI controller for I_q

The figure below illustrates the principle of field-oriented current control for operation with motor encoder:



v-ctrl Velocity controller
I-ctrl Current controller

Fig. 5-23: Simplified Schematic Diagram for Field-Oriented Current Control with Higher-Level Velocity Control

Working Ranges

Field-oriented current control of asynchronous and synchronous motors allows operation in the entire speed range.

The speed range is divided into the following working ranges:

- Basic speed range → **constant torque**
- Field weakening range 1 → **constant power**
- Field weakening range 2 → **power limit range**

General Features

Field-oriented current control has the following general features:

- Control of the motor current according to the principle of field orientation, i.e. separate control of the torque-generating current and the flux-generating current
- Compensation of the cross coupling of the d and q axes to increase dynamics
- Voltage controller for operation in the field weakening range
- Activation of the optimum current controller proportional gain value, depending on the current PWM frequency when loading the default values (motor-specific controller values)

Features of Synchronous Motor Control

In the case of **synchronous motors**, field-oriented current control additionally has the following features:

Overview of the Scope of Functions

Features of Asynchronous Motor Control

- Limitation of the I_q command value at the voltage limit for protection against too little control margin
- Utilization of the reluctance effect to increase the available torque in the basic speed range
- Support of synchronous motors with reluctance torque, i.e. motors with significantly different inductances in the d and q axes

In the case of **asynchronous motors**, field-oriented current control has the following features in addition to the general features:

- Optimum torque linearity, even in the field weakening range, by:
 - Permanent correction of the torque constant and the slip factor by means of the currently calculated rotor flux
 - Rotor flux model taking temperature and saturation behavior of the magnetizing inductance into account
- Improved dynamic behavior by:
 - Voltage- and load-dependent flux feedforward
 - Voltage controller for correcting the flux feedforward
 - Flux controller for dynamically generating the rotor flux
- Possibility of reducing the magnetizing current for low-loss operation at no load or in partial load range

Pertinent Parameters

Current controller setting:

- S-0-0106, Current loop proportional gain 1
- S-0-0107, Current loop integral action time 1
- P-0-0001, Switching frequency of the power output stage
- P-0-0045, Control word of current controller
- P-0-4002, Charact. of quadrature-axis induct. of motor, inductances
- P-0-4003, Charact. of quadrature-axis inductance of motor, currents

Voltage controller setting:

- P-0-0533,
- P-0-0534, Voltage loop integral action time
- P-0-0535, Motor voltage at no load
- P-0-0536, Maximum motor voltage

Rotor flux control for asynchronous motors:

- P-0-0528, Flux control loop proportional gain
- P-0-0529, Scaling of stall current limit
- P-0-0530, Slip increase
- P-0-0532, Premagnetization factor

Power monitoring:

- S-0-0158, Power threshold P_x
- S-0-0337, Status " $P \geq P_x$ "
- S-0-0382, DC bus power

Display parameters:

- S-0-0380, DC bus voltage
- P-0-0046, Status word of current controller
- P-0-0063, Torque-generating voltage, actual value

Overview of the Scope of Functions

- P-0-0064, Flux-generating voltage, actual value
 - P-0-0065, Absolute voltage value, actual value
- Pertinent Diagnostic Messages**
- C0132 Invalid settings for controller cycle times
 - E8025 Overvoltage in power section
 - E8028 Overcurrent in power section
 - F2077 Current measurement trim wrong
 - F8060 Overcurrent in power section

Sensorless Motor Operation, Flux-Controlled (FXC Control)

Brief Description



Base package of all firmware variants in **open-loop** and **closed-loop** characteristic, except MPE-18VRS.

For asynchronous and synchronous motors, flux-controlled, sensorless motor operation is available in the base packages "open-loop" and "closed-loop" of all firmware variants and can be used in the "velocity control" mode and in position-controlled operation modes which use position encoder 2 (external encoder).

When using the firmware expansion package "synchronization", you can also run the operation mode "velocity synchronization with real/virtual master axis".




Fig. 5-24: Principle of Sensorless, Flux-Controlled Motor Operation

- Features**
- Limitation of the maximum **stator frequency slope** that results from the command velocity change
 - "Stable" motor operation
 - To maintain the maximum possible torque
 - **Slip compensation** for asynchronous motors (estimated motor slip taken into account for calculating actual velocity value)
 - To minimize the stationary speed deviations, due to slip, from the command value when the asynchronous motor is loaded
 - Motor speed does not tend to oscillation in operation at partial load and no-load operation

Overview of the Scope of Functions

	• Velocity search mode of a coasting asynchronous motor after switching drive enable on • Possibility of taking user-side torque/force limitation into account
Pertinent Parameters	Motor control parameters of sensorless, flux-controlled motor operation: • P-0-4033, C3200 Command Calculate motor data • P-0-0532, Premagnetization factor • P-0-0565, C3600 Command Motor data identification • P-0-0578, Current for deceleration, absolute value • P-0-0579, Current for deceleration, time period • P-0-0580, Motor frequency • P-0-0594, FXC: Total flux loop integral action time • P-0-0595, Frequency loop proportional gain (FXC) • P-0-0596, FXC: Frequency loop scaling factor of inertia • P-0-0597, FXC: Current loop proportional gain • P-0-0598, FXC: Current loop integral action time • P-0-0599, FXC: Slip frequency filter time constant • P-0-0600, FXC: Rated slip frequency • P-0-0602, FXC: Minimum no-load current Motor data parameters: • P-0-0510, Rotor inertia • P-0-4004, Magnetizing current • P-0-4032, Motor type plate data Axis data parameters: • P-0-4010, Load inertia Control parameters: • P-0-0045, Control word of current controller • P-0-0601, Configuration motor data identification

5.4.3 Automatic Setting of Motor Control

Brief Description



Base package of all firmware variants in **open-loop and closed-loop** characteristic

For operating motors, it is necessary to collect the values for motor parameters (resistance values, inductances, ...), in order to determine the motor control parameters (flux controller, voltage controller, current controller, ...) with these values.

Depending on the manufacturer and type of the motor to be controlled, the values for motor parameters and motor control parameters are made available to the drive controller in different ways.

Rexroth Motors For Rexroth motors, the values for the motor and motor control parameters are optimized and made available by the manufacturer. The automatic setting of the motor control parameters by the drive firmware is not required and not allowed for Rexroth motors!

- For motors **with motor encoder data memory**:

Overview of the Scope of Functions

→ Parameters loaded automatically when drive is switched on (see "Default Settings in the Motor Encoder Data Memory ("Loading Default Values")")

- For motors **without motor encoder data memory**:
 - Parameters loaded via the "IndraWorks Ds/D/MLD" commissioning tool from the motor data base (DriveBase)
 - or –
 - Individual parameters manually written via the Engineering Port or the master communication interface by means of a motor parameter list.

Third-Party Motors

For third-party motors, the drive firmware possesses commands by means of which the values for the motor and motor control parameters are generated depending on the available output data and the functional principle of the motor.

The following commands are available for calculating values for the motor and motor control parameters:

- C3200 Command Calculate motor data:
 1. Calculating the motor parameter values for asynchronous motors from the **data on the type plate**.
 2. Calculating the values to be set for the motor control parameters.
- C3600 Command Motor data identification:
 1. Identifying (or optimizing) the motor parameter values.
Note: Appropriate start values already have to be available!
 2. Calculating the values of the motor control parameters.
- C4600 Command Calculate motor control parameters:

Calculating the values of the motor control parameters from the motor parameters for synchronous motors and, if necessary, for asynchronous motors (after manual input of motor data in motor parameters)




The prerequisite is the form "Manufacturer-Side Data for Synchronous Motors" or "Manufacturer-Side Data of Asynchronous Motors" to be filled out by the motor manufacturer; it can be found in the section "Third-Party Motors at IndraDrive Controllers"!

Overview

The figure below illustrates an overview of the possibilities of determining the motor and motor control parameters for motors without motor encoder data memory:

Overview of the Scope of Functions

**P-0-4032**

Motor type plate data

Fig. 5-25:

Determining Motor and Motor Control Parameters for Motors without Motor Encoder Data Memory

In addition to collecting or determining the motor and motor control parameters, further data on measuring system, temperature sensor, motor temperature model, motor holding brake and, if necessary, position and velocity controllers are required.

See "[Closed-Loop Axis Control \(Closed-Loop Operation\)](#)"

See the "Notes on Commissioning" in the section "[Third-Party Motors at IndraDrive Controllers](#)"

Pertinent Parameters

- P-0-0565, C3600 Command Motor data identification
- P-0-0566, C4600 Command Calculate motor control parameters
- P-0-4032, Motor type plate data

Overview of the Scope of Functions

Pertinent Diagnostic Messages

- P-0-4033, C3200 Command Calculate motor data
- C3200Command Calculate motor data
- C3201Incorrect input for current
- C3202Incorrect input for voltage
- C3203Incorrect input for frequency
- C3204Incorrect input for speed
- C3205Incorrect input for power factor
- C3206Incorrect input for power
- C3207Type plate list incomplete
- C3208 Error when writing parameters (->S-0-0423)
- C3209 Command execution impossible
- C3600 Command Motor data identification
- C3601 Motor not or not correctly connected
- C3602 Determined values invalid
- C3603 Device current limit too low
- C3604 Error when writing parameters (->S-0-0423)
- C3605 Motor turning
- C3606 Type of construction of motor not allowed
- C3607 Motor revolution/motion impeded
- C3608 Incorrect motor phases or rotational direction of encoder
- C3609 Incorrect number of pole pairs or number of encoder lines
- C3610 No encoder: Validation check impossible
- C3611 Test velocity not reached
- C3612 Command execution impossible
- C4600 Command Calculate motor control parameters
- C4601 Error when writing parameters (->S-0-0423)

5.4.4 Open-Loop Axis Control (Open-Loop Operation)

Brief Description

In sensorless operation (open-loop operation), the velocity control loop is not closed in the drive, but the drive is operated in a velocity-controlled way (without feedback) via open-loop V/Hz (U/f) control.



The method of open-loop/closed-loop motor control can be selected via bit 14 of "P-0-0045, Control word of current controller".

See also the section "[Motor Control](#)"

Overview of the Scope of Functions




Fig. 5-26: Principle of Drive Control in Open-Loop Operation

Features

The open-loop velocity control has the following features:

- Fine interpolation of the velocity command value (can be switched off)
- Monitoring of the velocity control loop is possible (can be switched off via P-0-0556; bit 1)
- Parameterizable filtering of the actual velocity value
- Additive velocity command value (S-0-0037)
- Display of the resulting command value (in P-0-0048)
- Monitoring and **limitation** of the maximum stator frequency slope that results from the command velocity change
- **Stall protection controller** (PI controller that can be optionally activated to prevent breakdown of the machine when the torque limits are attained)
- **Slip compensation** (feedforward of estimated slip of the machine by means of rotor time constant and slip compensation factor)
- Calculation of output voltage by means of **V/Hz (U/f) characteristic** based on motor model data
- Subsequent trimming of magnetization via premagnetization factor (linear or square characteristic to be selected)
- **IxR boost** (adjustable load-dependent feedforward of the output voltage due to the voltage drop on the motor winding resistance)
- **Oscillation damping** (adjustable load-dependent feedforward to prevent velocity oscillations in the partial load and idling ranges)
- **Current limitation controller** to protect the output stage
- **Velocity search mode** of a coasting machine after switching drive enable on (can be set for one or both rotational directions)

Pertinent Parameters

- S-0-0037, Additive velocity command value
- S-0-0040, Velocity feedback value
- S-0-0091, Bipolar velocity limit value
- P-0-0048, Effective velocity command value
- P-0-0049, Effective torque/force command value
- P-0-0555, axis controller messages
- P-0-0556, Config word of axis controller

Pertinent Diagnostic Messages • F8079 Velocity limit value exceeded (S-0-0091)

5.4.5 Closed-Loop Axis Control (Closed-Loop Operation)

General Information on Closed-Loop Axis Control

Control Loop Structure

The drive controller has a so-called cascade structure, i.e. the individual controllers (position, velocity and current) are interconnected. Depending on the active operation mode, there are different controller structures with different points of input and paths of the command values. Depending on the active operation mode, only the torque control loop, the torque control loop and the velocity control loop or, in addition to these two control loops the position control loop can be closed in the drive.

The structure and the interaction of the control loops are shown in two figures in the section "Overview of Drive Control" (see "[Control Loop Structure with Setting Parameters](#)" or "[Control Loop Structure with Display Parameters](#)").

Features of the Control Loops

For the simplification of the parameterization of the control loops and for an increase in performance, a number of standardizations and structural changes have been carried out.

Current controller, velocity controller and position controller are described in the section "Performance (Controller Cycle Times)" (see "[Overview of Drive Control, Features of the Control Loops](#)").

Possibilities of Accessing Outer Control Loops

In closed-loop operation it is possible to add command values in addition to the command values available in the control loop. Depending on the active operation mode, the following parameters are available to do this:

Operation mode	S-0-0081	S-0-0037	P-0-0059	S-0-0048
V/Hz (U/f) control (command value processing in velocity control)	--	--	--	--
Torque/force control	■	--	--	--
Velocity control / velocity synchronization	■	■	--	--
Position Control	■	■	■	--
Drive-controlled positioning	■	■	■	--
Positioning block mode	■	■	■	--
Phase synchronization	■	■	--	■
Electronic cam	■	■	--	■

S-0-0081 Additive torque/force command value

S-0-0037 Additive velocity command value


P-0-0059 Additive position command value, controller

S-0-0048 Additive position command value

Tab. 5-49: Overview of the Additive Command Values Depending on the Operation Mode

In closed-loop operation, it is possible to access the outer control loops from a higher-level operation mode. The access options to the individual control loops are illustrated in the following example:

Overview of the Scope of Functions



S-0-0037	Additive velocity command value
S-0-0047	Position command value
S-0-0081	Additive torque/force command value
S-0-0100	Velocity loop proportional gain
S-0-0101	Velocity loop integral action time
S-0-0104	Position loop Kv-factor
P-0-0059	Additive position command value, controller

Fig. 5-27: Structural Overview with Access Options

Command Value Processing Depending on Operation Mode

Position Control	For the following operation modes, the position control loop is closed internally (in the drive) in addition to the velocity and the current control loops: • Position control with cyclic command value input • Drive-internal interpolation • Positioning modes (drive-controlled positioning, positioning block mode) See also description of the respective operation mode.
Velocity Control	In the "velocity control" mode, the velocity control loop, apart from the current control loop, is closed in the drive, too. See also " Velocity Control "
Torque/force control	The "torque/force control" mode actually isn't torque or force control but current control. Therefore, only the current control loop is closed in the drive. See also " Torque/Force Control "

Notes on Commissioning for Control Loop Setting

The control loop settings in a digital drive controller are very important for the features of the servo axis.

To optimize the control loop setting, application-specific controller parameters are available for all digital Rexroth drives.

Overview of the Scope of Functions

Order of Manual Control Loop Setting

Due to the cascade structure of the control loops, it is necessary to parameterize them "from the inside to the outside". The resulting order for setting the control loops is as follows:

1. Current control loop

For **Rexroth motors with motor encoder data memory** (MSK and MKE series), the optimization of the current controller is not required, as the respective parameter values (S-0-0106 and S-0-0107) are read from the motor encoder data memory.

For all **Rexroth motors without motor encoder data memory** (e.g. linear motors), the parameter settings can be taken from a central motor database via the "IndraWorks Ds/D/MLD" commissioning tool.

The commissioning of **third-party motors** (including control loop settings) is described in the respective sections on third-party motors in this documentation (see "[Third-Party Motors at IndraDrive Controllers](#)").

2. Velocity control loop

The settings of the velocity controller (S-0-0100 and S-0-0101) with the respective filters (P-0-0004 and P-0-1120, P-0-1121, P-0-1122, P-0-1123, P-0-1140, P-0-1141, P-0-1142, P-0-1143) on the one hand depend on the motor parameters (inertia and torque/force constant), on the other hand they strongly depend on the mechanical properties (load inertia/mass, friction, rigidity of the connection, ...). Therefore, manual or automatic optimization is often necessary.

3. Position control loop

In general, the position control loop only has to be adjusted to the dynamics of the outer velocity controller, as well as to the kind of preset command values (jerk, acceleration and interpolation procedure).

Default Settings in the Motor Encoder Data Memory ("Load Motor Default Values")

"Load Motor Default Values" Command

For all Rexroth motors of the series with motor encoder data memory (e.g. MKE, MSK and possibly MAD and MAF), the basic settings for the controllers are stored and can be loaded to the drive by executing the "load motor default values" command (S-0-0262).

The parameter "S-0-0262, C07_x Load defaults procedure command" can be activated in two ways:

- Automatically when running up the drive by recognizing that the motor type (cf. parameter S-0-0141) has changed. The display then reads "RL" and by pressing the "Esc" button on the control panel, the "load motor default values" command is internally started unless this was deactivated in "P-0-0556, Config word of axis controller".
- Starting the command by writing "11b" to parameter S-0-0262.

See also "[Loading, Storing and Saving Parameters](#)"



In order to start the "load motor default values" command, the value "0" (default setting) must have been set in parameter "P-0-4090, Configuration for loading default values".

During the load motor default values procedure, the following control loop parameters are set to their default values optimized for the respective motor:

- S-0-0100, Velocity loop proportional gain
- S-0-0101, Velocity loop integral action time
- S-0-0104, Position loop Kv-factor

Overview of the Scope of Functions

- S-0-0106, Current loop proportional gain 1
- S-0-0107, Current loop integral action time 1
- P-0-0004, Velocity loop smoothing time constant



The default settings for the current control loop (cf. S-0-0106 and S-0-0107) are automatically adjusted to the currently parameterized PWM frequency (cf. P-0-0001) and performance setting (cf. P-0-0556)!

In addition, when the motor default values are loaded, the following control loop parameter is set to the firmware-side default value even though no default value has been stored in the motor data memory for this parameter.

- S-0-0348, Acceleration feedforward gain



In the majority of cases, the controller settings stored in the motor encoder data memory provide a useful and reliable control loop setting. In exceptional cases, however, it may be necessary to make the settings with regard to the specific application.

Automatic Setting of Closed-Loop Axis Control

Brief Description

To facilitate drive parameterization, the IndraDrive firmware provides automatic axis control setting in closed-loop operation.

- Together, the settings of axis control and the axis mechanics (e.g. stiffness/elasticity and load inertia/load mass) determine the control loop dynamics to be achieved.
- The required control loop dynamics depends on the application type (such as machine tool and handling axis).
- It allows setting the control loop parameters in such a way that they are adjusted to the application type and the axis structure (such as direct connection and drive with gearbox/toothed wheel), as well as to the mechanical properties of the axis.

Features

The function has the following features:

- The function is started with the command "P-0-0162, C1800 Command Drive optimization / command value box" and controlled with the parameter "P-0-0165, Drive optimization, control word".
- With the start of the function, switching to a drive-internal operation mode takes place and the drive makes itself independent of the control unit.
- The result of the control loop setting (achieved control loop dynamics) can be influenced via "P-0-0163, Damping factor for autom. controller setting" and "P-0-0164, Application for autom. controller setting".
- Via "P-0-0165, Drive optimization, control word" it is possible, by selecting the corresponding bit, to activate the respective subfunction of the automatic setting of axis control:
 - Calculation of velocity and/or position controller parameters (drive does not move)
 - Optimization of velocity and/or position controller parameters (drive moves)
 - Determination of acceleration feedforward (drive does not move)

Overview of the Scope of Functions

- Determination of load inertia (drive moves)
- Determination of the maximum acceleration (drive does not move)



Depending on the settings in "P-0-0165, Drive optimization, control word", it is necessary to move the drive to carry out the automatic setting of axis control. The drive moves when the load inertia is determined and when the velocity and position control loops are optimized.

- If motion is not required, the command can already be started in phase 4 (bb: drive ready for operation).
- If motion is required, drive enable (AF) is necessary to start the command.
 - The type of motion, oscillating motion or motion in one direction, and, if applicable, the direction of motion, positive or negative direction, are automatically determined from the processing format, absolute or modulo format, of the position data, "S-0-0076, Position data scaling type" (bit 7) and the "S-0-0393, Command value mode".
 - The travel range is defined either by inputting position limits or a travel distance.



When the IndraWorks engineering tool (as of 13V06) is used to control the function, further features are available:

- Automatic determination of the mechanical properties of antiresonance and resonance frequencies:
 - "P-0-0181, Drive optimization: Antiresonance frequency"
 - "P-0-0182, Drive optimization: Resonance frequency"
- Automatic setting of the speed control loop filters depending on the antiresonance and resonance frequencies




Fig. 5-28: IndraWorks Start Dialog "Automatic Setting of Axis Control"

Pertinent Parameters

- P-0-0161, Drive optimization: Periodic time
- P-0-0162, C1800 Command Drive optimization / command value box
- P-0-0163, Damping factor for autom. controller setting
- P-0-0164, Application for autom. controller setting

Overview of the Scope of Functions

- P-0-0165, Drive optimization, control word
 - P-0-0166, Drive optimization, end position negative
 - P-0-0167, Drive optimization, end position positive
 - P-0-0168, Maximum acceleration to be parameterized
 - P-0-0169, Drive optimization, travel distance
 - P-0-0170, Drive optimization, acceleration
 - P-0-0171, Drive optimization, velocity
 - P-0-0181, Drive optimization: Antiresonance frequency
 - P-0-0182, Drive optimization: Resonance frequency
- Pertinent Diagnostic Messages**
- C1800 Command Drive optimization / command value box
 - C1801 Start requires drive enable
 - C1802 No useful motor data
 - C1803 Inertia detection failed
 - C1804 Automatic controller setting failed
 - C1805 Travel range invalid
 - C1806 Travel range exceeded
 - C1807 Determining travel range only via travel distance
 - C1808 Drive not homed
 - E2049 Positioning velocity $\geq$ limit value (S-0-0091)
 - E2055 Feedrate override S-0-0108 = 0

Velocity Controller (with the Respective Filters)

Brief Description

In closed-loop operation, in addition to the field-oriented current controller, the velocity control loop is also closed in the drive by means of the drive software (PI cascade structure).

The closed-loop operation (current and velocity) can be carried for all types of motors with encoder and for asynchronous motors without encoder.



The selection of the type of motor control is carried out via the parameter "P-0-0045, Control word of current controller" (bit 14,15).

Overview of the Scope of Functions




Fig. 5-29: Structure of the Velocity Controller



The following description is restricted to the velocity controller including the respective options of filtration and feedforward. The processing of the velocity command value is described within the operation mode "[velocity control](#)".

- Features**
- Digital PI controller with anti-windup function, can be set by means of the following parameters:
 - S-0-0100, Velocity loop proportional gain
 - S-0-0101, Velocity loop integral action time
 - Setting can be carried out by
 - One time execution of the function "Load default values (motor-specific controller values)"
 - or –
 - Manual optimization (see description below)
 - or –
 - Automatic parameterization of the axis controller (see "[Automatic Setting of Closed-Loop Axis Control](#)").
 - Depending on the control performance which has been set, the cycle time $T_{A_velocity}$ is used for velocity controller calculations (see "[Performance Data](#)").
 - Possibility of mixing the velocities of motor encoder and optional encoder
 - 4 freely configurable 2nd order filters (e.g. band-stop filters) for filtering resonance frequencies



For firmware variant MPE, only 2 freely configurable filters are available.

Overview of the Scope of Functions

- Low-pass filter to attenuate interference frequencies, to be set via P-0-0004 (VZ1)
- Fine interpolation of the command values of the position controller (can be switched on via P-0-0556, bit 0)
- Monitoring of the velocity control loop (can be switched off via P-0-0556, bit 1)
- Optional acceleration feedforward from the torque command value (with filtering option)

Pertinent Parameters

- S-0-0037, Additive velocity command value
- S-0-0040, Velocity feedback value
- S-0-0081, Additive torque/force command value
- S-0-0084, Torque/force feedback value
- S-0-0091, Bipolar velocity limit value
- S-0-0100, Velocity loop proportional gain
- S-0-0101, Velocity loop integral action time
- S-0-0149, C1300 Positive stop drive procedure command
- S-0-0155, Friction compensation
- S-0-0156, Velocity feedback value 2
- S-0-0164, Acceleration feedback value 1
- S-0-0347, Velocity error
- S-0-0535, Active velocity feedback value
- P-0-0004, Velocity loop smoothing time constant
- P-0-0048, Effective velocity command value
- P-0-0049, Effective torque/force command value
- P-0-0180, Acceleration feedforward smoothing time constant
- P-0-0451, Actual acceleration torque/force value
- P-0-0452, Actual process torque/force value
- P-0-0555, axis controller messages
- P-0-0556, Config word of axis controller
- P-0-1119, Velocity mix factor feedback 1 & 2
- P-0-1120, Velocity control loop filter: Filter type
- P-0-1121, Velocity control loop filter: Limit frequency of low pass
- P-0-1122, Velocity control loop filter: Bandwidth of band-stop filter
- P-0-1123, Vel. cont. loop filter: Center frequency of band-stop filter
- P-0-1126, Velocity control loop: Acceleration feedforward
- P-0-1140, Velocity control loop filter: Numerator natural frequency
- P-0-1141, Velocity control loop filter: Denominator natural frequency
- P-0-1142, Velocity control loop filter: Numerator damping
- P-0-1143, Velocity control loop filter: Denominator damping
- P-0-2100, Velocity loop proportional gain, type plate
- P-0-2101, Velocity loop integral-action time, type plate
- P-0-3004, Speed controller smoothing time constant, type plate

Pertinent Diagnostic Messages

- E2059 Velocity command value limit active

Overview of the Scope of Functions

- E8260 Torque/force command value limit active
- F8078 Speed loop error

Position Controller (with Respective Feedforward Functions and Actual Value Adjustment)

Brief Description

The following section only describes the position controller with the respective feedforward options (velocity and acceleration feedforward).




Fig. 5-30: Structure of the Position Controller



The preprocessing of the position command value (command value adjustment) is described in the corresponding section of the position control mode (e.g. position control with cyclic command value input, positioning block mode, ...).

Features

- Digital proportional controller, can be set via the following parameter:
 - S-0-0104, Position loop Kv-factor
- Lag error is minimized by:
 - Variable velocity feedforward (see P-0-0040)
 - and -
 - Variable acceleration feedforward (see S-0-0348), including smoothing filter
- Depending on the control performance which has been set, the cycle time $T_{A_position}$ is used for position controller calculations (see "Performance Data").
- With lag error or lagless, i.e. with velocity feedforward
- Model monitoring for the lag error (see also F2028)

Overview of the Scope of Functions

	• Possibility of evaluating a "hybrid actual position value" from motor encoder and external position control encoder (up to now only motor encoder and measuring wheel encoder)
Pertinent Parameters	• S-0-0032, Primary operation mode → Bit 3 = 1 → Activation of lagless operation • S-0-0038, Positive velocity limit value • S-0-0039, Negative velocity limit value • S-0-0040, Velocity feedback value • S-0-0048, Additive position command value • S-0-0051, Position feedback value 1 • S-0-0053, Position feedback value 2 • S-0-0091, Bipolar velocity limit value • S-0-0092, Bipolar torque/force limit value • S-0-0104, Position loop Kv-factor • S-0-0189, Following distance • S-0-0348, Acceleration feedforward gain • S-0-0386, Active position feedback value • S-0-0520, Axis control word • S-0-0521, Axis status word • P-0-0040, Velocity feedforward evaluation • P-0-0048, Effective velocity command value • P-0-0049, Effective torque/force command value • P-0-0059, Additive position command value, controller • P-0-0109, Torque/force peak limit • P-0-0180, Acceleration feedforward smoothing time constant • P-0-0241, Actual pos. smoothing time constant for hybrid pos. control • P-0-0434, Position command value of controller • P-0-0454, Velocity feedforward actual value • P-0-0455, Acceleration feedforward actual value • P-0-0556, Config word of axis controller • P-0-0691, Additive position command value, process loop
Pertinent Diagnostic Messages	• F2028 Excessive deviation • F2036 Excessive position feedback difference • F2037 Excessive position command difference

5.4.6 Commutation Setting

Basics on Commutation Setting

Brief Description

General Information

Significance of Commutation Offset

Three-phase synchronous motors are only operational if the current in the primary part to the magnetic field in the secondary part is correctly assigned. For this purpose, the position of the primary part (motor windings) with respect to the pole pairs of the secondary part must always be known to con-

Overview of the Scope of Functions

trol. Depending on the primary part position signaled by the motor encoder, the "commutation offset" is used to generate the current in the three-phase windings such that a force effect is produced in the motor.

A synchronous motor can only produce the maximum torque or the maximum force in relation to the motor current if the value of the commutation offset is correct. Otherwise, the relation of torque/force to motor current (torque/force constant) would be lower and not optimum. A highly incorrect value implies the danger of the motor moving in an uncontrolled way.

If the motor encoder is not mounted in the defined orientation with respect to the primary and secondary part of the motor, an individual commutation offset value must be determined for each synchronous motor:

- With Rexroth synchronous motors with integrated motor encoders and encoder data memory (e.g. MSK motors), the commutation offset has already been determined at the factory and is provided in the motor encoder data memory. The user does not need to set the commutation offset!
- Synchronous Rexroth kit motors consist of motor components (primary part, secondary part). They are finally put together as an operational motor when they are installed in the machine axis and completed by the customer with a motor encoder. The commutation offset can only be determined by the user after the motor is complete.

The following Rexroth kit motors are manufactured according to the functional principle "synchronous motor":

- Linear motors LSF, MLF
- Rotary motors MBS and MBT

Motor Encoders for Synchronous Motors

Ideally, absolute motor encoders should be used for synchronous Rexroth kit motors. The advantage in this case is the absolute position detection of the motor position which immediately ensures, when drive enable is set, the correct assignment of current in the primary part to the magnetic field in the secondary part if the commutation offset was determined in the initial commissioning of the motor and saved in the drive.

For some applications it is necessary to use relative motor encoders because the available length of absolute motor encoders is limited, for example. The disadvantage in this case is that absolute detection of the motor position is impossible. It is therefore necessary, after each time the drive is switched on again or after having changed the communication phase from "PM" to "OM" ("bb" or "Ab") to set the commutation offset again. For linear motors, this disadvantage can be removed by using an additional Hall sensor component or option, because with regard to commutation setting the relative motor encoder then behaves like an absolute motor encoder.



If you use a relative motor encoder, using the additional Hall sensor component is absolutely recommended for linear Rexroth motors! In this way, you achieve highest safety with regard to correct motor function and compliance with the performance data!

Concerning operationally reliable drives with synchronous third-party motors and IndraDrive controllers with regard to the selected motor encoder, the same principles apply as for synchronous Rexroth kit motors (see above); however, the Hall sensor box SHL02.1 cannot be used for linear third-party motors.

Overview of the Scope of Functions

Overview of the Motor Encoders Usable with Synchronous Motors

Motor Encoder	Synchronous Rexroth kit motor (rotary, linear)	Synchronous Rexroth kit motor (linear) with SHL02 or Hall unit	Synchronous third-party motor
Absolute	+	--	+
Relative	o	+	o

+ Advantageous combination
o Combination possible, initial commissioning might possibly require especially trained staff
-- Combination not useful
Tab. 5-50: Possible Combinations of Motor Encoders and Synchronous Motors for Which Commutation Setting is Required



The motor encoder should be implemented with a high resolution and as a **motor encoder to be evaluated in absolute form**. If it is necessary to use a relative motor encoder, using encoders with square-wave signals should be avoided.

With synchronous motors with a gearbox between motor and motor encoder (**encoder gear**), in general an absolute motor encoder **cannot be evaluated as an absolute commutation encoder** (for special cases, see below).

For synchronous motors with relative motor encoders in combination with an additional **external encoder that can be evaluated in absolute form** installed at the axis, with a slip-free mechanical axis system the external encoder can be used as an **absolute commutation encoder** for the motor (for special cases, see below).

Pertinent Parameters

Besides the motor parameters (see overview of parameters in "[Basics on the Motors to be Controlled](#)"), other parameters are available for the commutation setting:

- P-0-0506, Amplitude for angle acquisition
- P-0-0507, Test frequency for angle acquisition
- P-0-0508, Commutation offset
- P-0-0509, Commutation offset coarse
- P-0-0517, Commutation: Required harmonics component
- P-0-0518, C5600 Command subsequent optimization of commutation offset
- P-0-0519, Commutation status word
- P-0-0521, Effective commutation offset
- P-0-0522, Control word for commutation setting
- P-0-0523, Commutation setting measured value
- P-0-0524, C1200 Commutation offset setting command
- P-0-3008, Commutation offset, type plate

Pertinent Diagnostic Messages

- C1200 Commutation offset setting command
- C1204 Error in offset calculation
- C1208 No adjustment with asynchronous motor
- C1209 Proceed to phase 4
- C1211 Commutation offset could not be determined.
- C1212 Motion range exceeded during commutation

Overview of the Scope of Functions

- C1214 Command only possible with linear synchronous motor
- C1215 Command only possible in 'bb'
- C1216 Commutation determination not selected
- C1217 Setting only possible in 'Ab'
- C1218 Automatic commutation: Current too low
- C1219 Automatic commutation: Overcurrent
- C1220 Automatic commutation: Timeout
- C1221 Automatic commutation: Iteration without result
- C1222 Error when writing offset parameters
- C1223 Command execution impossible
- C5600 Command Subsequent optimization of commutation offset
- C5601 Command requires drive enable
- C5602 Axis blocked
- C5603 Timeout: Axis in motion
- F2032 Validation error during commutation fine adjustment
- F8010 Autom. commutation: Max. motion range when moving back
- F8011 Commutation offset could not be determined
- F8012 Autom. commutation: Max. motion range
- F8013 Automatic commutation: Current too low
- F8014 Automatic commutation: Overcurrent
- F8015 Automatic commutation: Timeout
- F8016 Automatic commutation: Iteration without result
- F8017 Automatic commutation: Incorrect commutation adjustment

Overview of Methods for Determining the Commutation Offset

Methods for Determining the Commutation Offset

The commutation offset can be determined with different methods. The method is chosen in accordance with the axis geometry, the practicability and the chances of success of the respective method depending on motor and mechanical axis system.

The following methods are possible:

- **Calculation method**
→ For relative motor encoder when using the additional Hall sensor component SHL02 (distance measurement, currentless → only possible with linear Rexroth kit motors, see documentation "Hall Sensor Box SHL02.1")
- **Measuring method**
→ For motor encoder that can be evaluated in absolute form (distance measurement, currentless → only possible with linear Rexroth kit motors)
- **Saturation method** (axis needs to be blocked or at standstill, with current)
→ Possible with all types of motors in combination with motor encoders that can be evaluated in absolute form and with relative motor encoders; but see "Restrictions for Saturation Method" in table below
- **Sine-wave method** (requires unrestricted movement of axis, with current)

Overview of the Scope of Functions

→ Possible with all types of motors in combination with motor encoders that can be evaluated in absolute form and with relative motor encoders; but see "Restrictions for Sine-Wave Method" in table below

Determination methods, firmware dependency

Firmware variant	Method for determining the commutation offset			
	Calculation method	Measuring method	Saturation method	Sine-wave method
MPE	-	■	■	-
MPB	■	■	■	■
MPC	■	■	■	■
MPM	■	■	■	■

■ Available
- Not available

Tab. 5-51: Methods for Determining the Commutation Offset that are Available in the Firmware Variants

Recommendations for selecting the determination method:

Motor type	Determination method (and motor encoder that can be used)			
	Calculation method (relative linear encoder with additional Hall sensor component)	Measuring method (absolute linear encoders only)	Saturation method* (absolute or relative motor encoder)	Sine-wave method* (absolute or relative motor encoder)
MBSxx0	--	--	+	o
MBSxx2 (high speed)	--	--	o	+
MBT	--	--	+	o
LSF	+ (with SHL02)	+	+	o
MLF	+ (with SHL02)	+	+	o
MCL	(not required for "Hall unit..." option)	+	--	o
MSP	--	--	+	o
Sy third-party motors (rotary and linear)	--	--	+	o

+ Recommended method
o Method not recommended
-- Method not possible
* See application-related restrictions

Tab. 5-52: Recommendations for Selecting Determination Method for Commutation Offset Depending on Motor Type (for Rexroth Motors)



The sine-wave method (generally requires unrestricted movement of axis) should only be used if the saturation method cannot be used!

Overview of the Scope of Functions

Restrictions for saturation method

Applications of synchronous motors	Restrictions for saturation method
Third-party motors without or with only little saturation effects (e.g. ironless motors or motors with high leakage flux)	Saturation method cannot be used for determining commutation offset!
Applications with relative measuring system (without using the optimum commutation offset value with regard to the reference point)	Max. torque/force can be reduced by approx. 20% compared to the optimum value (autom. determination of commutation offset with "AF")!
Applications with relative measuring system that are using the optimum commutation offset value with regard to the reference point	Max. torque/force until reference mark is passed can be reduced by approx. 20%!
Drives that can be in motion during the determination of the commutation offset, e.g. coasting spindles, printing roller drives etc.	Saturation method is only possible for motors in standstill!
Drives with a low degree of overload capacity	Saturation method only possible if amplifier current is sufficiently high (2...4-fold continuous motor current required)!
Drives that are not permitted to move during determination of the commutation offset (low-friction axes with low inertia)	Saturation method (with current) can cause motor motion!

Tab. 5-53: Typical Applications and Restrictions for Saturation Method

Restrictions for Sine-Wave Method

Applications of synchronous motors	Restrictions for Sine-Wave Method
Linear axis with single motor or parallel motor	Only balanced (e.g. horizontal) axes with low friction!
Linear axes in Gantry arrangement	Only balanced (e.g. horizontal) axes with low friction! In addition, both drives have to carry out sequential commutation settings, "AF" must not be active at the other drive!
Axis with holding brake (e.g. vertical axis)	Holding brake must be released to determine the commutation offset successfully. Only balanced axes!
Rotary axes with single drive	Only balanced axes with little friction; high inertia can cause problems!
Rotary axes, mechanically connected	See above "Linear axes in gantry arrangement"!

Tab. 5-54: Typical Applications and Restrictions for Sine-Wave Method

The respective restrictions are explained in the subchapter.

Restrictions for Motors with Relative Motor Encoders and Digital Hall Sensors Identifying the Motor Encoder

Overview of the Scope of Functions




Fig. 5-31: Identifying the Absolute or Relative Motor Encoder Depending on the Motor and Application-Related Restrictions

Effect of an Encoder Gear

If a motor encoder to be evaluated in absolute form is connected via an encoder gear in the case of a synchronous motor, in general there is no unambiguous assignment of electrical angle and absolute actual position value. For this reason, the motor encoder to be evaluated in absolute form now behaves as a relative motor encoder with respect to the commutation.

In two special cases, however, absolute commutation encoder evaluation is possible for synchronous motors with encoder gear (rotary encoders only):

- Case 1, single-turn (or multi-turn) encoder:
 - If an n-fold motor revolution (n is an integer) results in exactly one encoder revolution
- Case 2, multi-turn encoder:
 - If exactly one motor revolution results in an m-fold encoder revolution (m is an integer)

Effect of an External, Absolute Encoder

For synchronous motors with relative motor encoders in combination with an additional external encoder that can be evaluated in absolute form installed at the axis, with a slip-free mechanical axis system the external encoder can be used as an absolute commutation encoder for the motor. If this is the case, the external encoder can be assigned as commutation encoder in "P-0-0185, Control word of encoder 2 (optional encoder)". Then the specifications as for a synchronous motor with a motor encoder that can be evaluated in absolute form apply.

Overview of the Scope of Functions

Determining the Commutation Offset

The active commutation offset value is contained in parameter "P-0-0521, Effective commutation offset". Due to its significance for the torque/force development of the motor and the operational safety, P-0-0521 is always write-protected.

Depending on the motor encoder used, you have to determine the commutation offset for the following situations:

- With absolute motor encoder only during **initial commissioning** of the drive
- With relative motor encoder both during **initial commissioning** of the motor and each time the drive has been switched on again (**recommissioning**)



With Rexroth synchronous motors with integrated motor encoders (e.g. MSK motors), the initial commissioning has already been performed at the factory and the motor-specific commutation offset has been determined and is provided in the motor encoder data memory. The user does not need to set the commutation offset!

Initial Commissioning and Recommissioning

During the initial commissioning of Rexroth kit motors and synchronous third-party motors, the commutation offset is determined during the initial commissioning of the motor with a suitable method made available by the drive. The quality of this commutation offset determination is subject to variations that can be caused by the current conditions of the mechanical axis system and electromagnetic factors. Because the torque or force development of the motor depends on the quality of the commutation offset value, however, this value should be carefully optimized during the initial commissioning of the motor.

However, to do this it is necessary to allow the parameter "P-0-0521, Effective commutation offset", which is normally write-protected, to be written so that the value can also be optimized manually if necessary. For this purpose, the drive provides the "initial commissioning mode" (activated in "P-0-0522, Control word for commutation setting").

The optimum value of the commutation offset identified during initial commissioning is displayed in "P-0-0521, Effective commutation offset" and should also be effective when the drive is switched on again (recommissioned). To do this, this value must be saved in the "initial commissioning mode" in an appropriate manner such that it is available during recommissioning:

- **For motors with absolute motor encoders as well as for relative motor encoders and analog Hall sensors (SHL02 for MLF, analog Hall unit for MCL):**

The value of the effective commutation offset (P-0-0521) is automatically saved in "P-0-0508, Commutation offset" as well. When the drive is recommissioned, this saved value becomes effective again. If the motor encoder has a data memory, the value of P-0-0521 is also saved in "P-0-3008, Commutation offset, type plate".

- **For motors with relative motor encoders and motors with additional digital Hall sensors (digital Hall unit for MCL, third-party motors):**

The value of the effective commutation offset (P-0-0521) is saved in reference to a fixed, reproducible motor or axis position in "P-0-0508, Commutation offset". This requires drive actions initiated by the user (drive-controlled homing or merely moving the motor). When recommissioning, after the drive is initially enabled (AF), first the automatic commutation setting of the motor is carried out or, in the case of digital Hall

Overview of the Scope of Functions

sensors, the acceptance of "P-0-0509, Commutation offset coarse" in P-0-0521. In turn, based on the appropriate drive actions initiated by the user (drive-controlled homing or moving the motor), the value saved in P-0-0508 becomes effective in a manner that is optimized for the automatically determined commutation offset (P-0-0521) in that a correction value is determined and added.



By adding a correction value, the effective commutation offset (P-0-0521), when the motor is recommissioned, achieves the quality of the value of the initial commissioning. This results in reproducible drive behavior with respect to torque/force development. The determination of the correction value is supported by the reference mark of the motor encoder or the homing dedicated position of the axis; for this reason, the correction method is called "optimum commutation offset with regard to reference point".

Commutation Setting for Rexroth Motors MLF, LSF

Brief Description

Linear Rexroth kit motors of the MLF and MCL series are manufactured according to the functional principle "synchronous motor". For kit motors, the motor components primary part, secondary part and motor encoder are finally assembled on the customer side in the machine.

Motors with Absolute Motor Encoders

The operatability of the synchronous motor can only be established on site by determining and setting the commutation offset. For motors with a motor encoder that can be evaluated in absolute form, this is done once during initial commissioning.

Motors with Relative Motor Encoders

For synchronous motors with a relative motor encoder, it is necessary to re-determine the commutation offset each time the drive is switched on again. Deviating commutation offset values are possible due to redetermination and this can cause lower force development at the same motor current.

To prevent this, it is recommended that Hall sensor components, developed especially for linear Rexroth motors be used in addition to the relative motor encoder.

Analog Hall Sensors

Via analog signals from Hall sensors, the controller detects the position of the motor windings with respect to the magnetic field of the motor and in this way also completes the commutation setting during initial commissioning. When the drive is recommissioned, the correct commutation offset is immediately available at drive enable ("AF").

- Hall sensor box SHL02.1 for MLF motors
- Analog Hall unit (motor option) for MCL motors



A second encoder input is required at the drive controller for evaluating the analog Hall sensor signals. This requires a controller with a Basic control section; an Economy control section cannot be used for this purpose!

Digital Hall Sensors

There is also a Hall unit with digital signals available as a motor option for the ironless MCL motors in Economy applications. Using three digital signals that are offset by 120° with respect to a pole pair, the controller detects the position of the motor windings with respect to the magnetic field of the motor with a precision of +/-30° (with respect to a pole pair). This enables the motor, im-

Overview of the Scope of Functions

mediately after it is switched on, to operate at at least 50% of the possible motor force.

The following homing procedure of the relative measuring system allows full motor force to be achieved again if this was prepared accordingly in the initial commissioning. The current state of the performance of the motor is diagnosed and can be queried on the control master side.



To evaluate the digital Hall sensor signals, the additional component "SHL03" is required (bringing together the motor encoder and Hall sensor signals). One control section with just one encoder input is sufficient for the controller. For this reason, Economy control sections can be used!

In principle, MLF or MCL motors in combination with a relative motor encoder can also be commutated without using a Hall unit or SHL02 additional components by using the available current supply methods:

- Saturation method for MLF motors
- Sine-wave method for MCL motors


Each time the drive is switched on again, the commutation setting is performed again with the disadvantages listed above. These disadvantages can be compensated for by using the "optimum commutation offset with regard to reference point".



Application-related restrictions are to be noted for the saturation and sine-wave methods! Using the "optimum commutation offset with regard to reference point" is highly recommended! (See above!)

Hall Sensor Box SHL02.1 for MLF

The Hall sensor box SHL02.1 is an absolute measuring system, outside of the motor, within one pole pair distance of linear Rexroth MLF motors.



- 1 Secondary part
- 2 Primary part
- 3 Hall sensor box SHL02 (connected with the primary part)

Fig. 5-32: Linear Rexroth Motor with Hall Sensor Box SHL02

For information on mounting and connection see the documentation on Hall sensor box SHL02.1.

Hall Unit, Motor Option with MCL

The Hall unit is an absolute measuring system, integrated into the motor, within one pole pair distance of linear Rexroth MCL motors. The Hall unit is optional; it can be ordered directly or retrofitted.

Overview of the Scope of Functions




Fig. 5-33: "Hall Unit" Option for MCL Motors; Dismounting the Dummy Unit, Retrofitting the Hall Unit

Information regarding dismounting/assembly and connection is contained in the "Ironless Linear Motors MCL" documentation.

Saturation Method

Brief Description

For rotary synchronous Rexroth kit motors and synchronous third-party motors, IndraDrive controllers only provide methods with current to determine the commutation offset. The saturation method, which requires that the motor does not move, is among these methods. A possibly available holding brake should remain applied!



For synchronous Rexroth motors with integrated motor encoder (MSK, MKE motors), it is not necessary to set the commutation offset! The correct value is provided in the motor encoder data memory and is automatically activated.

The saturation method is also relevant for linear synchronous Rexroth kit motors if they are equipped only with a relative motor encoder or for motors with a motor encoder that can be evaluated in absolute form if distance measurement at the axis is not possible due to installation issues.

As a prerequisite for successful application of the saturation method, the iron material of the motor must be magnetically saturated when current is supplied, i.e. the controller must be able to provide sufficiently high current to the motor. For synchronous motors which are not magnetically saturated at maximum allowed current, this method is unsuited for determining the commutation offset!



If the saturation method cannot be used, the controller provides the sine-wave method (works with current, too) for determining the commutation offset.

The saturation method is suitable for both the initial commissioning and the recommissioning, although the restrictions must be observed.



The restrictions to be observed when using the saturation method are described in the section "[Basics on Commutation Setting](#)". This section outlines the different methods which can be used for determining the commutation offset.

Sine-Wave Method

Brief Description

For synchronous motors, in addition to the saturation method, IndraDrive controllers provide the sine-wave method, also with current, to determine the commutation offset.

Application-Related Aspect

The sine-wave method for determining the commutation offset can be used for all types of synchronous motors.

The disadvantage of the sine-wave method is that the motor has to be put into motion by supplying current. Limitations of the motivity (e.g. friction or blocking) can reduce the quality of offset determination or even cause offset determination to fail! See the section "[Basics on Commutation Setting](#)".

Before using the sine-wave method, carefully check whether it is possible to use the saturation method, because unrestricted movement of the axis generally causes problems. For the saturation method movement of axis is not necessary, it should be blocked, if possible.

The sine-wave method is suitable for both the initial commissioning and the recommissioning, although the restrictions must be observed.



The restrictions to be observed when using the sine-wave method are described in the section "[Basics on Commutation Setting](#)". This section outlines the different methods which can be used for determining the commutation offset.

Commutation Setting via Digital Hall Sensors

Brief Description

General Information

Digital Hall Sensors for Three-Phase Synchronous Motors

In addition to the typical absolute measuring systems on the market, for three-phase synchronous motors the position of the motor windings with respect to the magnetic field of the motor can also be identified using three digital signals that are offset by 120° with respect to a pole pair. The precision of +/-30° with respect to a pole pair is low; however, with respect to the commutation offset it is still sufficient for use.

In combination with a relative motor encoder, for synchronous motors an absolute motor measuring system can be realized with respect to the commutation offset; this system can be evaluated by IndraDrive controllers. To do this, the additional component "SHL03" is required, which brings both measuring systems together on the hardware side and enables the connection to just one encoder input of the controller.

Rexroth MCL Motors, "Hall Unit, Digital" Option

Digital Hall sensors are available for the ironless linear Rexroth MCL motors. They can be ordered as the motor option "Hall sensor, digital" and are integrated into the primary part of the motor. An additional relative motor encoder and the SHL03 component are required!



- For information regarding the commutation setting of MCL motors, see the chapter "[Commutation Setting for Rexroth Linear Motors MLF, MCL](#)".
- See also the documentation "Rexroth IndraDyn L, Ironless Linear Motors MCL; Project Planning Manual".

Third-Party Motors with Digital Hall Sensors

General conditions

Overview of the Scope of Functions

- Three-phase synchronous motor with a fixed interconnection (star or delta connection)
- Three Hall sensor signals offset by 120° (with respect to a pole pair) for motor commutation
- Relative motor encoder for motor operation



When using an encoder combination of a relative motor encoder and digital Hall sensors, it is impossible to use an SSI encoder as the possibly required external encoder!

Hardware-side features and requirements

- Supply voltage for the motor encoder: DC 5V
- Supply voltage for the Hall sensors: DC12V
- Voltage level of the Hall sensor signals: 5VTTL
- Additional component SHL03 for bringing together the motor encoder and Hall sensor signals for connection to an encoder input of the drive controller.



For more information regarding the technical data, see the documentation "IndraDrive Cs Drive Systems; Project Planning Manual"

5.4.7 Limitations

Overview of Limitations

To protect the mechanical axis system, the controllers and the motors against overload, IndraDrive devices have different possibilities of limitation:

- Torque/force limitation
 - Axis-side torque/force limit values, depending on the preceding sign
 - Axis-side torque/force limit values, related to the absolute value (independent of the preceding sign)
- Current limitation
 - Absolute current limit values, depending on controller or motor
 - Dynamic current limitation, depending on the thermal load of controller or motor
- Velocity limitation
 - Motor-side velocity limit values
 - Axis-side velocity limit values
- Position limitation
 - Evaluation of axis-side travel range limit switches
 - Firmware-side travel range limit values

The existing limiting facilities are active depending on the method of motor control.

Voltage-Controlled Open-Loop Operation (V/Hz [U/f] Control)

With voltage-controlled, sensorless operation, the following limitations are available to protect the device or motor:

- Torque/force limitation via stall protection controller
- Current limitation via current limitation controller

Overview of the Scope of Functions

- Position limitation by
 - Travel range limit switches
 - Software limit switches
- Closed-Loop Operation of Motors (FXC, FOC, FOCsl)** In closed-loop operation (flux-controlled or current-controlled), there are the following parameterizable limitations to protect the device or motor:
- Torque/force limitation
 - Current limitation
 - Velocity limitation
 - Position limitation by
 - Travel range limit switches
 - Software limit switches

Current and Torque/Force Limitation

Brief Description

Current limitation and torque/force limitation avoid mechanical overload of the axis and thermal overload of motor and controller.

Torque/force limit values due to axis conditions and processing take effect statically as positive and negative limits of the torque/force command value. The thermal overload protection might possibly reduce these limits dynamically, depending on the current thermal load of motor and controller.

- Features**
- User-side limit values for torque/force (drive-internally converted to current limit values):
 - Bipolar limit values (S-0-0092, P-0-0109)
 - Unipolar limit values (S-0-0082, S-0-0083)
 - Display of the current torque/force command value in "P-0-0049, Effective torque/force command value"
 - Display of the process torque or process force in "S-0-0084, Torque/force feedback value"
 - Drive side, absolute current limit values in "S-0-0110, Amplifier peak current" and "S-0-0109, Motor peak current"
 - Dynamic current limitation depending on work load reduces maximum current to the thermally allowed continuous current on the basis of motor and amplifier temperature model (depending on motor type and possibly selected cooling type, as well as on PWM frequency and amplifier type); currently available maximum current and thermally possible continuous current displayed in the parameters:
 - P-0-4045, Maximum possible continuous current
 - P-0-4046, Effective peak current
 - Resulting torque/force limit values from the user-side torque/force limitations and the (dynamic) current limitation depending on work load are displayed in the parameters:
 - P-0-0442, Actual value torque limit positive (stationary)
 - P-0-0443, Actual value torque limit negative (stationary)
 - P-0-0444, Actual value peak torque limit
 - Status word for analysis of the currently active torque/current limitation (P-0-0445)

Overview of the Scope of Functions

- Display of effective torque-generating current command value ("limited" current command value) in parameter
 - P-0-0038, Torque-generating current, command value
- Display of actual current values in the parameters
 - P-0-0440, Actual output current value (absolute value)
 - P-0-0043, Torque-generating current, actual value
 - P-0-0044, Flux-generating current, actual value

Pertinent Parameters

- S-0-0082, Torque/force limit value positive
- S-0-0083, Torque/force limit value negative
- S-0-0092, Bipolar torque/force limit value
- S-0-0109, Motor peak current
- S-0-0110, Amplifier peak current
- S-0-0111, Motor current at standstill
- S-0-0112, Amplifier nominal current
- S-0-0384, Amplifier temperature
- P-0-0001, Switching frequency of the power output stage
- P-0-0038, Torque-generating current, command value
- P-0-0049, Effective torque/force command value
- P-0-0051, Torque/force constant
- P-0-0109, Torque/force peak limit
- P-0-0141, Thermal drive load
- P-0-0440, Actual output current value (absolute value)
- P-0-0441, Thermal drive load warning threshold
- P-0-0442, Actual value torque limit positive (stationary)
- P-0-0443, Actual value torque limit negative (stationary)
- P-0-0444, Actual value peak torque limit
- P-0-0445, Status word torque/current limit
- P-0-0045, Control word of current controller
- P-0-0640, Cooling type
- P-0-4034, Thermal time constant of winding
- P-0-4035, Thermal time constant of motor
- P-0-4037, Thermal short-time overload of winding
- P-0-4045, Maximum possible continuous current
- P-0-4046, Effective peak current
- P-0-4058, Amplifier type data
- P-0-4059, Electric type data of power section

Pertinent Diagnostic Messages

- E2050 Device overtemp. prewarning
- E2051 Motor overtemp. prewarning
- E2056 Torque limit = 0
- E2061 Device overload prewarning
- E8055 Motor overload, current limit active
- E8057 Device overload, current limit active

Overview of the Scope of Functions

- F2018 Device overtemperature shutdown
- F2019 Motor overtemperature shutdown
- F2021 Motor temperature monitor defective
- F2022 Device temperature monitor defective

Velocity Limitation

Brief Description

Velocity limitations are implemented in the drive that allow the velocity command value to be limited to a freely definable value or to various positive and negative values.

Features	• Unipolar velocity limit values (S-0-0038, S-0-0039), scaled, with reference to load if necessary • Cyclically configurable, bipolar velocity limit value (S-0-0091), scaled, with reference to load if necessary • Bipolar velocity limit value (P-0-0113) of the motor, unscaled, with reference to the motor only
Pertinent Parameters	• S-0-0036, Velocity command value • S-0-0037, Additive velocity command value • S-0-0038, Positive velocity limit value • S-0-0039, Negative velocity limit value • S-0-0091, Bipolar velocity limit value • P-0-0113, Bipolar velocity limit value of motor
Pertinent Diagnostic Messages	• E2059 Velocity command value limit active • E2063 Velocity command value > limit value • F8079 Velocity limit value exceeded

Position Limitation/Travel Range Limit Switches

Brief Description

To avoid accidents and damages to the machine, comprehensive preventive safety precautions are provided. Part of these safety precautions is the limitation of the allowed working range (travel range) by the drive. For this purpose, position monitoring functions and position limitations have been implemented in the drive.

CAUTION

The travel range monitoring function (travel range limit switches or software limit switches) only fulfills the requirements for protecting machinery, but is not sufficient for personal protection!

Realizing Travel Range Monitoring

The drive provides two possibilities of determining and monitoring a limitation of the working range (travel range):

- Monitoring of **position limit values (software limit switches)**
Monitoring of the motor position for exceeding one of the two position limit values (positive/negative → S-0-0049/S-0-0050) by the homed actual position value (S-0-0403), i.e. value related to the machine zero point.

Overview of the Scope of Functions

- Monitoring of **travel range limit switches**

Monitoring for activation of one of the two travel range limit switches (Limit+, Limit-) that are connected to the digital inputs of the drive.



The functionality of the travel range limit switches is only guaranteed, if the corresponding digital inputs have been configured for this purpose!

See "[Digital Inputs/Outputs](#)"

Features of Travel Range Limit Switches

- 2 travel range limit switches (Limit+, Limit-) can be monitored at the drive
- Signal behavior of travel range limit switches (N/C and N/O) can be set
- Travel range limit switches activated via parameter
- Reaction (error/warning) when exceeding travel range can be set
- Status display of travel range limit switches
- Command values monitored for validity when limit switch activated
- Travel range limit switches evaluated and position limit value monitor activated in 2 ms clock

Features of Position Limit Values

- 2 position limit values ("software limit switches") can be parameterized; only operational when axis has been homed
- Reaction (error/warning) when exceeding position limit values can be set
- Position limit values activated via parameter
- Automatic reference to measuring system that has been homed
- Command values monitored for validity when position limit values exceeded

Pertinent Parameters

- S-0-0012, Class 2 diagnostics
- S-0-0049, Positive position limit value
- S-0-0050, Negative position limit value
- S-0-0055, Position polarities
- S-0-0147, Homing parameter
- S-0-0403, Position feedback value status
- S-0-0478, Position/travel range limit status
(Alias: P-0-0091, Position/travel range limit status)
- S-0-0532, Travel range limit parameter
(Alias: P-0-0090, Travel range limit parameter)
- P-0-0222, Travel range limit switch inputs

Pertinent Diagnostic Messages

- E2053 Target position out of travel range
- E8029 Positive position limit exceeded
- E8030 Negative position limit exceeded
- E8042 Both travel range limit switches activated
- E8043 Positive travel range limit switch activated
- E8044 Negative travel range limit switch activated
- F6028 Position limit value exceeded (overflow)
- F6029 Positive position limit exceeded

Overview of the Scope of Functions

- F6030 Negative position limit exceeded
- F6042 Both travel range limit switches activated
- F6043 Positive travel range limit switch activated
- F6044 Negative travel range limit switch activated

5.4.8 Power Supply

Brief Description

Possibilities of Power Supply

The following IndraDrive devices are supported by this firmware:

- Single-axis converters of the IndraDrive Cs range (HCS01.1 controllers)
- Multi-axis converters (HCQ, HCT controllers)
- Single-axis converters of the IndraDrive C range (HCS02.1, HCS03.1, HCS04.2 controllers)
- Single- and double-axis inverters of the modular IndraDrive M range (HMS01.1, HMS02.1, HMD01.1 controllers)
- Single-axis inverters of the distributed IndraDrive Mi range (KSM02.1, KMS02.1 controllers)

Converters include a supply unit and an inverter unit. They are suitable for direct power supply connection, but can only be used in a single-axis design and a DC bus coupled, modular drive system.

Possible Device Combinations and Mains Connection

The possible device combinations are only described in principle for the purpose of explanation. As regards combinations of device types actually possible and specific facts to be observed, see the separate documentations.

Title Rexroth IndraDrive ...	Kind of documentation	Document typecode ¹⁾ DOK-INDRV*-...	Material number R911...
Cs Drive Systems with HCS01	Project Planning Manual	HCS01*****-PRxx-EN-P	322210
Drive Systems with HMV01/02, HMS01/02, HMD01, HCS02/03	Project Planning Manual	SYSTEM*****-PRxx-EN-P	309636
Supply Units and Power Sections	Project Planning Manual	HMV-S-D+HCS-PRxx-EN-P	318790
Drive Controllers HCS04.2E	Project Planning Manual	HCS04.2****-PRxx-EN-P	327334
Mi Drive Systems with KCU02, KSM02, KMS02	Project Planning Manual	KCU02+KSM02-PRxx-EN-P	335703


1) In the document typecodes, "xx" is a wild card for the current edition of the documentation (example: PR01 is the first edition of a Project Planning Manual)

Tab. 5-55: Documentations for the Project Planning of Drive Systems

Central Supply

The figure below illustrates the principle of central supply:

Overview of the Scope of Functions




Converter Includes a supply unit and an inverter unit. Converters that are supplied via the DC bus must be operated in the inverter mode (see P-0-0860).

Inverter Only consists of the inverter unit and is always supplied supplied via the DC bus

Fig. 5-34: Mains Supply via Converter

Group Supply

The figure below illustrates the principle of group supply:



Converter Includes a supply unit and an inverter unit. Each converter is directly supplied by the mains.

Fig. 5-35: Mains Supply via all Devices

Overview of the Scope of Functions



With IndraDrive C and IndraDrive M, the module bus has an eight-wire design (ribbon cable) and with IndraDrive Cs it has a two-wire design. Devices with module buses of different designs cannot be operated at the common DC bus.

Communication in Drive Group

Depending on the task of a drive system or of several drives cooperating in a process, it can be appropriate to rapidly carry out a common reaction to certain events. This requires the exchange of signals (communication) between the cooperating devices:

- Multi-axis converters have an internal communication between the supply unit and the axis inverters.
- Single-axis converters (IndraDrive Cs, IndraDrive C), as well as inverters and supply units of the modular series (IndraDrive M), are interconnected via the module bus.

Note Regarding Single-Axis Converters IndraDrive Cs/C

A single-axis converter combines the supply unit and inverter in one device. In a "drive system" (several drives the DC buses and module buses of which are interconnected), a converter can fulfill the following functions:

- Supply of an integrated inverter and other inverters or converters operated as such, or
- Operation only as an inverter at a DC bus

Note Regarding Multi-Axis Converters

A multi-axis converter combines the supply unit and several inverters in one device. It always works as a "drive system" (several drives the DC buses and module buses of which are interconnected). Supply of other external inverters or converters or external module bus connection is not possible.

Regenerated Energy

In the case of regenerative operation (e.g. deceleration mode) of the motors connected to a single-axis or multi-axis converter, the regenerated energy is first absorbed by the DC bus. If the energy absorption capacity is exhausted, the energy absorbed is transformed into heat via the braking resistor.

Braking Resistor

The braking resistor is connected on the DC bus side. Depending on the device series, an internal braking resistor is available or an external braking resistor can be connected.

Module bus

The module bus is used for the communication of all nodes at the DC bus. It protects the components by switching the power off. The collective package reaction of all nodes is also initiated via the module bus. The wiring of the hardware, connections and signals is described in the documentation of the devices (Project Planning Manual).

Pertinent Parameters and Diagnostic Messages

Pertinent Parameters

- S-0-0380, DC bus voltage
- P-0-0114, Undervoltage threshold
- P-0-0118, Power supply, configuration
- P-0-0119, Best possible deceleration
- P-0-0460, Module group, control word
- P-0-0461, Module group, status word
- P-0-0806, Current mains voltage crest value
- P-0-0809, Properties of charging circuit
- P-0-0815,
- P-0-0816, Amplifier temperature 2
- P-0-0833, Braking resistor threshold

Overview of the Scope of Functions

Pertinent Diagnostic Messages	• P-0-0844, thermal load of Braking resistor
	• P-0-0858, Data of external braking resistor
	• P-0-0859, Data of internal braking resistor
	• P-0-0860, Converter configuration
	• P-0-0861, Power supply status word
	• E2026 Undervoltage in power section
	• E2040 Device overtemperature 2 prewarning
	• E2050 Device overtemp. prewarning
	• E2061 Device overload prewarning
	• E2086 Prewarning supply module overload
	• E2810 Drive system not ready for operation
	• E2814 Undervoltage in mains
	• E2816 Undervoltage in power section
	• E2819 Mains failure
	• E2820 Braking resistor overload prewarning
	• E2829 Not ready for power on
	• E8025 Overvoltage in power section
	• E8026 Undervoltage in power section
	• E8028 Overcurrent in power section
	• E8057 Device overload, current limit active
	• E8058 Drive system not ready for operation
	• E8819 Mains failure
	• F2026 Undervoltage in power section
	• F2086 Error supply module
	• F2087 Module group communication error
	• F2816 Softstart fault power supply unit
	• F2818 Phase failure
	• F2819 Mains failure
	• F2820 Braking resistor overload
	• F2821 Error in control of braking resistor
	• F2825 Switch-on threshold braking resistor too low
	• F2836 DC bus balancing monitor error

5.5 Operation Modes

5.5.1 General Information on the Operation Modes

Assignment to the Functional Packages

For the assignment to the functional packages, see chapter "[Overview of Functions/Functional Packages, Supported Operation Modes](#)".

Operation Mode Handling

Selecting the Operation Mode

It is possible to configure up to 8 different operation modes in the drive (depending on "S-0-0292, List of supported operation modes"). Assignment and configuration are made via the following parameters:

Overview of the Scope of Functions

- S-0-0032, Primary operation mode
- S-0-0033, Secondary operation mode 1
- S-0-0034, Secondary operation mode 2
- S-0-0035, Secondary operation mode 3
- S-0-0284, Secondary operation mode 4
- S-0-0285, Secondary operation mode 5
- S-0-0286, Secondary operation mode 6
- S-0-0287, Secondary operation mode 7



If the value "0" was entered in one of these parameters, the error message "F2007Switching to non-initialized operation mode" is generated when this operation mode is activated.

Activating the Operation Mode

The operation mode is activated and controlled by the input in drive control words which depend on the type of master communication:

- S-0-0134, Master control word
- P-0-4077, Field bus: Control word
- P-0-4068, Field bus: Control word IO
- P-0-4028, Device control word
- P-0-0120, Control word easy startup

For the axis command triggering by the integrated MLD control and the use by the easy startup mode, there are 8 more internal operation modes available (permanently configured internally), so that a total of 16 operation mode preselection parameters are available. It is possible to choose between these operation modes in operation, and due to drive-controlled transition functions it is possible to switch between the operation modes in running operation.

The effective input is displayed in the bits 8, 9, 11 and 12 of the parameter "P-0-0116, Device control: Control word".

The following applies to parameter P-0-0116:

- Bits 8 and 9 → Selecting primary operation mode and secondary operation modes 1 to 3
- Bit 11 → Selecting secondary operation modes 4 to 7 (sercos only)



The secondary operation modes 4 to 7 can only be used via sercos interface. Bit 11 therefore only takes effect in the control word of the device control (P-0-0116) in conjunction with parameter S-0-0134 (master control word for sercos)!

The figure below illustrates the interrelation of the control word of the respective master communication and the device control word/device status word with regard to the operation mode selection.

Overview of the Scope of Functions




Fig. 5-36: Operation Mode Selection via Control Word



The control bits (8 and 9) contained in parameter P-0-0116 are also contained in the control words depending on the master communication (cf. S-0-0134, P-0-4077, P-0-4068 and P-0-4028) and can therefore be written via the control words.

An operation mode defined via the operation mode selection is active when:

- The drive (control section and power section) is ready for operation
- and -
- The drive enable signal sees a positive edge.

Acknowledging the Active Operation Mode

As regards the activation of an operation mode, there are the following kinds of feedback:

- With active operation mode, the display of the control panel reads "AF".
- In parameter "S-0-0390, Diagnostic message number", the respective diagnostic message number of the active operation mode is displayed (e.g. "C00A0101" in "velocity control" mode).
- In parameter "S-0-0095, Diagnostic message", the active operation mode is displayed in text form (e.g. "A0101Velocity control").
- In parameter "P-0-0115, Device control: Status word", bit 3 ("Drive follows external command values") is used to acknowledge whether the drive is running in the preset operation mode or not.
- In parameter "P-0-0115, Device control: Status word", bits 8, 9 and 10 ("Acknowledgment of operation mode") are used to signal the operation mode presently active.

Overview of the Scope of Functions



The status bits contained in parameter P-0-0115 (3, 8, 9 and 10) are also contained in the status words depending on the master communication (S-0-0135, P-0-4078) and can therefore be read in the status words. Bit 10, however, is only activated with sercos interface!

See also "Device Control and State Machines"

Changing the Operation Mode

When drive enable is activated, the drive, after having gone through the initialization routines, changes to the operation mode that was selected via bits 8 and 9 of the specific control word of the respective master communication (S-0-0134, P-0-4077, P-0-4068, P-0-4028 or P-0-0116).



The change of operation modes is carried out within one position controller clock (Advanced: 250 µs; Basic: 500 µs). Another position controller clock passes until the command values of the activated operation mode become effective, because the initialization of the operation mode is carried out first.

Special Cases

With the following **exceptional circumstances**, the desired operation mode is not carried out in spite of the operation mode having been correctly selected:

- **Drive error** is present
→ The corresponding error reaction is carried out.
- **Fatal warning** was triggered
→ The corresponding reaction is carried out.
- A **"drive command"** (e.g. homing procedure, set absolute position, ...) is executed
→ The command started is carried out.
- **Drive Halt**
→ This drive function is carried out.

See also "Device Control and State Machines"

Drive-Controlled Change of Operation Mode

In order to achieve a quick and smooth change of operation mode in running operation, it is possible to make a "drive-controlled change of operation mode". Drive-internally this procedure ensures that, when the operation mode is changed, the transition is carried out in a synchronized way, even if the command value changes abruptly.

See also "Command Value Adjustment with Position Control"

Command Value Acceptance and Acknowledgment

Immediate Command Value Acceptance

Each preset command value is accepted immediately, when the respective command value parameter (e.g. S-0-0036, S-0-0080, S-0-0258, ...) is written in the case of the operation modes:

- Torque/force control
- Velocity Control
- Position control with cyclic command value input
- Drive-internal interpolation
- Synchronization modes:
 - Velocity Synchronization with Real/Virtual Master Axis

Overview of the Scope of Functions

- Phase Synchronization with Real/Virtual Master Axis
- Electronic Cam with Real/Virtual Master Axis
- Electronic Motion Profile with Real/Virtual Master Axis

Command Value Acceptance After Master Request

In the **positioning modes** (drive-controlled positioning, positioning block mode), however, the command value (target position, velocity, positioning block, ...) is only accepted, when the master explicitly requests this by a "command value acceptance".

The command value acceptance is carried out in a different way, according to the positioning mode or profile type:

- Operation mode "Drive-controlled positioning"
Acceptance of preset command value (position, velocity) by toggling bit 0 of parameter "S-0-0346, Positioning control word"
→ **Toggle mechanism**
- Operation mode "Positioning block mode"
Acceptance of the positioning block selected via "P-0-4026, Positioning block selection" by a positive edge of bit 0 of parameter "P-0-4060, Positioning block control word", when the parallel interface or, in the case of field buses, the I/O mode is used as master communication
→ **Edge control**



When the positioning block mode is used for field buses in the freely configurable operating mode (P-0-4084 = 0xFFFE) or with sercos interface, the toggle mechanism is used **in spite of the above rule**.

Command Value Acknowledgment

The explicit acknowledgment of the command value acceptance only takes place for the positioning modes (drive-controlled positioning, positioning block mode).

It is possible to check in the master whether and when the preset command value was accepted in the drive (command value acceptance handshake).

The command value acknowledgment is carried out in a different way, according to the positioning mode:

- Operation mode "Drive-controlled positioning"
The drive acknowledges the command value acceptance by toggling bit 0 of parameter "S-0-0419, Positioning command acknowledge".
- Operation mode "Positioning block mode"
The drive acknowledges the command value acceptance by displaying the effective positioning block in parameter "P-0-4051, Positioning block acknowledgment".



In the positioning block mode, too, the acceptance of a new positioning block causes bit 0 of parameter S-0-0419 to be toggled, because in this case the internal processing of the positioning command values is identical to the "drive-controlled positioning" mode.

5.5.2 Torque/Force Control

Brief Description



Assignment to functional firmware package, see chapter "[Supported Operation Modes](#)".

In the "torque/force control" mode, a torque/force command value is preset for the drive. If required, this command value can be filtered. When the operation mode has been activated, the diagnostic message is "A0100Torque control".




Fig. 5-37: Block Diagram, "Torque/Force Control"

- Features**
- Torque/force control with regard to the sum of the command values preset in parameters "S-0-0080, Torque/force command value" and "S-0-0081, Additive torque/force command value"
 - Torque/force command value is generated internally by the velocity controller; value of S-0-0081 can be added as additive component
 - Limitation of the preset command value to limit value that can be parameterized
 - Command value filtered via "S-0-0822, Torque/force ramp" and "S-0-0823, Torque/force ramp time"

- Pertinent Parameters**
- S-0-0080, Torque/force command value
 - S-0-0081, Additive torque/force command value
 - S-0-0082, Torque/force limit value positive
 - S-0-0083, Torque/force limit value negative
 - S-0-0092, Bipolar torque/force limit value
 - S-0-0109, Motor peak current
 - S-0-0110, Amplifier peak current
 - S-0-0111, Motor current at standstill
 - S-0-0822, Torque/force ramp
 - S-0-0823, Torque/force ramp time
 - S-0-0824, Status "Torque/force command value attained"
 - P-0-0001, Switching frequency of the power output stage
 - P-0-0038, Torque-generating current, command value
 - P-0-0049, Effective torque/force command value
 - P-0-0051, Torque/force constant
 - P-0-0109, Torque/force peak limit
 - P-0-4046, Effective peak current

- Pertinent Diagnostic Messages**
- A0100 Torque control
 - E8057 Device overload, current limit active

Overview of the Scope of Functions

- E8260 Torque/force command value limit active
- F8079 Velocity limit value exceeded

5.5.3 Velocity Control

Brief Description



Assignment to functional firmware package, see chapter "[Supported Operation Modes](#)".

In the "velocity control" mode, a velocity command value is preset for the drive. The velocity command value is limited by ramps and filters.




Fig. 5-38: Block Diagram, "Velocity Control"

Features

- An external velocity command value is preset (sum of "S-0-0036, Velocity command value" and "S-0-0037, Additive velocity command value") via analog inputs or master communication interface (sercos, field bus, ...)
- Selection of predefined and internally stored velocity command values (31 fixed values) is possible via binarily coded digital inputs (e.g. for jogging forward/backward, feeding, setting up, ...) with separately definable acceleration and deceleration ramps (31 different ramps), as well as jerk filter to be set (31 different time constants)
- Use of a drive-internal command value generator for generating command value ramps ("motor potentiometer")
- Inversion of the provided velocity command value before it is processed in the ramp-function generator
- Window comparator for masking critical velocity ranges in the command value channel (e.g., machine resonances) with corresponding acceleration adjustment (see P-0-1209)
- Ramp-function generator with separately adjustable, two-stage acceleration and deceleration limits of the preset velocity command value; switching from ramp 1 to ramp 2 takes place with selectable velocity and run-up stop that can be parameterized
- Velocity control via a digital PI controller with extensive filter measures
- Monitoring of the command velocity and actual velocity for exceeding parameter "S-0-0091, Bipolar velocity limit value"
- Additional monitoring for the motor-related limit values "S-0-0113, Maximum motor speed" and "P-0-0113, Bipolar velocity limit value of motor"
- Smoothing of velocity control loop difference via filter that can be parameterized
- Smoothing of preset command value by means of average filter (jerk limitation by means of moving average filter)

Overview of the Scope of Functions

- Fine interpolation of the velocity command values; transmission of these command values in the position controller clock; the fine interpolator can be switched on or off (P-0-0556, bit 0)
- Velocity control loop monitoring (cannot be parameterized) to prevent the drive from running away; monitor can be switched on or off (P-0-0556, bit 1)
- Velocity controller internally generates the torque/force command value to which the value of the parameter can be added as an additive component
- Control word and status word especially for "velocity control" mode (P-0-1200 and P-0-1210)

Pertinent Parameters

- S-0-0036, Velocity command value
- S-0-0037, Additive velocity command value
- S-0-0040, Velocity feedback value
- S-0-0091, Bipolar velocity limit value
- S-0-0100, Velocity loop proportional gain
- S-0-0101, Velocity loop integral action time
- S-0-0113, Maximum motor speed
- S-0-0156, Velocity feedback value 2
- S-0-0535, Active velocity feedback value
- P-0-0004, Velocity loop smoothing time constant
- P-0-0048, Effective velocity command value
- P-0-0113, Bipolar velocity limit value of motor
- P-0-0556, Config word of axis controller
- P-0-1119, Velocity mix factor feedback 1 & 2
(not valid for MPE-18 firmware)
- P-0-1120, Velocity control loop filter: Filter type
- P-0-1126, Velocity control loop: Acceleration feedforward
- P-0-1200, Control word 1 velocity control
- P-0-1201, Ramp 1 pitch
- P-0-1202, Final speed ramp 1
- P-0-1203, Ramp 2 pitch
- P-0-1206, Memory of velocity command values
- P-0-1207, Lower limit of velocity masking window
- P-0-1208, Upper limit of velocity masking window
- P-0-1209, Acceleration factors for velocity masking window
- P-0-1210, Status word of velocity control mode
- P-0-1211, Deceleration ramp 1
- P-0-1213, Deceleration ramp 2
- P-0-1214, Control word 2 velocity control
- P-0-1215, Motor potentiometer, acceleration
- P-0-1216, Motor potentiometer, deceleration
- P-0-1217, Motor potentiometer, step size
- P-0-1218, Motor potentiometer, command value

Overview of the Scope of Functions

- P-0-1222, Velocity command filter
- P-0-1223, List of acceleration ramps
- P-0-1224, List of deceleration ramps
- P-0-1225, List of smoothing time constants

Pertinent Diagnostic Messages

- A0101 Velocity control
- E2059 Velocity command value limit active
- E2063 Velocity command value > limit value
- E8260 Torque/force command value limit active
- F8078 Speed loop error
- F8079 Velocity limit value exceeded

5.5.4 Position Control with Cyclic Command Value Input

Brief Description



Assignment to functional firmware package, see chapter "[Supported Operation Modes](#)".

In the "position control" mode, a cyclic position command value is preset for the drive in NC cycle time. This command value is fine interpolated in the drive and jerk-limited via filters, if necessary, before being transmitted to the position controller.

To minimize the lag error, variable acceleration feedforward is available in addition to variable velocity feedforward.

There are different forms of the "position control" mode which result in the corresponding diagnostic messages when the operation mode was activated (see "Pertinent Diagnostic Messages" below).




Fig. 5-39: Block Diagram, "Position Control with Cyclic Command Value Input"

Features

- Position control with regard to the command value preset in parameter "S-0-0047, Position command value"
- NC-controlled or drive-controlled position control with internal, dynamic synchronization when changing operation modes
- Timebase for cyclic command value input defined by "S-0-0001, NC cycle time (TNcyc)"
- Monitoring of the position command value difference for exceeding parameter "S-0-0091, Bipolar velocity limit value"
- Position command values of the control section smoothed by means of adjustable average value filter; calculation from acceleration and jerk limit values; displayed in parameter "P-0-0042, Current position command average value filter order"
- Fine interpolation of position command value of the control unit to position controller clock; can be switched via "P-0-0187, Position command processing mode"

Overview of the Scope of Functions

- Adjustable position command value delay in position cycle times (P-0-0456, Position command value delay), maximum of 32 cycles.
- Position control with regard to actual position value encoder 1 (motor encoder) or actual position value encoder 2 [external (load-side) encoder], can be dynamically switched
- Velocity feedforward through adjustable factor of 0...150 % (default = 100 %)
- Cyclic acceptance of an additive torque/force command value of the control unit (external acceleration feedforward)



The condition for this operation mode is synchronous communication between the control unit and the drive, as is the case with sercos interface, for example.

Pertinent Parameters

- S-0-0047, Position command value
- S-0-0081, Additive torque/force command value
- S-0-0091, Bipolar velocity limit value
- S-0-0138, Bipolar acceleration limit value
- S-0-0520, Axis control word
- P-0-0010, Excessive position command value
- P-0-0011, Last valid position command value
- P-0-0041, Position command average value filter time constant
- P-0-0042, Current position command average value filter order
- P-0-0047, Position command value control
- P-0-0059, Additive position command value, controller
- P-0-0070, Effective additive torque/force command value
- P-0-0099, Position command smoothing time constant
- P-0-0142, Synchronization acceleration
- P-0-0143, Synchronization velocity
- P-0-0187, Position command processing mode
- P-0-0434, Position command value of controller
- P-0-0456, Position command value delay
- P-0-0457, Position command value generator
- P-0-0458, Delay of add. command values
- P-0-0556, Config word of axis controller

Pertinent Diagnostic Messages

- A0102 Position mode, encoder 1
- A0103 Position mode, encoder 2
- A0104 Position mode lagless, encoder 1
- A0105 Position mode lagless, encoder 2
- A0154 Position mode drive controlled, encoder 1
- A0155 Position mode drive controlled, encoder 2
- A0156 Position mode lagless, encoder 1 drive controlled
- A0157 Position mode lagless, encoder 2 drive controlled
- F2036 Excessive position feedback difference
- F2037 Excessive position command difference

Overview of the Scope of Functions



The error message F2037 can also be configured as a warning. In this case, there is no error reaction on the drive side. The user is then responsible for initiating an appropriate reaction via the control master.

5.5.5 Drive-Internal Interpolation

Brief Description



Assignment to functional firmware package, see chapter "[Supported Operation Modes](#)".

The two operation modes "drive-internal interpolation" and "drive-controlled positioning" allow time-optimized positioning of a single axis. The "drive-internal interpolation" mode is the basis for the more comprehensive functionality of the "drive-controlled positioning" mode.

In the "drive-internal interpolation" mode, a target position is directly preset for the drive. In the internal positioning generator, a position command value characteristic is generated (interpolated), from the preset value for the target position considering preset positioning data (velocity, acceleration and jerk), as the input value for the position controller.

There are different forms of the "drive-internal interpolation" mode which result in the corresponding diagnostic messages when the operation mode was activated (see below "Pertinent Diagnostic Messages").




Fig. 5-40: Block Diagram, "Drive-Internal Interpolation"

Features

- Drive-internal generation of a position command value profile to travel to a preset target position (S-0-0258) while maintaining the positioning velocity (S-0-0259) and positioning acceleration (S-0-0260) or positioning deceleration (S-0-0359) that can be set; can be set separately
- Command value generation runs in the NC cycle "S-0-0001, NC cycle time (TNcyc)". The transition to the position controller cycle is made by cubic fine interpolation.
- Jerk limitation of the generated position command value via "S-0-0193, Positioning jerk"
- Setting of the average value filter (jerk limitation) to a fixed filter time with interpolation command value average value filter time constant (P-0-0641)
- Adjustable position command value delay in position cycle times (P-0-0456), maximum of 32 cycles.
- Evaluation of the positioning velocity with "S-0-0108, Feedrate override"
- Monitoring of the positioning velocity for exceeding "S-0-0091, Bipolar velocity limit value"

Overview of the Scope of Functions



When using safety technology, the positioning velocity can be limited by "P-0-3238, SMO: Active velocity threshold", see also "Rexroth IndraDrive, Integrated Safety Technology as of MPx-1x (Safe Motion)" (DOK-INDRV*-SI3*SMO-VRS-AP**-EN-P; mat. no. R911338920).

- Monitoring of the target position for compliance with the position limit values
- Command value mode can be set (S-0-0393) in modulo format (shortest distance, only positive or only negative direction)
- Position control with regard to "S-0-0051, Position feedback value 1" (motor encoder) or "S-0-0053, Position feedback value 2" [external (load-side) encoder]
- Acceleration and deceleration ramps, can be set separately
- No change in direction of motion when
"command value mode in modulo format" equals "shortest distance", if $v_{act} > S-0-0417$
- "Shortest distance" mode when "command value mode in modulo format" equals "only positive/negative direction of motion" and target position within "S-0-0418, Target position window in modulo mode"



In this operation mode, it is possible to separately parameterize the acceleration and deceleration processes. This allows optimum adjustment to the respective application-specific requirements.

Pertinent Parameters

- S-0-0108, Feedrate override
- S-0-0138, Bipolar acceleration limit value
- S-0-0193, Positioning jerk
- S-0-0258, Target position
- S-0-0259, Positioning velocity
- S-0-0260, Positioning acceleration
- S-0-0342, Status "Target position attained"
- S-0-0343, Status "Interpolator halted"
- S-0-0359, Positioning deceleration
- S-0-0393, Command value mode
- S-0-0417, Positioning velocity threshold in modulo mode
- S-0-0418, Target position window in modulo mode
- S-0-0430, Effective target position
- S-0-0437, Positioning status
- P-0-0059, Additive position command value, controller
- P-0-0434, Position command value of controller
- P-0-0456, Position command value delay
- P-0-0457, Position command value generator
- P-0-0556, Config word of axis controller
- P-0-0641, Interpolation cmd value average value filter time constant

Pertinent Diagnostic Messages

- A0106 Drive-internal interpolation, encoder 1

Overview of the Scope of Functions

- A0107 Drive-internal interpolation, encoder 2
- A0108 Drive controlled interpolation, lagless, encoder 1
- A0109 Drive controlled interpolation, lagless, encoder 2
- E2049 Positioning velocity $\geq$ limit value
- E2053 Target position out of travel range
- E2055 Feedrate override S-0-0108 = 0
- F2057 Target position out of travel range

5.5.6 Drive-Controlled Positioning

Brief Description



Assignment to functional firmware package, see chapter "[Supported Operation Modes](#)".

The operation modes "drive-internal interpolation" and "drive-controlled positioning" allow time-optimized positioning of a single axis. The "drive-internal interpolation" mode is the basis for the more comprehensive functionality of the "drive-controlled positioning" mode.

In the "drive-controlled positioning" mode, a positioning command value is preset for the drive. The drive can continue processing this value internally in absolute (position target) or relative (travel distance) form. In the internal interpolator, a position command value characteristic is generated as the input value for the position controller from the preset positioning data (effective target position, velocity, acceleration and jerk).

There are different forms of the "drive-controlled positioning" mode which result in the corresponding diagnostic messages when the operation mode was activated (see below "Pertinent Diagnostic Messages").




Fig. 5-41: Block Diagram, Drive-Controlled Positioning

Features

- Processing of an absolute target position or a relative travel distance
- Drive-internal generation of a position command value profile to travel to the positioning command value (S-0-0282) while maintaining the positioning velocity (S-0-0259) and positioning acceleration (S-0-0260) or positioning deceleration (S-0-0359) that can be set; can be set separately
- Command value generation runs in the NC cycle "S-0-0001, NC cycle time (TNcyc)". The transition to the position controller cycle is made by cubic fine interpolation.
- Acceptance of the positioning command value via toggle bit (S-0-0346, bit 0)
- Jerk limitation of the generated position command value with parameter "S-0-0193, Positioning jerk"

Overview of the Scope of Functions

- Setting of the average value filter (jerk limitation) to a fixed filter time with interpolation command value average value filter time constant (P-0-0641)
- Adjustable position command value delay in position cycle times (P-0-0456), maximum of 32 cycles.
- Evaluation of the positioning velocity with parameter "S-0-0108, Feedrate override"
- Monitoring of the positioning velocity for exceeding the value in parameter "S-0-0091, Bipolar velocity limit value"



When using safety technology, the positioning velocity can be limited by "P-0-3238, SMO: Active velocity threshold", see also "Rexroth IndraDrive, Integrated Safety Technology as of MPx-1x (Safe Motion)" (DOK-INDRV*-SI3*SMO-VRS-AP**-EN-P; mat. no. R911338920).

- Monitoring of the target position for compliance with the position limit values (see "S-0-0049, Positive position limit value", "S-0-0050, Negative position limit value")
- Command value mode can be set in modulo format in parameter "S-0-0393, Command value mode" (shortest distance, positive only or negative only direction, no reversal of direction of rotation)
- Position control with regard to "S-0-0051, Position feedback value 1" (motor encoder) or "S-0-0053, Position feedback value 2" [external (load-side) encoder]
- Acceleration and deceleration ramps can be set separately ("S-0-0260, Positioning acceleration" or "S-0-0359, Positioning deceleration")
- Position limit values taken into account when accepting target position, positioning velocity and positioning acceleration
- Jog mode ("infinite travel" positive/negative; S-0-0346, bits 1 and 2)
- Residual path processing can be activated
- "On-the-fly acceptance" of the new target position or intermediate stop



In this operation mode, it is possible to separately parameterize the acceleration and deceleration processes in order to achieve optimum adjustment to the respective application-specific requirements.

Pertinent Parameters

- S-0-0057, Position window
- S-0-0108, Feedrate override
- S-0-0138, Bipolar acceleration limit value
- S-0-0193, Positioning jerk
- S-0-0259, Positioning velocity
- S-0-0260, Positioning acceleration
- S-0-0282, Positioning command value
- S-0-0342, Status "Target position attained"
- S-0-0343, Status "Interpolator halted"
- S-0-0346, Positioning control word
- S-0-0359, Positioning deceleration

Overview of the Scope of Functions

- S-0-0393, Command value mode
- S-0-0417, Positioning velocity threshold in modulo mode
- S-0-0418, Target position window in modulo mode
- S-0-0419, Positioning command acknowledge
- S-0-0430, Effective target position
- S-0-0437, Positioning status
- P-0-0059, Additive position command value, controller
- P-0-0434, Position command value of controller
- P-0-0456, Position command value delay
- P-0-0457, Position command value generator
- P-0-0556, Config word of axis controller
- P-0-0641, Interpolation cmd value average value filter time constant

Pertinent Diagnostic Messages

- A0150 Drive-controlled positioning, encoder 1
- A0151 Drive-controlled positioning, encoder 1, lagless
- A0152 Drive-controlled positioning, encoder 2
- A0153 Drive-controlled positioning, encoder 2, lagless
- E2049 Positioning velocity $\geq$ limit value
- E2053 Target position out of travel range
- E2055 Feedrate override S-0-0108 = 0
- F2050 Overflow of target position preset memory
- F2057 Target position out of travel range

5.5.7 Positioning Block Mode

Brief Description



Assignment to functional firmware package, see chapter "[Supported Operation Modes](#)".

In the operation mode, it is possible to run up to 64 programmed positioning blocks. The drive moves to the target position in position control, while maintaining velocity, acceleration, deceleration and jerk limits as defined in the respective positioning block.




Fig. 5-42: Block Diagram, "Positioning Block Mode":

Features

- Parameterization of up to 64 positioning blocks; each with target position/travel distance, velocity, acceleration, deceleration and jerk
- Command value generation runs in the NC cycle "S-0-0001, NC cycle time (TNcyc)". The transition to the position controller cycle is made by cubic fine interpolation.
- Jerk limitation of the generated position command value via "P-0-4009, Positioning block jerk"

Overview of the Scope of Functions

- Setting of the average value filter (jerk limitation) to a fixed filter time with interpolation command value average value filter time constant (P-0-0641)
- Adjustable position command value delay in position cycle times (P-0-0456), maximum of 32 cycles.
- Defined block acceptance by toggling bit 0 in S-0-0346 with reaction time $t_{R_strobe} = t_{position}$
Note: For field bus drives, the I/O mode is an exception. In these cases, acceptance takes place by a positive edge of bit 0 in P-0-4060.
→ Block selection and acknowledgment via separate parameters (handshake principle)
- Positioning modes to be freely parameterized:
 - Relative positioning
 - Absolute positioning
 - Infinite travel (positive or negative)
- Single-block or sequential block mode with different conditions for advancing:
 - Block advance with switch cams
 - Block advance at defined position value
 - Block transition with "old" or "new" positioning velocity
- Positioning block transition with freely definable delay time (P-0-4018)
- Positioning while taking command value mode into account (shortest distance, positive direction, ...)
- Residual path processing can be activated (→ no loss of incremental dimension)
- "Slow travel" mode can be activated
- Velocity override to be set



When using safety technology, the positioning velocity can be limited by "P-0-3238, SMO: Active velocity threshold", see also "Rexroth IndraDrive, Integrated Safety Technology as of MPx-1x (Safe Motion)" (DOK-INDRV*-SI3*SMO-VRS-AP**-EN-P; mat. no. R911338920).

Fields of Application

Sequential block processing allows executing several positioning blocks in direct sequence without having to give a new start signal each time. Typical fields of application are:

- There is none or only a very simple higher-level control unit available and control is realized via digital I/Os only or a field bus control word (I/O mode with field bus interface).
- There are quick reaction times or block advances required. The required motion profiles can be represented in the drive by the maximum possible 64 positioning blocks.
- There are positioning processes required which cover long distances at high speeds (rapid traverse) and then position at the end position at low speed without any intermediate stops; for example:
 - Taking up or putting down transport goods in handling robots
 - Executing joining processes in assembly facilities

Overview of the Scope of Functions

- Pertinent Parameters**
- S-0-0138, Bipolar acceleration limit value
 - S-0-0259, Positioning velocity
 - S-0-0346, Positioning control word
 - S-0-0393, Command value mode
 - S-0-0419, Positioning command acknowledge
 - S-0-0430, Effective target position
 - S-0-0437, Positioning status
 - P-0-0059, Additive position command value, controller
 - P-0-0434, Position command value of controller
 - P-0-0456, Position command value delay
 - P-0-0457, Position command value generator
 - P-0-0556, Config word of axis controller
 - P-0-0641, Interpolation cmd value average value filter time constant
 - P-0-4006, Positioning block target position
 - P-0-4007, Positioning block velocity
 - P-0-4008, Positioning block acceleration
 - P-0-4009, Positioning block jerk
 - P-0-4018, Positioning block delay time
 - P-0-4019, Positioning block mode
 - P-0-4026, Positioning block selection
 - P-0-4051, Positioning block acknowledgment
 - P-0-4052, Positioning block, last accepted
 - P-0-4053, Positioning block, last active
 - P-0-4057, Positioning block, input linked blocks
 - P-0-4060, Positioning block control word
 - P-0-4061, Positioning block status word
 - P-0-4063, Positioning block deceleration



Parameter S-0-0259 is used in positioning block mode to reduce positioning velocity (see also "P-0-4060, Positioning block control word").

- Pertinent Diagnostic Messages**
- A0162 Positioning block mode
 - A0206 Positioning block mode, encoder 1
 - A0207 Positioning block mode lagless, encoder 1
 - A0210 Positioning block mode, encoder 2
 - A0211 Positioning block mode lagless, encoder 2
 - E2049 Positioning velocity $\geq$ limit value
 - E2053 Target position out of travel range
 - E2054 Not homed
 - E2055 Feedrate override S-0-0108 = 0
 - E2058 Selected positioning block has not been programmed
 - F2028 Excessive deviation

5.5.8 Synchronization Modes

Basic Functions of the Synchronization Modes


Overview

General Information on Synchronization Modes

The synchronization modes allow the drive to run synchronously with regard to a real or virtual master axis. The synchronization modes are basically divided into the following groups:

- **Velocity synchronization**
- **Position synchronization with the operation modes**
 - Phase synchronization
 - Electronic cam
 - MotionProfile

The figure below illustrates how the synchronization modes are integrated in the control loop structure.



1) No position controller with "velocity synchronization" mode

Fig. 5-43: General Block Diagram of the Synchronization Modes

All synchronization modes have the following identical or similar basic functions which are comprehensively described in this section:

- Adjustment of master axis, consisting of
 - Generation of master axis
 - Master axis offset and modulo limitation
 - Electronic gear with fine adjustment
- Drive-controlled dynamic synchronization




The individual synchronization modes basically differ in the following function blocks:

- Command value processing specific to operation mode
- Command value addition for slave axis

These function blocks are described specific to operation mode in the individual sections on the respective synchronization modes.

Overview of the Scope of Functions

The figure below illustrates the interaction of the individual basic functions (function blocks) of the synchronization modes.



P-0-0048	Effective velocity command value
P-0-0052	Actual position value of measuring encoder
P-0-0053	Master axis position
P-0-0054	Additive master axis position
P-0-0088	Control word synchronization modes
P-0-0434	Position command value of controller
P-0-0692	Additive position command value, process loop
P-0-0694	Gear ratio fine adjustment, process loop
P-0-0761	Master axis position for slave axes
P-0-0764	Master axis speed
P-0-0775	Resulting master axis position
P-0-0776	Effective master axis position
P-0-0777	Effective master axis velocity
P-0-0778	Synchronous position command value
P-0-0779	Synchronous velocity
P-0-0787	Group axis position

Fig. 5-44: Function Blocks of the Synchronization Modes

Explanation of Terms

Master axis:

The virtual or real axis that provides the master axis position for generating the synchronous position command value for the slave axis is called master axis.

Master axis cycle:

The master axis cycle specifies the range in which the master axis values move. It corresponds to one master axis revolution or a multiple of that. So that the master axis positions can be processed correctly (e.g. in the case of modulo overflow), the size of the master axis cycle must be known to the drive. The control unit communicates the size of the master axis cycle to the drive in the configuration of parameter "P-0-0750, Master axis revolutions per master axis cycle".

Slave axis:

The drive that follows the command values derived from the master axis is called the slave axis.

Overview of the Scope of Functions

Command value cycle:

In processes with different machining cycles, the slave axis must be able to synchronize over several master axis revolutions or divisions of a master axis revolution. The so-called command value cycle provides this option. The modulo value of the command value cycle is calculated internally depending on the electronic gear (P-0-0156, Master drive gear input revolutions; P-0-0157, Master drive gear output revolutions) and the values "P-0-0750, Master axis revolutions per master axis cycle" and "S-0-0103, Modulo value".

See also parameter description "P-0-0754, Command value cycle".

Actual value cycle (actual position value in the actual value cycle):

The actual value cycle ("P-0-0786, Modulo value actual value cycle") is the modulo range within which the actual position values of the slave axis are to be found when the position synchronization mode is active (P-0-0753, Position actual value in actual value cycle). The user can specify the modulo value of the actual value cycle.



The operation modes of the position synchronization (phase synchronization, cam and MotionProfile) use the "actual position value in the actual value cycle" (P-0-0753) to close their position control loop.

The travel distance for synchronization is determined using the "actual position value in the actual value cycle" and the set synchronization range (see parameter description "P-0-0155, Synchronization mode") when one of the operation modes of the position synchronization is activated. The travel distance is limited by the synchronization range, i.e. the command value cycle, division of the command value cycle or modulo range (S-0-0103, Modulo value).

See parameter description "P-0-0753, Position actual value in actual value cycle".

See parameter description "P-0-0786, Modulo value actual value cycle".

The modulo value of the actual value cycle must be specified such that it corresponds with a whole number multiple of the command value cycle or the modulo range (S-0-0103, Modulo value).

Configuring and Controlling the Synchronization Modes

The synchronization modes velocity synchronization and position synchronization are configured and controlled by means of the following synchronization parameters:

Pertinent Parameters (Synchronization Parameters)

- S-0-0520, Axis control word
- S-0-0521, Axis status word
- P-0-0086, Configuration word synchronous operation modes
- P-0-0088, Control word synchronization modes
- P-0-0089, Status word synchronization modes

The following specifications can be made for the position-controlled operation modes using parameter S-0-0520:

- Position control with lag error or lagless
- Use of encoder 1 or encoder 2

See also "[Operation Mode Handling](#)".

Overview of the Scope of Functions

Command Value Addition

This section contains an overview of the basic possibilities of adding command values. The characteristics and details specific to operation mode are described in the section of the respective synchronization mode.

Pertinent Parameters

- S-0-0037, Additive velocity command value
- S-0-0048, Additive position command value
- P-0-0048, Effective velocity command value
- P-0-0054, Additive master axis position
- P-0-0060, Filter time constant additive position cmd value
- P-0-0434, Position command value of controller
- P-0-0686, Additive position command value, positioning velocity
- P-0-0687, Additive position command value, positioning acceleration
- P-0-0688, Additive master axis position, positioning velocity
- P-0-0689, Additive master axis position, positioning acceleration
- P-0-0690, Additive velocity command value, process loop
- P-0-0691, Additive position command value, process loop
- P-0-0692,
- P-0-0693, Filter time constant, add. master axis pos., process loop

The figure below contains a rough overview of the command values which can act on the master and slave axis and of how they can be influenced.




Fig. 5-45: Possibilities of Command Value Addition for Master and Slave Axis

Velocity Synchronization with Real/Virtual Master Axis

Brief Description



Assignment to functional firmware package, see chapter "[Supported Operation Modes](#)".

In the operation mode "velocity synchronization with real/virtual master axis", the drive follows a preset master axis velocity at a synchronous velocity.


The real master axis velocity is generated by a measuring encoder; in contrast, the virtual master axis velocity is preset by the master.

See also "Dynamic Synchronization of the Slave Axis" in the section "Basic Functions of the Synchronization Modes"

Overview of the Scope of Functions

- Features**
- Determination of the effective velocity command value (P-0-0048) from the differentiated and fine interpolated sum of master axis position (P-0-0053) or measuring encoder position (P-0-0052) and additive components of "P-0-0054, Additive master axis position" and "P-0-0692, ", multiplied by master axis gear and fine adjustment
 - Adjustable master axis polarity
 - Synchronization takes place in single-step form
 - Synchronization mode to be selected
 - Velocity adjustment always uses synchronization acceleration (P-0-0142)
 - Velocity adjustment using synchronization acceleration (P-0-0142) only in the first synchronization

The figure below illustrates the interaction of the individual subfunctions (function blocks) of the "velocity synchronization" mode:



P-0-0048	Effective velocity command value
P-0-0052	Actual position value of measuring encoder
P-0-0053	Master axis position
P-0-0088	Control word synchronization modes
P-0-0761	Master axis position for slave axis
P-0-0777	Effective master axis velocity
P-0-0787	Group axis 1 position

Fig. 5-46: Function Blocks of the Operation Mode "Velocity Synchronization with Real/Virtual Master Axis"

Variants of the Operation Mode

The following variants can be configured:

- Velocity synchronization with real master axis
- Velocity synchronization with virtual master axis

How to Use the Operation Mode

Velocity synchronization is used, for example, for simple transport rolls of printing machines. The drive runs with a velocity synchronous to the master axis. The track speed at the circumference of the transport roll or the winder is preset by the electric gear. A defined tension can be set by the fine adjustment of the gear.

Pertinent Parameters

In addition to the general parameters of all synchronization modes, there are other parameters involved in velocity synchronization:

- S-0-0037, Additive velocity command value
- S-0-0183, Velocity synchronization window

Overview of the Scope of Functions

- P-0-0159, Slave drive feed travel
- P-0-0690, Additive velocity command value, process loop
- P-0-0777, Effective master axis velocity

See also "Pertinent Parameters" in the subsections of "[Basic Functions of the Synchronization Modes](#)"

Pertinent Diagnostic Messages

In addition to the general diagnostic messages of all synchronization modes, there are other diagnostic messages involved in velocity synchronization:

- A0110 Velocity synchronization, virtual master axis
- A0111 Velocity synchronization, real master axis
- A0164 Velocity synchronization
- E2063 Velocity command value > limit value

See also "Pertinent Diagnostic Messages" in the subsections of "[Basic Functions of the Synchronization Modes](#)"

Position Synchronization: Phase Synchronization

Brief Description



Assignment to functional firmware package, see chapter "[Supported Operation Modes](#)".

In the operation mode "phase synchronization with real/virtual master axis", the drive follows a preset master axis position in an absolute or relative phase synchronous way.

The real master axis velocity is generated by a measuring encoder; in contrast, the virtual master axis velocity is preset by the master.


See also "Dynamic Synchronization of the Slave Axis" in the section "Basic Functions of the Synchronization Modes"

Features

- Determination of the position command value from the master axis position using the electronic gear with fine adjustment, adjustable master axis polarity
- Synchronization mode to be selected
- Single-step, double-step or optimized double-step synchronization
- Absolute or relative phase synchronization
- Synchronization range to be selected

The figure below illustrates the interaction of the individual subfunctions (function blocks) of the "phase synchronization" mode:

Overview of the Scope of Functions



P-0-0052	Actual position value of measuring encoder
P-0-0053	Master axis position
P-0-0088	Control word synchronization modes
P-0-0434	Position command value of controller
P-0-0776	Effective master axis position
P-0-0777	Effective master axis velocity
P-0-0778	Synchronous position command value
P-0-0779	Synchronous velocity
P-0-0787	Group axis 1 position

Fig. 5-47: Function Blocks of the Operation Mode "Phase Synchronization with Real/Virtual Master Axis"

Variants of the Operation Mode

The following variants can be configured:

- Position Synchronization: Phase synchronization
 - Phase synchronization with real master axis, encoder 1
 - Phase synchronization with real master axis, encoder 2
 - Phase synchronization with real master axis, encoder 1, lagless
 - Phase synchronization with real master axis, encoder 2, lagless
 - Phase synchronization with virtual master axis, encoder 1
 - Phase synchronization with virtual master axis, encoder 2
 - Phase synchronization with virtual master axis, encoder 1, lagless
 - Phase synchronization with virtual master axis, encoder 2, lagless



The position synchronization mode "phase synchronization", "cam" or "MotionProfile" and the active master axis are selected in parameter "P-0-0088, Control word synchronization modes". Encoder selection and specification of lagless position control or position control with lag error are made in parameter "S-0-0520, Axis control word".

Application "Absolute Phase Synchronization"

In machining processes that require absolute phase synchronization, e.g. printing, punching or perforating in printing machines, the absolute position reference to the master axis is established in the "phase synchronization"

Overview of the Scope of Functions

Application "Relative Phase Synchronization"

mode. The drive synchronizes with a position command value that is generated from master axis position and additive position command value.

For machining processes that only require relative phase synchronization, e.g. synchronization of belts or feed rollers without defined starting point, a relative position reference to the master axis is established. During the first synchronization, there is only an adjustment to the synchronous velocity but no position adjustment carried out.

Pertinent Parameters

In addition to the general parameters of all synchronization modes, there are other parameters involved in phase synchronization:

- S-0-0103, Modulo value
- S-0-0520, Axis control word
- S-0-0521, Axis status word
- P-0-0086, Configuration word synchronous operation modes
- P-0-0088, Control word synchronization modes
- P-0-0089, Status word synchronization modes
- P-0-0159, Slave drive feed travel
- P-0-0776, Effective master axis position
- P-0-0777, Effective master axis velocity
- P-0-0778, Synchronous position command value
- P-0-0779, Synchronous velocity

See also "Pertinent Parameters" in the subsections of ["Basic Functions of the Synchronization Modes"](#)

Position Synchronization: Electronic Cam

Brief Description



Assignment to functional firmware package, see chapter ["Supported Operation Modes"](#).

In the operation mode "electronic cam with real/virtual master axis", there is a fixed relationship between the master axis position and the slave axis.

The real master axis velocity is generated by a measuring encoder; in contrast, the virtual master axis velocity is preset by the master.

See also "Dynamic Synchronization of the Slave Axis" in the section "Basic Functions of the Synchronization Modes"


Features

- 4 cam tables with a max. of 1024 data points (P-0-0072, P-0-0092, P-0-0780, P-0-0781)
- 4 cam tables with a max. of 128 data points (P-0-0783, P-0-0784, P-0-0785, P-0-0786)
- Cubic spline interpolation of the cam data points
- Dynamic angle offset and angle offset at begin of profile
- Freely definable switch angle for cam and cam distance
- Synchronization mode to be selected
- Single-step, double-step or optimized double-step synchronization
- Absolute or relative phase synchronization
- Synchronization range to be selected
- Change of format "on the fly"

Overview of the Scope of Functions

- Cross cutter function
- Clocked pull roll

The figure below illustrates the interaction of the individual subfunctions (function blocks) of the "electronic cam" mode:



P-0-0052	Actual position value of measuring encoder
P-0-0053	Master axis position
P-0-0088	Control word synchronization modes
P-0-0434	Position command value of controller
P-0-0776	Effective master axis position
P-0-0777	Effective master axis velocity
P-0-0778	Synchronous position command value
P-0-0779	Synchronous velocity
P-0-0787	Group axis 1 position

Fig. 5-48: Function Blocks of the Operation Mode "Electronic Cam"

Variants of the Operation Mode

The following variants can be configured:

- Position Synchronization: Cam with real master axis, encoder 1
- Position Synchronization: Cam with real master axis, encoder 2
- Position Synchronization: Cam with real master axis, encoder 1, lagless
- Position Synchronization: Cam with real master axis, encoder 2, lagless
- Position Synchronization: Cam with virtual master axis, encoder 1
- Position Synchronization: Cam with virtual master axis, encoder 2
- Position Synchronization: Cam with virtual master axis, encoder 1, lagless
- Position Synchronization: Cam with virtual master axis, encoder 2, lagless



The position synchronization mode "phase synchronization", "cam" or "MotionProfile" and the active master axis are selected in parameter "P-0-0088, Control word synchronization modes". Encoder selection and specification of lagless position control or position control with lag error are made in parameter "S-0-0520, Axis control word".

Overview of the Scope of Functions

Pertinent Parameters In addition to the general parameters of all synchronization modes, there are other parameters involved in this operation mode:

- S-0-0103, Modulo value
- S-0-0520, Axis control word
- S-0-0521, Axis status word
- P-0-0061, Angle offset begin of table
- P-0-0072, Cam table 1
- P-0-0073, Cam distance 2
- P-0-0085, Dynamic angle offset
- P-0-0086, Configuration word synchronous operation modes
- P-0-0088, Control word synchronization modes
- P-0-0089, Status word synchronization modes
- P-0-0092, Cam table 2
- P-0-0093, Cam distance
- P-0-0094, Cam switch angle
- P-0-0144, Cam distance switch angle
- P-0-0158, Angle offset change rate
- P-0-0159, Slave drive feed travel
- P-0-0227, Cam table, access angle
- P-0-0695, Angle offset begin of table, process loop
- P-0-0696, Filter time constant, angle offset profile, process loop
- P-0-0776, Effective master axis position
- P-0-0777, Effective master axis velocity
- P-0-0778, Synchronous position command value
- P-0-0779, Synchronous velocity
- P-0-0780, Cam table 3
- P-0-0781, Cam table 4
- P-0-0782, Cam table 5
- P-0-0783, Cam table 6
- P-0-0784, Cam table 7
- P-0-0785, Cam table 8

See also "Pertinent Parameters" in the subsections of "[Basic Functions of the Synchronization Modes](#)"

Pertinent Diagnostic Messages In addition to the general diagnostic messages of all synchronization modes, there are other diagnostic messages involved in this operation mode:

- A0128 Cam, encoder 1, virtual master axis
- A0129 Cam, encoder 2, virtual master axis
- A0130 Cam, encoder 1, real master axis
- A0131 Cam, encoder 2, real master axis
- A0132 Cam, lagless, encoder 1, virt. master axis
- A0133 Cam, lagless, encoder 2, virt. master axis
- A0134 Cam, lagless, encoder 1, real master axis
- A0135 Cam, lagless, encoder 2, real master axis

Overview of the Scope of Functions

- A0163 Position synchronization
- F2002 Assignment of encoder for synchronization is not allowed
- F2005 Cam table invalid

See also "Pertinent Diagnostic Messages" in the subsections of "[Basic Functions of the Synchronization Modes](#)"

Position Synchronization: MotionProfile

Brief Description



Expansion package **Synchronization** (order code **SNC**) for the variants **MPB** and **MPD** in **closed-loop** characteristic

In the operation mode "MotionProfile with real/virtual master axis", there is a fixed relationship between the master axis position and the slave axis.

The real master axis velocity is generated by a measuring encoder; in contrast, the virtual master axis velocity is preset by the master.


See also "Dynamic Synchronization of the Slave Axis" in the section "Basic Functions of the Synchronization Modes"

Features

- 2 sequences of motion with up to 8 motion steps per master axis revolution
- Definition of a motion step by standardized profile or cam table
- Motion laws can be selected (rest in rest, rest in velocity, velocity in rest, velocity in velocity, constant velocity)
- Motion laws realized by 5th order polynomial or, in the case of rest in rest, alternatively by inclined sine curve
- Individual distance for each motion step
- Dynamic angle offset and angle offset at begin of profile
- Absolute synchronization can be switched off
- Synchronization mode to be selected
- Absolute or relative processing of the motion steps to be selected
- Synchronization range to be selected
- Cross cutter function

The figure below illustrates the interaction of the individual subfunctions (function blocks) of the "MotionProfile" mode:

Overview of the Scope of Functions



P-0-0052	Actual position value of measuring encoder
P-0-0053	Master axis position
P-0-0088	Control word synchronization modes
P-0-0434	Position command value of controller
P-0-0776	Effective master axis position
P-0-0777	Effective master axis velocity
P-0-0778	Synchronous position command value
P-0-0779	Synchronous velocity

Fig. 5-49: Function Blocks of the "MotionProfile" Mode

Variants of the Operation Mode

The following variants can be configured:

- Position Synchronization: MotionProfile
 - MotionProfile with real master axis, encoder 1
 - MotionProfile with real master axis, encoder 2
 - MotionProfile with real master axis, encoder 1, lagless
 - MotionProfile with real master axis, encoder 2, lagless
 - MotionProfile with virtual master axis, encoder 1
 - MotionProfile with virtual master axis, encoder 2
 - MotionProfile with virtual master axis, encoder 1, lagless
 - MotionProfile with virtual master axis, encoder 2, lagless



The position synchronization mode "phase synchronization", "cam" or "MotionProfile" and the active master axis are selected in parameter "P-0-0088, Control word synchronization modes". Encoder selection and specification of lagless position control or position control with lag error are made in parameter "S-0-0520, Axis control word".

Pertinent Parameters

In addition to the general parameters of all synchronization modes, there are other parameters involved in this operation mode:

- S-0-0103, Modulo value
- S-0-0520, Axis control word

Overview of the Scope of Functions

- S-0-0521, Axis status word
- P-0-0061, Angle offset begin of table
- P-0-0085, Dynamic angle offset
- P-0-0086, Configuration word synchronous operation modes
- P-0-0088, Control word synchronization modes
- P-0-0089, Status word synchronization modes
- P-0-0158, Angle offset change rate
- P-0-0159, Slave drive feed travel
- P-0-0227, Cam table, access angle
- P-0-0695, Angle offset begin of table, process loop
- P-0-0696, Filter time constant, angle offset profile, process loop
- P-0-0700, MotionProfile, master axis switching position
- P-0-0701, Motion step 1, slave axis initial position
- P-0-0702, MotionProfile, diagnosis, set 0
- P-0-0703,
- P-0-0704, Master axis velocity, set 0
- P-0-0705, List of master axis initial positions, set 0
- P-0-0706, List of motion laws, set 0
- P-0-0707, List of distances, set 0
- P-0-0708, List of slave axis velocities, set 0
- P-0-0709, MotionProfile, diagnosis, set 1
- P-0-0710,
- P-0-0711, Master axis velocity, set 1
- P-0-0712, List of master axis initial positions, set 1
- P-0-0713, List of motion laws, set 1
- P-0-0714, List of distances, set 1
- P-0-0715, List of slave axis velocities, set 1
- P-0-0755, Gear reduction
- P-0-0776, Effective master axis position
- P-0-0777, Effective master axis velocity
- P-0-0778, Synchronous position command value
- P-0-0779, Synchronous velocity

See also "Pertinent Parameters" in the subsections of ["Basic Functions of the Synchronization Modes"](#)

Pertinent Diagnostic Messages

In addition to the general diagnostic messages of all synchronization modes, there are other diagnostic messages involved in this operation mode:

- A0136 MotionProfile, encoder 1, virtual master axis
- A0137 MotionProfile, encoder 2, virtual master axis
- A0138 MotionProfile, encoder 2, real master axis
- A0139 MotionProfile, encoder 1, real master axis
- A0140 MotionProfile lagless, encoder 1, virtual master axis
- A0141 MotionProfile lagless, encoder 2, virtual master axis
- A0142 MotionProfile lagless, encoder 1, real master axis

Overview of the Scope of Functions

- A0143 MotionProfile lagless, encoder 2, real master axis
- A0163 Position synchronization
- F2002 Assignment of encoder for synchronization is not allowed
- F2003 Motion step skipped
- F2004 Error in MotionProfile

See also "Pertinent Diagnostic Messages" in the subsections of "[Basic Functions of the Synchronization Modes](#)"

5.6 Extended Axis Functions

5.6.1 Availability of the Extended Axis Functions

For an overview that illustrates in which base or functional packages the respective extended axis function is available, see chapter "[Overview of Functions/Functional Packages, Availability of the Extended Axis Functions](#)".

5.6.2 Drive Halt

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

The "Drive Halt" function is used to shut down an axis with defined acceleration and defined jerk.

In the default case, Drive Halt is executed as a quick stop in position control or velocity control. Position control is activated when one of the operation modes (S-0-0032 ...) with position control is defined (including internal PLC operation modes). Otherwise, velocity control is active.

With the Drive Halt configuration (P-0-0558, bit 1, bit 2), the type of control can also be freely selected.

- Bit 1 = 1, bit 2 = 1: Position Control
- Bit 1 = 1, bit 2 = 0: Velocity Control

With the "Drive Halt" configuration (P-0-0558, bit 0 = 1), it is possible to switch to the "operational stop" function. Then the operation modes "velocity control", "drive-internal interpolation", "drive-controlled positioning" and "positioning block" are stopped internally with Vcmd = 0. After "Drive Halt" has been removed, motion is active again.

The adjustable position command value delay in position cycle times (P-0-0456) is a maximum of 32 cycles.



In addition to the "Drive Halt" function, there is an operational stop for the operation modes "drive-controlled positioning" and "drive-internal interpolation". This function, however, has its own control signal.

Features

- Activation using the "halt bit" of the master communication (see "Device Control and State Machines")
- Active operation mode interrupted; drive remains in control (after setting the "halt bit" the interrupted operation mode is continued)
- Quick stop in position control

Overview of the Scope of Functions

- Shutdown with acceleration (S-0-0372) and jerk limit values (S-0-0349) in position control
 - **Quick stop in velocity control**
 - Shutdown with acceleration (S-0-0372) and jerk limit values (S-0-0349) in velocity control
 - If the Drive Halt acceleration bipolar (S-0-0372) is set to "0", "S-0-0138, Bipolar acceleration limit value" is effective at shutdown.
 - Acknowledgement of "Drive Halt" in P-0-0115
- Pertinent Parameters**
- S-0-0124, Standstill window
 - S-0-0349, Bipolar jerk limit
 - S-0-0372, Drive Halt acceleration bipolar
 - S-0-0138, Bipolar acceleration limit value
 - P-0-0115, Device control: Status word
 - P-0-0434, Position command value of controller
 - P-0-0456, Position command value delay
 - P-0-0457, Position command value generator
 - P-0-0558, Drive Halt configuration

5.6.3 Error Reactions

Overview of Error Reactions

Depending on the operation mode that is used and some parameter settings, the drive controller carries out monitoring functions. An error message is generated by the drive controller, if a state is detected that no longer allows correct operation.

Errors are classified in error classes. The error class is represented by the first two digits of the diagnostic message number.

See also "[Terms, Basic Principles](#)"

See also "[Diagnostic System](#)"

If the drive controller is in control (drive enable was set) and an error occurs, the drive controller automatically starts a drive error reaction.

This drive error reaction depends on:

- The error class of the error occurred and
- The settings of the following parameters:
 - P-0-0117, Activation of control unit reaction on error
 - P-0-0118, Power supply, configuration
 - P-0-0119, Best possible deceleration



At the end of each error reaction, the drive goes torque-free. Power off depends on the setting in P-0-0118!

Error Classes There are different error classes with increasing priority:

Overview of the Scope of Functions

Diagnostics Number and Error class	Control unit reaction according to "P-0-0117, Activation of control unit reaction on error"	Power supply switched off according to "P-0-0118, Power supply, configuration"	Drive-side error reaction according to "P-0-0119, Best possible deceleration"
F2xxx Non-fatal error	■	■	■
F28xx Non-fatal error	■	General shutdown of power supply, because this concerns errors of the supply unit of the converter	■
F3xxx Non-fatal Safety technology error	-	■	■
F4xxx Error of master communication	-	■	■
F6xxx Emergency stop error	-	■	■
F7xxx Safety technology error	-	■	■ At the end of each F7 error reaction, the drive goes torque-free.
F8xxx Fatal error	-	■	■
F83xx Fatal error of safety technology	-	■	■
F9xxx Fatal system error	-	■	Always torque disable

Tab. 5-56: Error Classes and Drive Reaction



The error class defines the drive behavior in the case of error. The "fatal system error" (E-xxxx) has the highest priority.

Best Possible Deceleration

Brief Description

The error reaction "best possible deceleration", which can be set in "P-0-0119, Best possible deceleration", is carried out automatically in the case of the following states:

- Non-fatal errors (F2xxx)
- Non-fatal safety technology errors (F3xxx)
- Interface errors (F4xxx)
- Drive enable is removed
- Drive-controlled transition to the special mode standstill SS1ES/SS1

Overview of the Scope of Functions

- Travel range errors (F6xxx)
- Errors of safety technology (F7xxx)
- Fatal errors (F8xxx), if possible
- Fatal warnings (E8xxx)

One of the following reactions for "best possible deceleration" can be set in P-0-0119:

- Velocity command value reset (emergency stop)
- Velocity command value reset with ramp and filter (emergency stop)
- Velocity command value reset with ramp and filter (quick stop)
- Return motion
- Emergency stop by means of motor winding short circuit
- Torque disable



See also parameter description "P-0-0119, Best possible deceleration"



In the case of fatal system errors (F9xxx), the setting in P-0-0119 is without effect; the drive immediately goes torque-free. Shut-down on the drive side is no longer possible!

Pertinent Parameters

- S-0-0138, Bipolar acceleration limit value
- S-0-0273, Maximum drive off delay time
- S-0-0349, Bipolar jerk limit
- S-0-0372, Drive Halt acceleration bipolar
- S-0-0429, Emergency halt deceleration
- P-0-0045, Control word of current controller
- P-0-0055, Return distance
- P-0-0056, Return velocity
- P-0-0057, Return acceleration
- P-0-0058, Return jerk
- P-0-0109, Torque/force peak limit
- P-0-0119, Best possible deceleration
- P-0-0525, Holding brake control word
- P-0-0569, Maximum stator frequency slope

Package Reaction on Error

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

"Package reaction" is the simultaneous error reaction of all axis drives supplied by a common power bus (DC bus). Drive errors of a drive can be signaled to all other axis drives via the module bus (signal bus) which allows the simultaneous error reaction (according to setting in parameter "P-0-0119, Best possible deceleration") of all axis drives.

Overview of the Scope of Functions

The settings for signaling drive errors and package reaction are made individually for each drive in "P-0-0118, Power supply, configuration". This allows activating the package reaction only for individual axes. The behavior of the axes for which the package reaction has not been activated has to be taken into account for the case of error and must be controlled on the master side, if necessary!



The supply unit switches off power supply only in the case of its own errors and in the case of fatal drive errors (F8xxx), if the drive signaling errors signals F8 errors to the supply.

Fields of Application

Examples of applications with interactive (interpolating, synchronized) use of drives that are supplied by a common power bus ("drive system"):

- Machine tools (e.g. milling, turning, grinding machines)
- Gear cutting machines (gear wheel machining)
- Printing mechanisms of printing machines, etc.

By setting the error reaction of the drive system devices according to the application, the following damages can be minimized:

- Machine damages
- Tool/workpiece/material damages

WARNING

The package reaction is not suitable for avoiding personal injury!

Overview of the Scope of Functions

Reaction to drive errors	Priority of appropriate error reactions for typical drive applications	Setting in P-0-0117	Setting in P-0-0118	General conditions
NC master-side reaction	NC master-side priority of shutdown and power off	NC reaction active	No package reaction, no signaling of drive errors	Drive with F8 error does not decelerate!
Drive reaction	Shutdown spindle drive (asynchronous motors) Shutdown servo drives (synchronous motors) Power off	NC reaction not active	Package reaction, signaling of drive errors	Drive with F8 error does not decelerate! , No DC bus short circuit Power off via NC master
	Shutdown servo drives (synchronous motors) Power off Shutdown spindle drive (asynchronous motors) irrelevant	NC reaction not active	Package reaction, signaling of drive errors, signaling of F8 errors to supply	Power off only with F8 error, otherwise via NC master with DC bus short circuit
	Power off Shutdown spindle drive (asynchronous motors) Shutdown servo drives (synchronous motors)	NC reaction not active	Package reaction, signaling of drive errors, signaling of F8 errors to supply	Power off only with F8 error, otherwise via NC master; no DC bus short circuit, drive with F8 error does not decelerate!
	Power off Shutdown servo drives (synchronous motors) Shutdown spindle drive (asynchronous motors)	NC reaction not active	Package reaction, signaling of drive errors, signaling of F8 errors to supply	Power off only with F8 error, otherwise via NC master with DC bus short circuit

Tab. 5-57: Examples of Settings in P-0-0117 and P-0-0118, Depending on the Priority of Appropriate Error Reactions (with General Conditions)



The above examples are not binding and provide basic information on the settings that have to be made according to the axis-specific and application-dependent requirements.

Pertinent Parameters

- P-0-0118, Power supply, configuration
- P-0-0119, Best possible deceleration

Notes on Commissioning

Basic settings with regard to error handling have to be made in parameter "P-0-0118, Power supply, configuration":

- Reaction to signaled errors of other drives in the drive system ("package reaction")
- Signaling of own drive errors in drive system via module bus
- Handling of "undervoltage" message for inverters (HMS or HMD type) and converters (HCS type)

Overview of the Scope of Functions

- Automatic clearing of the error "F2026Undervoltage in power section" by switching off drive enable
- Signaling of own, fatal drive errors (F8xxx) to the supply via module bus

Control Reaction on Error

NC Reaction on Error

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

To avoid damage to the machine, some applications require that the master (e.g. NC) retains control of the travel profile of the axes even in case of error and shuts down the machine axes in a coordinated way. For this case, the "NC reaction on error" option was implemented; it can be activated via parameter P-0-0117.

The master is informed of an error in the drive controller via the drive status word (see S-0-0135) so that the master can shut down the machine axes in a coordinated way and therefore avoid possible damage.



NC reaction on error is only possible with non-fatal errors (diagnostic message F2xxx), otherwise the drive always reacts with an immediate drive-side error reaction.

Pertinent Parameters

- S-0-0135, Drive status word
- P-0-0117, Activation of control unit reaction on error
- P-0-0119, Best possible deceleration

MLD Reaction on Error

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

As an alternative to the NC reaction, the IndraMotion MLD reaction on error can also be realized for the (local) axis. In this, the MLD reaction and the NC reaction are differentiated functionally insofar as by means of IndraMotion MLD, even for an interface error (F4xxx) an error reaction to be defined by the user can be executed for the (local) axis.



Prerequisite for using the MLD error reaction is the enabling of the PLC function in the drive (see "[Enabling of Functional Packages](#)").

Pertinent Parameters

- S-0-0135, Drive status word
- P-0-0117, Activation of control unit reaction on error
- P-0-0119, Best possible deceleration
- P-0-2003, Selection of functional packages

5.6.4 E-Stop Function

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

The E-Stop function is used to shut down the drive with a selectable drive reaction (see Parameter Description "P-0-0008, Activation E-Stop function") via a digital input of the drive controller.

To use the E-Stop function, you have the following options:

- E-Stop with reaction to interface error (F4034 Emergency-Stop activated)
→ **Reaction:** Best possible deceleration (as set in P-0-0119)
- E-Stop with reaction to travel range error (F6034 Emergency-Stop activated)
→ **Reaction:** Velocity command value reset
- E-Stop as fatal warning "E8034Emergency-Stop activated"
→ **Reaction:** Best possible deceleration (as set in P-0-0119)



If "E-Stop" was parameterized as a warning, the diagnostic message does not have to be cleared!

Pertinent Parameters

- P-0-0008, Activation E-Stop function
- P-0-0119, Best possible deceleration
- P-0-0223, E-Stop input
- P-0-0249, E-Stop and safety zones

Pertinent Diagnostic Messages

- E8034 Emergency-Stop activated
- F4034 Emergency-Stop activated
- F6034 Emergency-Stop activated

5.6.5 Compensation Functions / Corrections

Friction Torque Compensation

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

The behavior of a machine axis is negatively affected by static friction when starting or when reversing the direction. The drive-internal friction torque compensation allows compensating the static friction by adding, depending on the direction of movement, a torque/force command value.

Overview of the Scope of Functions




Fig. 5-50: Friction Torque Curve with Static Friction



Friction torque compensation is mainly intended to be used in precision machine tools and to reduce the path errors caused by static friction. This applies particularly to circular errors at the quadrant transitions.

Pertinent Parameters

- S-0-0092, Bipolar torque/force limit value
- S-0-0124, Standstill window
- S-0-0155, Friction compensation

Axis Error Correction

Brief Description

The actual position value provided by the measuring system can differ from the real actual position value at the axis, e.g. at the point of chip removal in the case of metal-cutting machining, due to

- inaccuracy of the measuring system,
- transmission inaccuracy in mechanical transmission elements such as gear, clutch, feed spindle etc.,
- thermal expansion of machine parts of the drive system.

For compensating the mechanically determined position error sources, IndraDrive controllers provide the following correction functions:

- Backlash on reversal correction
- Precision axis error correction
- Control-side axis error correction

The control-side axis error correction is always active. The correction value can be transmitted in the cyclic telegram or in the service channel. In addition, precision axis error correction or reversal clearance can be activated, precision axis error correction having higher priority.

Moreover, it is possible to activate the temperature error correction. IndraDrive controllers provide two possibilities of correcting temperature errors:

- Independent of axis position
 - Depending on axis position
- Pertinent Parameters**
- S-0-0058, Reversal clearance
 - S-0-0124, Standstill window
 - P-0-0400, Axis correction external correction value
 - P-0-0401, Axis correction active correction value
 - P-0-0402, Axis correction reference temperature

Overview of the Scope of Functions

- P-0-0403, Axis correction reference position for temp. corr.
- P-0-0404, Axis correction actual temperature pos.-dependent
- P-0-0405, Axis correction actual temperature pos.-independent
- P-0-0406, Axis correction temperature factor pos.-dependent
- P-0-0407, Axis correction temperature factor pos.-independent
- P-0-0408, Axis correction start position
- P-0-0409, Axis correction end position
- P-0-0410, Axis correction support point distance
- P-0-0411, Axis correction, correction table positive
- P-0-0412, Axis correction, correction table negative
- P-0-0413, Axis correction control word

Quadrant Error Correction

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

In the case of axis drives that are controlled, for example, in circular interpolation, static friction at the reversal points of the direction of motion can cause distortion of the circular contour.

In order to compensate this contour error at the so-called "quadrant transitions" (velocity reversal), IndraDrive controllers provide the "quadrant error correction" function.

This correction function is useful for such cases when drives are operated in cyclic position control and in circular interpolation by the control master.

Pertinent Parameters

- P-0-0100, Position command value extension
- P-0-0435, Control word of position controller
- P-0-0436, Reference radius for quadrant error correction
- P-0-0437, Velocity time range for quadrant error correction
- P-0-0438, Table of path velocities for quadrant error correction
- P-0-0439, Table of velocity pulse for quadrant error correction

Cogging Torque Compensation

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

Motors for which the magnetic excitation is realized with permanent magnets (e.g. synchronous motors) in many cases show cogging torques or cogging forces. Cogging torques/cogging forces already act on the moving component of the motor in the de-energized state and aim at moving it to a stable position.

When the motor is put into motion by control, the cogging torques/cogging forces act on the motor in a decelerating or accelerating way, according to the position. For applications in which minimum lag error or very constant velocity is important, the position-dependent cogging torques/cogging forces can have a negative effect.

Overview of the Scope of Functions

To improve the synchronous operation and lag error behavior of synchronous motors, IndraDrive controllers provide cogging torque and cogging force compensation for drives with high demands on lag error and synchronous operation quality. For this purpose, the position-dependent, additive torque command values that take effect in drive control require an unequivocal position reference from the motor measuring system to the motor.

The position reference is automatically established using a search of the reference marks. If this is not possible, you can switch to the "position reference by homing" function (P-0-1131, Control word of cogging torque compensation). The position reference is then established only by the "homing" command; in this way, even encoders without a mark or with several marks can be used.

The range in which the cogging torque compensation takes effect can cover the entire travel range of an axis, but can also be restricted to a definable position range. The restricted position range can be less than one motor revolution (rotary motor) or one pole pair distance (linear motor). The drive controller determines the compensation values at axis motion with constant velocity and the values, depending on the direction of motion and referring to the position, are stored in tables.

Hardware Requirements The compensation of the cogging torque or the cogging force is possible for the use of both measuring systems with absolute evaluation and measuring systems with relative evaluation. The following restriction applies to relative measuring systems where the reference point is automatically established:

- For rotary motors only **one** reference mark may occur per revolution or the motor encoder has distance-coded reference marks!
- For linear motors only **one** reference mark may occur over the travel distance or the motor encoder has distance-coded reference marks!

Hardware Requirements The motor must be equipped with a motor encoder. Cogging torque compensation is not possible with sensorless motor operation!

- Pertinent Parameters**
- P-0-0162, C1800 Command Drive optimization / command value box
 - P-0-0165, Drive optimization, control word
 - P-0-0170, Drive optimization, acceleration
 - P-0-0171, Drive optimization, velocity
 - P-0-1129, Cogging torque compensation value
 - P-0-1130, Table of cogging torque compensation values pos. direction
 - P-0-1131, Control word of cogging torque compensation
 - P-0-1132, Table of cogging torque compensation values neg. direction
 - P-0-1133,
 - P-0-1134, Velocity threshold for attenuation of cogging torque compens.
 - P-0-1135, Velocity threshold for switching off cogging torque compens.
 - P-0-1136, Lead time cogging torque compensation
 - P-0-1138, C4800 Command Determine cogging torque compensation table
 - P-0-1139,
 - P-0-1145, Cogging torque compensation: Lower position limit
 - P-0-1146, Cogging torque compensation: Upper position limit
 - P-0-1147, Cogging torque compensation: Offset positive
 - P-0-1148, Cogging torque compensation: Offset negative

Overview of the Scope of Functions

Pertinent Diagnostic Messages

- C1808 Drive not homed
- C4800 Command Determine cogging torque compensation table
- C4801 Cogging torque compensation: Measuring vel. too high
- C4802 Cogging torque compensation: Measuring vel. too low
- C4803 Cogging torque compensation: Inadmissible acceleration
- C4804 Cogging torque comp.: Err. when storing corr. val table
- C4805 Cogging torque comp.: Motor measuring system not homed
- C4806 Cogging torque compensation: Measuring range invalid

Correction of Torque/Force Constant

Brief Description

Fields of Application



Base package of all firmware variants in **closed-loop** characteristic

Display of Motor Load, Load Limit Values

For IndraDrive devices, the current load of the motor is determined and displayed on the drive side. The load can be limited by means of the drive controller.

The unit of the load display and load limit value input can be selected:

- Percentage-based, in relation to the continuous motor current or nominal motor current
- Physically, values in "Nm" (rotary) or "N" (linear)

The load of the motor is determined by means of the measured motor current; with physical scaling, the controller determines the motor torque or force by using the currently flowing current for calculating the motor-type-specific torque or force constant.

If torque/force precision up to approx. +/- 5% is required (e.g., for load limitation) due to the mechanical axis system or process technology, the controller provides the "correction of torque/force constant". In this case, the motor-type-specific value is corrected depending on the current motor current, the motor temperature and the average speed.



Due to the downward compatibility of the firmware and possibly unavailable parameter values (e.g., for third-party motors), this correction must be separately activated!

Pertinent Parameters

- P-0-0448, Temperature-dependent torque/force coefficient
- P-0-0449, Speed-dependent torque/force coefficient
- P-0-0450, Current torque/force constant
- P-0-0556, Config word of axis controller
- P-0-3055,
- P-0-3056,
- P-0-3057,
- P-0-3058,
- S-0-0533, Nominal torque/force of motor
- S-0-0534, Maximum torque/force of motor

Overview of the Scope of Functions

Pertinent Diagnostic Messages

- None -

5.6.6 Measuring Wheel Mode

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

The measuring wheel mode is used for material feed axes, e.g. in sheet-metal machining. For direct measurement of the infeed of moved material, a rotary encoder that is detecting the infeed length is driven via a measuring wheel with frictionally engaged contact to the material surface.

The position control loop is closed via motor encoder and measuring wheel encoder, possible slip between motor and material does not cause incorrect measured values of material length.



The measuring wheel mode may only be activated when contact has been established between measuring wheel and material surface.




Fig. 5-51: Typical Arrangement of a Drive for Material Infeed with Measuring Wheel Encoder

Hardware Requirements

The measuring wheel encoder is an optional (external) encoder that is connected according to the connection diagram contained in the separate documentation (see "[Reference Documentations](#)").

See also [Measuring Systems](#)

Pertinent Parameters

The following parameters are used to parameterize this function:

- S-0-0520, Axis control word
- S-0-0521, Axis status word
- P-0-0241, Actual pos. smoothing time constant for hybrid pos. control
- P-0-0242, Current actual slip value
- P-0-0243, Maximum occurred actual slip value

- P-0-0244, Monitoring window of slip

The following parameters are used to parameterize the measuring wheel encoder:

- S-0-0115, Position feedback 2 type
- S-0-0117, Resolution of feedback 2
- P-0-0123, Feed constant 2 (optional encoder)
- P-0-0124, Gear 2 load-side (optional encoder)
- P-0-0125, Gear 2 encoder-side (optional encoder)
- P-0-0185, Control word of encoder 2 (optional encoder)
- F2036 Excessive position feedback difference

Pertinent Diagnostic Messages

5.6.7 Positive Stop Drive Procedure

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

For special applications, it is required to move machine axes operated in position or velocity control up to a limit stop in order to generate forces of pressure.

When an axis in the standard situation has moved up to a limit stop, the drive should signal a drive error by the monitoring facilities of the position or velocity control loop and react with shutdown.

But if the drive can detect the special case of operation "positive stop drive procedure", it can ignore the messages of the position and motions monitors and generate the required force of pressure, if necessary.

The control master signals this special case to the controller of IndraDrive devices via a command. Upon this command, the drive switches off the respective monitors and acknowledges axis standstill to have been detected and a parameterizable force or torque threshold to have been exceeded.

Pertinent Parameters

- S-0-0082, Torque/force limit value positive
- S-0-0083, Torque/force limit value negative
- S-0-0092, Bipolar torque/force limit value
- S-0-0124, Standstill window
- S-0-0149, C1300 Positive stop drive procedure command
- S-0-0331, Status "n_feedback = 0"

Pertinent Diagnostic Messages

- C1300 Positive stop drive procedure command
- C1301 Class 1 diagnostics error at command start

5.6.8 Redundant Motor Encoder

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

Motor control of synchronous motors requires a position measuring system that measures the position of the moving part of the motor as opposed to the static part. If there is malfunction or defect in the position measuring system

Overview of the Scope of Functions

(motor encoder), a synchronous motor can no longer be decelerated in a controlled way.

Depending on the requirements, position control can require an external measuring system at the axis which detects the position at the load with the required precision.

For axis control, the entire mechanical drive system between motor encoder and load position of the external encoder is mapped via parameters. This allows calculating the position of the motor encoder from the position of the external encoder or determining the load position from the motor encoder position, if the mechanical drive system is without slip.

If there is a defect in the motor encoder, the motor position, when an external encoder is used, can be determined via the position of the external encoder and the synchronous motor can be decelerated in a controlled way.

For asynchronous motors with motor encoder, it is also possible to use an external measuring system for controlled deceleration, if there is a defect in the motor encoder. But if the asynchronous motor, depending on the drive task, is operated without encoder, controlled deceleration via external encoder in the case of error is not possible!



You can only use measuring systems with $U_{pp} = 1V$ or resolvers as redundant motor encoders!

Pertinent Parameters

- P-0-0185, Control word of encoder 2 (optional encoder)

Pertinent Diagnostic Messages

- F2031 Encoder 1 error: Signal amplitude incorrect
- F2042 Encoder 2: Encoder signals incorrect
- F8022 Enc. 1: Enc. signals incorr. (can be cleared in ph. 2)
- F8042 Encoder 2 error: Signal amplitude incorrect

5.6.9 Spindle Positioning

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

With the drive function "spindle positioning", the drive, at a command of the master, aligns the spindle independently with regard to the spindle zero position. The command position is transmitted to the drive controller via parameter and can be preset as absolute or relative position.

By means of the "position spindle" command, the spindle can be positioned in a position-controlled way (e.g. within the "velocity control" mode) without having to switch the operation mode from velocity to position control.

How to use the drive function "spindle positioning":

- For **milling and drilling spindles**
 - To prepare tool change → spindle remains at a defined position to allow changing the tool
- For **turning machine main spindles**
 - To change the workpiece (if required)
 - To place balancing drillings for workpieces to be balanced
 - To index the workpiece for further machining
- For **revolving transfer machines**

Overview of the Scope of Functions

- To advance the turntable in order to bring workpieces to a defined machining position at the different stations

Hardware Requirements	The use of a home switch may be required. See " Establishing Position Data Reference for Relative Measuring Systems "
Pertinent Parameters	• S-0-0152, C0900 Position spindle procedure command • S-0-0153, Spindle angle position • S-0-0154, Spindle positioning parameter • S-0-0180, Spindle relative offset • S-0-0222, Spindle positioning speed • S-0-0372, Drive Halt acceleration bipolar • S-0-0417, Positioning velocity threshold in modulo mode • S-0-0418, Target position window in modulo mode • S-0-0437, Positioning status • S-0-0041, Homing velocity • S-0-0042, Homing acceleration • P-0-1201, Ramp 1 pitch • P-0-1202, Final speed ramp 1 • P-0-1203, Ramp 2 pitch • P-0-1211, Deceleration ramp 1 • P-0-1213, Deceleration ramp 2
Pertinent Diagnostic Messages	• C0900 Position spindle command • C0902 Spindle positioning requires drive enable • C0903 Error during initialization • C0906 Error during search for zero pulse

5.6.10 Parameter Set Switching

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

IndraDrive devices are equipped with eight parameter sets (MPB-18VRS, MPC-18VRS, MPE-18VRS) or four parameter sets (MPM-18VRS), and it is possible to switch between these parameter sets during operation. One of the switchable parameter sets is always active. Switching takes place upon command of the control master.

Notes on Application By switching parameter sets during operation, the values of specific parameters can be adjusted to the different operating phases or machining processes. This supports the work flow in flexible production facilities.

Examples of application:

- Changing from C-axis to roughing or finishing operation in the case of spindles
- Positioning mode for tool change with different gear ratios
- Changing motor spindles for different machining phases

Overview of the Scope of Functions

	- Adjusting the control loop gains to different load inertia or load masses (e.g. with very different workpieces) - Star-delta switching of motors with switchable winding to increase the torque in short-time operation
Classification of Switchable Parameters	Under the application-related point of view, the parameters to be switched are divided into the following groups: - Application Parameters - Control Loop Parameters - Load Gear Parameters (for MPB-18VRS, MPC-18VRS, MPM-18VRS only in the alternative functional package Main spindle function) - Winding Parameters (for MPB-18VRS, MPC-18VRS, MPM-18VRS only in the alternative functional package Main spindle function) - Motor Control and Motor Encoder Parameters (for MPB-18VRS, MPC-18VRS, MPM-18VRS only in the alternative functional package Main spindle function)
Pertinent Parameters	- S-0-0216, C4100 Switch parameter set command - S-0-0217, Preselect parameter set command - S-0-0219, IDN-list of parameter set  List parameters S-0-0219 to S-7-0219 contain parameter sets no. 0 to no. 7 - S-0-0254, Current parameter set - P-0-2216, Parameter set switching, configuration - P-0-2217, Parameter set switching, preselection range - P-0-2218, Parameter set switching, delay time
Pertinent Diagnostic Messages	- C0273 Modulo value for motor encoder cannot be displayed - C0278 Modulo value for optional encoder cannot be displayed - C0280 Maximum travel range cannot be displayed internally - C4100 Switch parameter set command - C4101 Switching only possible without AF - C4103 Preselect parameter set forbidden value - C4104 Error during parameter set switching (->S-0-0423)

5.6.11 Star-Delta Switching


Brief Description

Fields of Application

With star(Y)-delta(D) switching, the torque power characteristic of a spindle for short-time operation without mechanical transmission elements can be adjusted to various processing requirements:

- Removing material (roughing): High torque, low speed
- Fine machining (finishing): High speed, low torque

Overview of the Scope of Functions



Y Star connection
Δ Delta connection

Fig. 5-52: Schematic Operating Characteristic of a Spindle Drive with a Star-Delta-Switchable Motor

The spindle output capacity with star connection is just 2/3 of the output capacity with delta connection, i.e. the star-delta-switching is not a complete replacement for gear switching because the same output capacity is available for each gear stage! The increased torque in short-time operation with star connection in comparison with delta connection is not associated with an increase in the continuous torque of the spindle!



Instead of with star-delta-switching, the increase in the short-time operation torque can also be achieved with an increased type current of the controller by a motor the winding of which has internally been unchangeably star-connected or delta-connected. This eliminates the contactor circuit that is not maintenance-free over the long term and with which additional wiring effort and braking problems in case of mains power failure are associated!

Overview of the Scope of Functions

For milling spindles, due to long run-up times for star connection, star-delta switching is usually not suitable!

Features

Motor Design	Star-delta switching can only be used with Rexroth motors specially designed for this purpose or with third-party motors. With these motors, all six winding ends of the three-phase motor are run into the motor terminal box. Standard motors are interconnected internally in a fixed manner; only three power connections are accessible!
Procedure for Star-Delta Switching	IndraDrive controllers support star-delta switching of synchronous and asynchronous three-phase a.c. motors in the following way: • Using switchable parameters, a parameter set with all of the relevant motor parameters is assigned to every type of motor connection in the controller. To do this, the functional package "Main spindle" is required, which provides "parameter set switching". • Star-delta switching can be performed during operation, i.e. with an active drive. The controller converts the motor control voltage to the new type of connection and, in so doing, implements a connection type transition without it being noticed. However, the controller does not control the contactors for switching the motor windings; this must be carried out externally by the control master. • Each connection type must be put into operation individually and each is independently effective and functional. There is no conversion of winding-specific parameter values based on the respective connection type.
Triggering Star-Delta Switching	The change to the other connection type is triggered by the switching of parameters (parameter set switching).

Pertinent Parameters

- P-0-2216, Parameter set switching, configuration
- S-0-0216, C4100 Switch parameter set command
- S-0-0217, Preselect parameter set command
- S-0-0219, IDN-list of parameter set

Pertinent Diagnostic Messages

- C4100 Switch parameter set command

5.6.12 Drive-Controlled Oscillation

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

Upon a command of the control master, the drive ignores the cyclic command value input and independently turns alternately in positive and negative direction (speed oscillation). The cyclic speed characteristic can be set via parameters and can be realized symmetrically or asymmetrically.

Notes on Application

With speed oscillation the main drive supports the following applications, for example:

- Meshing the toothed wheels when switching a gear train
- Engaging positive clutches (e.g. connecting IC engine equipment under test to test stands)

Overview of the Scope of Functions

- Pertinent Parameters**
- S-0-0190, C4200 Drive-controlled oscillation procedure command
 - S-0-0213, Oscillation speed
 - S-0-0214, Oscillation offset speed
 - S-0-0215, Oscillation cycle time

- Pertinent Diagnostic Messages**
- C4200 Drive-controlled oscillation command
 - C4201 Oscillation requires drive enable
 - C4202 Oscillation command speed cannot be reached

5.6.13 Parking Axis

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Extended Axis Functions](#)".

If individual axes within a master communication group (e.g. sercos ring, PROFIBUS) are to be temporarily deactivated, without taking them out of the axis group on the hardware and communication side, the "parking axis" function can be activated via command.

When a drive has been put into the "parking axis" state, it behaves "neutrally" with regard to hardware and master communication. Errors possibly detected by the drive are suppressed and have no effect on the axes in operation. This allows, for example, uncoupling the motor and the motor encoder in the "parking axis" state without errors being signaled.

The axis that has been "parked" behaves as if it would not exist!

- Pertinent Parameters**
- S-0-0139, C1600 Parking axis procedure command

- Pertinent Diagnostic Messages**
- C1600 Parking axis command

5.6.14 Integrated Safety Technology

Brief Description

Optional Modules of the Integrated Safety Technology

To employ the integrated safety technology with the corresponding control sections or drive systems, at least the following firmware version or higher must be used in the drive:

Device	Optional modules for IndraDrive Cs	Safety functions selected via	Firmware version
HCS01.1	L3, STO (Safe Torque Off)	24 V inputs at the drive controller	As of MPx-17V06
	L4, STO (Safe Torque Off) and SBC (Safe Brake Control)	24 V inputs at the drive controller	As of MPx-16V14
	S4, SMO (Safe Motion)	24 V inputs at the safety zone module "HSZ01" or safety bus	As of MPB/MPC-18V08
	Optional modules for IndraDrive Mi		Firmware version
KSM02.x KMS02.x	L3, STO (Safe Torque Off)	24 V inputs at the drive controller	As of MPB-17V08 (KSM02.x) As of MPB-17V10 (KMS02.x)
	S3, SMO (Safe Motion)	Safety bus	As of MPB-18V08

Overview of the Scope of Functions

	Optional modules for IndraDrive M / IndraDrive C		Firmware version
Cxx02.x	L3, STO (Safe Torque Off)	24 V inputs at the drive controller	As of MPx-18V08
	S4, SMO (Safe Motion)	24 V inputs at the safety zone module "HSZ01" or safety bus	

Tab. 5-58: Integrated Safety Technology and Required Firmware

Certification

The safety technology was certified by TÜV Rheinland ®; certificates are available on the Internet or Extranet. The NRTL listing by TÜV Rheinland of North America is in preparation.

Requirements That Can Be Realized

The integrated safety technology is independent of

- Type of master communication
- Higher-level control unit
- Supply modules

It is available as a functional characteristic of the standard drive system. The requirements below can be realized in the machine or in the installation:

- Measures according to ISO 12100-2, if accessing the danger zone is required, for example, for equipping, teaching or material withdrawal.
- Requirements for safety-related parts of control units according to ISO 13849-1 Category 4 PL e and IEC 62061 SIL 3, as required in EN 1010-1 (printing and paper converting machines), EN 12415 (turning machines) and EN 12417 (machining centres).
- Control functions in the case of error according to IEC 60204-1 (homogeneous redundancy).

Integrated Safety Technology "Safe Torque Off" and "Safe Brake Control"

Overview of Safety Functions

- Definition**
- "Safe Torque Off" means application-related safety functions which are applicable for personal protection at machines according to ISO 13849-1 Category 4 PL e and IEC 62061 SIL 3.
 - "Safe Brake Control" means application-related safety functions which are applicable for personal protection at machines according to ISO 13849-1 Category 4 PL e and IEC 62061 SIL 3.

With the optional safety technology modules "L3" (STO) and "L4" (STO und SBC), it is exclusively the "Safe standstill" group of safety technology functions with the following functions which is supported:

Overview of the Scope of Functions

Safety technology functions	Optional modules		
	IndraDrive Cs (HCS01.1)	IndraDrive Mi (KSM02.x, KMS02.x)	IndraDrive M / IndraDrive C (Cxx02.x)
The energy supply to the drive is interrupted in a safe way. The drive cannot generate any torque/force and, as a consequence, it cannot generate any dangerous motions, either.	L3, STO (Safe Torque Off) L4, STO (Safe Torque Off) and SBC (Safe Brake Control)	L3, STO (Safe Torque Off)	L3, STO (Safe Torque Off)
With "Safe brake control", the motor holding brake is switched off safely (via two channels).	L4, STO (Safe Torque Off) and SBC (Safe Brake Control)	-	-
With "Safe stop 1", the energy supply to the motor is safely interrupted. The motor cannot generate any torque/any force and therefore no dangerous movements. The duration of the transition to "Safe stop 1" is monitored. "Safe stop 1" (Emergency stop) is only possible in conjunction with an external, time-delayed safety selection device.	L3, STO (Safe Torque Off) L4, STO (Safe Torque Off) and SBC (Safe Brake Control)	L3, STO (Safe Torque Off)	L3, STO (Safe Torque Off)

Tab. 5-59: Safety Technology Functions Depending on the Optional Modules

Notes on Commissioning

Using the optional safety technology modules "L3" (STO) or "L4" (STO and SBC) does not require any kind of separate commissioning. The corresponding wiring is sufficient.

For details of the function, notes on commissioning and examples of application, see separate documentation "Rexroth IndraDrive, Integrated Safety Technology as of MPx-1x (Safe Torque Off)" (DOK-INDRV*-SI3-OP-MAN*-APxx-EN-P; mat. No. R911332634)

Integrated Safety Technology "Safe Motion"

Overview of Safety Functions

As of the firmware MPx18V08, the optional safety technology modules "Safe Motion" ("S3" and "S4") make available the following functions for safe motion monitoring and safe standstill monitoring:

Overview of the Scope of Functions

Safety functions which, according to ISO 13849-1 Category 4 PL e and IEC 62061 SIL 3, are applicable for personal protection at machines.	Optional module "Safe Motion"		
	"S3"	"S4"	
	IndraDrive Mi (KSM02.x KMS02.x)	IndraDrive Cs (HCS01.1)	IndraDrive M / IndraDrive C (Cxx02.x)
Safety Zone Acknowledge (SZA) By means of "Safety Zone Acknowledge" and the safety zone module "HSZ", an acknowledgment master can monitor the safety of a safety zone and acknowledge the safety to a higher-level control unit. It is also possible for the acknowledgment master of the safety zone to directly control a safety door locking device connected to the safety zone module.	-	■	
Safe Door Locking (SDL) The locking device of an interlocking guard is controlled via two channels when the safe zone acknowledgment signals "Safety" and the user by means of a pushbutton requests the safety door to be unlocked. The position of the locking device is safely monitored	-	■	
Safe Zone Error (SZE) The "Safe Zone Error" function is a subfunction of the safety function "Safety Zone Acknowledge". The "Safe Zone Error" function allows the zone nodes to signal locally present safety technology errors to all zone users via a safe output and to trigger individual error reactions. It is also possible for the acknowledgment master of a safety zone to signal zone errors via the safe communication to the higher-level control unit.	-	■	
Safe torque off (STO) The energy supply to the drive is interrupted in a safe way. The drive cannot generate any torque/force and, as a consequence, it cannot generate any dangerous motions, either.	■	■	
Safe Brake Control (SBC) With the safety function "Safe brake control", the motor holding brake is switched off safely (via two channels).	-	□	
Safe stop 1 (SS1), time-prioritized [Safe Stop 1 (SS1)] When the transition function "Safe stop 1" is activated, the drive is stopped in a safely monitored way. After the stopping process has been completed, but at the latest after the parameterized delay is over , the safety function "Safe torque off" is activated and the energy supply to the motor is safely interrupted. The motor cannot generate any torque/any force and therefore no dangerous movements. Activation of STO function in standstill with drive enable removed, but at the latest after the parameterized delay is over	■	■	

■

Available

□

In preparation for Cxx02.x

-

Not available

Tab. 5-60:

Safety Technology Functions Depending on the Optional Modules

Overview of the Scope of Functions

Safety functions which, according to ISO 13849-1 Category 4 PL e and IEC 62061 SIL 3, are applicable for personal protection at machines.	Optional module "Safe Motion"		
	"S3"	"S4"	
	IndraDrive Mi (KSM02.x KMS02.x)	IndraDrive Cs (HCS01.1)	IndraDrive M / IndraDrive C (Cxx02.x)
Safe stop 1 (SS1), standstill-prioritized [Safe Stop 1 (SS1)] When the transition function "Safe stop 1" is activated, the drive is stopped in a safely monitored way. After the stopping process has been completed, the safety function "Safe torque off" is activated and the energy supply to the motor is safely interrupted. The motor cannot generate any torque/any force and therefore no dangerous movements.	■	■	
Safe Operating Stop (SOS) In the case of the safety function "safe operating stop", the drive is in controlled standstill, i.e. all control functions between the electronic control unit and the drive are maintained. The dual-channel monitoring prevents the drive from carrying out dangerous movements due to errors although the energy supply is not interrupted.	■	■	
Safe Stop 2 (SS2) When the transition function "Safe stop 2" is activated, the drive is stopped in a safely monitored way. After the stopping process has been completed, the safety function "Safe Operating Stop" is activated and it is safely prevented that the motor deviates from the stopping position by more than a specified absolute value.	■	■	
Safe Maximum Speed (SMS) In the case of the safety function "Safe Maximum Speed", dual-channel monitoring prevents the drive from exceeding the preset velocity limit value.	■	■	
Safe Direction (SDI) In the case of the safety function "Safe Direction", dual-channel monitoring guarantees that motion is only possible in one direction.	■	■	
Safely Limited Speed (SLS) In the case of the safety function "Safely Limited Speed", dual-channel monitoring is used to monitor that the drive does not exceed a previously defined limitation of the velocity window.	■	■	
Safely Monitored Transient Oscillation (SLS-LT) In the case of the safety function "Safely Monitored Transient Oscillation", the transient oscillation with regard to a "Safely-limited speed" is monitored by means of a velocity window and a tolerance time.	■	■	

Overview of the Scope of Functions

Safety functions which, according to ISO 13849-1 Category 4 PL e and IEC 62061 SIL 3, are applicable for personal protection at machines.	Optional module "Safe Motion"		
	"S3"	"S4"	
	IndraDrive Mi (KSM02.x KMS02.x)	IndraDrive Cs (HCS01.1)	IndraDrive M / IndraDrive C (Cxx02.x)
Safely Limited Increment (SLI) In the case of the safety function "Safely Limited Increment", dual-channel monitoring makes sure that the drive moves only within the maximum increment.	■	■	
Safely Monitored Deceleration (SMD) In the case of the safety function "Safely Monitored Deceleration", dual-channel monitoring is used to detect whether the actual velocity of the drive, given a change in the operating status or given an error reaction, is within a parameterized velocity envelope curve.	■	■	

■ Available
Tab. 5-61: Safety Functions according to ISO 13849-1 Category 3 PL d and IEC 62061 SIL 2

Notes on Commissioning

The optional safety technology modules "Safe Motion" ("S3" and "S4") are commissioned via dialogs by means of the "IndraWorks Ds/D/MLD" commissioning tool (supported ≥ IndraWorks 13V08).



In the condition as supplied, i.e. also after a firmware update / firmware upgrade, the safety technology is in the following "SafetyDefault" state:

- The output stage is locked, i.e. the axis has gone torque-free
- Safety status: "Axis not safe"
- The digital local outputs have been set to "0"
- The brake output has been deactivated (an electrically releasing brake is applied)

For the functional commissioning, it is first necessary to set "P-0-3201, SMO: Configuration of functional commissioning", bit 0 = 1.

For details of the function, notes on commissioning and examples of application, see separate documentation "Rexroth IndraDrive; Integrated Safety Technology as of MPx-1x (Safe Motion)" (DOK-INDRV*-SI3*SMO-VRS-APxx-EN-P; mat. no. R911338920).

5.7Optional Device Functions


5.7.1Availability of the Optional Device Functions

For an overview that illustrates in which base or functional packages the respective optional device function is available, see chapter "Overview of Functions/Functional Packages, Availability of the Optional Device Functions".

5.7.2 Cross Communication (CCD)

Brief Description

Overview The IndraDrive "cross communication" device function (Cross Communication Drives → CCD) allows electronic (digital) coupling of axes and the connection of I/O modules for IndraMotion MLD.



* Master communication (MC), optional (alternatively no MC or PROFIBUS® or MultiEthernet)

Fig. 5-53: Hardware Topology of Drive Cross Communication (CCD)

Bus Topology

Configuration of the CCD slaves and communication with the external control unit always takes place via the CCD master drive, as the individual CCD slaves are connected to the master via a sercos interface. Therefore, external access always takes place via the drive acting as the CCD master, which requires a master communication interface (e.g. PROFIBUS®) in addition to the CCD optional module ("sercos master connection").

CCD Modes (Kinds of Coupling)

When cross communication (CCD) is used between the drives, we distinguish the following variants (CCD modes):

- **CCD system mode**

The CCD slaves have a direct logic connection to the field bus master. The command triggering and input of process data are carried out via an external control.

- **CCD basic mode**

Overview of the Scope of Functions

The same functions as for the CCD system mode are available. However, the user has to program them. It is not possible to use the MLD-M functionality in the master axis.

- **MLD-M system mode**

The CCD slaves have no direct logic connection to the external control unit, but only to the MLD-M in the CCD master. Command triggering and input of process data take place by the MLD-M in the CCD master.

Features The device function "cross communication (CCD)" is characterized by the following features:

- Synchronization of CCD slaves to CCD master
- Transmission of freely configurable external **process data** (command values and actual values of the external control unit)
- Command value linking by transmission of freely configurable process data of the CCD axes (e.g. master/slave, Gantry axis)
- SLc03 safety control is supported
- Connection of I/O extensions for sercos via CCD (a maximum of 4 modules per CCD master) (only in MLD-M system mode)
- CCD (sercos) cycle time can be parameterized (0.25 ms to 4 ms; depends on CCD mode, controller performance and number of axes)
- Max. baud rate: 100 MBaud
- CCD communication protocol: sercos (see "[sercos](#)")
- Data channels:
 - Cyclic data channel (MDT, AT): Max. 48 bytes and 16 IDN
 - Parameter or service channel: 4 bytes
- Parameterization of all axes in the CCD group via the CCD master interfaces (RS232, Engineering Port, field bus, ...)
- Command triggering of the CCD slaves depending on selected CCD mode via external control section or internally via MLD in CCD master
- Possible compensation of transmission time / dead time of the cyclic process data
- Generation of up to 3 master axis positions for master axis linking
- Max. number of CCD slaves: 7 or 9 (depends on CCD mode; see "Functional Description of the CCD Modes, Performance Features")

Fields of Application Typical fields of application for cross communication:

- Control tasks for multi-axis applications
 - Anti backlash
 - Synchronous operation control
 - Load control of several axes
- Simple command value linking
 - Position command value linking (Gantry axes)
 - Torque/force linking
- Simple motion controls with decentralized command value adjustment for single-axis positioning and master axis linking
- I/O extension by connection of I/O modules for sercos via CCD

Restrictions When using cross communication, observe the following restrictions:

- With the cross communication function, "Coordinated Motion" is not possible!

Overview of the Scope of Functions

- In the MLD-M system mode, the multiplex channel for external controls in the CCD is not available
- sercos I/O extensions only possible in MLD-M system mode

Hardware Requirements The drive function "cross communication" requires the following control section design:

CCD master	
HCS01.1E-W00xx-A-0x-A-CC-xx-xx-xx-xx-FW	IndraDrive Cs Advanced - single-axis
CSH02.1B-CC-EC-xx-xx-xx-NN-FW	IndraDrive: Advanced control section - single-axis
CCD slaves	
CSE02.1A-S3-EC-NN-xx-NN-FW	IndraDrive: Economy control section - single-axis
CSB02.1x-ET-EC-xx-xx-xx-NN-FW	IndraDrive: Basic control section - single-axis
CDB02.1B-ET-EC-EC-xx-xx-xx-xx-NN-FW	IndraDrive: Basic control section - double-axis
CSH02.1B-CC-EC-ET-xx-xx-NN-FW	IndraDrive: Advanced control section - single-axis
HCS01.1E-W00xx-A-0x-B-ET-xx-xx-xx-xx-FW	IndraDrive Cs Basic - single-axis
HCS01.1E-W00xx-A-0x-E-S3-xx-xx-xx-xx-FW	IndraDrive Cs Economy - single-axis
HCS01.1E-W00xx-A-0x-A-CC-xx-xx-xx-xx-FW	IndraDrive Cs Advanced - single-axis
KMS02.1B-A0xx-P-D7-ET-xxx-xx-xx-FW	IndraDrive Mi, distributed drive controller
KSM02.1B-0xxC-xxN-xx-Hxx-ET-xx-D7-xx-FW	IndraDrive Mi, distributed servo drive

Tab. 5-62: Hardware Requirements



See documentation "Control Sections for Drive Controllers; Project Planning Manual"

Firmware Requirements When using the drive function "cross communication", observe the following aspects regarding the firmware:

- This drive function is supported as of the firmware version MPx04.
- The CCD master must be operated with the MPC-18VRS firmware.
In this case, CCD slaves with MPx04 to MPx08 cannot be operated.
- As for integrated safety technology, this firmware function does not require separate enabling of functional packages; the function of drive cross communication is available with the corresponding hardware design.

Pertinent Parameters The parameters listed below only exist for the CCD master:

- P-0-1640, CCD: MAC address
- P-0-1641, CCD: IP address
- P-0-1642, CCD: Network mask
- P-0-1643, CCD: Gateway address
- P-0-1644, CCD: Status IP communication
- P-0-1800.0.1, CCD: Configuration
- P-0-1800.0.10, CCD: Cycle time
- P-0-1800.0.3, CCD: Control word
- P-0-1800.0.30, CCD: Extrapolated cmd value IDN list signal selection
- P-0-1800.0.31, CCD: Extrapolated cmd value signal selection

Overview of the Scope of Functions

- P-0-1800.0.32, CCD: Number of extrapolation steps
- P-0-1800.0.33, CCD: Extrapolated command value
- P-0-1800.0.5, CCD: Allowed telegram failures
- P-0-1801.0.1, CCD: Slave identification
- P-0-1801.0.10, CCD: Addresses of projected drives
- P-0-1801.0.11, CCD: Addresses of projected I/Os
- P-0-1801.0.2, CCD: Command topology addresses
- P-0-1801.0.20, CCD: Command topology
- P-0-1801.0.21, CCD: Actual topology
- P-0-1801.0.22, CCD: Slave addresses at end of line
- P-0-1801.0.23, C7100 CCD: Command Close ring
- P-0-1801.0.3, CCD: Actual topology addresses
- P-0-1801.0.4, CCD: Slave information at topology location
- P-0-1801.0.5, C7000 CCD: Command adjust slave addresses
- P-0-1802.0.1, C7400 CCD: Switching to phase 2
- P-0-1802.0.2, C7500 CCD: Switching to phase 4
- P-0-1802.0.3, CCD: Command communication phase
- P-0-1802.0.4, CCD: Actual communication phase
- P-0-1803.2.1 - P-0-1803.8.1,
CCD: Slave address in high level network
- P-0-1803.2.11 - P-0-1803.10.11,
CCD: Configuration list master communication cmd values
- P-0-1803.2.12 - P-0-1803.10.12,
CCD: Configuration list master communication actual values
- P-0-1803.2.20 - P-0-1803.10.20,
CCD: Master comm. C0100 Comm. phase 3 transition check
- P-0-1803.2.21 - P-0-1803.10.21,
CCD: Master comm. C5200 Comm. phase 4 transition check
- P-0-1803.2.22 - P-0-1803.10.22,
C5300 CCD: sercos SYNC delay measuring procedure command
- P-0-1803.2.24 - P-0-1803.10.24,
CCD: Master communication gateway parameter pool 1
- P-0-1803.2.25 - P-0-1803.10.25,
CCD: Master communication gateway parameter pool 2
- P-0-1804.1.1 - P-0-1804.10.1,
CCD: Configuration list signal status word
- P-0-1804.1.2 - P-0-1804.10.2,
CCD: Configuration list signal control word
- P-0-1804.1.3 - P-0-1804.10.3,
CCD: Assignment list signal status word
- P-0-1804.1.4 - P-0-1804.10.4,
CCD: Assignment list signal control word

Overview of the Scope of Functions

- P-0-1805.1.1 - P-0-1805.10.1,
CCD: Configuration list master cmd values
- P-0-1805.1.2 - P-0-1805.10.2,
CCD: Configuration list actual master values
- P-0-1805.1.3 - P-0-1805.10.3,
CCD: Configuration list slave cmd values
- P-0-1805.1.4 - P-0-1805.10.4,
CCD: Configuration list actual slave values
- P-0-1806.1.1 - P-0-1806.14.1,
CCD: Slave IP address
- P-0-1806.1.10 - P-0-1806.14.10,
CCD: Resource-Status (S-Res)
- P-0-1806.1.11 - P-0-1806.14.11,
CDD: Resource-Control (C-Res)
- P-0-1806.1.2 - P-0-1806.14.2,
CCD: Device Status (S-Dev)
- P-0-1806.1.3 - P-0-1806.14.3,
CCD: Device Control (C-Res)
- P-0-1806.1.4 - P-0-1806.14.4,
CCD: Connection-Control #0 (C-Con)
- P-0-1806.1.5 - P-0-1806.14.5,
CCD: Connection-Control #1 (C-Con)
- P-0-1807.x.1, CCD connection: Configuration
- P-0-1807.x.10, CCD connection: Producer cycle time
- P-0-1807.x.11, CCD connection: Allowed losses of producer data
- P-0-1807.x.12, CCD connection: Error counter data losses
- P-0-1807.x.2, CCD connection: Connection number
- P-0-1807.x.20, CCD connection: IDN allocation of real-time bits
- P-0-1807.x.21, CCD connection: Bit number allocation of real-time bits
- P-0-1807.x.3, CCD connection: Telegram assignment
- P-0-1807.x.4, CCD connection: Max. length of connection
- P-0-1807.x.5, CCD connection: Current connection length
- P-0-1807.x.6, CCD connection: Configuration list
- P-0-1807.x.7, CCD connection: Assigned connection capability
- P-0-1807.x.8, CCD connection: Connection control (C-Con)
- P-0-1807.x.9, CCD connection: State
- P-0-1808.1.1 - P-0-1808.10.1,
CCD: Diagnostic message number, slave
- P-0-1808.1.10 - P-0-1808.10.10,
CCD: Active actual position value
- P-0-1808.1.11 - P-0-1808.10.11,
CCD: Actual velocity value

Overview of the Scope of Functions

- P-0-1808.1.12 - P-0-1808.10.12,
CCD: Actual torque/force value
- P-0-1808.1.13 - P-0-1808.10.13,
CCD: Status word synchronous operation modes
- P-0-1808.1.2 - P-0-1808.10.2,
CCD: Signal status word
- P-0-1808.1.20 - P-0-1808.10.20,
CCD: Command value data container 1 4Byte
- P-0-1808.1.21 - P-0-1808.10.21,
CCD: Command value data container 2, 4Byte
- P-0-1808.1.22 - P-0-1808.10.22,
CCD: Command value data container 3, 4Byte
- P-0-1808.1.23 - P-0-1808.10.23,
CCD: Command value data container 4, 4Byte
- P-0-1808.1.3 - P-0-1808.10.3,
CCD: Signal control word
- P-0-1808.1.30 - P-0-1808.10.30,
CCD: Command value data container 1, 2Byte
- P-0-1808.1.31 - P-0-1808.10.31,
CCD: Command value data container 2, 2Byte
- P-0-1808.1.32 - P-0-1808.10.32,
CCD: Command value data container 3, 2Byte
- P-0-1808.1.33 - P-0-1808.10.33,
CCD: Command value data container 4, 2Byte
- P-0-1808.1.40 - P-0-1808.10.40,
CCD: Actual value data container 1, 4Byte
- P-0-1808.1.41 - P-0-1808.10.41,
CCD: Actual value data container 2, 4Byte
- P-0-1808.1.42 - P-0-1808.10.42,
CCD: Actual value data container 3, 4Byte
- P-0-1808.1.43 - P-0-1808.10.43,
CCD: Actual value data container 4, 4Byte
- P-0-1808.1.50 - P-0-1808.10.50,
CCD: Actual value data container 1, 2Byte
- P-0-1808.1.51 - P-0-1808.10.51,
CCD: Actual value data container 2, 2Byte
- P-0-1808.1.52 - P-0-1808.10.52,
CCD: Actual value data container 3, 2Byte
- P-0-1808.1.53 - P-0-1808.10.53,
CCD: Actual value data container 4, 2Byte
- P-0-1810.0.10, CCD: Diagnostic message text
- P-0-1810.0.11, CCD: Diagnosis code

Overview of the Scope of Functions

- P-0-1810.0.12, CCD: Error counter Port-1
- P-0-1810.0.13, CCD: Error counter Port-2
- P-0-1810.0.15, CCD: AT error counter
- P-0-1810.0.16, CCD: Axis error
- P-0-1810.0.2, CCD: Status word
- P-0-1810.0.3, CCD: Timing settings
- P-0-1815.0.1, CCD: Master communication, synchronization input value
- P-0-1815.0.2, CCD: Master communication, synchronization output value
- P-0-1816.0.1, CCD: Master communication, synchronization counter
- P-0-1816.0.2, CCD: Master communication, synchronization P-gain
- P-0-1816.0.3, CCD: Master communication, synchronization I-gain
- P-0-1816.0.4, CCD: Master communication, synchronization error window
- P-0-1816.0.5, CCD: Master communication, synchronization delay
- P-0-1820.0.1, CCD: Master axes configuration list
- P-0-1820.0.2, CCD: Source of measuring encoder position feedback value
- P-0-1820.0.3, CCD: Actual position value of measuring encoder
- P-0-1820.0.4, CCD: Axis position selection
- P-0-1821.1.1 - P-0-1821.3.1,
CCD: Position command value for master axis n
- P-0-1821.1.2 - P-0-1821.3.2,
CCD: Master axis n, filter type
- P-0-1821.1.3 - P-0-1821.3.3,
CCD: Master axis n, filter corner frequency
- P-0-1821.1.4 - P-0-1821.3.4,
CCD: Master axis n, number of extrapolation steps
- P-0-1821.1.5 - P-0-1821.3.5,
CCD: Master axis n, master axis position
- P-0-1822.0.1,
CCD: Default master axis selection for the IndraDrive axes
- P-0-1822.0.2,
CCD: Master axis selection for the IndraDrive axes
- P-0-1823.1.1 - P-0-1823.10.1,
CCD: Default synchronization mode for axis n
- P-0-1823.1.2 - P-0-1823.10.2,
CCD: Master axis position for axis n



For configuring the sercos communication in the slaves, the standard sercos parameters are used (e.g. "S-0-1002, sercos: Communication Cycle time (tScyc)" etc.).

Pertinent Diagnostic Messages

- C0265 Incorrect CCD address configuration
- C0266 Incorrect CCD phase switch

Overview of the Scope of Functions

- C0267 CCD timeout phase switch
- C0403 Switching to CCD phase 2 impossible
- C7000 CCD: Command Close ring
- C7001 CCD: Impossible to close ring
- C7100 CCD: Command Close ring
- C7101 CCD: Impossible to close ring
- C7400 CCD: Switching to phase 2
- C7401 CCD: Impossible to switch to phase 2
- C7500 CCD: Switching to phase 4
- C7501 CCD: Impossible to switch to phase 4
- E4012 Maximum number of CCD slaves exceeded
- E4013 Incorrect CCD addressing
- E4014 Incorrect phase switch of CCD slaves
- E4016 CCD: Topology error
- E4017 CCD: Unknown I/O configuration
- F2140 CCD slave error
- F4012 Incorrect I/O length
- F4140 CCD communication error
- F6140 CCD slave error (emergency halt)
- F8140 Fatal CCD error

5.7.3 Rexroth IndraMotion MLD (Drive-Integrated PLC)

Brief Description



Assignment to Functional Firmware Package: Expansion packages **IndraMotion MLD** (order code **ML**, **MA** or **TF**)

The optional expansion packages "IndraMotion MLD" provide the function of a PLC integrated in the drive according to IEC 61131-3 with the following scope of functions:

- **Integrated logic control** (standard PLC tasks)
 - Compliant with IEC-61131-3
 - Online Change
 - Debugging
- **Integrated multi-axis/single-axis motion control**
 - Motion function block according to PLCopen positioning and synchronization mode
 - Programming via ST, SFC, FBD and LD
 - Library management with system and user libraries
- **Basis for technology functions**
 - Examples: Following-on cutting devices, process controller (register controller, winding computation, Productivity Agent, IndraMotion for Handling, IndraMotion for Metal Forming, ...)

Overview of the Scope of Functions



This optional extension of the drive functionality is described in detail in the separate documentation "Rexroth IndraMotion MLD (2G) as of MPx18" (DOK-INDRV*-MLD3-**-VRS*-AP**-EN-P; mat. No. R911338914).

Hardware Requirements / Characteristics

According to the design, the expansion packages "IndraMotion MLD" require one of the following control section designs:

- **IndraMotion MLD-M** (multi-axis motion control; only firmware "MPC")
 - Single-axis ADVANCED (HCS01.1E-W0xx-A-02-**A**-...)
 - As stand-alone multi-axis Motion Logic Control using CCD (Cross Communication Drives) on the basis of sercos
- **IndraMotion MLD-S** (single-axis motion control; only firmware "MPB" / "MPC")
 - Single-axis ADVANCED (HCS01.1E-W0xx-A-02-**A**-...)
 - Single-axis BASIC (HCS01.1E-W0xx-A-02-**B**-...)
 - IndraDrive Mi, distributed drive controller (KMS02.1B-A0xx-P-D7-ET-...)
 - IndraDrive Mi, distributed servo drive (KSM02.1B-0xxC-xxN-xx-Hxx-ET-...)
 - As intelligent servo axis (extension of drive functionality) - stand-alone single-axis Motion Logic Control

Firmware Requirements

In the **MPx-18VRS** firmware, the "IndraMotion MLD" function is available in the following variants:

- Advanced design (**MPC**)
- Basic single-axis design (**MPB**)



Using the "IndraMotion MLD" function generally requires the enabling of one of the additive expansion packages **ML**, **MA** or **TF**.

See also sections:

- ["Overview of Functions/Functional Packages"](#)
- ["Enabling of Functional Packages"](#)

Features/Characteristic Values

The functional packages "IndraMotion MLD" include the following general features/characteristic values:

- It is possible to configure up to 4 different user tasks. Possible task types:
 - Periodic (min. cycle time: 1 ms for Advanced; 2 ms for Basic)
 - Free-running (permanently cyclic)
 - Event-triggered (min. reaction time: 1 ms for Advanced; 2 ms for Basic)
- Memory resources:
 - MPB-18*
 - Internal code memory: 2 MB (program, constants, management)
 - Data memory: 3 MB (variables, instances, management)
 - Storage of the boot project: 650 kB in parameters
 - Retain memory: 472 bytes (incl. persistent variables)

Overview of the Scope of Functions

MPC-18

- Internal code memory: 12 MB (program, constants, management)
- Data memory: 4 MB (variables, instances, management)
- Storage of the boot project: 650 kB in parameters, 8 MB on μ SD card
- Retain memory: 31704 bytes (incl. persistent variables)
- Digital inputs/outputs:
 - 1...7 digital inputs, 1 switchable digital input/output at x31
→ PLC and drive are sharing the inputs!
 - 1 relay output at x47
→ PLC and drive are sharing the inputs!
- Analog inputs/outputs:
 - 1 analog input (+/-10 V differential input) at x32
- Inputs/outputs on remote axes:
 - Digital and analog inputs/outputs of the slaves connected to sercos can be read and written.
 - Number of inputs/outputs depends on the used hardware of the slaves
- sercos I/O
 - Evaluation of Inline Block IOs - each block with 32 inputs or with 16 inputs and 16 outputs
 - Evaluation of Inline Modular IOs - max. 4 bus terminals with 16 modules (nodes) each
- Parameters for general purpose:
 - Parameters for process image: PII inputs
 - 20 input words per 2 bytes
 - 8 input words per 4 bytes
 - Parameters for process image: POI outputs
 - 20 output words per 2 bytes
 - Global registers (4 bytes)
 - 32 buffered parameters
 - 32 unbuffered parameters
 - List parameters (4 bytes)
 - 1 list register with 8192 values (not buffered)
 - 3 list registers with 1024 values (buffered)
 - 2 global text registers with 255 characters each
 - Display format of the global registers that can be parameterized
 - Name, unit and limit values of the global registers can be configured via PLC functions
- Other features:
 - Extensive debug possibilities (Single-Step, Watch, Force/Write, Breakpoints, Powerflow)
 - File access from the PLC (save source code on μ SD card, ...)

Overview of the Scope of Functions

- Symbol files are stored on µSD card for accessing PLC variables of the HMI
- Source download (only with µSD card)
- Access to Ethernet interface

Pertinent Parameters

PLC parameters for general purpose:

- P-0-1350, PLC control word
- P-0-1351, PLC status word
- P-0-1352, PLC user program administration data
- P-0-1361, PLC program name
- P-0-1362, PLC boot project info
- P-0-1363, PLC project info
- P-0-1367,

User program (filing):

- P-0-1353, PLC user program area 0
- P-0-1354, PLC user program area 1
- P-0-1355, PLC user program area 2
- P-0-1356, PLC user program area 3
- P-0-1357, PLC user program area 4
- P-0-1358, PLC user program area 5

Process input images PIIs

- P-0-1390,
to
P-0-1409, PLC input WORD19 AT %IB38
- P-0-1440,
to
P-0-1447, PLC input DWORD32 AT %IB128

Process output images POIs

- P-0-1410,
to
P-0-1429, PLC output WORD19 AT %QB38

Global PLC registers, unbuffered:

- P-0-1270, PLC Global Register A0
to
P-0-1301, PLC Global Register A31

Global text registers, unbuffered:

- P-0-1387,
to
P-0-1388,

Global list register, unbuffered:

- P-0-1368, PLC Global Register AL0

Global PLC registers, buffered:

- P-0-1370, PLC Global Register G0

Overview of the Scope of Functions

to

P-0-1385, PLC Global Register G15

- P-0-1316, PLC Global Register G16

to

P-0-1331 PLC Global Register G31

Global list registers, buffered:

- P-0-1389, PLC Global Register GL0
- P-0-1311, PLC Global Register GL1
- P-0-1312, PLC Global Register GL2

To configure the display format of the registers:

- P-0-1386, PLC display format Global Register

Notes on Installation / System Configuration

Installation

For installing "IndraMotion MLD" on the PC, it is necessary to install the current version of the **"IndraWorks MLD" commissioning tool** on the PC.

After successful installation the **"IndraLogic" PLC programming system** and **"IndraWorks"** can simultaneously communicate with the drive.

Project Planning Manual

The system configuration of "IndraMotion MLD" is carried out via a PC with the "IndraLogic" program installed that communicates with the drive via TCP/IP communication.

The projects are filed on the PC. The generated binary code is loaded to the drive and stored in parameters or on the µSD card. With the µSD card plugged, the source code, symbols and user files can also be stored there.

5.7.4 Digital Inputs/Outputs

Brief Description

General Information

In their basic variant, all IndraDrive systems and control sections already have configurable digital inputs/outputs.

Hardware Requirements

The table below shows the number and function of the digital inputs/outputs.

Drive system / control section	Basic device (on board)		Option "DA" ¹⁾		
	Number of standard inputs (probe inputs thereof)	Number of switchable Inputs/outputs	Number Inputs	Number Outputs	Number of switchable Inputs/outputs
HCS01.1	7 (2)	1	6	6	2
HCQ02.1, HCT02.1	16 (-)	-	-	-	-
KSM02.1, KMS02.1	-	4	-	-	-
CSE02.1A, CSB02.1A	7 (2)	1	-	-	-

Overview of the Scope of Functions

Drive system / control section	Basic device (on board)		Option "DA" ¹⁾		
	Number of standard inputs (probe inputs thereof)	Number of switchable Inputs/outputs	Number Inputs	Number Outputs	Number of switchable Inputs/outputs
CDB02.1B	14 (4)	8	6	6	2
CSB02.1B, CSH02.1B	11 (2)	5	6	6	2

¹⁾ As of MPx18V10

Tab. 5-63: Drive System / Control Section, Number of Inputs/Outputs

For further hardware properties, see the respective Project Planning Manual.

- Features**
- Sampling of digital inputs and outputs or transmitting data to them is done in the position controller clock $T_{A_position}$ (see "Performance Data")
 - Configurable digital inputs/outputs with effective direction that can be freely set to some extent (input or output):
 - Probe inputs are queried in steps of μs
 - All inputs/outputs refer to the level of 0 V (LOW) or 24 V (HIGH)
 - Assignment of the inputs/outputs on several axes within one device possible
 - Several axes within one device can be addressed by one digital input
 - Within a device, each axis can access each input/output present on the hardware side
 - Multiple assignments for an input possible with multiple parameters
 - An axis output can be used simultaneously as an input on the same parameter.
 - Signal states of digital inputs/outputs of a device are mapped to their respective individual parameters.
 - In addition, the signal states of digital inputs/outputs of an axis are mapped to their respective individual parameters.
 - Digital outputs can be directly controlled by the control master, if not used on drive-side
- Pertinent Parameters**
- S-0-0398, IDN-list of configurable data in signal status word
 - S-0-0399, IDN-list of configurable data in signal control word

Digital Inputs

- P-0-0300, Digital inputs, assignment list
- P-0-0301, Digital inputs, bit numbers
- P-0-0303, Digital inputs, input image of device
- P-0-0306, Digital inputs, assignment connector and pin
- P-0-0307, Digital inputs, input image sub-device

Digital Outputs

- P-0-0304, Digital outputs, output image of device
- P-0-0310, Digital outputs, assignment list
- P-0-0311, Digital outputs, bit numbers
- P-0-0312, Digital outputs, assignment sub-device
- P-0-0313, Digital outputs, output image sub-device
- P-0-0316, Digital outputs, assignment connector and pin

Overview of the Scope of Functions

Pertinent Diagnostic Messages • F2010 Error when initializing digital I/O (-> S-0-0423)

5.7.5 Analog Inputs

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Optional Device Functions](#)".

In accordance with the drive system or control section, IndraDrive controllers have a different number of analog inputs. This allows processing analog voltage and current values from command values in the drive.

Hardware Requirements

The table below shows the number of analog inputs in accordance with the drive system or control section type:

Drive system / control section	Basic device (on board)	Option "DA" ¹⁾
	Number of analog inputs	Number of analog inputs
HCS01.1	1	2 ²⁾
HCQ02.1, HCT02.1	-	-
KSM02.1, KMS02.1	-	-
CSE02.1A, CSB02.1A	1	-
CDB02.1B	2	2
CSB02.1B, CSH02.1B	3	2

1) As of MPx18V10


2) Not with HCS01 Economy

Tab. 5-64: *Analog Inputs*

For further hardware properties, see the respective Project Planning Manual.

Overview

The figure below illustrates the assignment options of the analog inputs.



P-0-0218 Analog input, control parameter

Fig. 5-54: *Overview: Analog Input and Assignment ("DA" Option is Supported as of MPx18V10)*

Features

General features:

- 3 assignment mechanisms (assignment A, B, C) with different sampling rates are possible

Overview of the Scope of Functions

- Assignment channel A works in position controller clock (see "[Performance Data](#)")
- Assignment channels B and C work in 2 ms clock
- Assignment to command value/limit value/control parameters of the drive by means of adjustable scaling
- Variable scaling
- Parameterizable dead zone to suppress zero drift
- Automatic offset and amplification adjustment via command is possible
- Low-pass filtering to be activated for the analog channel
- Analog input designed as differential input
- Parameterizable wire break monitoring
- Input voltage range of $\pm 10V$
- Analog inputs 2 (not with CDB02.1B) and 3, as well as analog inputs 1 and 2 of optional module DA, can also be set as current inputs $\pm 20\text{ mA}$ or $\pm 4\text{...}20\text{ mA}$. Optional module DA is supported as of 18V10.



For the technical properties of the analog inputs, see the respective Project Planning Manual.

Pertinent Parameters

Configuration

- P-0-0255, Analog input; hardware configuration
- P-0-0212, Analog input, list of assignable parameters
- P-0-0218, Analog input, control parameter
- P-0-0219,
- P-0-0220,

Analog input values:

- P-0-0210, Analog input 1
- P-0-0211, Analog input 2
- P-0-0228, Analog input 3
- P-0-0229, DA: Analog input 1
- P-0-0208, DA: Analog input 2
- P-0-0217, Analog input 1, time constant input filter
- P-0-0231, Analog input 2, time constant input filter
- P-0-0232, Analog input 3, time constant input filter
- P-0-0233, DA: Analog input 1, time constant input filter
- P-0-0234, DA: Analog input 2, time constant input filter

Assignment A:

- P-0-0213,
- P-0-0214, Analog input, assignment A, scaling
- P-0-0215, Analog input, assignment A, signal value at 0
- P-0-0216, Analog input, assignment A, dead zone

Assignment B:

- P-0-0236,
- P-0-0237, Analog input, assignment B, scaling
- P-0-0238, Analog input, assignment B, signal value at 0

Overview of the Scope of Functions

- P-0-0239, Analog input, assignment B, dead zone

Assignment C:

- P-0-0245, Analog input, assignment C, target parameter
- P-0-0246, Analog input, assignment C, scaling
- P-0-0247, Analog input, assignment C, signal value at 0
- P-0-0248, Analog input, assignment C, dead zone

Pertinent Diagnostic Messages

- C2800 Analog input adjustment command
- C2801 Analog input not configured
- C2802 Oscillations of input signal outside tolerance range
- C2803 Measured values at zero point and max. value identical
- C2804 Automatic adjustment failed
- F2270 Analog input, wire break

5.7.6 Analog Outputs

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Optional Device Functions](#)".

In accordance with the drive system or control section, IndraDrive controllers have a different number of analog outputs.

The drive function "analog outputs" allows outputting analog signal values for commissioning and optimizing drives with appropriate measuring devices (e.g. oscilloscope, multimeter), as well as for visualizing the contents of drive parameters.

Hardware Requirements

The table below shows the number of analog outputs in accordance with the drive system or control section type:

Drive system / control section	Basic device (on board)	Option "DA" ¹⁾
	Number of analog outputs	Number of analog outputs
HCS01.1	-	2 ²⁾
HCQ02.1, HCT02.1	-	-
KSM02.1, KMS02.1	-	-
CSE02.1A, CSB02.1A	-	-
CDB02.1B CSB02.1B, CSH02.1B	2	2

1)
2)


As of MPx18V10
Not with HCS01 Economy

Tab. 5-65: Analog Inputs

Overview

The figure below illustrates the interaction of the two analog output channels with the analog outputs.

Overview of the Scope of Functions



* Only with CDB02.1 control section

Fig. 5-55: Assignment Mechanism for the Analog Outputs

Features

General features:

- Analog outputs are updated in position controller clock (see "Performance Data")
- Analog outputs can be written via master communication (cyclic or acyclic channel)
- Internal status variables and signals (= parameter contents) are output as analog voltage signals at output terminal connectors of the drive controller (see separate documentation "Control Sections for Drive Controllers; Project Planning Manual")
- Monitoring function with regard to double assignment of outputs
- Variable scaling of analog outputs
- Switching of the behavior at the limits of voltage range that can be displayed between overflow and limitation
- Parameterizable output offset or parameterizable reference value



For the technical properties of the analog inputs, see the respective Project Planning Manual.

Pertinent Parameters

Configuring the analog outputs:

- P-0-0426, Analog output IDN list of assignable parameters
- P-0-0427, Control parameter of analog output

Analog output 1:

- P-0-0418, Analog output 1, signal value at 0V
- P-0-0420, Analog output 1, signal selection
- P-0-0422, Analog output 1, scaling [1/V]
- P-0-0139, Analog output 1

Analog output 2:

- P-0-0419, Analog output 2, signal value at 0V
- P-0-0423, Analog output 2, signal selection
- P-0-0425, Analog output 2, scaling [1/V]
- P-0-0140, Analog output 2

Analog output 3:

Overview of the Scope of Functions

- P-0-0428, DA: Analog output 1, signal value at 0V
- P-0-0459, DA: Analog output 1, signal selection
- P-0-0463, DA: Analog output 1, scaling [1/V]
- P-0-0414, DA: Analog output 1

Analog output 4:

- P-0-0429, DA: Analog output 2, signal value at 0V
- P-0-0462, DA: Analog output 2, signal selection
- P-0-0464, DA: Analog output 2, scaling [1/V]
- P-0-0415, DA: Analog output 2

5.7.7 Virtual Master Axis Generator

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Optional Device Functions](#)".

The master axis generator serves for generating a master axis position which can be used as input variable for the position synchronization modes and the "velocity synchronization" mode.

There are three ways of generating the master axis position:

- Format conversion of an actual position value or a command position value of the local axis or of an axis connected via CCD [1]
- Generation of a virtual actual position value via a positioning motion and subsequent format conversion [2]
- Phase-synchronous motion of the master axis position to a primary master (secondary master mode) [3]

Overview of the Scope of Functions




Fig. 5-56: Possibilities of Generating the Master Axis Position for the Slave Axis

Features

Features of generating the virtual actual position value with the master axis generator:

- 3rd order command value interpolator
- Absolute, relative and additive positioning capability

Overview of the Scope of Functions

- "Infinite travel" (jogging) is possible
- Position data format to be set:
 - Linear → 0.0001 mm / 0.0001 inch
 - Rotary → 0.0001 degrees
- Modulo value to be set
- "Absolute" or "modulo" master axis
- Format conversion from position format "virtual master axis" to master axis format (modulo value "virtual master axis" → $2^{P-0-0084} \times P-0-0750$ or $2^{P-0-0773} \times P-0-0763$)
- Virtual master axis generator realized as virtual axis in IndraMotion MLD with individual scaling system
- Setting of virtual master axis generator, either directly via parameters or via the following function blocks:
 - MC_MoveVelocity / MX_MoveVelocity
 - MC_MoveAbsolut / MX_MoveAbsolut
 - MC_MoveAdditiv / MX_MoveAdditiv
 - MC_MoveRelativ / MX_MoveRelativ
 - MC_Stop
 - MB_Stop

Note:

The function blocks for the virtual axis behave exactly like those for a real axis. The diagnostic and error messages, however, are different.

Features of the secondary master mode:

- Real and virtual primary master can be selected
- Electronic gear with fine adjust
- Dynamic synchronization to the primary master
- Master axis position is added as an offset with parameterization of the acceleration and velocity that can be changed
- Activating by means of the functional block "MB_GearInPos"; deactivating by means of the functional block "MB_GearOut"

Pertinent Parameters

- P-0-0084, Number of bits per master axis revolution
- P-0-0750, Master axis revolutions per master axis cycle
- P-0-0756, Virtual master axis, scaling type
- P-0-0757, Virtual master axis, modulo value
- P-0-0758, Virtual master axis, actual position value
- P-0-0759, Virtual master axis, actual velocity value
- P-0-0760, Virtual master axis, positioning control word
- P-0-0761, Master axis position for slave axis
- P-0-0762, Virtual master axis, velocity limit value
- P-0-0763, Modulo factor, master axis format converter
- P-0-0766, Virtual master axis, positioning command value
- P-0-0767, Virtual master axis, effective target position
- P-0-0768, Virtual master axis, positioning status
- P-0-0769, Virtual master axis, command value mode

Overview of the Scope of Functions

- P-0-0770, Virtual master axis, positioning velocity
- P-0-0771, Virtual master axis, positioning acceleration
- P-0-0772, Virtual master axis, positioning deceleration
- P-0-0773, Number of bits per master axis revolution, format converter
- P-0-0774, Virtual master axis, positioning window shortest distance
- P-0-0911, Virtual master axis, positioning window
- P-0-0912, Virtual master axis, standstill window
- P-0-0913, Virtual master axis, positioning jerk
- P-0-0914, Virtual master axis, velocity threshold positioning
- P-0-0915, Master axis format converter IDN list signal selection
- P-0-0916, Master axis format converter signal selection
- P-0-0917, Control word of master axis generator
- P-0-0918, Feed travel internal virtual master axis
- P-0-0919, Synchronization mode, secondary master
- P-0-0920, Synchronization acceleration, secondary master
- P-0-0921, Synchronization velocity, secondary master
- P-0-0922, Preferred synchronization direction, secondary master
- P-0-0923, Synchroniz. window for shortest distance, secondary master
- P-0-0924, Selection primary master
- P-0-0925, Master drive gear input revolutions, secondary master
- P-0-0926, Master drive gear output revolutions, secondary master
- P-0-0927, Master drive gear fine adjustment, secondary master
- P-0-0928, Additive master axis position, secondary master
- P-0-0929, Change velocity of add. master axis posit., secondary master
- P-0-0930, Change accel. of add. master axis posit., secondary master
- P-0-0931, Synchronous position, secondary master
- P-0-0932, Synchronization range, secondary master

Pertinent Diagnostic Messages

- E2100 Positioning velocity of master axis generator too high
- F2063 Internal overflow master axis generator
- F2064 Incorrect cmd value direction master axis generator

5.7.8 Drive-Integrated Command Value Generator

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Optional Device Functions](#)".


The drive-integrated command value generator can be used for commissioning and controller optimization of drives. The command value generator is used to generate various signal shapes (square wave, sine, noise, sine sweep) that are added to the closed control loop as command values.



In conjunction with the integrated oscilloscope function, the drive-integrated command value generator also provides the possibility of measuring the frequency response.

Overview of the Scope of Functions

The figure below illustrates the points at which the drive-integrated command value generator can take effect:



S-0-0037	Additive velocity command value
S-0-0047	Position command value
S-0-0081	Additive torque/force command value
P-0-0038	Torque-generating current, command value
P-0-0039	Flux-generating current, command value
P-0-0059	Additive position command value, controller
P-0-1150	Command value generator output
P-0-1152	Command value generator, target parameter assignment

Fig. 5-57: Points at which "Command Value Generator" Function can Take Effect

- Features**
- Possibility of generating different signal shapes that are added as additive command values to the respective control loop command value (position, velocity or current)

The following signal shapes are possible:

- Square-wave signals
- Sine signals
- Noise signals
- Modified sine signals
- Sine sweep

- Generating **velocity and position command values** in the position controller clock; **current command values** in the velocity controller clock
- With regard to **amplitude and frequency**, generated command values can be freely defined

- Pertinent Parameters**
- P-0-1150, Command value generator output
 - P-0-1151, Command value generator, list of possible target parameters
 - P-0-1152, Command value generator, target parameter assignment
 - P-0-1153, Command value generator, control word
 - P-0-1154, Command value generator, offset
 - P-0-1155, Command value generator, amplitude
 - P-0-1156, Command value generator, duration 1
 - P-0-1157, Command value generator, duration 2

- P-0-1158, Command value generator, periodic time
- P-0-1159, Command value generator, sine sweep start frequency
- P-0-1160, Command value generator, sine sweep end frequency
- P-0-0028, Oscilloscope: Control word
- P-0-0031, Oscilloscope: Time resolution
- P-0-0032, Oscilloscope: Size of memory

5.7.9 Drive-Internal "Command Value Box"

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Optional Device Functions](#)".

With IndraDrive controllers, a so-called "command value box" is internally available for manual drive optimization. It provides the possibility to internally (independent of the master) generate a command value characteristic that can be defined by the user. In this way, an axis drive can be moved in the same way as with an external command value box, without an external command value being effective (→ drive-internal "command value box"). Drive enable must merely be set for the drive.

The command value characteristic that can be defined by the user, allows for an axis to be moved within determinable position limits in continuous sequence in the velocity control loop or position control loop. This can be made use of, in order to manually optimize the control loop parameters of the drive, by e.g. moving the drive with a low velocity command value and by evaluating the status variables "actual current value" and "actual velocity value".



More details on the manual control loop setting are described in the "Overview of Drive Control: Notes on Commissioning for Control Loop Setting".

By the internal command value box, an axis can be continuously moved in an "oscillating movement" (oscillating between two position limit values) or in "stepper mode" (unidirectional moving over a defined path or a travel range).

The internal command value box is configured via a command word, the command value characteristic is defined via the respective parameters. The drive-internal command value box is activated via a command.

Pertinent Parameters

- P-0-0162, C1800 Command Drive optimization / command value box
- P-0-0165, Drive optimization, control word
- P-0-0166, Drive optimization, end position negative
- P-0-0167, Drive optimization, end position positive
- P-0-0169, Drive optimization, travel distance
- P-0-0170, Drive optimization, acceleration
- P-0-0171, Drive optimization, velocity
- P-0-0172, Drive optimization, dwell time

Pertinent Diagnostic Messages

- C1800 Command Drive optimization / command value box
- C1801 Start requires drive enable
- C1806 Travel range exceeded

Overview of the Scope of Functions

5.7.10 Encoder Emulation

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Optional Device Functions](#)".

By means of encoder emulation it is possible to convert available encoder signals (encoder 1, encoder 2 or measuring encoder) or internal position command values into one of the following two formats:

- **Signals of an incremental encoder (track A, track B and zero pulse with 5V TTL or 24V level)**
- **Serial 24-bit position of an absolute encoder (SSI format, Gray-coded)**

This allows, for example, evaluating the signals in a higher-level master in order to close the position control loop in the external control unit in conjunction with the freely parameterizable resolution and the data reference.



Using the encoder emulation in **precision applications** (mostly in machine tool applications) is considered as **critical** and always **has to be carefully considered** beforehand!

For sophisticated applications for which the position control loop is closed by means of emulation, Rexroth recommends to use digital interfaces, such as sercos.

See "Restrictions" in the section "Notes on Commissioning"

Incremental Encoder Emulation

Incremental encoder emulation is the simulation of a real incremental encoder by the drive controller.

With incremental encoder emulation we distinguish between

- Signal emulation
- and -
- Motor encoder emulation.

In the form of **incremental encoder signals**, a higher-level numeric control (NC) receives information about the velocity of the motor connected to the controller. By integration of these signals, the control unit receives the required position information and it is thereby possible to close a higher-level position control loop.



Emulation takes place in scaling-dependent (see S-0-0076) or encoder-related form, the resolution is input in lines/revolution (1 line corresponding to 4 increments) or in mm or inch.

Features of Incremental Encoder Emulation

- Cyclic calculation of the increments output by the emulator in the position controller clock (see "[Performance Data](#)")
- Freely selectable position signals for emulation (P-0-0900, P-0-0901.x.1)
- Parameterizable resolution (lines/revolution or mm resp. inch)
- Encoder-related emulation (incremental)
- Dead time compensation that can be activated (P-0-0901.x.2, bit 3)
- Shiftable zero pulse (P-0-0901.x.4)

Overview of the Scope of Functions

- Parameterizable cyclic zero pulse output for zero pulse distance (P-0-0901.x.4) and position data reference (P-0-0901.x.2)
- Encoder emulation can be switched off in operation (→ pause)
- Internal clock increase of incremental encoder emulation to reduce zero pulse jitter and frequency jitter
- Signal-related or motor-encoder-related emulation to be freely selected (→ influence on position of zero pulse!)

Absolute Encoder Emulation

Absolute encoder emulation means that the drive controller has the option of simulating a real absolute encoder in **SSI data format**. It is thereby possible to transmit the position in the SSI data format to the connected control unit (NC) and to close the position control loop via the control unit.



Emulation takes place in scaling-dependent form (see S-0-0076) and the resolution is input in bits.

Features of Absolute Encoder Emulation

- Cyclic calculation of the position output by the emulator in the position controller clock (see "Performance Data")
- Freely selectable position signals for emulation (P-0-0900, P-0-0901.x.1)
- Parameterizable resolution (bits)
- Scaling-related emulation (S-0-0076)
- Synchronization of SSI emulation to SSI clock

Hardware Requirements

The encoder emulation function of the firmware requires the following device design:

IndraDrive Cs	
BASIC	HCS01.1E-W00xx-A-0x-B-ET-EC-EM-xx-NN-FW
ADVANCED	HCS01.1E-W00xx-A-0x-A-CC-EC-EM-xx-NN-FW
IndraDrive control sections	
Basic control section - double-axis	CDB02.1B-ET-EC-EC-EM-xx-xx-xx-NN-FW
	CDB02.1B-ET-EC-EC-yy-xx-xx-EM-NN-FW for yy = PB, EC or EM
Advanced control section - single-axis	CSH02.1B-CC-EC-EM-xx-xx-NN-FW
	CSH02.1B-CC-EC-yy-xx-EM-NN-FW for yy = ET, PB, CN or EC
Basic control section - single-axis	CSB02.1B-ET-EC-yy-xx-EM-NN-FW for yy = PB, CN or EC
	CSB02.1x-ET-EC-EM-xx-xx-NN-FW

PB	PROFIBUS
EC	Encoder IndraDyn / Hiperface / 1 Vpp / TTL / EnDat
EM	Encoder emulation
ET	MultiEthernet
CN	CANopen

Tab. 5-66: Control Section Design for Encoder Emulation



With double-axis control sections, encoder emulation is simultaneously possible in both axes. Requirements for the device configuration: See Project Planning Manual for Control Sections

Overview of the Scope of Functions

Pertinent Parameters	• P-0-0900, Encoder emulation signal selection list • P-0-0901.x.1, Encoder emulation signal selection • P-0-0901.x.2, Encoder emulation control parameter • P-0-0901.x.3, Encoder emulation resolution • P-0-0901.x.4, Encoder emulation zero pulse offset • P-0-0901.x.5, Encoder emulation zero pulse distance • P-0-0901.x.6, Encoder emulation assignment • P-0-0901.0.7, Encoder emulation, external signal • P-0-0901.0.8, Encoder emulation, modulo value of external signal
	The structure instance ("x" digit) of the parameter IDN represents the optional slot of encoder emulation (EM) in the corresponding control section or HCS01 device, e.g. P-0-0901.x.1 with x = 2 means that the optional slot of the encoder emulation is slot 2.
Pertinent Diagnostic Messages	• C0242 Multiple configuration of a parameter (->S-0-0423) • C0260 Incremental enc. emulator resol. cannot be displayed • F2053 Incr. encoder emulator: Pulse frequency too high • F2054 Incr. encoder emulator: Hardware error

Basic Information on the Function

Activating the Function

The kind of encoder emulation including its activation is determined via bit 0 and bit 1 of "P-0-0901.x.2, Encoder emulation control parameter".

The following settings can be selected via parameter "P-0-0901.x.2, Encoder emulation control parameter":

- No encoder emulation activated
- Incremental encoder emulation (IGS) activated
 - Signal emulation
 - Motor encoder emulation
- Absolute encoder emulation (SSI) activated
 - Signal emulation



The settings in parameter "P-0-0901.x.2, Encoder emulation control parameter" only take effect after progression to the operating mode!



See also Parameter Description "P-0-0901.x.2, Encoder emulation control parameter"

Selecting the Signal to be Emulated

Supported Emulation Signals

The input of the signals that the drive supports for emulation is depending on the following factors:

- Firmware version and enabled functional packages
- Hardware of the control section and its configuration
- With double-axis device, utilization as axis or device function

Overview of the Scope of Functions

	 The emulation signals currently supported by the drive are contained in the list parameter "P-0-0900, Encoder emulation signal selection list".
Determining the Kind of Emulation (for Incremental Encoder Emulation)	In bit 12 of "P-0-0901.x.2, Encoder emulation control parameter", determine whether it is directly the signal of the motor encoder that is to be emulated or the signal that was defined via the parameter "P-0-0901.x.1, Encoder emulation signal selection" (see below).
Selecting the Emulation Signal	If bit 12 = 0 in parameter P-0-0901.x.2, the emulation signal is determined by entering the desired IDN from the list parameter P-0-0900 in parameter "P-0-0901.x.1, Encoder emulation signal selection".
	 The resolution of the emulated signal is determined for both kinds of emulation (SSI and IGS) in parameter "P-0-0901.x.3, Encoder emulation resolution".

5.7.11 Programmable Position Switch

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Optional Device Functions](#)".

The firmware function "programmable position switch" can be used instead of a mechanical position switch that has to be externally mounted.

Features	- Realization of a maximum of 8 dynamic position switch points (switch cams) in the position controller clock - Freely selectable reference signals (P-0-0130) for generating the switch cams, all 8 cams are referring to the same signal (P-0-0131) Switch-on and switch-off position can be separately parameterized via list parameters (P-0-0132, P-0-0133); corresponding position switch bit can be inverted by selecting the switch-on and switch-off threshold Lead time that can be separately parameterized via list parameter (P-0-0134) for compensating internal processing times (dead time compensation) 8 position switch bits displayed in the position switch status word (P-0-0135) which can be assigned to digital outputs or cyclically transmitted via master communication interface - Permanently defined switch hysteresis to avoid position switch bit flicker when the switch-on or switch-off threshold is reached
Pertinent Parameters	- P-0-0130, Position switch signal selection list - P-0-0131, Position switch signal selection - P-0-0132, Position switch switch-on threshold - P-0-0133, Position switch switch-off thresholds - P-0-0134, Position switch lead times - P-0-0135, Position switch status word
Pertinent Diagnostic Messages	C0242 Multiple configuration of a parameter (->S-0-0423)

Overview of the Scope of Functions

5.7.12 Probe Function

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Optional Device Functions](#)".

- | | |
|-----------------------------|---|
| Features | <ul style="list-style-type: none"> • 2 probes (S-0-0401 / S-0-0402) can be evaluated per axis. • The two probe evaluations (S-0-0401, S-0-0402) can be assigned to any input that can handle probes. Several probe evaluations can use the same input. For HCS01 it is the digital inputs I_1 and I_2, for HCT, HCQ it is the inputs I2 and I3. • Measuring signals can be actual position values of motor encoder, external encoder or measuring encoder, in addition master axis position values • Measurement of absolute signal values, of signal value differences, detection of time intervals between measuring signals • Measurement triggered by positive and/or negative probe signal edges • Single measurement or continuous measurement to be selected, measurement events are counted in the case of continuous measurement • Position value range ("expectation window") per probe can be defined within which measurement can take place (activation of a "failure counter" when expectation window is passed through without measuring event) • Quick stop triggered via probe input • Adjustable dead time compensation for each probe, separately for each edge (positive / negative) up to 50000 µs • Measuring accuracy depends on hardware design, see section "X31, Digital Inputs, Digital Output" and section "Digital Inputs - Probe" in the documentation "Rexroth IndraDrive Cs, Drive Systems with HCS01" (DOK-INDRV*-HCS01*****-PR01-EN-P; mat. No. R911322210) |
| Pertinent Parameters | <ul style="list-style-type: none"> • S-0-0130, Probe value 1 positive edge • S-0-0131, Probe value 1 negative edge • S-0-0132, Probe value 2 positive edge • S-0-0133, Probe value 2 negative edge • S-0-0169, Probe control parameter • S-0-0170, Probing cycle procedure command • S-0-0179, Probe status • S-0-0401, Probe 1 • S-0-0402, Probe 2 • S-0-0405, Probe 1 enable • S-0-0406, Probe 2 enable • S-0-0409, Probe 1 positive latched • S-0-0410, Probe 1 negative latched • S-0-0411, Probe 2 positive latched • S-0-0412, Probe 2 negative latched • S-0-0426, Signal selection probe 1 |

Overview of the Scope of Functions

- S-0-0427, Signal selection probe 2
- S-0-0428, Probe, IDN-list signal selection
- S-0-0524, Dead time compensation, positive edge, probe 1
- S-0-0525, Dead time compensation, negative edge, probe 1
- S-0-0526, Dead time compensation, positive edge, probe 2
- S-0-0527, Dead time compensation, negative edge, probe 2
- P-0-0200, Start position probe function 2 active
- P-0-0201, End position probe function 2 active
- P-0-0202, Difference probe values 1
- P-0-0203, Difference probe values 2
- P-0-0204, Start position probe function 1 active
- P-0-0205, End position probe function 1 active
- P-0-0206, Probe 1, max. number of marker failures
- P-0-0207, Probe 2, max. number of marker failures
- P-0-0224, Probe 1, number of marker failures
- P-0-0225, Probe 2, number of marker failures
- P-0-0226, Probe, extended control word
- P-0-0300, Digital inputs, assignment list
- P-0-0306, Digital inputs, assignment connector and pin

Pertinent Diagnostic Messages

- A0403 Quick stop with probe detection is active
- C0250 Probe inputs incorrectly configured

5.7.13 Measuring Encoder

Brief Description



Assignment to functional firmware package, see chapter "[Availability of the Optional Device Functions](#)".

Position measurement

Measuring encoders are used for position evaluation of a rotary motion that takes effect as a command variable for drive control. The actual position value of the measuring encoder therefore is of command value nature for drive control, the measuring encoder can be connected to a shaft or axis via a gearbox and acts as a master axis encoder, for example.

Evaluating Position Measurement

Depending on its design and the mechanical arrangement at the axis, the measuring encoder can be evaluated as

- Relative encoder (incremental encoder)

- or -

- Absolute encoder (absolute value encoder).

Relative Position Measurement

In the case of relative position measurement, only position differences can be evaluated by means of the measuring system. The actual position values signaled by the measuring system refer to the (mostly undefined) position at the time the drive is switched on. If the actual position value is to refer to an axis or shaft, it is necessary to establish position data reference ("homing").

Absolute Position Measurement

In the case of absolute position measurement, the encoder signals actual position values with a fixed encoder-dependent reference point to the controller. After the drive is switched on, the correct actual position value is immediately

Overview of the Scope of Functions

	available for each axis or shaft position. Due to the mostly undefined mounting situation of the encoder, it is necessary during initial commissioning to once adjust the actual position value to the axis or shaft ("set absolute position").
Precision, Resolution	The precision of the position measurement depends on • the resolution of the measuring system (division periods = DP), • the absolute encoder precision, • the digitalization quality of the analog encoder signals, • the size of the selected modulo range of the encoder.
Monitoring Functions	The correct position information of the measuring encoder is required for correct recording of a command variable. The encoder signals are therefore monitored for validity and compliance with the allowed tolerances. In addition, it is possible to monitor drives with an encoder that can be evaluated in absolute form for compliance with the position when switching on compared to the last time the drive was switched off. See "Monitoring the Measuring Systems"
Hardware Requirements	For connecting the measuring systems to the controller, the control section has to be equipped with the corresponding interfaces. Parameter "P-0-0079, Assignment measuring encoder->optional slot" is used to determine the interface to which the respective encoder is connected. For multi-axis drive controllers (HCT, HCQ), it is only possible to assign a measuring encoder to one axis. The assignment is made in parameter "P-0-0076, Encoder type 3 (measuring encoder)". If a measuring encoder was assigned to several axes, an error message will be displayed!  For multi-axis control sections (HCQ / HCT), the measuring encoder can only be connected to the X8 interface (option 5)!
Pertinent Parameters	• P-0-0052, Actual position value of measuring encoder • P-0-0076, Encoder type 3 (measuring encoder) • P-0-0079, Assignment measuring encoder->optional slot • P-0-0084, Number of bits per master axis revolution • P-0-0087, Actual position value offset of measuring encoder • P-0-0097, Absolute encoder monitoring window for measuring encoder • P-0-0127, Input revolutions of measuring gear • P-0-0128, Output revolutions of measuring gear • P-0-0179, Absolute encoder buffer 3 (measuring encoder) • P-0-0326, Multiplication of measuring encoder • P-0-0327, Encoder resolution of measuring encoder • P-0-0328, Type of position encoder for measuring encoder • P-0-0329, Smoothing of actual position value 3 of measuring encoder • P-0-0330, Control word of measuring encoder • P-0-0331, Status of measuring encoder • P-0-0332, Actual velocity value of measuring encoder • P-0-0334, Absolute encoder range of measuring encoder • P-0-0347, Encoder 3, cosine signal • P-0-0348, Encoder 3, sine signal

Overview of the Scope of Functions

- P-0-0765, Modulo factor measuring encoder
- P-0-1020, Kind of encoder 3, encoder memory
- P-0-1021, Encoder 3 resolution, encoder memory
- P-0-1022, Absolute encoder offset 3, encoder memory
- Pertinent Diagnostic Messages**
 - C0291 Incorr. parameterization of measuring enc. (hardware)
 - C0292 Measuring encoder unknown
 - C0293 Modulo value for measuring encoder cannot be displayed
 - C0294 Incorrect measuring encoder configuration
 - C0227 Error when initializing position of measuring encoder
 - C0228 Initialization velocity measuring encoder too high
 - E2076 Measuring encoder: Encoder signals disturbed
 - F2043 Measuring encoder: Encoder signals incorrect



The error message F2043 can also be configured as a warning. In this case, there is no error reaction on the drive side. The user is then responsible for initiating an appropriate reaction via the control master

- F2076 Actual pos. value 3 outside absolute encoder window
- F2176 Loss of measuring encoder reference
- F2179 Modulo limitation error of measuring encoder

5.8 Handling, Diagnostic and Service Functions

5.8.1 Parameters, Basics

Properties/Features of Parameters

Brief Description

The controller firmware via data maps the drive to an internal mathematical model. All operating data relevant therefor are mapped to parameters. An identification number (IDN) is assigned to each parameter. The IDN allows accessing operating data via

- the Engineering Port

- or -

- a master communication interface suited for data transfer.

The operating data stored in parameters can be identified by means of the IDN. They can be read and transferred, if required. The user write access to parameters depends on the properties of the respective parameter and the current communication phase. Specific parameter values (operating data) are checked for validity by the drive firmware.

Loading, Storing and Saving Parameters

Brief Description

- Parameters** All relevant operating data are mapped to parameters and stored in the controller.
- Data Memory** Several non-volatile data memories are available in an IndraDrive device:
 - In the controller

Overview of the Scope of Functions

	• In the motor encoder (depending on motor type) In addition, the controller has a volatile data memory (working memory).
Condition as Supplied	Condition as supplied of the Rexroth drive components: • The controller memory contains the drive firmware and the controller-specific parameter values. • The motor encoder memory contains the encoder-specific and, depending on the motor type, the motor-specific parameter values.
Storing the Application-Specific Parameter Values	The application-specific parameter values are stored in the controller. Due to the limited number of writing cycles of non-volatile storage media, application-specific parameter values can be stored in the working memory (volatile memory), too.
Saving Parameter Values	Saving application-specific parameter values is required in the following cases: • After initial commissioning of the machine axis or the motor • Before replacing the controller for servicing (if possible) Application-specific parameter values can be saved via: • "IndraWorks Ds/D/MLD" commissioning tool → saving the parameter values to an external data carrier • Control master → saving parameter values on master-side data carrier
Parameter IDN Lists	The drive supports master-side saving of parameter values by listing parameter identification numbers (IDNs). Using these lists guarantees complete storage of the application-specific parameter values. It is also possible to determine IDN lists defined by the customer.
Loading Parameter Values	Loading parameter values is required in the following cases: • Initial commissioning of the motor (loading default values and motor-specific parameter values) • Serial commissioning of machine axes at series machines (loading the values saved after initial commissioning) • Reestablishing a defined initial state (repeated loading of the values saved after initial commissioning) • Replacing the controller for servicing (loading the current parameter values saved before servicing) Possibilities of loading parameter values to the controller: • Motor encoder data memory → loading the parameter values by command or via the control panel during initial motor commissioning • "IndraWorks Ds/D/MLD" commissioning tool → loading the parameter values from an external data carrier • Control master → loading the parameter values from master-side data carrier
Checksum of Parameter Values	By means of checksum comparison, the control master can determine whether the values of the application-specific parameter values currently active in the drive correspond to the values saved on the master side.
Pertinent Parameters	• S-0-0017, IDN-list of all operation data • S-0-0192, IDN-list of all backup operation data • S-0-0262, C07_x Load defaults procedure command • S-0-0263, C2300 Load working memory procedure command • S-0-0264, C2200 Backup working memory procedure command

Overview of the Scope of Functions

- S-0-0269, Storage mode
- S-0-0270, IDN-list of selected backup operation data
- S-0-0293 , C2400 Selectively backup working memory procedure command
- S-0-0326, Parameter checksum
- S-0-0327, IDN list of checksum parameter
- S-0-0531, Checksum of backup operation data
- P-0-0013, List of all IDNs not corresponding to default value
- P-0-0660.0.1, Configurable factory default values
- P-0-4023, C0400 Communication phase 2 transition
- P-0-4065, Active non-volatile memory
- P-0-4090, Configuration for loading default values

Pertinent Diagnostic Messages

Load default values:

- C0700 Load defaults proced. command (motor-spec. controller val.)
- C0702 Default parameters not available
- C0703 Default parameters invalid
- C0704 Parameters not copyable
- C0706 Error when reading the controller parameters
- C0720 SMO: Load defaults procedure command
- C0721 SMO: Load defaults procedure not possible
- C0722 SMO: Error in load defaults procedure
- C0723 SMO: Error in deactivation
- C0730 Load defaults procedure command (MLD)
- C0740 Command Activate field bus profile settings
- C0743 Error in activation of field bus profile settings
- C0750 Load defaults procedure command (factory settings)
- C0751 Parameter default value incorrect (-> S-0-0423)
- C0752 Locked with password
- C0761 Factory default values incorrect (->S-0-0423)
- C0799 An invalid index was set

Backup working memory procedure:

- C2202 Error when writing data to non-volatile memory
- C2200 Backup working memory procedure command

Load working memory:

- C2300 Load working memory procedure command
- C2301 Error when reading non-volatile memory
- C2302 Error when converting parameters

Selectively backup working memory procedure:

- C2400 Selectively backup working memory procedure command
- C2402 Error when saving parameters

Other diagnostic messages:

- F2100 Incorrect access to command value memory

Overview of the Scope of Functions

- F2102 It was impossible to address I2C memory
- F2103 It was impossible to address EnDat memory

IDN Lists of Parameters

General Information

Some of the parameters stored in the drive contain, as their operating data (parameter value), a list of IDNs of drive parameters corresponding to a specific, given criterion. These so-called IDN lists enable the master or a commissioning software to handle drive parameters in a specific way.

Using a Password

Brief Description

IndraDrive controllers provide the possibility to protect parameter values against accidental or unauthorized change by means of a password. With regard to write protection, there are 3 groups of writable parameters:

- Parameters that are generally write-protected, such as motor parameters, hardware code parameters, encoder parameters, error memories, etc. ("administration parameters"). The values of these parameters ensure correct function and performance of the drive.
- Parameters the customer can combine in groups and protect them with a so-called customer password. This allows protecting parameter values, that are used for adjusting the drive to the axis, after having determined them.
- All other writable parameters and are not contained in the above-mentioned groups. They are not write-protected.

The drive firmware allows activating and deactivating the write protection for parameter values by means of three hierarchically different passwords:

- **Customer password**
→ The parameter values of a parameter group combined by the customer can be protected.
- **Control password**
→ Parameters protected by a customer password are writable; "administration parameters" remain read-only.
- **Master password**
→ All writable parameters, including "administration parameters" and parameters protected by a customer password, can be changed.



The customer password can be defined by the customer, the control password and the master password are defined by the manufacturer!

Pertinent Parameters

- S-0-0192, IDN-list of all backup operation data
- S-0-0267, Password
- S-0-0279, IDN-list of password-protected operation data
- P-0-4064, Password level

Central Backup & Restore

Brief Description

Fields of Application

This function allows managing the device data of a complete CCD group by means of a central machine archive. The machine archive is stored on the optional memory card of the CCD master. It is possible to store the active parameterization of all drives in the CCD group in centralized form and to restore it, if required, or to load an existing machine archive to another installation.

The machine archive contains all the application-relevant data (parameters according to the list of backup operation data, MLD program, retain variables, firmware).

The following actions are possible:

- Save, restore or update an MLD project including the MLD retain data
- Save, restore or update the operating data of one or several axes
- Carry out a firmware update
- After a device has been replaced, put the new device into operation with the configuration of the old device
- Duplicate an existing installation

Overview of Functions

Creating a Machine Archive

Using the command C6500, all application-relevant data are centrally stored on the SD card of the CCD master.

- Backup operation data ("S-0-0192, IDN-list of all backup operation data")
- MLD application ("P-0-1353, PLC user program area 0" to "P-0-1358, PLC user program area 5") incl. retain data ("P-0-1359, PLC retain data") or boot project of optional memory card
- Retain data of the device ("P-0-0192, Error memory of diagnostic numbers")
- Firmware



When machine archive is created, the operating data of all CCD slaves are saved on the SD card of the CCD master. Therefore, the execution of the command might take several minutes. During this time, write access to the operating data to be saved should be avoided to ensure the consistency of the machine archive.

Restoring the Device Data

Using the command "C6600Restore device data", the device data stored in the machine archive are automatically restored on all drives of the CCD group. When the replacement of a device was detected, the data of the machine archive in the strict mode are automatically loaded to the replacement device, before the progression to the operating mode takes place.

Updating the Device Data

It is possible to make available a valid machine archive as an update. Using the command "C6700Update of device data", these data are activated in the drives.



The update does not modify the retain data.

Hardware Requirements

IndraDrive Cs Advanced with SD card required.

Overview of the Scope of Functions

Pertinent Parameters

- P-0-0665, C6500 Command Archive device data
- P-0-0666, C6600 Command Restore device data
- P-0-0668, Device data archiving, configuration
- P-0-0669, Device data archiving, status
- P-0-0195, IDN list of retain data (replacement of devices)
- P-0-1360, PLC program identifier
- P-0-1518, Module code of control section
- P-0-1521, Programming module identifier
- S-0-0030, Manufacturer version
- S-0-0192, IDN-list of all backup operation data
- S-0-0531, Checksum of backup operation data

Pertinent Diagnostic Messages

- C0200 Exit parameterization level procedure command
- C0201 Invalid parameters (->S-0-0423)
to
C0299 Configuration changed. Restart
- C6500 Archive device data
- C6501 Error when creating machine archive
- C6502 Error when reading device data
- C6503 Inconsistent backup of machine archive
- C6600 Restore device data
- C6601 Error when accessing machine archive
- C6602 Error when writing device data
- C6604 Error when reading device data
- C6605 Device data incompletely restored
- C2200 Backup working memory procedure command
- C2202 Error when writing data to non-volatile memory
- E2667 Machine archive is not up-to-date

5.8.2 Diagnostic System

Coded Diagnostic Messages of the Drive

Brief Description

The drive provides a diagnostic system including different options that are basically divided into two groups:

- Recognizing and displaying the current drive state by means of drive-internal, priority-dependent generation of diagnostic messages

Overview of the Scope of Functions



As of MPx-18, the diagnostic message number is generated in accordance with the sercos specification. For this purpose, the bits 31-24 in the parameter "S-0-0390, Diagnostic message number" are written, too; these bits were always "0" in previous versions. In the control panel and in IndraWorks dialogs, these bits are hidden so the display remains unchanged there.

If the diagnostic messages are to be displayed in S-0-0390 as in the previous versions, bit 0 must be set in "P-0-0006, Diagnostic message configuration".

Pertinent Parameters

- Collective messages for various status messages

Additionally, there are parameters for all important operating data the values of which can be transmitted both via master communication (e.g., sercos) and a parameterization interface (RS-232/485 in the ASCII protocol or SIS protocol; see "Serial Communication").

- S-0-0030, Manufacturer version
- S-0-0095, Diagnostic message
- S-0-0140, Controller type
- S-0-0375, Diagnostic numbers list
- S-0-0390, Diagnostic message number
- S-0-1302.0.3, Application type
(S-0-0142 only exists as a legacy (or alias) parameter for S-0-1302.0.3.)
- P-0-0478, Logbook event
- P-0-0479, Logbook time stamp

Status Classes, Status Displays, Control Parameters

General Information

In the drive there are many parameters with important status information (bit lists). Some of the bits contained in these lists can be used for configuring real-time status bits and additionally can be assigned to digital outputs or to the configurable signal status word.

See "[Digital Inputs/Outputs](#)"

See "[Configurable Signal Status Word](#)"

The drive differentiates the error, warning and message states (status classes).

In the drive there are parameters

- with direct relation to the status of the sequence of different drive functions (fixed status displays)
- for controlling the drive functions (control parameters)

Operating Hours Counter

Brief Description

There are operating hours counters available in the drive that separately record the operating time for control section and power section. The respective operating time is displayed in the parameters P-0-0190 or P-0-0191. These times are directly stored from the control section or power section so that assignment is maintained also for servicing.

Pertinent Parameters

- P-0-0190, Operating hours control section
- P-0-0191, Operating hours power section

Overview of the Scope of Functions

Parameter "P-0-0190, Operating hours control section" displays the operating time of the control section of the drive. The unit is seconds.

The time the drive has been switched on is considered to be the operating time of the control section.

Parameter "P-0-0191, Operating hours power section" displays the operating time of the power section of the drive with drive enable having been set. The unit is seconds.

The time during which the output stage has been enabled is considered to be the operating time of the power section.



Before delivery, the operating hours counters are set to a defined value at the factory. They can therefore indicate the total runtime of a component in field duty.

In addition, there is an operating hours counter for motors with which the dynamic operating data of the motor are collected and stored.

See the section "[Diagnostic Data of Motor Operation](#)"

Error Memory (Power Section and Control Section)

Brief Description

In the drive, all errors occurred are recorded in an error memory on the control section. If an error occurs in the power section, it is additionally stored in a separate error memory on the power section. It is thereby made sure that the relevant information is still available on the power section after separating the power section and control section.



When an error occurs, the diagnostic message number and the current count of the operating hours counter are automatically stored.

Pertinent Parameters

- S-0-0390, Diagnostic message number
- P-0-0190, Operating hours control section
- P-0-0191, Operating hours power section
- P-0-0192, Error memory of diagnostic numbers
- P-0-0193, Error memory operating hours of control section
- P-0-0194, Error memory power section



The contents of the parameters P-0-0192 and P-0-0193 are stored on the control section. The content of parameter P-0-0194 is stored on the power section.

Diagnostic Data of Motor Operation

Brief Description

For preventive maintenance and service purposes, the firmware provides the option to collect dynamic operating data of the motor and store them in the controller.

The operating hours counter for motors allows planning maintenance intervals, minimize machine downtimes and reduce maintenance costs.

Features

- Recording the total time during which:

Overview of the Scope of Functions

- Operating state "AF" present
- Velocity unequal zero
- Motor temperature is greater than 10 K below shutdown threshold (parameter "S-0-0204, Motor shutdown temperature")
- Recording the maximum velocity of the motor in operation
- Determining the average value of the motor velocity in operation
- Recording the maximum temperature of the motor winding in motor operation
- Determining the average value of the motor winding temperature, referring to the duration of the operating status "AF"
- Determining the operational performance of the motor by multiplying average speed and duration with velocity unequal zero

Pertinent Parameters

- P-0-2051, Operating hours counter, motor
- P-0-2052, Thermal operating data, motor
- P-0-2053, Mechanical operating data, motor
- P-0-2054, Operational performance, motor
- P-0-2055, Serial number, motor

Load Preview

Brief Description

When operating electric drives, there also is power dissipation when the motor delivers power or torque/force. For electrical equipment or electrical components, due to the materials used, there is a maximum permissible operating temperature up to which continuous operation is safe. This temperature determines the permissible continuous load for the electrical components.

Overload Capacity

The temperature rise of electrical components based on current supply runs in parallel with their thermal time constants. As long as the maximum permissible operating temperature has not been reached, an electrical component may be overloaded, i.e. short-time operation with more than the permissible continuous load. This causes the temperature rise to occur more quickly but does not pose a problem as long as the permissible operating temperature is not exceeded.

If the permissible operating temperature is reached, the overload must be reduced to the permissible continuous load so that the electrical components are not damaged. Functions for limiting overload are present on Rexroth drives for various drive components that are relevant to performance:

- Motor
- Inverter of the controller
- Braking resistor of the supply unit or converter

Protective Functions

The functions that supply protection from loads that are not permitted are realized in the hardware or firmware side:

- Hardware-side temperature measurement in the motor windings and on the controller heat sink
- Firmware-side temperature model calculation for temperatures at temperature-sensitive components that cannot be measured on the hardware-side.

Overview of the Scope of Functions

	With hardware-side temperature measurement, only the temperature rise processes that take place in the seconds range can be recorded; the temperature rise that takes place more quickly can only be monitored using firmware-side model calculation anyway.
Overload Limitation	The high overload capacity of electric drives can only be realized such that operational safety is ensured by using temperature model calculation and automatic overload limits: • Current limitation with controller temperature model (inverter) • Current limitation with motor temperature model • Power limitation with braking resistor temperature model
Load Preview	Limits that intervene automatically do protect the electrical components from damage, but also affect the torque or power output of the drive and can lead to shutdown due to resulting errors or rejects during processing. Early detection and reporting of threatening limitations is possible with the "load preview" function for the three temperature model calculations mentioned above: • Processing the machining cycle with the highest load • Determining the difference of the load curve (difference between maximum value and start value) • Determining a threshold value for the load at which the expected load difference is still just possible without reaching the limit • Message when the thermal load has reached the specified threshold value.
Pertinent Parameters	• P-0-0141, Thermal drive load • P-0-0441, Thermal drive load warning threshold • P-0-0446, Thermal motor load • P-0-0465, Maximum value thermal drive load • P-0-0466, Maximum value thermal motor load • P-0-0467, • P-0-0468, Prewarning threshold of therm. motor load • P-0-0469, Prewarning threshold of therm. load of braking resistor • P-0-0844, thermal load of Braking resistor
Pertinent Diagnostic Messages	• E2051 Motor overtemp. prewarning • E2061 Device overload prewarning • E2820 Braking resistor overload prewarning

5.8.3 Control Panel

Brief Description

IndraDrive controllers are equipped with a "control panel"; its front consists of a display and four keys located below it. The display shows operating states, command and error diagnoses, as well as present warnings.

Overview of the Scope of Functions




Fig. 5-58: Control Panel of IndraDrive Cs Advanced with Optional Memory Card




Fig. 5-59: Schematic Illustration of the IndraDrive Cs Control Panel

The four keys can be used to display extended diagnostic messages and trigger simple commands (in addition to master communication, IndraWorks or NC control). The menus are all in English; any present diagnostic and error messages are displayed in the language set in parameter "S-0-0265, Language selection".

Display Options of the Control Panel

The display of the IndraDrive controller automatically shows

- Status of the master communication
- Operating status
- Commands and diagnostic command messages
- Warnings and diagnostic error messages
- Extended displays such as contents of type designation of firmware active in the device or safety technology code (if safety technology option available)

Control Panel Variants

There are the following control panel variants

1. Standard control panel
2. Standard control panel incl. slot for optional memory card
3. Advanced control panel incl. slot for optional memory card

In addition to the functions of the standard control panel, the Advanced control panel has an extended retain data memory for MLD. Using the Advanced control panel requires IndraDrive Cs Advanced.

4. VCP operator terminal, optional

As an option, an operator terminal can additionally be connected to the drive via an Ethernet connection. VCP operator terminals are freely programmable, i.e. it is possible to implement application-dependent settings and diagnostic messages.

Setting Options Using the Control Panel

The following settings can be made using the control panel:

- Setting the drive address (drive number in the bus system of the master communication)

Overview of the Scope of Functions

	• Activating the easy startup mode for initial commissioning • Setting the master communication protocol • Setting IP addresses for Engineering
Command Activation Using the Control Panel	The following commands can be activated using the control panel: • Activating "S-0-0262, C07_x Load defaults procedure command" (load controller parameters or basic parameters) • Activating other commands, such as: – C0300 Set absolute position procedure command – C2000 Command Release motor holding brake
Configuring the Control Panel	The standard menu can be reached via the Enter key. The control panel can be configured to a limited extent: • It is possible to choose between the edit mode and the view mode of the control panel. – "P-0-0680, Control panel: Configuration", bit 14 = 0, Edit Mode, changes can be made via the control panel. – "P-0-0680, Control panel: Configuration", bit 14 = 1, View Mode, editing via the control panel is locked. If the modification screen is activated on the display for a datum which basically can be changed, the "Edit disabled" message is generated, it is impossible to change the value. However, a temporary edit mode can be activated by keeping ESC +ENTER pressed for 8 seconds. If the standard menu is started in this way, parameters can be adjusted as usual. • Before a value is changed, the additional query "Ok?" is displayed. This query must be confirmed with the ENTER key before a value is actually changed. This is meant to prevent accidental changes. • By means of the corresponding setting in "P-0-0680, Control panel: Configuration", the output of diagnostic texts can be deactivated. In this case, the diagnostic message number is always output, the diagnostic text is not displayed.

5.8.4 Firmware Replacement

Brief Description

	Basic Principles
Explanation of Terms	The following cases are distinguished for firmware replacement: • Release update An old firmware release (e.g. MPB18V06) contained in the device is replaced by a new firmware release (e.g. MPB18V10). • Version upgrade The old firmware version contained in the device is replaced by a new firmware version (example: MPB17V10 is replaced by MPB18V06).

Overview of the Scope of Functions

	 The following chapters regarding the release update and firmware upgrade exclusively apply to devices of the IndraDrive Cs type, as well as control sections (CSB02, CSH02, CDB02, CSE02) and IndraDrive Mi (KSM02, KMS02). The information does not apply to IndraDrive HCQ / HCT, but is described in the separate documentation "Rexroth IndraMotion MTX micro12VRS System Description" (DOK-MTXMIC-SYS*DES*V12-PR01-EN-P, mat. no. R911334369).
How to Replace the Firmware	Firmware for IndraDrive can be replaced using the following hardware and software: • Computer with FireFox or Internet Explorer web browser or • Computer with "IndraWorks" software or • Computer with TFTP client • IndraMotion Service Tool (IMST) or IndraDrive Service Tool (IDST) (as of MPx18V10)
	 "IndraMotion Service Tool (IMST)" or "IndraDrive Service Tool (IDST)" allow accessing the drive system, e.g. for remote diagnostics. Besides, authorized users can handle different service cases with IMST or IDST, such as replacing drive components, loading parameters or updating/upgrading the drive firmware. "IndraMotion Service Tool (IMST)" additionally analyzes drive systems connected via cross communication (CCD). Further information on "IndraMotion Service Tool (IMST)" and "IndraDrive Service Tool (IDST)" is described in the separate documentation „Rexroth IndraDrive Service Tools IMST/IDST“ (DOK-IM*MLD-IM-STIDSTV13-RE**-EN-P; mat. no. R911342652).
	 The "IndraWorks" commissioning software can be ordered from Rexroth. The scope of supply of "IndraWorks" contains a documentation which describes the operation of the program.
To be Noticed	After every firmware replacement (release update and version upgrade), check the following parameters for validity: • P-0-2003, Selection of functional packages • P-0-4089.0.1, Master communication: Protocol It might possibly be necessary to set them valid during the first run-up after the firmware replacement.
IndraDrive HCQ / IndraDrive HCT	The firmware replacement for "IndraDrive HCQ" / "IndraDrive HCT" is described in the documentation "Rexroth IndraMotion, MTX micro 12VRS, System Description" (DOK-MTXMIC-SYS*DES*V12-PR01-EN-P, material number R911334369).
Preparing the Firmware Replacement	Preparations and Conditions for Firmware Replacement You have to make the following preparations for firmware replacement: 1. Drive controller must be on (24 V supply). 2. Drive controller mustn't be in operating mode (communication phase 4) (cf. P-0-0115).

Overview of the Scope of Functions

	3. It is recommended to save the backup parameters before replacing the firmware (see Functional Description "Loading, Storing and Saving Parameters").
General Notes on How to Carry Out Firmware Replacement	You have to observe the following points when carrying out the firmware replacement: • For firmware replacement via IndraWorks or IndraMotion Service Tool (IMST) resp. IndraDrive Service Tool (IDST), Ethernet communication with the drive must be possible. (IMST and IDST are available as of MPx18V10.) • Do not switch off the 24 V control voltage while replacing the firmware. • The firmware replacement always must be carried out completely.
Communication Types	The engineering communication works in different ways, depending on the activated bus system (cf. P-0-4089.0.1). Make the settings and comply with the requirements in accordance with the bus system used. For further information, see "chapter TCP/IP Communication". Via the programming module, the active IP settings can be viewed or adjusted, if necessary (see Functional Description "Standard Control Panel").  After you have changed the IP settings, the device must be re-started for activating the settings. If several devices have been connected via the master communication bus, you have to make sure that an unequivocal IP address is assigned to each node.
IP Configuration in the Easy Menu IP Settings at the Computer	See Functional Description "Standard Control Panel" See Microsoft help, keyword "LAN connection"
Firmware Release Update	General Information Before the firmware release update, it is recommended to save the backup parameters of the drive!  If the firmware is replaced at a device activated in a safety-related way, this procedure must be recorded in the machine logbook, together with the axis identifier, configuration type data and parameterization type data. Firmware Release Update with Computer  When the safety technology options S3 or S4 are used, the system checks whether firmware and parameter set are compatible. This prevents the safety technology from being operated with an incompatible parameter set. Incompatible changes typically do not occur in the case of a release update. In the case of an incompatibility, it is possible to either • continue with the existing parameterization by reloading the originally available firmware, or • continue with the new firmware by means of initial commissioning (incl. loading of basic parameters for SMO contained therein) 1. Connect drive to computer (recommended: Cat5e Ethernet cables)

Overview of the Scope of Functions

2. Load firmware

There are three possibilities of performing a firmware release update using a computer:

- By means of IndraWorks
- With a TFTP client
- Via the supplied web interface IMST or IDST.

This option only applies to firmware updates of MPx18V10 and above; IMST and IDST are not available for older versions.

1. *Firmware Download with IndraWorks*

- 1.1 Call "IndraWorks".
- 1.2 Load project for corresponding axis or create new project; to do this, address axis via Ethernet.
- 1.3 Switch project "online".
- 1.4 Select/highlight controller and call "Firmware Management" in context menu.

A new window opens and firmware currently available in drive is displayed.
- 1.5 Highlight new firmware (*.ibf file) in upper part of dialog and start firmware download via "Download" button.

Firmware download runs automatically and all required firmware components are loaded to drive.
- 1.6 After firmware download has been completed, close "Firmware Management" window.

2. *Firmware Download Using a TFTP Client*

- 2.1 Firmware update service is made available via a TFTP server. Command for sending the firmware is "put" command. The TFTP client must transmit the file in the binary format.



It is possible with any TFTP client supporting this command (e.g. Windows command line program "tftp.exe") to carry out a firmware release update **without IndraWorks**.

Example (with "Microsoft Windows consoles TFTP client"):

To carry out a firmware release update, only a "put" request is transmitted. Do not use an optional alternative name for the file on the target system. The IP address of IndraDrive must be specified as the target (the standard is 192.168.0.1): `tftp -i 192.168.0.1 put FWA-INDRV_-MPB-17V12-D5.ibf`

The parameter "-i" means that the file is to be transmitted in binary form.

See also Functional Description: "[Firmware Download via TFTP Server](#)"

3. *Firmware Download with IMST/IDST (as of MPx18V10)*

- 3.1 Enter IP address of IndraDrive in web browser
- 3.2 Log in as service user at web interface
- 3.3 In navigation tree on the left side select "Firmware Update" dialog in "Service" folder

Overview of the Scope of Functions

- 3.4 Select new firmware by clicking "Search" button, firmware update is started by clicking download button

3. Restart drive

At the end of the update, IndraWorks and IMST/IDST automatically provide the option to restart IndraDrive via the reboot command S-0-1350. As an alternative, IndraDrive can be restarted by means of control voltage reset

4. Put machine into ready-for-operation status again according to machine manufacturer's instructions.
5. Check functions of the drive.

Firmware Version Upgrade

General Information

When firmware in a drive controller is replaced by firmware of a **more recent version**, this is called firmware version upgrade (e.g., FWA-INDRV*-MPB-16V24-D5 replaced by FWA-INDRV*-MPB-17V12-D5).



Before carrying out the firmware version upgrade, you must save all parameters (e.g., with "IndraWorks"). **After** firmware replacement, the parameters must be restored, because the command "C07_1 Load defaults procedure command (factory settings)" is carried out automatically. After the desired parameter file was loaded, the drive controller is ready for operation again.

Saving Parameter Values

Before firmware upgrade, all application-specific parameter values must be saved on a data carrier. The parameter backup can be carried out by means of:

- **Commissioning software "IndraWorks"**
→ Saving parameter values on external data carrier
- or -
- IndraMotion Service Tool (IMST) or IndraDrive Service Tool (IDST) (as of MPx18V10)
→ Saving parameter values on external data carrier
- or -
- **Control master**
→ Saving parameter values on master-side data carrier

Version Upgrade with "IndraWorks"

Requirements

The following requirements should have been fulfilled in order that carrying out the firmware version upgrade with "IndraWorks" makes sense:

- Existing Ethernet connection between PC and drive controller
- Current parameter setting of axis was saved.



When upgrading from MPB16VRS to MPB17VRS, for example, the error F8100 is sometimes generated during the drive controller's first run-up. This error can be cleared via the display and will not occur again during the next booting process.

Overview of the Scope of Functions

Firmware Upgrade with "IndraWorks"

Carrying out the firmware version upgrade with "IndraWorks" requires the following steps:

1. Load firmware

- 1.1 Call "IndraWorks".
- 1.2 Load project for corresponding axis or create new project; to do this, address axis via Ethernet.
- 1.3 Switch project "online".
- 1.4 Select/highlight controller and call "Firmware Management" in context menu.
A new window opens and firmware currently available in drive is displayed.
- 1.5 Highlight new firmware (*.ibf file) in upper part of dialog and start firmware download via "Download" button.
Firmware download runs automatically and all required firmware components are loaded to drive.
- 1.6 After firmware download has been completed, close "Firmware Management" window.
- 1.7 Reboot drive controller

2. Put drive into ready-for-operation state

⇒ Switch project "online".

After project has been switched "online", a message sometimes signals that "IndraWorks" could not establish communication to drive via Ethernet interface, as drive-internal settings for Ethernet communication were reset.

⇒ In this case, reconfigure communication via button "Search for devices"!

⇒ As firmware in drive no longer complies with version stored in project, a corresponding message is displayed. Select desired option in dialog to make drive available in project again and allow reestablishing communication to device.

⇒ Manually set functional package and master communication protocol via corresponding parameters.

⇒ Activate command "C07_1 Load defaults procedure command (factory settings)". All buffered parameters are thereby set to their default values.

3. Load parameter values

⇒ Load parameter file which was saved.

⇒ Switch off drive and start it again so that the parameterization becomes active.

4. Put machine into ready-for-operation state

⇒ Put machine into ready-for-operation state again according to machine manufacturer's instructions.

⇒ Check functions of drive.

Possible Problems During Firmware Replacement

General Information

After an incomplete firmware update, the drive controller possibly is no longer operable.

Overview of the Scope of Functions

Firmware replacement is carried out incompletely, if one of the following situations occurs during the sequence of firmware replacement:

- 24 V supply of control section is switched off
- Connection to drive is interrupted (e.g., defective interface cable)
- Crash of update software / of computer

If there isn't any valid firmware available in the control section, the loader is started. The text "LOADER active! IP address: 192.168.0.1" appears on the display in light writing. With the loader, it is possible to replace the firmware of the control section.



Upon successful firmware replacement in the control section, a restart has to be carried out.

Firmware Replacement in Control Section in the Case of Error

The following steps are required for loading the firmware to the control section in the case of error:

1. Call "IndraWorks".
2. In menu, call firmware management under **Tools Drive ▶ Firmware Management**.
A new window opens in which firmware file last used is displayed on PC.
3. Select "Download via Ethernet" tab.
4. Set IP address "192.168.0.1".
5. Highlight desired firmware (*.ibf file) and start firmware download via **Download** button.
6. Firmware download runs automatically and all required firmware components are loaded to drive.
7. After firmware download has been completed, close "Firmware Management" window.
8. Restart drive.

5.8.5 Optional Memory

Brief Description

Fields of Application

- Accessing file level via FTP server
- Using a web application via web server
- Expanded MLD project (4 MB of memory space)
- Extended retain data memory for MLD (31,725 bytes), no longer available as of MPx17V10
- Backup & Restore of the operating data
- MLD programs can use memory to store user data

Overview of Functions

The optional memory serves as a backup memory. If a memory card has been plugged when the device is booted, the card is checked for a valid partition. Besides, these folders are created as a standard, if they do not exist:

Folder	Significance
USER	Folder is at free disposal
PLC	Storage location of an MLD project and, if necessary, of the MLD retain data when replacing devices

Overview of the Scope of Functions

Backup	Internal memory of the Backup & Restore function
Documentation	Presently not used; the user can employ it to file machine-specific documentation
Tools	Storage location for web application of Rexroth
Temp	Folder is at free disposal

Tab. 5-67: List of Automatically Created Folders

It is impossible to use a memory card plugged during operation. To use the memory card, the device must be restarted. This can be done, for example, via "S-0-1350, C6400 reboot command".

Features	• Use of a partition • FAT-16 format • Capacity limited to a max. of 2 GB • Only Rexroth SD cards are allowed
Hardware Requirements	IndraDrive Cs Advanced
Pertinent Parameters	• P-0-1521 Programming module identifier • P-0-4066 Card Identification Data
Pertinent Diagnostic Messages	• C6500 Archive device data • C6600 Restore device data • C6700 Update of device data • F2101 File system structure error on the memory card • F2120 Memory card could not be initialized

5.8.6 Replacing the Controller

Overview

A controller of the IndraDrive range consists of the components power section, control section and programming module / control panel (incl. firmware). The control section can be configured with additional components (e.g., optional safety technology module). The control section and power section are firmly connected; only Rexroth service engineers or especially trained users are allowed to replace individual components. The paragraphs below describe how to replace the complete controller.



The controller must be replaced by a device of the identical type. Only in this way is it ensured that the originally configured functions can be used in unchanged form.

When devices with integrated safety technology are used, it is necessary to ensure by organizational measures, e.g. by a lockable control cabinet, that the device is exclusively replaced by an authorized person. It is also necessary to ensure that the replacement of devices is not carried out for several axes at the same time in order to avoid accidentally interchanging them.



A device which is intended for replacement and has already been in operation (thus is not in the factory-new condition as supplied), must be brought to the condition as supplied again ["load defaults procedure (factory settings)", command C0750] before it is used.

The figure below illustrates the basically required individual steps.

Overview of the Scope of Functions




Fig. 5-60: Sequence of Controller Replacement



"IndraMotion Service Tool (IMST)" or "IndraDrive Service Tool (IDST)" allow accessing the drive system, e.g. for remote diagnostics. Besides, authorized users can handle different service cases with IMST or IDST, such as replacing drive components, loading parameters or updating/upgrading the drive firmware.

"IndraMotion Service Tool (IMST)" additionally analyzes drive systems connected via cross communication (CCD). Further information on "IndraMotion Service Tool (IMST)" and "IndraDrive Service Tool (IDST)" is described in the separate documentation „Rexroth IndraDrive Service Tools IMST/IDST“ (DOK-IM*MLD-IM-STIDSTV13-RE**-EN-P; mat. no. R911342652).

How to Proceed when Replacing Controllers

Replacing Controller and Programming Module

1. Open the main switch
2. Make sure the main switch cannot be switched on again.
3. Make sure drive controller is de-energized.

WARNING! Lethal electric shock by live parts with more than 50 V! Before working on live parts: De-energize installation and secure power switch against unintentional or unauthorized re-energization. Wait at least **30 minutes** after switching off the supply voltages to allow **discharging**. Check whether voltage has fallen below 50 V before touching live parts!

4. Separate connection lines from the controller.
5. Dismount controller from the control cabinet.
6. Dismount programming module / control panel
 - With IndraDrive C/M/Cs: Unplug programming module / control panel from the defective device.
 - With IndraDrive Mi: Dismount programming module (X107) from the defective device, write down positions of the address selector switches S4 and S5 (the address selector switches are to be found under the connections X103.1 and X103.2).
7. Mount programming module / control panel
 - With IndraDrive C/M/Cs: Plug programming module / control panel of the defective device in the new controller.
 - With IndraDrive Mi:
 1. Set the address selector switches in the same way as for the defective device.
 2. Dismount cover from slot X107.
 3. Plug programming module of the defective device in the replacement device.

Overview of the Scope of Functions

4. Mount cover of slot X107.

NOTE: Damage to the programming module caused by penetration of dirt or moisture. When mounting the cover of X107, make sure that the sealing ring is undamaged and fits correctly.

8. Mount new controller.



The controller must be replaced by a device of the identical type. Only in this way is it ensured that the originally configured functions can be used in unchanged form.

Putting Controller and Machine Into Ready-For-Operation State

9. Connect device according to machine circuit diagram

1. Restore control voltage.
2. Put machine into ready-for-operation state again according to the machine manufacturer's instructions.
3. Activate safety technology (only for active Safe Motion with S3/S4 option)

With single-axis devices, the following message appears on the display of the control panel during the booting process:

"Load new Safety?"

With double-axis devices, the following message appears on the display of the control panel during the booting process:

".1 Load new Safety?" for Axis 1 or **".2 Load new Safety?"** for Axis 2

Pressing the "Enter" key at the control panel acknowledges the message. The safety technology parameters are now loaded from the control panel to memory of the optional safety technology module.



IndraDrive Mi does not feature a control panel; this is why the parameter image of safety technology must be activated by executing the command "P-0-3231.0.3, C8300 SMO: Command Activate parameter image", e.g. by means of the IndraDrive Service Tool (IDST).

The error "F8330, SMO: Configuration data record has not been activated" generated during the booting process signals that the active image identifier on the programming module does not comply with the image identifier that was stored on the safety technology hardware. After the command C8300 was successfully executed, the error must be cleared by "clear error" (C0500). The command execution is described in the Functional Description of the firmware, see chapter "Command Processing".

4. Check functions of the drive.
5. Check safety technology parameters (only for active Safe Motion with S3/S4 option)

Completing the process, you must check with activated safety technology whether the correct safety technology parameters have been loaded for the drive.

The replacement of the device must be recorded in the machine logbook. For this purpose, the data of the following safety technology parameters must be documented accordingly and checked for correctness

Overview of the Scope of Functions

(they can be queried via the control panel in the "SMO Info" menu; for IndraDrive Mi, the data must be read by means of the IndraDrive Service Tool (IDST), for example, because IndraDrive Mi does not feature a control panel):

- P-0-3230, SMO: Password level
- P-0-3235.0.1, SMO: Active axis identifier
- P-0-3234.0.1, SMO: Configuration checksum
- P-0-3234.0.2, SMO: Operating hours at last change of configuration
- P-0-3234.0.3, SMO: Configuration change counter
- P-0-3234.0.4, SMO: Parameterization checksum
- P-0-3234.0.5, SMO: Operating hours at last change of parameterization
- P-0-3234.0.6, SMO: Parameterization change counter

Possible Problems During Controller Replacement

Display Defective or Programming Module Defective

If the programming module / the display is defective, the parameter values saved after initial commissioning must be loaded.

NOTICE

The parameter values saved after initial commissioning are not generally suited for reestablishing the operability of the drive after a device has been replaced!

Check actual position values and active target position before setting drive enable!

When firmware and drive parameters are to be transmitted to the replacement controller, the required firmware and a parameter backup of the respective axis must be available.

1. Reestablish the control voltage supply of the controller.
2. Carry out firmware update, see also chapter "[Firmware Replacement](#)"
3. Via the "IndraWorks" commissioning tool or the control master, load the parameter file to the controller:
 - "IndraWorks" commissioning tool
Load the parameter values saved after initial commissioning to the controller.
 - "IMST" or "IDST" service tool
Load the parameter values saved after initial commissioning to the controller.
 - Control master
Load the axis-specific parameter values [according to list parameters "S-0-0192, IDN-list of all backup operation data" and "P-0-0195, IDN list of retain data (replacement of devices)"] saved after initial commissioning.



With active Safe Motion, the initial commissioning or serial commissioning of the controller is required after the programming module has been replaced!



In the case of drives with absolute value encoder and modulo format, the position data reference must be established again after having loaded the parameter values saved after initial commissioning, even if the actual position values are signaled to be valid via the parameter "S-0-0403, Position feedback value status"!

5.8.7 Enabling of Functional Packages

Brief Description

The scope of functionality of the IndraDrive firmware can be scaled by the user. This allows adjusting the scope of firmware functions to the respective requirements and, if necessary, reducing its complexity.

The drive functionality is scaled by licensing (enabling) optional expansion packages that are available in addition to the standard base package of the respective IndraDrive firmware.

See also "[Overview of Functions/Functional Packages](#)"

- | | |
|--------------------------------------|--|
| Features | <ul style="list-style-type: none"> • Activated functional packages displayed in parameter "P-0-2004, Active functional packages" • Firmware type designation in parameter "S-0-0030, Manufacturer version" dynamically adjusted to the active functional packages displayed in P-0-2004 • Functional packages activated/deactivated via parameter • Count of operating hours counter at last change of access enable is stored |
| Pertinent Parameters | <ul style="list-style-type: none"> • S-0-0030, Manufacturer version • S-0-1350, C6400 reboot command • P-0-2002, Oper. hours of contr. sect. at change of functional packages • P-0-2003, Selection of functional packages • P-0-2004, Active functional packages |
| Pertinent Diagnostic Messages | <ul style="list-style-type: none"> • C0202 Parameter limit error (->S-0-0423) • C0299 Configuration changed. Restart |

5.8.8 Extended Diagnostic Possibilities

Logbook Function

Brief Description

A logbook function is realized in the drive firmware in order to obtain a detailed diagnostic error message in the case of error. The information provided by the logbook function allows reproducing the internal firmware sequence, if required.

- | | |
|-----------------------------|---|
| Pertinent Parameters | <ul style="list-style-type: none"> • P-0-0478, Logbook event • P-0-0479, Logbook time stamp |
|-----------------------------|---|

Patch Function

Brief Description

The patch function can be used for reading and writing any storage location (or internal variable) as a data object via the master communication, the analog output or the oscilloscope function.

Overview of the Scope of Functions

In conjunction with the analog output or the oscilloscope function, this functionality can be used for locating errors.

The PLC patch function serves for diagnosis of internal signal states and internal data of the PLC by developers and instructed users.



When using the patch display in the oscilloscope you have to take into account that first the patch address and then the oscilloscope signal is assigned. This must be repeated after every change in the patch address.



As it is a **function for exclusive use by the development staff**, the patch display parameters P-0-0485 and P-0-0491 write-protected with the master password.

The configuration parameters of the patch function are **not stored in the flash**, but are lost when the drive is switched off.

Pertinent Parameters

General patch functions:

- P-0-0480, Patch function 1, source pointer
- P-0-0481, Patch function 1, attribute
- P-0-0482, Patch function 1, bit mask
- P-0-0483, Patch function 1, exponent
- P-0-0485, Patch function 1, display
- P-0-0486, Patch function 2, source pointer
- P-0-0487, Patch function 2, attribute
- P-0-0488, Patch function 2, bit mask
- P-0-0489, Patch function 2, exponent
- P-0-0491, Patch function 2, display

5.8.9 RMS Value Generator in the Drive

Brief Description

Fields of Application

To evaluate the thermal load of drive controller and motor over a machine cycle, the total rms value of the output current of the output stage is the decisive characteristic value.

Overview of Functions

The drive cyclically generates the rms value of the output current of the output stage. Via a control bit, the beginning and the end of the cycle are defined.

Pertinent Parameters

- P-0-0610, Control word of current rms value generator
- P-0-0611, Current rms value

Pertinent Diagnostic Messages

None

5.8.10 Oscilloscope Function

Brief Description

The oscilloscope function can be used to record drive-internal and external status variables (parameter contents). This function can be effectively used both for initial commissioning and debugging. Its functionality can be compared to that of a 4-channel oscilloscope.

The total scope of the oscilloscope function is divided into the following function blocks:

- **Recording measured values**

It is possible to record 4 channels at the same time, the signals being selected by configuration of signal selection lists (IDN lists).

- **Configuration (basic settings)**

The control/status block determines the basic functions (start/stop, time resolution, size of memory, operating mode). The current status (status diagram) of the oscilloscope is continuously transmitted to the master.

- **Trigger function**

Besides extensive trigger functions, the drive provides the possibility of triggering at different signals and events in the drive.

Features The oscilloscope function is characterized by the following features:

- **Recording measured values**

- 4 channels, each with a maximum of 8192 measured values
- Time resolution to be freely selected in steps of the position loop clock (see "[Performance Data](#)")
- Signal selection by indicating the IDN of the respective parameter
- Data of the SMO option Sx (S0, S4 and S5) can at maximum be updated and recorded in the cycle time of the SMO application cycle ($t = 1 \text{ ms}$)

- **Configuration (basic settings)**

- Multi-channel display in "IndraWorks Ds/D/MLD"
- More than 100 different measuring and trigger signals (cf. P-0-0149)
- Expanded oscilloscope function using patch function

- **Trigger function**

- Trigger signal selection by indicating the parameter IDN
- Internal trigger or external trigger
- External trigger with trigger offset determination for synchronizing multiple-axis measurements
- Unit of trigger level adjusting to trigger signal selection
- Possibility of triggering at internal memory contents with patch signal

- **Trend mode**

It is possible to switch from a single measurement (Single Shot) to a continuous measurement (trend mode).

- Recording of up to 4 channels in a cyclic mode
- Signal selection via the previous parameters

Overview of the Scope of Functions

- Values are administrated in a buffer memory and cyclically called
- IndraWorks can read this buffer memory and display it continuously
- Setting of time resolution and signal selection only in trend mode that has been switched off
- Allowed time resolutions must be a multiple of 2 ms
- Single Shot mode cannot be used in parallel

Pertinent Parameters

- P-0-0020, Oscilloscope: Operation mode
- P-0-0136, Oscilloscope: Manual trigger signal
- P-0-0279, Oscilloscope: Trend mode, time resolution
- P-0-0280, Oscilloscope: Trend mode, list of measured values

Control/status:

- P-0-0028, Oscilloscope: Control word
- P-0-0029, Oscilloscope: Status word
- P-0-0031, Oscilloscope: Time resolution
- P-0-0032, Oscilloscope: Size of memory
- P-0-0149, Oscilloscope: Signal selection list
- P-0-0150, Oscilloscope: Number of valid measured values

Measuring channels:

- P-0-0021, Oscilloscope: List of measured values 1
- P-0-0022, Oscilloscope: List of measured values 2
- P-0-0023, Oscilloscope: Signal selection 1
- P-0-0024, Oscilloscope: Signal selection 2
- P-0-0145, Oscilloscope: List of measured values 3
- P-0-0146, Oscilloscope: List of measured values 4
- P-0-0147,
- P-0-0148,

Trigger function:

- P-0-0025, Oscilloscope: Trigger mask
- P-0-0026, Oscilloscope: Trigger signal selection
- P-0-0027, Oscilloscope: Trigger level
- P-0-0030, Oscilloscope: Trigger edge
- P-0-0033, Oscilloscope: Number of measured values after trigger event
- P-0-0035, Oscilloscope: Trigger control offset
- P-0-0036, Oscilloscope: External trigger signal
- P-0-0037, Oscilloscope: Internal trigger signal

5.8.11 Options for Integrated Energy and Power Measurement

Brief Description

Fields of Application

Mounting energy costs increasingly require the project planning of automation systems to conform with energy efficiency. To discover energy saving potentials, it is of crucial significance to analyze the energy consumption of the individual system components. For this purpose, the IndraDrive system

Overview of the Scope of Functions

makes available specific energy and power values which allow analyzing and evaluating the energy consumption on the drive level.

As a standard, the IndraDrive system provides this function in its basic configuration. By using IndraDrive, installations in the industrial production automation can therefore benefit from this functionality, independently of their respective industrial sector and by deriving measures of increase in energy efficiency from the measured variables.

Overview of Functions

The figure below shows an overview of the energy and power values of the IndraDrive system for a single-axis system.




Fig. 5-61: Energy and Power Values of the IndraDrive System

We distinguish between

- axis-related values (S-0-0385, S-0-0382, P-0-0819, P-0-0851) and
- device-related values (P-0-0382, P-0-0383, P-0-0384).

The energy and power requirements of an individual axis can be determined by means of the above axis-related values. These parameters are available in each axis. Mains-side energy and power values are device-related and only available for converters. They can be used to determine the total power requirements of a drive system.

Features

- Determining the axis-specific power requirement
- Calculating the motor power dissipation
- Determining the total energy absorption of a drive system
- Drawing up a power balance of the drive system
- Discovering optimization potentials for saving energy
- Determining the maximum mains input current (HCS01.1E-W0054 only)
- Including the energy and power values in IndraWorks is possible
- Depicting dynamic power processes in the position controller cycle

Hardware and Software Requirements

The availability of the energy and power values depends on the hardware:

- Axis-related values are axis parameters and available for all IndraDrive devices: S-0-0385, S-0-0382, P-0-0851 and P-0-0819.

Overview of the Scope of Functions

- Mains-side values are device parameters and therefore only available for converters: P-0-0382, P-0-0383 and P-0-0384. The significance of the displayed value depends on the topology and available sensors: Only converters without DC bus connection or converters which do not supply any other inverters via the DC bus, and the HCS01.1E-W0054 device, provide correct values. In all other cases, the mains-side values cannot be calculated due to the restricted sensor system. The displayed values are not correct. For an overview of the availability of the energy and power values depending on the hardware used, see chapter "Determining the Energy and Power Values".



In order that the energy and power values are correctly displayed, it is obligatory to **activate** the **output stage compensation**. For this purpose, set bit 5 of parameter "P-0-0045, Control word of current controller".

Pertinent Parameters

- S-0-0040, Velocity feedback value
- S-0-0084, Torque/force feedback value
- S-0-0109, Motor peak current
- S-0-0110, Amplifier peak current
- S-0-0111, Motor current at standstill
- S-0-0380, DC bus voltage
- S-0-0381, DC bus current
- S-0-0382, DC bus power
- S-0-0383, Motor temperature
- S-0-0385, Motor power
- S-0-0533, Nominal torque/force of motor
- S-0-0534, Maximum torque/force of motor
- P-0-0043, Torque-generating current, actual value
- P-0-0044, Flux-generating current, actual value
- P-0-0045, Control word of current controller
- P-0-0051, Torque/force constant
- P-0-0063, Torque-generating voltage, actual value
- P-0-0064, Flux-generating voltage, actual value
- P-0-0065, Absolute voltage value, actual value
- P-0-0114, Undervoltage threshold
- P-0-0382, Mains power
- P-0-0383, Mains energy counter
- P-0-0384, Short-time mains energy counter
- P-0-0440, Actual output current value (absolute value)
- P-0-0450, Current torque/force constant
- P-0-0532, Premagnetization factor
- P-0-0556, Config word of axis controller
- P-0-0819, Energy counter
- P-0-0833, Braking resistor threshold
- P-0-0851, Short-time energy counter

- P-0-0853, Max. DC bus voltage, motor
- P-0-0860, Converter configuration
- P-0-4048, Stator resistance

Pertinent Diagnostic Messages

None

5.9 Engineering/Diagnostic Interfaces

5.9.1 TCP/IP Communication

Brief Description



In the section "TCP/IP Communication", all necessary information for standard Ethernet communication is given. In addition to TCP/IP, communication via UDP/IP is also possible.

To prevent confusion with the master communication "EtherNet/IP™ interface", the designation "Ethernet communication" was not used here; instead, the term "IP communication" is used.

It is possible to communicate with an IndraDrive controller via standard Ethernet telegrams. These Ethernet telegrams contain TCP/IP or UDP/IP telegrams for application-side connection. For communication with the device, the CSMA/CD access method is applied. Interfaces over which TCP/IP communication is possible provide connection options. This can be an inactive port of the master communication card (e.g. sercos or EtherNet/IP™), a separate Engineering port (if present) or optionally an inactive port of the master communication interface of the CCD master.

Example of sercos Master Communication

For sercos, in addition to the time-controlled transmission of sercos-type Ethernet telegrams (MDT and AT), the Unified Communication Channel (UCC) exists, with which IP telegrams are transmitted in a specially reserved time slot.

Therefore, for sercos, another option for asynchronous data transmission is available in addition to the existing service channel, that is very well suitable for large data volumes due to the maximum lengths of useful data of approx. 1500 bytes.

Possible Applications

With the utilization of the TCP/IP communication in the drive, different application options are available, which are summarized in the following table.

Connection	Server application	Exemplary client applications
SIP protocol	Parameter access	IndraWorks Engineering with CCD master
SIP protocol	Parameter access	IndraWorks parameter application
TFTP	Firmware update service	Carrying out a firmware update
HTTP	Web server	Displaying the IndraMotionServiceTool
FTP	File server	File access to the optional memory card (only available, if optional memory card plugged during the booting process)

Tab. 5-68: Overview of the Possible Applications

Pertinent Parameters

- S-0-1019, Master comm. engineering over IP: MAC address

Overview of the Scope of Functions

- S-0-1020, Master comm. engineering over IP: IP address
- S-0-1021, Master comm. engineering over IP: Network mask
- S-0-1022, Master comm. engineering over IP: Gateway address
- P-0-1044, Master comm. engineering over IP: Status IP communication
- P-0-1530, Engineering: MAC address
- P-0-1531, Engineering: IP address
- P-0-1532, Engineering: Network mask
- P-0-1533, Engineering: Gateway address
- P-0-1534, C6100 Command Activate IP settings
- P-0-1544, Engineering: Status IP communication
- P-0-1640, CCD: MAC address
- P-0-1641, CCD: IP address
- P-0-1642, CCD: Network mask
- P-0-1643, CCD: Gateway address
- P-0-4089.0.10, Master communication: MAC address device
- P-0-4089.0.13, Master communication: IP address
- P-0-4089.0.14, Master communication: Network mask
- P-0-4089.0.15, Master communication: Gateway address

Pertinent Diagnostic Messages

- C6101 Incorrect IP settings
- F2190 Incorrect Ethernet configuration

5.9.2 S/IP Protocol

Brief Description

Fields of Application

S/IP allows easy access to all drive parameters.

Typical fields of application are:

- Communication with the drive for Engineering via IndraWorks
- Replacement for cyclic bus communication for controlling simple axis applications without real-time requirements, e.g. in positioning block mode or for drive-controlled positioning

Overview of Functions

Features

- TCP/IP-based protocol
- The protocol is focused on exchanging data; very little management is required.
- User-defined Busy-Timeout (time until drive sends a defined answer)
- User-defined Lease-Timeout (time after which the connection is released again if no new queries are made)
- Its own service for reading out all information of a parameter in a query
- Up to two connections possible simultaneously

Pertinent Diagnostic Messages

The following error messages have been defined, and the drive directly returns them in an individual service:

Overview of the Scope of Functions

Name	Value in telegram	Significance
CONNECTION_ERROR	1	Error in establishing the connection
ABORTED	2	Procedure aborted
UNKNOWN_MESSAGE_TYPE	3	Message type in header is unknown
SERVICE_SPECIFIC	4	Service-specific error, e.g. "Operation data is write protected"

Tab. 5-69: S/IP Error Classes

5.9.3 Firmware Download via TFTP Server

Brief Description

Fields of Application

If a firmware download is to be carried out, a TFTP server is available for this purpose. This makes it possible to download new firmware to the device.

Overview of Functions

Identifying Firmware	A special "ReadRequest" can be used to identify firmware existing in the device. To do this, in the "ReadRequest" the string "Firmware" is transmitted. The response telegram contains a data packet, the first four bytes of which are the control section circuit board code and the following content is the manufacturer version (cf. S-0-0030.0.0).
Firmware Download	The download procedure is started using a WriteRequest. To do this, the drive must be in PM. Here the "WriteRequest" also initiates the connection to the TFTP server. Then "DataRequests" is used to download the firmware to the device. The device takes over various checks: • Can the new firmware file be used with this device (compatibility check)? • Was the correct quantity of data transmitted (data integrity check)? • Was the firmware file transferred correctly and was it valid (validity check)?
Error Diagnostics	Any possible error that occurs during this procedure is returned via the Error-Frame in the TFTP. The error text is available as a plain text.

Features

The TFTP server of an IndraDrive device has the following features:

- A TFTP connection does not know any authentication
- The following five packet types are present in a TFTP connection:
 - "ReadRequest" (reading of files from server/drive starts)
 - "WriteRequest" (writing of files from server/drive starts)
 - "Data" (data are transmitted)
 - "Acknowledge" (data packets are confirmed)
 - "Error" (any type of error message)
- Each data packet must be confirmed with "Acknowledge" before the next data packet is transmitted.

Overview of the Scope of Functions

Pertinent Diagnostic Messages

Errors that occur are transmitted in plain text via "TFTP ErrorFrame" (see the description of diagnostic message: "Firmware Download")

5.9.4 File Handling by FTP via Ethernet**Brief Description**

Base package of all firmware variants in **open-loop** and **closed-loop** characteristic

Via an integrated FTP server, IndraDrive devices with Ethernet communication can access the data of the optional memory card by means of FTP connection. This allows reading or writing data/directories on the memory card.




Fig. 5-62: Schematic Illustration of FTP File Handling

- Features** The FTP server of an IndraDrive device has the following features:
- Two kinds of login to the FTP server:
 - Anonymous login (read-only data access)
 - User login (read and write access to data)
 - A maximum of 2 simultaneous connections
 - The effective transmission rate depends on processor load and current drive status
- The transmission rate is approx. 450 kbytes/s for download (STOR command) and 300 kbytes/s for upload (RETR command) with an active connection. If 2 FTP connections are simultaneously active (download or upload), the effective transmission rate is dramatically reduced in both directions.
- Hardware Requirements** The following hardware requirements must have been fulfilled:
- IndraDrive Cs Advanced with Advanced display
 - Memory card plugged before booting
- If no memory card was recognized during the booting process, the parameter "P-0-4066, Card Identification Data" contains the value 0xFFFFFFFF.
- Pertinent Parameters**
- P-0-4066, Card Identification Data
 - S-0-1020, Master comm. engineering over IP: IP address
 - P-0-1531, Engineering: IP address
 - P-0-1641, CCD: IP address

5.10 Commissioning

5.10.1 Commissioning Motors

Checking the Installation/Assembly

Checking the Assembly



Check the assembly of the IndraDrive controllers and supply units as well as motors with regard to correct implementation, according to the data contained in respective Project Planning Manual.

Checking the Installation



Check the wiring of control cabinet and machine with regard to correct implementation, according to the data contained in the Project Planning Manual and the recommendations in the documentation "Electromagnetic Compatibility (EMC) in Drive and Control Systems".

Initial Commissioning/Serial Commissioning

Brief Description

The drive can be commissioned after assembly and installation have been correctly implemented.

Initial Commissioning

The initial commissioning of a drive differs from the commissioning of other identical drives (serial commissioning).

The initial commissioning is carried out in the following steps:

- Establishing the operability of the drive (including the required measuring systems)
- Adjusting the drive behavior to the requirements of the application
- Adjusting the master communication interface between master and drive
- Integrating drive functionalities in the machine processes

In each of the mentioned steps, values of relevant parameters are adjusted to the requirements. The result of the initial commissioning is a drive the behavior of which is exactly adjusted to the axis. By storing the values of the initial commissioning in the form of a parameter set the drive behavior can be reproduced.

Serial Commissioning

For the commissioning of other identical axis drives on machines of the same type, the set of parameter values determined during the initial commissioning is loaded to the respective controller (serial commissioning). This allows

- exactly reproducing the drive behavior
- and -
- reducing the effort for further commissioning to a little adjustment work and, if necessary, search and elimination of assembly/installation errors.

Possibilities of Commissioning

As a matter of principle, commissioning can be carried out by means of

- the "IndraWorks Ds/D/MLD" commissioning tool by Rexroth which is connected to the drive via sercos interface, via an engineering interface, via Ethernet or a field bus,
- the control panel of the controller and digital and analog input signals,
- a control unit connected to the drive via a master communication interface.

Overview of the Scope of Functions

Two-Step Commissioning It is basically recommended to always carry out both the initial commissioning and the serial commissioning in two steps:

- 1st objective: Initial Start of the Motor
- 2nd objective: Providing drive functions for the machine axis




Fig. 5-63: Two-step drive commissioning (schematic)

In the first step, the two-step procedure ensures the operability of the drive (1st objective during initial commissioning and serial commissioning). In the second step, the drive functions required for the machine axis and the drive's advantageous properties are individually adjusted to the machine axis in a reasonable order (2nd objective during initial commissioning) or the expected functional principle is checked (2nd objective during serial commissioning).



As a matter of principle, it is advantageous to establish the operability of a drive independent of a higher-level control system. The drive should therefore first be commissioned as a self-contained unit via "IndraWorks Ds/D/MLD" or in the "Easy-Startup" mode!

See the following sections:

- ["Initial Start in "Easy Startup" Mode"](#)
- ["Initial Start with the Commissioning Tool"](#)

Initial Start in "Easy Startup" Mode

Brief Description

The so-called "easy startup mode" allows moving the drive without connected or active control unit (or master communication master) or external command

Overview of the Scope of Functions

value box. When using a Rexroth motor with encoder data memory, this is also possible without using a commissioning PC, because all motor and controller parameters are stored in the encoder data memory.



The easy startup mode is therefore particularly suited for **initial commissioning** of individual axes, as well as for maintaining an **emergency mode** when the control unit has failed.

- Features**
- **Activation** of "easy startup" mode via:
 - Engineering interface or digital inputs
 - Control panel of drive controller
 - Automatic **deactivation** of master communication interface (see P-0-4077, S-0-0134) and activation of "P-0-0120, Control word easy startup"
 - Activation of **drive enable** (P-0-0120, bit 15) via:
 - The digital input assigned to drive enable (different according to hardware design, see default assignment under "Automatic Configuration of the Inputs")
 - Engineering interface when configuration of digital inputs for "easy startup" mode made before was removed
 - Drive moves in "velocity control" mode with a parameterizable velocity command value (cf. P-0-1206) without external command value box
 - Selection of **travel direction** (positive/negative) via digital input signals (see parameter "P-0-1200, Control word 1 velocity control")

Overview of the Scope of Functions




Fig. 5-64: Activating the "Easy Startup" Mode, Overview

Hardware Requirements

For the "easy startup" mode, the digital inputs at interface X31 must be wired as follows:

- X31/1 +24V for activating drive enable
- X31/6 +24V for activating the positive direction of rotation
- X31/7 +24V for activating the negative direction of rotation

Pertinent Parameters

- S-0-0032, Primary operation mode
- S-0-0091, Bipolar velocity limit value
- P-0-0120, Control word easy startup
- P-0-0300, Digital inputs, assignment list
- P-0-0301, Digital inputs, bit numbers
- P-0-1200, Control word 1 velocity control
- P-0-1206, Memory of velocity command values
- P-0-4085, C4700 Command Activate easy startup mode
- P-0-4086, Master communication status

Overview of the Scope of Functions

- Pertinent Diagnostic Messages** In the "easy startup" mode, additional simple diagnostic texts appear on the display of the control panel in "light writing":
- When the "easy startup" mode has been activated, the display switches between the drive address and the message "CM" (Commissioning Mode).
 - During commissioning, the relevant messages appear on the display.

Initial Start with the Commissioning Tool

Brief Description

Establishing the Operability of the Drive After complete and correct assembly and wiring of the drive or the drives it is advisable to establish the operability. With drives of the IndraDrive range, this is very easily done means of initial start in the "easy startup" mode (velocity-controlled operation, master communication master not required) in conjunction with the Rexroth commissioning tool "IndraWorks Ds/D/MLD".

According to the available equipment, the initial commissioning of the motor is supported as follows:

- If there is **no** commissioning tool (e.g. PC) available, Rexroth motors with encoder data memory can be easily commissioned in the "easy startup" mode. The motor parameters and motor control parameters of these motors are automatically loaded from the data memory to the controller by switching control voltage on.
- IndraDrive: If a PC with Rexroth commissioning tool is available, the motor parameters and motor control parameters of motors without encoder data memory can be loaded from the internal database of the commissioning tool to the controller via the engineering interface. This allows initial commissioning in the "easy startup" mode for these motors, too.

Available Commissioning Tools Rexroth provides the following commissioning tools (software) for drives:

- IndraDrive: IndraWorks Ds/D/MLD

IndraWorks Ds/D/MLD "IndraWorks Ds/D/MLD" is a component of the "IndraWorks" software range which supports parameterization and commissioning of control units and drives by Rexroth.

The "IndraWorks Ds/D/MLD" commissioning tool provides the following options and advantages:

- The functions and features made available by the drive are structurally visualized, the respective parameter values are displayed in their functional context.
- Parameter values can be directly changed and thereby adjusted to the respective requirements.
- The parameter values available in the drive can be saved drive-externally as a group (parameter set), e.g. on the PC hard disk, and can be reloaded from the hard disk.
- Diagnostic messages and operating status messages are displayed in clearly arranged form.
- For the purpose of commissioning, commands can be started.
- Via the "easy startup" mode, IndraDrive devices can be commissioned and moved.

5.10.2 Commissioning Machine Axes

Procedure for Commissioning

The drive supports different commissioning procedures. The type of commissioning depends on the existing machine components (control, drive control-

Overview of the Scope of Functions

lers, motor, mechanical system). Commissioning is made using one of the commissioning tools available.

Commissioning Procedure




Fig. 5-65: Overview of Procedures for Commissioning

Real Operation In real operation all necessary components are available. The parameterization of the drive controller is made online; then commissioning of the axis system can be made in setting-up mode. The commissioning of the machine is made by means of a control.

Offline Simulation The offline simulation does not require any machine component. The parameterization of the drive controller is made offline. The parameters are applied to the drive controller during transition to real operation. The parameterization for a drive-internal control (MLD) can also be made offline, as well as creation of motion programs.

Simulation Mode In simulation mode only the drive controller is required, parameterization is made online. With the axis simulation the velocity and actual position values are simulated, the drive can be operated in velocity- and position-controlled operation modes. A higher-level control unit can thus test its motion programs even without motor or mechanical system.

Brief Description

Before commissioning machine axis-specific functions it is useful to make sure that the drive, consisting of controller, motor and motor encoder, is operational. The best way to do this is the initial start of the drive with the PC-based commissioning tool "IndraWorks Ds/D/MLD" by Rexroth (see ["Initial Start with the Commissioning Tool"](#)).

The commissioning of machine axis-specific functions should also be carried out via "IndraWorks Ds/D/MLD", if possible. The advantage is that the correct sequence of an axis-specific function can be configured and ensured independent of the control unit. Further commissioning of the drive, with widely complete configuration, is then easier for the control unit.

5.10.3 Axis Simulation

Brief Description

Contained in **base package** of variants **MPB, MPM and MPE** in **open-loop and closed-loop** characteristic.

The "simulation mode" function is made available for the function check of control units. It provides the possibility for the control unit to execute a program check without axis motion. For this purpose, only a drive control section is required of the drive, the power supply, motor and encoder are not used; therefore, the drive is directly ready for enabling ("AB") in the operating mode.

The function is carried out with the "Parking axis" command. For this purpose, the "permanently parked axis" function is activated with the parameter "P-0-0399, Configuration of simulation mode". The command and thereby the axis simulation are automatically started during the transition to the operating mode.

Pertinent Parameters

- P-0-0399, Configuration of simulation mode
- S-0-0448, Set absolute position control
- S-0-0139, C1600 Parking axis procedure command
- S-0-0147, Homing parameter

6 Service and Support

Our worldwide service network provides an optimized and efficient support. Our experts offer you advice and assistance should you have any queries. You can contact us **24/7**.

Service Germany

Our technology-oriented Competence Center in Lohr, Germany, is responsible for all your service-related queries for electric drive and controls.

Contact the **Service Helpdesk & Hotline** under:

Phone:	+49 9352 40 5060
Fax:	+49 9352 18 4941
E-mail:	service.svc@boschrexroth.de
Internet:	http://www.boschrexroth.com

Additional information on service, repair (e.g. delivery addresses) and training can be found on our internet sites.

Service worldwide

Outside Germany, please contact your local service office first. For hotline numbers, refer to the sales office addresses on the internet.

Preparing information

To be able to help you more quickly and efficiently, please have the following information ready:

- Detailed description of malfunction and circumstances resulting in the malfunction
- Type plate name of the affected products, in particular type codes and serial numbers
- Your contact data (phone and fax number as well as your email address)

Index

A

Absolute encoder emulation.....	305
Actual value adjustment (for position controller).....	205
Actual value cycle.....	245
Additional documentations.....	103
Addressing.....	37
Administration commands.....	75
Advanced performance.....	93
Alias parameters	
Modified.....	59
New.....	53
Amount of resources, overview	35
Analog inputs.....	29, 294
Analog interface.....	136
Analog output.....	296
Analog outputs.....	29, 296
Appropriate use.....	7
Applications.....	7
Automatic setting of axis control	31
Availability	
Extended axis functions.....	87
Optional device functions.....	88
Axis control	
Position controller.....	205
Velocity controller.....	202
Axis control (closed-loop operation)	
Overview.....	176
Axis control (open-loop operation)	
Overview.....	176
Axis error correction.....	264
Axis functions, extended.....	256
Availability.....	87
Axis simulation.....	349

B

Basic functions of internal master axis generation	
Master axis format converter.....	35
Basic functions of master communication.....	106
Basic functions of the synchronization modes..	243
Basic performance.....	93
Best possible deceleration.....	258
Brief description.....	258
Braking resistor	
Internal and external.....	33
Brief descriptions.....	73
Brief functional descriptions.....	73
BRWS Protocol Server	
HMI.....	42

C

Cam, electronic.....	250
CANopen interface.....	134
CCD (cross communication).....	281
CCD: Addressing	27

CCD: Basic mode	27
CCD: CC connections	27
CCD: CCD system mode	27
CCD: Diagnostics	27
CCD: Error reaction	27
CCD: MLD-M system mode	27
CCD: Overview, features, modes	27
CCD: Phase progression	27
CCD: Process data mapping	27
CCD: sercos III I/O	26
Changes and enhancements.....	19
Changing the operation mode.....	229
Checking the installation/assembly.....	343
Checksum of parameter values.....	74, 312
Clearing an error message.....	77
Clock rates.....	93
Closed-loop axis control.....	197
Automatic setting.....	200
Closed-loop axis control (closed-loop operation)	
General information.....	197
Closed-loop operation (axis control)	
Overview.....	176
Cogging torque compensation.....	33, 265
Combined encoders.....	158
Command value acceptance.....	229
Command value acknowledgment.....	229
Command value box, drive-internal.....	303
Command value cycle.....	245
Command value generator, drive-integrated....	301
Commands.....	75
Commissioning	
Checking the installation/assembly.....	343
Easy startup mode.....	344
Initial commissioning/serial commissioning.	343
Machine axes.....	347
Motor.....	343
With commissioning tool.....	347
Commissioning tool, initial start with	347
Commutation offset	
Determined by saturation method.....	216
Determined by sine-wave method.....	217
Commutation Offset	
Determined by sine-wave method.....	217
Commutation setting.....	206
Basics.....	206
Digital Hall sensors.....	32
For Rexroth motors.....	214
Compatible new functions and functional changes.....	30
Compensation functions.....	263
Axis error correction.....	264
Cogging torque compensation.....	265
Friction torque compensation.....	263
Control loop features.....	197
Control loop setting.....	198

Index

Control loop structure.....	177, 197
Control loop structure (figure)	
With display parameters.....	179
With setting parameters.....	178
Control loops	
Features.....	179
Control options (via master communication).....	108
Control panel.....	320
Standard control panel.....	320
Control password.....	314
Control section	
Analog inputs.....	29
Analog outputs.....	29
Digital inputs/outputs.....	29
Control sections	
CDB02, double-axis plug-in unit.....	20
CSB02, Basic plug-in unit.....	19
CSE02, Economy plug-in unit.....	30
CSH02, Advanced plug-in unit.....	20
Control sections, overview.....	99
Controllers, overview.....	95
Cross communication (CCD).....	281
Current and torque/force limitation.....	219
Current control, field-oriented (FOC control).....	188
Customer password.....	314
Cycle times.....	93

D

Data storage.....	73
Deceleration, best possible.....	258
Definite control panel function.....	28
Definitions of terms, general basic principles.....	73
Detecting the marker position.....	168
Device functions, optional.....	280
Availability.....	88
Diagnostic data of motor operation.....	318
Diagnostic functions.....	316
Diagnostic interfaces.....	339
Diagnostic messages	
Modified.....	71
New.....	68
No longer existing.....	71
Diagnostic messages of the drive.....	316
Diagnostic possibilities, extended.....	333
Diagnostic system.....	316
Digital encoders.....	158
Digital Hall sensors	
Commutation setting.....	32
Digital inputs.....	292
Digital inputs/outputs.....	29, 292
Digital outputs.....	292
Display defective.....	332
Distributed Clocks.....	20
Documentation	
Additional documentations.....	103
Overview.....	103
Reference documentations.....	103

Documentation, notes on how to use it.....	5
Drive control.....	175
Basic principles and terms.....	175
Overview.....	175
Principles.....	176
Drive control commands.....	75
Drive controller	
Replace.....	330
Drive controllers.....	95
Control sections.....	99
Power section platform.....	98
Drive controllers, special design.....	97
Drive controllers, standard design.....	95
Drive firmware, overview.....	80
Drive Halt.....	256
Drive profile.....	115
Drive state machine.....	22
Drive system.....	9
Drive systems, overview.....	98
Drive-controlled homing procedure.....	167
Drive-controlled oscillation.....	274
Drive-controlled positioning.....	238
Block diagram.....	238
Drive-integrated PLC.....	91
Drive-integrated PLC (Rexroth IndraMotion MLD).....	288
Drive-internal command value box.....	35
Drive-internal interpolation.....	236
Block diagram.....	236
DriveTop.....	347
Duplicating an installation.....	315

E

E-Stop function.....	263
Easy startup mode	
For initial start of the motor.....	344
Economy performance.....	93
Electric drive system.....	9
Electronic cam with real/virtual master axis.....	250
Enabling of functional packages.....	333
Encoder emulation.....	35, 304
Engineering/diagnostic interfaces.....	339
Error classes.....	76, 257
Reactions.....	33
Return motion.....	33
Error corrections	
Axis error correction.....	264
Quadrant error correction.....	265
Error memory.....	77
Power section and control section.....	318
Error reactions.....	257
Best possible deceleration.....	258
Drive error reactions.....	77
MLD reaction.....	262
NC reaction.....	262
Overview.....	257
Package reaction.....	259

Errors.....	76
Drive error reactions.....	77
Establish position data reference	
For absolute measuring systems.....	162
Establishing position data reference	
For relative measuring systems.....	164, 167
Establishing the position data reference.....	161
Establishing the position data reference, general information.....	161
EtherCAT.....	120
EtherCAT (SoE)	
Synchronization and Timing.....	20
EtherNet/IP(TM) interface.....	123
Events.....	37
Explanation of terms (for synchronization modes).....	244
Extended axis functions.....	256
Availability.....	87
Extended diagnostic possibilities.....	333
Logbook function.....	333
Optional memory.....	328
Patch function.....	333

F

Field-oriented current control (FOC control).....	188
Field-oriented current control with motor en- coder (FOC).....	182
File handling by FTP (via Ethernet).....	342
Firmware release update.....	324
Firmware replacement.....	322
Basic principles, terms.....	322
Possible problems.....	327
Firmware types.....	84
Firmware update.....	315, 322
Firmware upgrade.....	322
Firmware variants.....	80
Firmware version upgrade.....	326
FOC control.....	182, 188
Friction torque compensation.....	263
FTP, file handling by	342
Functional enhancement.....	30
Axis control.....	31
Braking resistor.....	33
Commutation setting.....	32
Compensation functions / corrections.....	33
Control sections.....	30
Diagnostics and control.....	42
Drive-internal command value box.....	35
Encoder emulation.....	35
EnDat 2.2 interface.....	31
Error reactions.....	33
FEAT-00022103.....	33
FEAT-00025991.....	35
FEAT-00026532.....	31
FEAT-00026827.....	32
FEAT-00026926.....	30
FEAT-00026955.....	30

FEAT-00026956.....	30
FEAT-00026957.....	30
FEAT-00026958.....	30
FEAT-00026959.....	30
FEAT-00026992.....	31
FEAT-00026997.....	33
FEAT-00027369.....	30
FEAT-00028055.....	33
FEAT-00028233.....	42
FEAT-00028371.....	30
FEAT-00028543.....	32
FEAT-00028578.....	30
FEAT-00028584.....	41
FEAT-00028632.....	30
FEAT-00029923.....	41
FEAT-00030037.....	42
FEAT-00031113.....	35
FEAT-00031233.....	31
FEAT-00032584.....	35
FEAT-00036552.....	31
FEAT-00037013.....	30
FEAT-00037015.....	30
FEAT-00038280.....	35
FEAT-00044960.....	42
FEAT-00047072.....	34
HMI.....	42
Limitations.....	32
Master axis linking.....	35
Modbus TCP.....	30
Offline mode.....	42
Oscilloscope function.....	41
Parameters.....	41
Position spindle.....	34
sercos.....	30
Setting motor control.....	31
System overview electr. drive controllers.....	30
System overview, electric drive controllers.....	30
Virtual master axis generator.....	35
Functional enhancement, incompatible	
Analog inputs/outputs.....	29
CCD function.....	26, 27
Connection conditions.....	21
Control sections.....	19, 20
Diagnostics.....	28
Diagnostics and control.....	28
Digital inputs/outputs.....	29
FEAT-00025158.....	27
FEAT-00025159.....	28
FEAT-00026851.....	26
FEAT-00026853.....	27
FEAT-00026882.....	28
FEAT-00026892.....	27
FEAT-00026893.....	27
FEAT-00026896.....	27
FEAT-00026897.....	27
FEAT-00026898.....	27
FEAT-00026899.....	27
FEAT-00026900.....	27

Index

FEAT-00026901	27	IndraDrive product range.....	78
FEAT-00026902	27	IndraMotion MLD.....	91, 288
FEAT-00026928.....	19	IndraWorks D.....	347
FEAT-00026930.....	20	IndraWorks Ds/D/MLD.....	347
FEAT-00026931.....	20	Initial commissioning.....	343
FEAT-00026996.....	21	Initial start in easy startup mode.....	344
FEAT-00027740	21	Initial start with the commissioning tool.....	347
FEAT-00028010.....	29	Integrated energy measurement.....	336
FEAT-00028011.....	29	Integrated power measurement.....	336
FEAT-00028032.....	29	Integrated safety technology.....	91, 275
FEAT-00028060	21	Interface	
FEAT-00028500.....	22	EnDat 2.2.....	31
FEAT-00028594.....	28		
FEAT-00028708.....	22	L	
FEAT-00028710.....	21	Limit switches.....	221
FEAT-00038388.....	20	Limitations.....	218
Master communication.....	20	Current and torque/force limitation.....	219
Motors.....	21	Overview.....	218
Operation modes.....	21, 22	Position limitation.....	221
PLC system.....	27, 28	Velocity limitation.....	221
Power supply.....	22	Load motor default values.....	199
Functional packages.....	81	Load preview.....	319
Additive functional packages.....	90	LOADER IP address: 192.168.0.1.....	327
Alternative functional packages.....	89	Loading parameter values, general.....	74
Base packages.....	85	Logbook function.....	333
Enabling.....	333		
Functions of the inverter	22	M	
FXC control.....	182, 191	Machine axes, commissioning.....	347
		Machine commissioning.....	347
H		Master axis.....	244
Hall sensor box SHL.....	215	Master axis generator, virtual.....	298
Handling, diagnostic and service functions.....	311	Master axis linking	
HCS02 IndraDrive single-axis converters size 2.	30	MLD-M axis group.....	35
HCS03 IndraDrive single-axis converters size 3.	30	Master axis range.....	244
HCS04 IndraDrive converters		Master communication.....	106
Single-axis size 4.....	30	Analog interface.....	136
HMD IndraDrive double-axis inverters.....	30	Basic functions.....	106
HMS IndraDrive single-axis inverters.....	30	CANopen interface.....	134
Holding brakes, brake check.....	21	EtherCAT.....	120
Homing.....	164, 167	EtherNet/IP(TM) interface.....	123
How to use this documentation.....	5	Operating modes.....	110
How to use this documentation, notes.....	5	Overview.....	81
		PROFIBUS-DP.....	126, 131
I		sercos.....	116
IDN lists of parameters.....	314	SERCOS III.....	116
Inappropriate use.....	8	Master password.....	314
Consequences, exclusion of liability.....	7	Means of representation	
Incompatible new functions and functional		Conventions of notation.....	6
changes.....	19	Notations.....	6
Incremental encoder emulation.....	304	Notes.....	6
IndraDrive Cs.....	30	Measuring encoder.....	309
IndraDrive Mi (KMS01.2-B, near motor servo		Measuring systems.....	153
drive).....	98	Absolute measuring systems.....	156
IndraDrive Mi (KSM01.2-B, motor-integrated		Arrangement.....	169
servo drive).....	97	Basics.....	153
IndraDrive Mi, distributed drive controller.....	30	Monitoring.....	155
IndraDrive Mi, distributed servo drive.....	30	Relative measuring systems.....	157

Index

Resolution.....	153
Supported measuring systems.....	102
Measuring wheel mode.....	268
Mechanical axis system.....	169
MLD → IndraMotion MLD.....	288
MLD 2G	
System behavior.....	28
MLD reaction on error.....	262
MLD: Advantages.....	37
MLD: Determining the performance.....	40
MLD: Modified functions.....	37
Addressing.....	37
Event task.....	37
Libraries.....	38
Local real-time channel: Replacement.....	38
PLC browser: Replacement.....	38
MLD: New functions.....	37
IO configuration.....	38
Offline configuration of IOs.....	38
PLC events.....	38
System events.....	38
MLD: Power / performance.....	40
MLD: Project conversion.....	40
MLD: Reference documentations.....	35
MLD: Required memory.....	40
MLD: User interface.....	35
Modbus TCP.....	30
Model-based current control without motor encoder (FXC).....	182
Monitor commands.....	75
Monitoring functions	
Measuring systems.....	155
Motor temperature.....	141
MotionProfile.....	253
MotionProfile with real/virtual master axis.....	253
Motor	
Commissioning.....	343
Commissioning motors.....	343
Motor control.....	181
Automatic setting.....	192
General information.....	181
Motor control frequency.....	186
Motor control method	
Notes on selection of method.....	183
Motor control methods	
Field-oriented current control with motor encoder (FOC).....	182
Model-based current control without mo- tor encoder (FXC).....	182
Overview.....	181
Motor control parameters	
Automatic setting.....	192
Motor encoder data memory.....	199
Motor encoder, redundant.....	269
Motor holding brake.....	149
Brief description.....	149
Function check.....	152
Operating behavior.....	151

Motor operation, diagnostic data.....	318
Motor operation, sensorless, flux-controlled.....	191
Motor parameters	
Automatic setting.....	192
Motor temperature monitoring.....	141
Motors	
Basics.....	139
General information for operation with IndraDrive.....	139
Hardware data.....	140
Rexroth housing motors.....	145
Rexroth kit motors.....	147
Supported motors.....	102
Temperature monitoring.....	141
Third-party motors.....	148
Motors that can be operated, general.....	21
Multiplex channel.....	109

N

NC reaction on error.....	262
NC-controlled homing.....	167
Non-volatile data memories.....	73
Notes on application.....	19

O

Object-oriented programming.....	38
Offline mode.....	42
Open-loop axis control.....	195
Open-loop operation (axis control)	
Overview.....	176
Operating hours counter.....	317
Operating modes of master communication.....	110
Operation mode handling.....	22
Operation modes.....	226
Basic principles.....	75
Changing the operation mode.....	229
Drive-controlled positioning.....	238
Drive-internal interpolation.....	236
Electronic cam with real/virtual master axis.....	250
General information.....	226
MotionProfile with real/virtual master axis.....	253
Operation mode handling.....	226
Phase synchronization with real/virtual master axis.....	248
Position control with cyclic command val- ue input.....	234
Positioning block mode.....	240
Selecting the operation mode.....	226
Supported operation modes.....	86
Synchronization modes.....	243
Torque/force control.....	231
Velocity control.....	232
Velocity synchronization with real/virtual master axis.....	246
Operation modes, general.....	21
Optional device functions.....	280
Availability.....	88

Index

Optional memory.....	328
Optional modules.....	99
Oscillation, drive-controlled.....	274
Oscilloscope function.....	335
Trend mode.....	41
Overview of functions/functional packages.....	81

P

Package reaction on error.....	259
Parameter handling, general.....	73
Parameter set switching.....	271
Parameters	
Basics.....	311
Definitions of terms.....	73
Loading, storing and saving.....	311
Modified.....	57
New.....	42
New, modified or no longer existing.....	42
No longer existing.....	66
Properties/features.....	311
Parking axis.....	275
Password.....	74, 314
Patch function	
General patch function.....	333
PLC patch function.....	333
PELV.....	13
Performance data.....	93
Phase synchronization with real/virtual master axis.....	248
PLC events.....	38
PLC patch function.....	333
Position control	
Block diagram.....	234
Position controller.....	205
Position limit values and travel range limit switches.....	32
Position limitation.....	221
Position spindle.....	34
Position switch, programmable.....	307
Positioning block mode.....	240
Positive stop.....	269
Positive stop drive procedure.....	269
Power sections, overview.....	98
Power supply.....	223
Mains connection.....	223
Possible device combinations.....	223
Power supply of converter, mains failure and phase failure.....	21
Probe function.....	308
PROFIBUS-DP.....	131
Profile types	
Freely configurable mode.....	113
I/O mode.....	113
Overview.....	113
Profile types (with field bus interfaces).....	113
PROFINET-DP.....	126
Programming module defective.....	332

Protective extra-low voltage.....	13
-----------------------------------	----

Q

Quadrant error correction.....	265
--------------------------------	-----

R

Redundant motor encoder.....	269
Reference documentations.....	103
Release Notes, notes on how to use them.....	5
Release update.....	322
Replace	
Drive controller.....	330
Replacement of devices	
Commissioning.....	315
Replacing devices	
Drive controller.....	329
Reset to default values.....	41
Resolution of measuring systems.....	153
Restoring	
MLD project.....	315
Parameters.....	315
Retain handling	
Storage, organization, configuration, commands.....	27
Rexroth housing motors	
With encoder data memory.....	145
Without encoder data memory.....	146
Rexroth IndraMotion MLD.....	288
Rexroth kit motors.....	147
Asynchronous.....	148
Synchronous.....	147
Rexroth motors.....	142
Basics.....	142
Rexroth housing motors.....	145
Rexroth kit motors.....	147
RMS value generator in the drive.....	334

S

S/IP Communication.....	340
Safe Motion	
S3.....	277
S4.....	277
Safe Torque Off	
L3.....	276
L4.....	276
Safety instructions for electric drives and controls	9
Safety technology, integrated.....	91, 275
Saturation method.....	216
Saving	
MLD project.....	315
Parameters.....	315
Saving parameter values, general.....	73
Scaling of physical data.....	173
Scaling the drive functionality.....	81
Scope of functions.....	73
Selecting the operation mode.....	226
Sensorless motor operation, flux-controlled.....	191

sercos connections.....	30
SERCOS III.....	116
Serial commissioning.....	343
Set absolute measuring.....	162
Set/shift coordinate system procedure.....	168
Setting motor control	
Loading controller default values.....	31
Setting of axis control	
Automatic.....	31
Shifting the position data reference.....	168
Signal control word.....	108
Signal status word.....	109
Sine-wave method.....	217
Slave axis.....	244
Spindle positioning.....	270
SSI encoders.....	158
Star-delta switching.....	272
State machine.....	115
State-of-the-art.....	7
Structure and priority-based generation	28
Support	
See service hotline.....	351
Supported devices, general.....	30
Synchronization modes.....	243
Basic functions.....	243
System behavior	
MLD 2G.....	28
System events.....	38
System overview.....	73

T

Task system.....	37
TCP/IP communication.....	339
Torque/force control	
Block diagram.....	231
Torque/force limitation.....	219
Travel range limit switches.....	221
Types of commands.....	75
Types of passwords, overview.....	74

U

Use	
Appropriate use.....	7
Inappropriate use.....	8

V

V/Hz (U/f) control.....	187
Velocity control	
Block diagram.....	232
Velocity controller.....	202
Velocity limitation.....	221
Velocity synchronization with real/virtual	
master axis.....	246
Version Notes, notes on how to use them.....	5
Version upgrade.....	322
Virtual master axis generator.....	298

Voltage-controlled open-loop operation	
(V/Hz [U/f] control).....	187

W

Warning classes.....	76
Reactions.....	33
Warnings.....	76
Web server.....	42

Notes

Notes

Bosch Rexroth AG
Electric Drives and Controls
P.O. Box 13 57
97803 Lohr, Germany
Bgm.-Dr.-Nebel-Str. 2
97816 Lohr, Germany
Tel. +49 9352 18 0
Fax +49 9352 18 8400
www.boschrexroth.com/electrics



R911338658

DOK-INDRV*-MP*-18VRS**-RN03-EN-P