


IndraWorks 14VRS

CamBuilder

Application Description
R911387570

Edition 01



Title IndraWorks
14VRS
CamBuilder

Type of Documentation Application Description

Document Typecode DOK-IWORKS-CAMBUIL*V14-AP01-EN-P

Internal File Reference RS-23b88ae44aa963510a6846a501b20068-1-en-US-4

Change Record

Edition	Release Date	Note
Edition 01	2018 - 01	First edition 14VRS

Copyright © Bosch Rexroth AG 2018

All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial property rights.

Liability The specified data is intended for product description purposes only and shall not be deemed to be a guaranteed characteristic unless expressly stipulated in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.

Editorial Department Automation Systems XLC/MLC Software, OLST (MiNi/MePe)

Table of Contents

	Page
1 About this documentation.....	5
1.1 Validity of the documentation.....	5
1.2 Documentation structure.....	5
1.3 Required and supplementing documentation XLC/MLC.....	6
1.4 Information representation.....	12
1.4.1 Safety instructions.....	12
1.4.2 Symbols used.....	12
1.4.3 Names and abbreviations.....	13
2 Introduction.....	15
2.1 General information.....	15
2.2 Cams and synchronization modes.....	15
2.3 CamBuilder - Features.....	15
2.4 Definition of terms.....	16
3 First steps – CamBuilder.....	17
3.1 Preparation.....	17
3.2 Creating and downloading cams.....	19
3.3 Analyzing the cam.....	25
3.4 Creating a variable cam and a PLC function block.....	27
4 Creating cams and preview objects.....	31
4.1 Creating new cams.....	31
4.2 Creating preview objects.....	32
4.3 Creating preview objects of superimposed cam motions.....	32
5 Editing and analyzing cams.....	35
5.1 Graph editor.....	35
5.1.1 General information.....	35
5.1.2 Structure.....	35
5.1.3 Editing a cam graphically.....	36
5.1.4 Changing the view.....	36
5.1.5 Graph Manager settings.....	37
5.2 Motion step editor.....	38
5.2.1 Overview.....	38
5.2.2 Attributes of the superordinate section.....	40
5.2.3 Attributes of the tabular section.....	40
5.2.4 Attributes of the form-based section.....	41
5.2.5 Calculating the motion step.....	45
5.2.6 Undo/redo editing.....	46
5.2.7 Absolute editing of the slave axis position (Y-values).....	46
5.2.8 Relative editing of the slave axis position (Y-values).....	47
5.2.9 Absolute editing of the master axis range (X-values).....	47

Table of Contents

	Page
5.2.10	Relative editing of the master axis range (X-values)..... 48
5.2.11	Editing the motion step cam table..... 49
5.2.12	Adding a new step after the focused step..... 49
5.2.13	Adding a new step before the focused step..... 51
5.2.14	Deleting a focused motion step..... 53
5.3	Event editor..... 54
5.3.1	Overview..... 54
5.3.2	Attributes..... 54
5.3.3	Functionality..... 56
5.4	Variable editor..... 56
5.4.1	Overview..... 56
5.4.2	Attributes..... 56
5.4.3	Functionality..... 57
5.5	Formula editor..... 57
5.5.1	Overview..... 57
5.5.2	Functionality..... 58
5.5.3	Keyword formula..... 59
5.6	Application-specific wizard..... 61
5.6.1	General information..... 61
5.6.2	CrossCutter wizard..... 61
5.6.3	Feed wizard..... 62
5.6.4	Print length correction wizard..... 64
5.6.5	FlyingShear wizard..... 64
5.7	Cam table..... 66
5.8	Extreme values..... 67
5.9	Cam preview..... 67
5.10	Preview of superimposed cams (XY)..... 69
6	Managing cams and preview objects in the IndraWorks project..... 73
7	Interacting with Bosch Rexroth devices..... 75
7.1	Downloading cams to devices..... 75
7.1.1	General information..... 75
7.1.2	Downloading cams to cam table parameters..... 75
7.1.3	Downloading Cams to MotionProfile Parameters..... 76
7.1.4	Downloading cams to FlexProfile parameters..... 76
7.1.5	Downloading cams to a CF memory card..... 76
7.2	Uploading cams from devices..... 76
7.3	Creating a PLC function block..... 77
8	Importing and exporting cams..... 79
8.1	General information..... 79
8.2	Exporting cams..... 79
8.3	Importing cams..... 81

Table of Contents

	Page
9 CamBuilder options and cam properties.....	83
9.1 CamBuilder options.....	83
9.2 Cam properties.....	85
10 Printing cams.....	87
11 Motion laws.....	89
11.1 General information.....	89
11.2 Analytic functions.....	93
11.2.1 General information.....	93
11.2.2 Rest-in-rest.....	93
11.2.3 Rest-in-velocity.....	103
11.2.4 Velocity-in-rest.....	104
11.2.5 Velocity-in-velocity.....	105
11.2.6 General motion.....	108
11.2.7 Extended motion laws.....	112
Resulting distance.....	112
Extended, resulting master axis range.....	114
Miscellaneous.....	116
11.3 Cam tables.....	119
12 Service and support.....	121
Index.....	123

1 About this documentation

1.1 Validity of the documentation

Overview on target groups and product phases

This documentation describes the basics and the operation of the CamBuilder for the version 14VRS.

In the following illustration, the framed activities, product phases and target groups refer to the present documentation.

Example: In the product phase "Engineering", the target group "programmer" can execute the activity "programming" and create electronic cams using this documentation.

Required qualification: Individual who is able to assess the tasks assigned and to identify possible safety risks owing to qualification in the subject, knowledge and experience. The individual should also be familiar with the standards and regulations.




Fig. 1-1: Assigning the present documentation to the target groups, product phases and activities of the target group

1.2 Documentation structure

The [chapter 2 "Introduction"](#) on page 15 provides general notes on synchronization modes, CamBuilder features as well as term definitions.

The [chapter 3 "First steps – CamBuilder"](#) on page 17 provides information on licensing, creating, downloading and analyzing cams.

The [chapter 4 "Creating cams and preview objects"](#) on page 31 describes the creation of cams and preview objects.

The [chapter 5 "Editing and analyzing cams"](#) on page 35 provides information on editing and analyzing cams.

The [chapter 6 "Managing cams and preview objects in the IndraWorks project"](#) on page 73 describes the cam management (e.g. to create "Cam Pool" folder, open/save cam) and preview objects in the IndraWorks project.

The [chapter 7 "Interacting with Bosch Rexroth devices"](#) on page 75 describes the download/upload from/to devices as well as the generation of a PLC function block.

About this documentation

The [chapter 8 "Importing and exporting cams"](#) on page 79 contains information on the import and export of cams.

The [chapter 9 "CamBuilder options and cam properties"](#) on page 83 describes the CamBuilder options and the cam properties.

The [chapter 10 "Printing cams"](#) on page 87 describes the possible print presets to print a cam.

The [chapter 11 "Motion laws"](#) on page 89 provides an overview on the available motion laws as well as a description of the analytic functions and the definition of a slave axis motion of a motion step using a cam table.

For information on the customer service helpdesk, refer to [chapter 12 "Service and support"](#) on page 121.

1.3 Required and supplementing documentation XLC/MLC

Documentation titles with type codes and part numbers

System overview
IndraLogic XLC IndraMotion MLC 14VRS System Overview DOK-XLCMLC-SYSTEM**V14-PRRS-EN-P, R911341504 This documentation provides an overview on the possible hardware/software components of the automation systems IndraLogic XLC and IndraMotion MLC of the mentioned version. The documentation facilitates assembling a system.

Tab. 1-1: XCL/MLC documentation overview - System overview

First steps
IndraMotion MLC 14VRS First Steps DOK-MLC***-F*STEP**V14-CORS-EN-P, R911341517 This documentation describes the first steps of the IndraMotion MLC and the RobotControl. It includes the hardware and software prerequisites as well as the creation of a project.
IndraLogic XLC 14VRS First Steps DOK-XLC***-F*STEP**V14-CORS-EN-P, R911341489 This documentation describes the first steps of the IndraLogic XLC. It includes the hardware and software prerequisites as well as the creation of a project.
Rexroth IndraLogic XLC IndraMotion MLC 14VRS Project Conversion DOK-XLCMLC-PROCONV*V14-APRS-EN-P, R911341494 This documentation describes the project conversion of the IndraMotion MLC.

Tab. 1-2: XCL/MLC documentation overview - First steps

Engineering
IndraWorks 14VRS Software Installation DOK-IWORKS-SOFTINS*V14-CORS-EN-P, R911344286 This documentation describes the IndraWorks installation.
IndraWorks 14VRS Engineering DOK-IWORKS-ENGINEE*V14-APRS-EN-P, R911343566 This documentation describes the application of IndraWorks in which the Rexroth Engineering tools are integrated. It includes instructions on how to work with IndraWorks and how to operate the oscilloscope function.
IndraLogic XLC IndraMotion MLC 14VRS Function Description DOK-XLCMLC-FUNC***V14-APRS-DE-P, R911341700 This documentation describes wizards, context menus, dialogs, control commissioning, device configuration and functionalities of the IndraMotion MLC.

Tab. 1-3: XCL/MLC documentation overview - Engineering

Diagnostics and service
IndraLogic XLC IndraMotion MLC 14VRS Diagnostics DOK-XLCMLC-DIAG***V14-RERS-EN-P, R911341481 This documentation includes all control diagnostics implemented in the control systems IndraLogic XLC and IndraMotion MLC.
IndraLogic XLC IndraMotion MLC 14VRS Parameters DOK-XLCMLC-PARAM***V14-RERS-EN-P, R911341479 This documentation describes the parameters of the XLC/MLC systems as well as the interaction between parameterization and programming. It includes the axis parameters, control parameters, kinematic parameters, touch probe parameters and programmable limit switch parameters.
IndraLogic XLC IndraMotion MLC 14VRS Commissioning DOK-XLCMLC-STARTUP*V14-CORS-EN-P, R911341502 This documentation describes the steps to commission and service the IndraMotion MLC and IndraLogic XLC systems. It includes checklists for frequent tasks and a detailed description of the steps.
WebAssistant DOK-GENERL-WEB*ASSIST*-APRS-EN-P, R911381469 This documentation describes the WebAssistant. The WebAssistant is a webbased diagnostic tool used to access a control system via an Ethernet highspeed connection. The WebAssistant allows OEMs, end users and service engineers to access and to remotely diagnose a system. A PC with Internet Explorer version 11 or higher, Firefox version 45 or above or Google Chrome version 54 or above is required. The following control variants are supported: • IndraMotion MLC L25/L45/L65/L75/XM2 • IndraLogic XLC L25/L45/L65/L75/VEP
IndraWorks IndraMotion Service Tool DOK-IWORKS-IMST*****-APRS-DE-P, R911341383 This documentation describes the IndraMotion Service Tool (IMST). IMST is a web-based diagnostic tool used to access a control system via an Ethernet high-speed connection. The IMST allows OEMs, end users and service engineers to access and remotely diagnose a system. The PC has to use at least Internet Explorer 8, Firefox 3.5 or a higher version. The following control variants are supported: • IndraMotion MLC L25/L45/L65/L75/XM12/XM2/VPx • IndraLogic XLC L25/L45/L65/L75

Tab. 1-4: XCL/MLC documentation overview - Diagnostics and service

About this documentation

Firmware
Rexroth IndraDrive MPx-20, Functions ¹⁾ DOK-INDRV*-MP*-20VRS**-AP01-EN-P, R911345608 This documentation describes all functional properties of the IndraDrive firmware in the variants MPB-20, MPM-20, MPC-20 and MPE-20.
Rexroth IndraDrive MPx-16 to MPx-20 und PSB, Parameters DOK-INDRV*-GEN1-PARA**-RERS-EN-P, R911328651 This documentation contains the descriptions of all parameters implemented in the firmware for drive controllers of the IndraDrive range. It supports the drive controller parameterization.
Rexroth IndraDrive MPx-16 to MPx-20 and PSB, Diagnostic Messages DOK-INDRV*-GEN1-DIAG**-RERS-EN-P, R911326738 This documentation contains the descriptions of all diagnostic messages implemented in the following firmware products: • Drive controller firmware variants MPx-16 to MPx-20 • PSB firmware variants for "HMU05" and "KMV03" type supply units • Firmware variants for "HMF01" type supply units It assists machine operators and installation programmers with troubleshooting.
Hardware
Rexroth IndraDrive Control Sections CSB02, CSE02, CSH02, CDB02 DOK-INDRV*-Cxx02*****-PRRS-EN-P, R911338962
Rexroth IndraDrive Cs Drive Systems with HCS01 DOK-INDRV*-HCS01*****-PRRS-EN-P, R911322210
Rexroth IndraDrive Mi Drive Systems with KCU02, KSM02, KMS02/03, KMV03 DOK-INDRV*-KCU02+KSM02-PRxx-EN-P, R911335703
Rexroth IndraDrive ML Drive Systems with HMU05 DOK-INDRV*-Hxx05*****-PRxx-EN-P, R911344279

1)

In preparation

Tab. 1-5:

Overview of documentations for drive controllers

PLC
IndraWorks 14VRS PLC Programming System IndraLogic 2G DOK-IWORKS-IL2GPRO*V14-APRS-EN-P, R911343571 This documentation describes the PLC programming tool IndraLogic 2G and its usage. It includes the basic use, first steps, visualization, menu items and editors.
IndraWorks 14VRS Basic Libraries IndraLogic 2G DOK-IL*2G*-BASLIB**V14-LIRS-EN-P, R911343920 This documentation describes the system-comprehensive PLC libraries.
IndraLogic XLC IndraMotion MLC 14VRS PLCopen Libraries DOK-XLCMLC-FUNLIB**V14-LIRS-EN-P, R911341491 This documentation describes the function blocks, functions and data types of the RIL_CommonTypes, ML_Base and ML_PLCopen libraries for the IndraLogic XLC/IndraMotion MLC. It also includes the error reactions of function blocks.

Tab. 1-6:

XCL/MLC documentation overview - PLC

Field buses
IndraWorks 14VRS Field Buses DOK-IWORKS-FB*****V14-APRS-EN-P, R911341485 This documentation describes the field bus and local periphery connections supported by the IndraLogic XLC, IndraMotion MLC and IndraMotion MTX systems. The focus of this documentation is on the configuration, parameterization, commissioning and the diagnostics of the different periphery connections. This documentation is the basis for the online help.
IndraWorks 14VRS Field Buses Libraries DOK-IWORKS-FB*LIB**V14-LIRS-EN-P, R911343575 This documentation describes the field bus libraries: RIL_ProfibusDP_02, RIL_ProfibusDP Slave, RIL_ProfinetIO, RIL_ProfinetIODevice, RIL_EtherNetIPAdapter, RIL_MappingList, RIL_SERCOSIII, RIL_Inline including their diagnostics and error reactions of the function blocks.
Rexroth IndraWorks 12VRS FDT Container DOK-IWORKS-FDT*CON*V12-APRS-EN-P, R911334398 This documentation describes the IndraWorks FDT Container functionality. It includes the activation of the functionality in the project and working with DTMs.
Sercos System Manual for I/O Devices DOK-CONTRL-ILS3*****-APxx-EN-P, R911333512 This documentation describes the configuration, parameterization, commissioning and diagnostics of I/O devices with a Sercos interface.

xx Corresponding edition
Tab. 1-7: XCL/MLC documentation overview - Field buses

HMI
IndraWorks 14VRS HMI DOK-IWORKS-HMI*****V14-APRS-EN-P, R911343569 This documentation describes the functions, configuration and operation of the user interfaces IndraWorks HMI Engineering and IndraWorks HMI Operation.
IndraWorks 14VRS WinStudio 7.4 DOK-IWORKS-WINSTUD*V14-APRS-EN-P, R911341585 This "User Manual and Technical Reference Book" facilitates working with the "Rexroth WinStudio" software for optimal results. This document provides technical information and step-by-step instructions to create web-enabled HMI/SCADA programs.
Rexroth IndraLogic XLC IndraMotion MLC 14VRS HMI Connection DOK-XLCMLC-HMI*****V14-APRS-EN-P, R911341497 This documentation describes the visualization systems supported by the IndraLogic XLC and IndraMotion MLC and their connection.

Tab. 1-8: XCL/MLC documentation overview - HMI

About this documentation

Technology
IndraLogic XLC IndraMotion MLC 14VRS Generic Application Template DOK-XLCMLC-TF*GAT**V14-APRS-EN-P, R911341487 This documentation provides a structured template to the IndraLogic PLC programmer. This template can be used to add and edit the PLC programming code. It includes the template, the template wizard and example applications.
IndraMotion MLC 14VRS Technology Libraries DOK-MLC***-TF*LIB**V14-LIRS-EN-P, R911341511 This documentation describes the function blocks, functions and data types of the "ML_TechInterface.library", "ML_TechMotion.library", "RMB_TechCam.library" and "ML_TechBase.library". It also includes libraries for the winder functionality, register controller functionality and CrossCutter functionality.
IndraWorks 14VRS Energy Efficiency Management DOK-IWORKS-4EE*****V14-APRS-EN-P, R911339229 This documentation describes the HMI connection of the energy management system and the function blocks, functions and data types of the "RIL_4EE " library. The documentation also includes the error reactions of the function blocks.
Rexroth IndraMotion MLC 14VRS RegisterControl (Library) DOK-MLC***-REGI*CO*V14-LIRS-EN-P, R911341509 This documentation describes the inputs and outputs of the individual function blocks and provides notes on their use.
IndraMotion MLC 14VRS RegisterControl (Application Description) DOK-MLC***-REGI*CO*V14-APRS-EN-P, R911341507 This documentation describes the application of the integrated register control for a rotogravure printing machine. The components of the mark stream sensor, the HMI application and the error recovery options are described. This instruction provides information on how to operate the register control, react to errors and query diagnostics. This documentation is written for machine setters and machine operators.
Rexroth IndraMotion MLC 14VRS Winder Function Application DOK-MLC***-TF*WIND*V14-APRS-EN-P, R911341513 This application-related system documentation describes the application of the winder technology functions.
Rexroth IndraWorks CamBuilder 13VRS DOK-IWORKS-CAMBUIL*V13-APRS-EN-P, R911336291 This documentation describes the basic principles and operation of the CamBuilder, the cam editing tool.
IndraMotion MLC 14VRS Robot Control V2 DOK-MLC***-ROCO****V14-RERS-EN-P, R911341588 This documentation provides information about the Robot Control V2. The focus is on PLCopen programming. The program structure, variables, functions, motion statements and the required system parameters are described. This documentation also includes the description of the "ML_Robot" library. Robot Control V2 is supported by a kinematic interface. The components of this interface are described in the "ML_KinTech" library.

Tab. 1-9: XCL/MLC documentation overview - Technology

Open Core Engineering - OCE
IndraLogic XLC IndraMotion MLC 14VRS First Steps MLPI (online help) DOK-XLCMLC-MLPI****V14-CORS-EN-E, R911341033 This document describes the installation and the commissioning of the MLPI interface.
IndraLogic XLC IndraMotion MLC 14VRS Automation Interface (online help) DOK-XLCMLC-AUT*INT*V14-APRS-EN-E, R911341499 This documentation describes the script-based access to IndraWorks project data via the interface of the Automation Interface.

Tab. 1-10: XCL/MLC documentation overview - Open Core Engineering - OCE

SafeLogic
IndraWorks SafeLogic 14VRS First Steps DOK-IWORKS-SL*STEP*V14-CORS-EN-P, R911341520 This documentation describes the initial commissioning of the Safety function module and its external Safety periphery. Taking the example of a project, all required steps to commission a simple Safety application are executed.
IndraLogic XLC IndraMotion MLC 14VRS SafeLogic System Overview DOK-XLCMLC-SL**SYS*V14-PRRS-EN-P, R911341696 This documentation describes the project planning, configuration, creation and commissioning of safety-related devices.
IndraWorks 14VRS SafeLogic - Project Configuration, Version 1.2.0.0. DOK-IWORKS-SL**PRJ*V14-APRS-EN-P, R911341694 This documentation describes the configuration of Safety applications.
IndraControl CFL01.1-F1 Safety Function Module DOK-CTRL-SL**FM*****-ITRS-DE-P, R911336576 This documentation is provided with the hardware and describes the commissioning, the installation, the decommissioning and disposal of the hardware.

Tab. 1-11: XCL/MLC documentation overview - SafeLogic

Hardware
Rexroth IndraControl L45/L65/L85 Control DOK-CTRL-ICL45L65L85-PRxx-EN-P, R911332116 This documentation describes the IndraControl L45/L65/L85 controls.
Rexroth IndraControl L25 DOK-CTRL-IC*L25*****-PRxx-EN-P, R911328474 This documentation describes the IndraControl L25 controls.
Rexroth IndraControl Lxx 14VRS Function Modules DOK-CTRL-FM*LXX**V14-APRS-EN-P, R911341583 This documentation describes all function modules of the Lxx controls including engineering and diagnostics.
IndraControl XM21, XM22 Controls DOK-CTRL-IC*XM2*****-ITRS-EN-P, R911340667 This documentation describes the IndraControl XM21/XM22 controls.
IndraControl XFE 01.1 Extension Modules Profibus, RT-Ethernet, Sercos, CAN DOK-CTRL-XFE**EXTMOD-ITRS-EN-P, R911345570 This documentation describes all extension modules of the XM controls.

xx Corresponding edition

Tab. 1-12: XCL/MLC documentation overview - Hardware

About this documentation

Hydraulics
Rexroth IndraMotion MLC 14VRS Hydraulic Functions DOK-MLC***-TF*HMOT*V14-LIRS-EN-P, R911341907 This documentation describes the function blocks, functions and data types of the MH_TechHydrBase and MH_TechHydrMotion libraries. The documentation also includes the error reactions of the function blocks.
Rexroth IndraLogic XLC IndraMotion MLC 14VRS Sequential Programming DOK-XLCMLC-SEQPROG*V14-LIRS-EN-P, R911341909 This documentation describes the sequential programming options, also when using GAT, and the MH_HydrControlProg library.

Tab. 1-13: XCL/MLC documentation overview - Hydraulics

1.4 Information representation

1.4.1 Safety instructions

If there are safety instructions in the documentation, they contain certain signal words ("Danger", "Warning", "Caution", "Notice") and sometimes a safety alert symbol (according to ANSI Z535.6-2006).

The signal word draws attention to the safety instruction and indicates the risk potential.

The safety alert symbol (triangular safety reflector with exclamation marks), preceding the signal words "Danger", "Warning", "Caution" indicates hazards for persons.

The safety instructions are represented as follows in this documentation:

 DANGER
In case of non-compliance with this safety instruction, death or serious injury will occur.
 WARNING
In case of non-compliance with this safety instruction, death or serious injury can occur.
 CAUTION
In case of non-compliance with this safety instruction, minor or moderate injury can occur.
NOTICE
In case of non-compliance with this safety instruction, material damage can occur.

1.4.2 Symbols used

Note Notes are represented as follows:

	This is a note for the user.
---	------------------------------

Tip Tips are represented as follows:



This is a tip for the user.

1.4.3 Names and abbreviations

Term	Explanation
Cam Pool	Folder in IndraWorks (to store the created cams)
Function block	Provides application-specific functionalities
Graph	Graphic representation of a function
VisualMotion	Programmable multi-axis motion control system
IndraMotion MLC	Compact Motion Logic systems with Motion, Robot and Logic Control functionalities
IndraLogic XLC	Compact PLC system with integrated Motion functionality
IndraWorks	Project planning and commissioning tool of Bosch Rexroth
IndraDrive	Drive control unit
IndraSize	Software tool to determine the drive design
Wizard	Wizard guiding through several dialogs for an ergonomic data input
IEC	International Electrotechnical Commission
XML	Extensible Markup Language (XML). It is a markup language to represent hierarchical structured data as text data
CSV	This file format describes the structure of a text file to save or exchange simply structured data. The file extension .csv is an abbreviation for Comma-"Separated Values"
PAR	Parameter file in ASCII format to save data
ST	Structured Text
CFC	Continuous Function Chart
TPD	Turning Point Displacement
ms	millisecond
mm	Millimeter
%	Percent
Rad/s	Angular velocity
rpm	speed
Degrees	Angular size

Tab. 1-14: Names and abbreviations used

2 Introduction

2.1 General information

The CamBuilder is a tool integrated into IndraWorks Engineering to simply and conveniently create electronic cams. The CamBuilder supports the direct download of cams to Bosch Rexroth drive controllers as well as the creation of cam PLC function blocks to parameterize FlexProfiles. Thanks to these features, this tool meets the requirements and characteristics of the Bosch Rexroth drive controllers.

2.2 Cams and synchronization modes

Electronic cams control the motion sequences of slave axes with regard to master axes.

The Bosch Rexroth drive controllers have different synchronization modes to execute cams.

Cam table	The position of the slave axis is calculated from the distance and the percentage values of the table at runtime.
MotionProfile	The position of the slave axis is calculated using analytical functions or cam tables at runtime.
FlexProfile	The FlexProfile corresponds to an extension of the Motion-Profile (the time can be used as reference variable for the slave axis and has a greater selection of motion laws and an event control).

The CamBuilder is a superordinate tool and does not differentiate between the various operation modes while creating and editing. Only if a cam is downloaded to a device, the corresponding operation mode has to be specified.

2.3 CamBuilder - Features

The essential features of the CamBuilder are:

- Easy creation of cams using graphic objects
- Comfortable cam editing
- Opening of several cams parallelly in a preview and analyzing them at different master axis velocities
- Usage of VDI 2143-compliant motion laws
- Upload and download of cams to Bosch Rexroth drives and controls
- Generating a PLC code to change the cam in the PLC program at runtime
- Entering variables, formulas and references into the cam editor to generate flexible cam definitions
- Automatic display of position, acceleration, velocity and jerk
- Support for common requirements (application-specific cams such as CrossCutter) using wizards
- Import of cam tables as motion laws
- Automatic identification and calculation of the boundary conditions of the individual cam motion steps
- Zoom functionality
- Import/export functionality in different formats (*.XML, *.PAR, *.CSV)

Introduction

2.4 Definition of terms

Cam




Fig. 2-1: Chart of a cam graph for the term definition

- a** Master axis (x-axis)
- b** Slave axis (y-axis)
- c** Motion steps (0 - n)
- d** Focused motion step
- e** Motion law (analytical function or cam table)
- f** Starting point of the focused motion step (X_n, Y_n)
- g** End point of the focused motion step (X_{n+1}, Y_{n+1})
- h** Distance of the focused motion step (ΔY)
- i** Range of the focused motion step, which can either be the time duration (ΔT) or the master axis range (ΔX).

A cam defines the position of a slave axis with regard to a master axis or the time. It consists of one or more motion steps. Each motion step has a motion law that specifies the connection between master axis or time and slave axis. The individual motions of the steps combined create a cam.

In the CamBuilder, it is the focused motion step of a cam that is always edited. Editing takes place either via a graphic representation or numeric inputs. Depending on the editing mode and the change, the preceding or subsequent motion steps can also change.



From the second motion step onwards, all motion steps start with the end point of the preceding step.

3 First steps – CamBuilder

3.1 Preparation

Installation and start The CamBuilder is integrated into the IndraWorks Suite installation package and is installed automatically.

If the CamBuilder is licensed, it starts automatically with the IndraWorks Engineering program.

- Licensing**
1. Purchase a full license to use the CamBuilder without limitations.
 2. Open the license overview via the menu items **Tools ▶ Options ▶ General ▶ Software licenses**.




Fig. 3-1: Menu: Tools




Fig. 3-2: Dialog: Options (Software licenses)

3. Enable the CamBuilder license via the **License...** button.

First steps – CamBuilder




Fig. 3-3: Dialog: Install Licenses

A demo license valid for 30 days is available without activation key.

After 30 days, the objects managed by the CamBuilder are disabled in IndraWorks projects. The CamBuilder can be licensed to continue using the cams created. If the disabled objects are no longer required, delete them.

Library All CamBuilder objects can be found in the IndraWorks library under "CamBuilder". These objects can be inserted via drag&drop (it is focused on individual elements in the following examples).

The following objects are available:

Cam pool A "Cam Pool" folder manages all cams created in the current project with the CamBuilder.

Also create a new cam via the context menu of a "Cam Pool" node.

Cams A cam in the CamBuilder is defined by one or several motion steps.

Double-click to open the cam for editing purposes.

Preview A preview in the CamBuilder shows one or several cams with regard to a master axis.

Double-click to open the preview. Add more cams to the preview via drag&drop.

Preview of superimposed cams (X/Y) A can preview to offline analyze two right-angled, superimposed, translatory cam motions with reference to a master axis.

3.2 Creating and downloading cams

This chapter describes how to create and download a cam consisting of three motion steps.

Topic The master and slave axis are rotary axes. The master axis rotates at a velocity of 100 rpm.

The slave axis starts at 0 degrees and should be moved on a fixed axis range of 180 degrees from the standstill to 120 degrees. It should pause there for 100 milliseconds (irrespective of the master axis velocity) and then travel up to the master axis end position of 360 degrees and return to standstill at 0 degrees.

The cam is then downloaded to an IndraMotion MLC or IndraLogic XLC control.

Operating sequence 1. Creating a cam




Fig. 3-4: Menu: View

The "Project Explorer" and the "Library" are made visible via the "View" menu.




Fig. 3-5: Library: CamBuilder section

Add a "Cam Pool" from the IndraWorks library to the "CamBuilder" section via drag&drop.

First steps – CamBuilder




Fig. 3-6: Context menu: Cam Pool

In the Project Explorer, right click on the "Cam Pool" node and select **Add ► Cam** in the context menu.

2. Wizard




Fig. 3-7: Dialog: Create a New Cam (wizard)

Enter a specific name into the wizard and optionally a description for the new cam. To create a freely definable cam, select "none" under "Application-specific wizard".

First steps – CamBuilder

The scalings of master and slave axis are set to "Rotary (Degree)."

To execute the cam cyclically, the option "Identical velocity in starting and end point (cyclic execution)" is selected.

Press **Finish** and a default cam is created, saved in IndraWorks and a graph window opens automatically.

3. Editing motion step 0




Fig. 3-8: Dialog: IndraWorks Engineering – First steps (cam)

The motion step editor opens at the same time as the graph window. The first motion step was automatically generated and is filled with default values. Depending on the motion law and mathematical degrees of freedom, not all fields of a step can be edited. To facilitate the input of values, all editable fields have a white background.

- 1 The master axis rotates at 100 rpm.
- 2 As all steps have to be input consecutively, the editing mode shows "Relative" - Symbol .
- 3 The slave axis should follow the master axis. Thus, the reference is to be set to the motor symbol .
- 4 The relative distance of the slave axis is defined at 120 degrees (ΔY).
- 5 The distance refers to a master axis range of 180 degrees (ΔX).
If the cam consists of only one step, the step type is automatically defined as "Default step".
- 6 The "Rest-in-rest - Polynomial 5th order" is selected as motion law. All other fields are automatically filled in.

Then, another step is added to the end of the focused step using the "Add motion step after focused step" button .

First steps – CamBuilder



If focused, modify the graph with the following keys:

- <Pos1> - Show all
- <Arrow keys> - Move view
- <+ / -> - Zoom in/out view

Change the zoom factor via mouse wheel. Press the <space> key/mouse key in the middle to move the view.

Find special tools to change the graph view in the CamBuilder toolbar.



Fig. 3-9: CamBuilder toolbar, graph

4. Editing motion step 1




Fig. 3-10: Dialog: IndraWorks Engineering – First steps (cam)

The fields of the second motion step are pre-assigned with default values from the CamBuilder options.

- 1 The reference of the slave axis is changed from the master axis to the time (symbol ⌚),
, thus disabling the input fields ΔX and X_2 .
- 2 Now, the duration of the step in milliseconds has to be entered into the column ΔT (100 ms).
- 3 After switching the motion law to "Rest-in-Rest - Standstill", all automatically calculated fields are disabled.

After every input, the cam is automatically recalculated and it is checked whether all values are valid. In case of invalid values, the relevant input field is highlighted and a message is output.

Click on the first line of the table to change to the first motion step. If the active step includes input

First steps – CamBuilder

errors, it is not possible to change to another step. Click on "Undo" to discard the last changes at the cam.

4

Add another step to the end of the focused step using the "Add motion step after focused step"

button .

5. Editing motion step 2




Fig. 3-11: Dialog: IndraWorks Engineering – First steps (cam)

1

The last step should refer to the master axis again. Thus, the slave axis reference is set to the motor symbol.

2

To refer the slave axis absolutely to the master axis again, the step type is set to "FlexStep with absolute slave axis position and absolute master axis position".

3

The master axis end position X_3 is set to 360 degrees.

4

The slave axis end position Y_3 is set to 0 degrees.

5

The new cam is now located in the Project Explorer as node below the "Cam Pool" node.

If the IndraMotion MLC/IndraLogic XLC in the project is in online or offline parameterization mode, the cam can be downloaded to the control via its context menu in the Project Explorer.

First steps – CamBuilder

6. Downloading the cam




Fig. 3-12: Dialog: Download cam to device

The target "FlexProfile 0" of the desired axis is selected, in the example "Drive1" is selected. Confirm with **OK** and the parameters of the cam "First steps" are loaded to the parameters of the control. A message confirms that the process has been completed successfully.




Fig. 3-13: Dialog: Download to device...



If a FlexProfile is already on the axis and currently in use (axis in motion), the FlexProfile is write-protected and cannot be replaced. Close the operation mode and write the FlexProfile to another empty profile set.

3.3 Analyzing the cam

This chapter describes the analysis of the cam from the previous [chapter 3.2 "Creating and downloading cams"](#) on page 19.

- Topic** The cam reaction at different master axis velocities is to be analyzed.
- Operating sequence**
1. Creating a preview
In the Project Explorer, right-click on the "Cam Pool" node and select the context menu items **New ► Preview....**
 2. Adding cams to the preview
In the Project Explorer, move the cam "First steps" to the preview window by keeping the left mouse button pressed and dropping the cam there.




Fig. 3-14: Position preview of the cam at a master axis velocity of 100 rpm

3. Changing the master axis velocity
Click on the "Settings..." link to change the master axis velocity to 200 rpm for example.
As the 2nd cam motion step does not have a master axis range but it refers to the time, there is less time for the 3rd motion step (FlexStep) to return to the home position.

First steps – CamBuilder




Fig. 3-15: Position preview of the cam at a master axis velocity of 200 rpm



Use the mouse to move the measuring line.

Change the view of a preview window in the CamBuilder toolbar using the graph tools.

4. Analyzing the slave axis velocity

Click on the blue position profile of the cam and the position preview of the cam changes to a velocity preview. Analyze the velocity using the measuring tool.

First steps – CamBuilder




Fig. 3-16: Velocity preview of the cam at a master axis velocity of 200 rpm



Several cams can be added to a preview via drag&drop. The cams can be analyzed simultaneously relating to the same master axis.

3.4 Creating a variable cam and a PLC function block

This chapter explains how to create and download a variable cam consisting of two motion steps.

Topic The master and slave axis are rotary axes. The master axis rotates at a velocity of 100 rpm.

The slave axis starts at 0 degrees and is to be moved to a variable position (Variable "Distance") from standstill to a variable master axis range (sum of 10 and a variable "Range"). From this position, the slave axis has to be traveled up to a defined master axis end position of 360 degrees and then back to 0 degrees at standstill.

A PLC function block should be created from the cam. With this function block, the FlexProfile of an axis can be variably parameterized in an IndraMotion MLC/IndraLogic XLC PLC application.

Operating sequence

1. Creating a cam

A new cam with default settings is created under the name "Cam1" as described in chapter [chapter 3 "First steps – CamBuilder" on page 17](#).

2. Editing motion step 0

The cam is defined without a formula input in the first draft. Make the following entries:

First steps – CamBuilder

The master axis velocity is 100 rpm.

The editing mode is set to "Relative".

At first, the relative distance of the slave axis distance should be set to 120 degrees (ΔY).

At first, the master axis range should be set to 180 degrees (ΔX).

Add another step to the end of the focused step using the "Add motion step after focused step" button.

3. Editing motion step 1

The master axis end position X_2 is set to 360 degrees.

The slave axis end position Y_2 is set to 0 degrees.

4. Creating a variable distance of first step




Fig. 3-17: Dialog: IndraWorks Engineering – Cam1 (variable cam)

- 1 The distance of the first motion step is to be defined via a "Distance" variable. No digit is entered in the $[\Delta Y]$ input field of the motion step editor, but a "=" character as in a spreadsheet.
- 2 A formula editor window opens in which the "=Distance" formula can be entered for the current field.
The formula is applied when confirming the dialog and a prompt is displayed, asking if the unknown "Distance" variable should be automatically created with a default value. Confirm with **Yes**.
- 3 A value of 120 degrees for example can now be entered for the "Distance" variable into the newly opened variable window.

5. Creating a variable master axis range of the first step

The master axis range of the first motion step is defined by the sum of 10 and a "Range" variable. No digit is entered in the $[\Delta Y]$ input field of the motion step editor, but a "=" character as in a spreadsheet.

The formula "=10 + Range" is entered in the formula editor for the current field.

This variable is created automatically with a default value.

First steps – CamBuilder

A value of e.g. 170 degrees can now be entered in the new variable window for the "Range" variable.

6. Creating a variable distance of the second step

The slave axis end position of the second motion law has to be 0 degrees. The distance of the second step has to be equal to the negative distance of the first step. Therefore, enter the formula " $= -DY0$ " in the formula editor for the $[\Delta Y]$ input field. $DY0$ stands for the distance of the first motion step.

7. Creating a variable master axis range of the second step

The master axis end position of the second motion law has to be 360 degrees. Consequently, the master axis range of the second step has to be 360 degrees minus the master axis range of the first step. This is achieved by entering the formula " $=360 - DX0$ " in the formula editor for the $[\Delta Y]$ input field. " $DX0$ " stands for the master axis range of the first motion step.

8. Creating a PLC function block

Start the creation of the PLC function block via the context menu of the cam in the Project Explorer or via the CamBuilder toolbar.




Fig. 3-18:

If there is an IndraMotion MLC/IndraLogic XLC in the project, the function block is created in the "General Module Folder".

9. Using a PLC function block

Instantiate and execute the function block in the PLC application of the IndraMotion MLC/IndraLogic XLC. Change the parameterization of the FlexProfile via the "Range" and "Distance" inputs.

Example ST code:

Program:

```
PROGRAM PlcProg
VAR
    fbCam1      : ChangeFlexSet_Cam1;
    bExecute    : BOOL      := TRUE;
    uiSetNumber : UINT      := 0;
    lrDistance  : LREAL     := 180;
    lrRange     : LREAL     := 170;
END_VAR

fbCam1 (
    Execute    := bExecute,
    SetNumber  := uiSetNumber,
    Distance   := lrDistance,
    Range      := lrRange,
    Done=> ,
    Active=> ,
    Error=> ,

```

First steps – CamBuilder

```

ErrorID=> ,
ErrorIdent=> ,
Axis      := Drive1, (* Name of slave axis *) );

```

Example CFC code:




Fig. 3-19:

Result:

The FlexProfile of the "SlaveAxis" of the IndraMotion MLC/IndraLogic XLC is parameterized according to the function block inputs and can be executed by executing the cam function block in the PLC program on the IndraMotion MLC/IndraLogic XLC.

4 Creating cams and preview objects

4.1 Creating new cams

- Starting the wizard** A new cam is created in one step using the wizard.
- Start the wizard via the context menu items **Add ► Cam** of the "Cam Pool" node in the Project Explorer. Alternatively, copy a "cam" from the IndraWorks library from the "CamBuilder" section to the project.
- General settings** Multiple attributes of the cam are preset in the wizard.
- The wizard suggests a default **name** ("Cam#") for the cam that can be changed.
- The user can also enter a short **description** of the cam.
- The **application-specific wizard** determines whether a wizard is to be used for a specific application.
- The CamBuilder provides wizards for common technologies (CrossCutter, feed, print length correction, FlyingShear) which assist when creating a cam. All requirements and unique features of the application are dialog-controlled.



This property is set once when creating a cam and cannot be modified later on.

No application-specific wizard is set by default. The user can freely define the individual motion steps in the following motion step editor.

Additionally, the **scalings of master and slave axis** can be set. These settings are automatically entered and disabled when an application-specific wizard is selected.

Three standards can be selected for the scaling of an axis:

1. Rotary (degree)
 - Position = degree
 - Velocity = 1/min
 - Acceleration = rad/s^2
 - Jerk = rad/s^3
2. Translatory (mm)
 - Position = mm
 - Velocity = mm/min
 - Acceleration = mm/s^2
 - Jerk = mm/s^3
3. Translatory (inch)
 - Position = in
 - Velocity = in/min
 - Acceleration = in/s^2
 - Jerk = in/s^3

The selection of the units "position", "velocity", "acceleration" and "jerk" can be modified individually. The unit of the position specifies whether the axis is a rotary or a translatory axis. For the other variables, only the respective units can be selected.

1. Rotary

Creating cams and preview objects

- Position = degree; radiant
- Velocity = 1/min; 1/s; degree/min; degree/s; rad/min; rad/s
- Acceleration = 1/min²; 1/s²; degree/min²; degree/s²; rad/min²; rad/s²
- Jerk = 1/min³; 1/s³; degree/min³; degree/s³; rad/min³; rad/s³

2. Translatory

- Position = mm; in
- Velocity = mm/min; mm/s; in/min; in/s
- Acceleration = mm/min²; mm/s²; in/min²; in/s²
- Jerk = mm/min³; mm/s³; in/min³; in/s³

Completing or canceling Once the entries are complete, the wizard creates a cam after clicking on **Finish**.

Each cam can either be edited after "Completion" via the motion step editor or via the graph.

Click on **Cancel** at any time and the wizard closes. All already detected entries to define a new cam are discarded.



Application-specific cams can additionally be edited using a wizard. If an application parameter is changed and applied to the wizard window, the cam is recalculated and any possible changes of the motion step editor or graph are discarded.

To edit cams, see [chapter 5 "Editing and analyzing cams" on page 35](#).

4.2 Creating preview objects

Creating a preview Create an empty new preview via the context menu items **Add ► Preview** of the "Cam Pool" node in the Project Explorer. Alternatively, copy a "preview" from the IndraWorks library from the "CamBuilder" section to the project.

The wizard suggests a unique name ("preview#") for the preview which can be changed.

Adding cams to the preview Add one or several cams from the current project to a preview via drag&drop or copy&paste. Therefore, select the desired cams in the Project Explorer and drag them to the preview with the left mouse button pressed and drop them there. Alternatively, select the cams in the Project Explorer and copy them via "Edit/Paste" in the menu and add them to the preview window with "Edit/Paste".

Removing cams from the preview A cam opened in the preview can be removed from the preview via the X interface of its title bar.

To analyze the cams in a preview, refer to [chapter 5.9 "Cam preview" on page 67](#).

4.3 Creating preview objects of superimposed cam motions

Creating a preview Create an empty new preview via the context menu items **Add ► Preview superimposed cams (XY)** of the "Cam Pool" node in the Project Explorer. Alternatively, copy a "preview of superimposed cams (XY)" from the IndraWorks library from the "CamBuilder" section to the project.

The wizard suggests a unique name ("preview#") for the preview which can be changed.

Creating cams and preview objects

Adding cams of the x- and y-axis to the preview

Add two translatory cams from the current project to a preview via drag&drop or copy&paste. Therefore, select the desired cams in the Project Explorer and drag them to the preview with the left mouse button pressed and drop them there. Alternatively, select the cams in the Project Explorer and copy them via "Edit/Paste" in the menu and add them to the preview window with "Edit/Paste".

Editing cams from the x- and y-axis

Edit the cam selection of the x- or y-axis via the **X-axis...** button of the preview title bar.

To analyze the superimposition of the two translatory cam motions in x- and y-direction in a preview, see [chapter 5.10 "Preview of superimposed cams \(XY\)" on page 69](#).

5 Editing and analyzing cams

5.1 Graph editor

5.1.1 General information

The graph window is the core element of the CamBuilder. Open a graph (double-click on a cam of a "Cam Pool" node) and the graph is displayed in the IndraWorks main screen. Only one cam is always "focused" in the CamBuilder and can be edited via the graph or the motion step editor. If another cam is opened, this cam is "focused." Focus (click on a cam window with the mouse) and the cam is automatically registered as focused by the CamBuilder. All CamBuilder inputs and displays refer to the focused cam.

5.1.2 Structure

A CamBuilder graph consists of a cam in a **coordinate system**.

In the coordinate system, up to four different slave axis profiles are displayed at the same time (**position profile**, **velocity profile**, **acceleration profile** and **jerk profile**).

Show or hide the different profile diagrams using the Graph Manager (refer to [chapter 5.1.5 "Graph Manager settings" on page 37](#)). Set the color in which the profiles are drawn in the "Options" dialog (see [chapter 9.1 "CamBuilder options" on page 83](#)).

The **x-axis unit** is the unit of the master axis.

The **y-axis unit** corresponds to the respectively focused profile diagram. Focus a profile diagram by clicking on the respective profile.

The **axes of the coordinate system** always have the color of the focused diagram. The grid is used to provide a better overview.

The **motion step limits** are vertical lines marking the limits of the motion steps.

The **focused motion step** is highlighted with a different background color.

Focus another step by clicking into the area of that motion step.

The **limit points** of a **focused motion step** are highlighted by a black square.

Zoom in/out or move the section of the cam displayed in the coordinate system.

Editing and analyzing cams

5.1.3 Editing a cam graphically

Moving the starting or end point

The starting and end points of the focused profile (position, velocity, acceleration or jerk) of the focused motion step are displayed as black squares.

How to move a point is shown as symbol with arrows when the cursor is on the point.



Data point can be moved horizontally and vertically



Data point can only be moved horizontally



Data point can only be moved vertically

The data points of the **position diagram** can be moved vertically and horizontally depending on the editability of the values defined by the selected motion law.

The cam changes in different ways depending on the editing mode set (relative or absolute). The reaction of the cam due to changes of the boundary values is described in detail in [chapter 5.2.9 "Absolute editing of the master axis range \(X-values\)" on page 47](#) and [chapter 5.2.10 "Relative editing of the master axis range \(X-values\)" on page 48](#).

The data points of the **velocity**, **acceleration** and **jerk diagrams** can only be moved vertically according to the editability of the values defined by the selected motion law.

Deleting a focused motion step Delete

Delete a motion step via the context menu of the graph as described in [chapter 5.2.14 "Deleting a focused motion step" on page 53](#).

5.1.4 Changing the view

Set a graph to different modes via the toolbar. By default, a selection tool (arrow) is enabled.



Fig. 5-1: Icons: Tools for the CamBuilder graph window

Show all

The entire cam is shown in the graph window via the context menu item **Show all**.

Alternatively, enable this function via the "toolbar", the "Graph Manager" and the <Pos1> key.

Selection

The context menu item **Selection** enables an arrow as mouse cursor. Points can be moved and profiles can be enabled in this mode.

Alternatively, enable this mode via the "toolbar", the "Graph Manager" and the <Esc> key.

Zoom in

The context menu item **Zoom In** enable a magnifying symbol as mouse cursor. Click into the coordinate system and mark a rectangle to specify the area to be zoomed in.

Alternatively, enable this mode via the "toolbar" and the "Graph Manager".

The mouse wheel also controls the zoom level.

The keys <+>/<-> zoom the view in/out by 25%.

Pan view	The context menu item Pan enable a hand symbol as mouse cursor. Click into the coordinate system and drag. This pans the section. Alternatively, enable this mode via the "toolbar" and the "Graph Manager". Alternatively, pan the graph via the mouse button the middle or via the <space> key.
Copying the graph to clipboard	Copy the section of the cam currently displayed to the clipboard via the context menu and use it in other applications such as word processing.
Showing tool window	The context menu of the main graph window includes a menu to enable all other CamBuilder tools windows. Furthermore, there is an option to show and hide all other tool windows created by the CamBuilder in the IndraWorks View ► Other Windows menu.
Restoring default layout	The Restore Default Layout menu hides all CamBuilder tools except the motion step editor and the Graph Manager and enables the toolbar. Arrange, show and hide all windows freely. Each layout change is permanently saved. The last layout used is preset at a CamBuilder restart.

5.1.5 Graph Manager settings

Open the Graph Manager via the context menu of a graph or a preview: **Show tool window ► Graph Manager**. It can also be shown and hidden via the main menu **View ► Other windows ► Graph Manager**.

The Graph Manager is used to focus, show and hide the different profile diagrams.

- **Slave axis position** (shown/hidden and focused/not focused)
- **Velocity** (shown/hidden and focused/not focused)
- **Acceleration** (shown/hidden and focused/not focused)
- **Jerk** (shown/hidden and focused/not focused)

Start the different actions on the graph window via the "Graph tool selection" buttons

- **Show all**
- **Selection**
- **Zoom in**
- **Pan**

The cursor coordinate area displays the mouse coordinates related to the focused profile diagram with all units.

Set the visibility of different data in the graph window via the advanced options.

- **Coordinate axes** (shown/hidden)
- **Coordinate net** (shown/hidden)
- **Motion step limits** (shown/hidden)
- **Border coordinates** (shown/hidden)

The settings in the Graph Manager directly affect the graphic output.



Cross-project settings, such as colors and line thickness of the graph and preview window can be set in the menu **Tools ► Options ► CamBuilder ► Graph** (see [chapter 9.1 "CamBuilder options" on page 83](#)).

Editing and analyzing cams

5.2 Motion step editor

5.2.1 Overview

A cam can consists of any number of motion steps. The motion step editor configures the individual motion steps.



The "MotionProfile" and "FlexProfile" operation modes of the devices are limited to a maximum number of motion steps! If too many steps are defined, the cam can no longer be downloaded for the corresponding operation mode.




Fig. 5-2: Dialog: Motion step editor

The editor is divided into three sections.

- 1 The **superordinate** section relates to all cam motion steps.
 - 2 The **tabular** section provides an overview and navigation between the individual motion steps and allows to change single attributes.
 - 3 The **form-based** section provides the option of editing other attributes of the motion step focused in the tabular part.
- One motion step is set as default.

Editing and analyzing cams

Not all attributes can always be edited. Some attributes are automatically calculated depending on the selection of other attributes. All disabled attributes are always calculated after a property change (after clicking on <Enter> or by moving the cursor to another attribute). If a non-numerical value is entered into a numerical entry field, the value is automatically reset. Other incorrect entry fields are marked by an error symbol and a note.

The latest 50 changes made to a cam can be undone providing the cam has not yet been saved.

Instead of constant values, formulas can also be entered into almost all fields to calculate the values (see [chapter 5.5 "Formula editor" on page 57](#)).

5.2.2 Attributes of the superordinate section

The attributes of the superordinate section refer to the entire cam.

Master axis velocity A cam is defined with reference to a master axis velocity. All limit values of the motion steps refer to the master axis velocity in the editor.

Create a "preview" (see [chapter 4.2 "Creating preview objects" on page 32](#)) to analyze the cam response at different master axis velocities.

The master axis velocity is set depending on the preset master axis scaling.

This attribute can always be edited.

Minimum

- Master axis velocity > 0
- The master axis velocity has sufficiently high so that no ΔX of a time-related motion step is lower than the minimum increment (see [chapter 9.1 "CamBuilder options" on page 83](#))

Maximum

- The master axis velocity has an upper limit if there are time-related motion steps in front of a FlexStep with an absolute master axis end position and these would extend beyond the absolute master axis end position

Editing mode The "relative" or "absolute" editing mode determines the reaction of the subsequent motion steps when editing ΔY , ΔX , ΔT , Y_1 or X_2 (see also [chapter 5.2.9 "Absolute editing of the master axis range \(X-values\)" on page 47](#) and [chapter 5.2.10 "Relative editing of the master axis range \(X-values\)" on page 48](#)).

5.2.3 Attributes of the tabular section

The attributes of the tabular section show the values of all cam motion steps. Only the values of the focused motion step can be edited.

Reference The reference defines the reference of the slave axis. There are two options:

- The motion of the slave axis should follow the master axis. This option is displayed by a motor symbol (default)
- The motion of the slave axis should follow the time. This option is displayed by a clock symbol

This attribute can always be edited.

ΔY ΔY represents the relative distance of the slave axis within the focused motion step and is specified in the unit of the slave axis.

Changing ΔY results in the immediate calculation of Y_2 .

This attribute cannot be edited if the step type is a "FlexStep with absolute slave axis position" or if the current motion law defines the distance.

- ΔX** ΔX represents the relative master axis range of the focused motion step with regard to the master axis and is given in the unit of the master axis.
Changing ΔX results in the immediate calculation of X_2 and ΔT .
This attribute cannot be edited if the reference of the slave axis is the time (the value is then calculated by specifying the master axis velocity and ΔT).
This attribute cannot be edited if the step type is a "FlexStep with an absolute master axis position" or if the current motion law defines the master axis range.
- Minimum*
- $\Delta X \geq$ minimum increment
- Maximum*
- ΔX has an upper limit if a FlexStep with an absolute master axis end position follows and if ΔX would extend the focused step beyond the absolute master axis end position
- ΔT** ΔT represents the relative duration of the focused motion step measured in milliseconds.
Changing ΔT results in the immediate calculation of ΔX and X_2 .
This attribute cannot be edited if the reference of the slave axis is the master axis position (the value is then calculated by specifying the master axis velocity and ΔX).
This attribute cannot be edited if the step type is a "FlexStep with an absolute master axis position" or if the current motion law defines the master axis range.
- Minimum*
- $\Delta T \geq 1$ millisecond
- Maximum*
- ΔT has an upper limit if a FlexStep with an absolute master axis end position follows and if ΔT would extend the focused step beyond the absolute master axis end position

5.2.4 Attributes of the form-based section

The attributes of the form-based section refer to the focused motion step.

Step type There are two categories of step types.

- **Default step**

At the time of creation, a default step has defined boundary values (X_1 , Y_1 , V_1 , A_1 , J_1 , X_2 , Y_2 , V_2 , A_2 , J_2). The motion path is calculated based on these values. The motion path of a default step is thus fix and does not change at runtime.

Use any motion law for this step type.

- **FlexStep**

A FlexStep is an active step, i.e it applies the boundary values of the starting point at runtime from the real values (X_1 , Y_1 , V_1 , A_1 , J_1) and the boundary values of the end point from the predefined values (ΔX or X_2 , ΔY or Y_2 , V_2 , A_2 , J_2). The motion path is calculated at runtime in such a way that no velocity jumps result.

There are four different FlexStep types

- **FlexStep with relative distance and relative master axis range**

Editing and analyzing cams

ΔX and ΔY are user-defined.

X_2 is calculated from $X_1 + \Delta X$

Y_2 is calculated from $Y_1 + \Delta Y$

– **FlexStep with absolute slave axis end position and relative master axis range**

Y_2 and ΔX are user-defined

ΔY is calculated from $Y_2 - Y_1$

X_2 is calculated from $X_1 + \Delta X$

– **FlexStep with relative distance and absolute master axis end position**

This step type cannot be selected for time-dependent motion steps.

X_2 and ΔX are user-defined

ΔX is calculated from $X_2 - X_1$

Y_2 is calculated from $Y_1 + \Delta Y$

– **FlexStep with absolute slave axis end position and absolute master axis end position**

This step type cannot be selected for time-dependent motion steps.

Y_2 and X_2 are user-defined.

ΔX is calculated from $X_2 - X_1$

ΔY is calculated from $Y_2 - Y_1$

Use only motion laws of the "General motion type" (polynomial 5th order or polynomial 7th order) for a FlexStep.

If a FlexStep is selected, and the current motion law does not match, there is an automatic changeover to a polynomial 5th order.

The step type attribute can be edited if the subsequent step is a default step. If the last step is focused and the starting velocity and the starting acceleration are identical to the end velocity and the end acceleration of the cam (cyclical design of cam), the first step of the cam is used as subsequent step.

Motion law The motion law defines the **motion of the slave axis**, to be performed between the starting and end points of the focused motion step.

The different motion laws are described in detail in [chapter 11 "Motion laws" on page 89](#).

The motion law is selected using the following dialog:




Fig. 5-3: Dialog: Motion law selection

The dialog is sub-divided into two sections:

At the top, there is a filter option which is used to display only specific motion laws, e.g. only for MotionProfile.

The lower sections displays the motion laws.

Existing cam tables for the focused cam can be uploaded as a motion law under the category "Cam Table". Only the cam tables used as motion law are saved together with the cam. Imported cam tables which are not used are no longer accessible once the cam has been closed and reopened.

Not all motion laws can always be selected. If the preceding step ends in rest, the focused motion step has to be continued with rest or a general motion law. If the step type is not a default step, only two motion laws of the general motion type (polynomial 5th order and 7th order) are available.

Starting point X1

X_1 is the master axis position at the starting point of the focused motion step in the master axis unit.

Minimum

- $X_1 \geq 0$

Maximum

- X_1 has an upper limit if a FlexStep with an absolute master axis end position follows and if X_1 would extend the focused step beyond the absolute master axis end position

Editing and analyzing cams

- Y1** X_1 is the **slave axis position at the starting point** of the focused motion step in the slave axis unit.

This attribute cannot be edited if Y_2 of the preceding step cannot be edited.



Y_1 , the offset of the first motion step, serves only for the purpose of illustration in the CamBuilder and is deducted during transmission into the devices.

- V1** V_1 is the **velocity at the starting point** of the focused motion step. The unit depends on the selected slave axis scaling.

This attribute cannot be edited if it is automatically calculated by the selected motion law or if V_2 of the preceding step cannot be edited.

- A1** A_1 is the **acceleration at the starting point** of the focused motion step. The unit depends on the selected slave axis scaling.

This attribute cannot be edited if it is automatically calculated by the selected motion law or if A_2 of the preceding step cannot be edited.

- J1** A_1 is the **jerk at the starting point** of the focused motion step. The unit depends on the selected slave axis scaling.

This attribute cannot be edited if it is automatically calculated by the selected motion law or if J_2 of the preceding step cannot be edited.

- End point X2** X_2 is the master axis position at the end point of the focused motion step in the master axis unit.

In case of a motion step in the cam including an absolute master axis end position as its step type, the X_2 change of the other motion steps is limited by this point.

The following applies if the focused motion step lies before the step with an absolute master axis end position:

$$(X_{1 \text{ focus}} + \text{minimum increment} \leq X_{2 \text{ focus}} \leq X_{2 \text{ fix}} + \text{minimum increment})$$

This attribute X_2 cannot be edited if the reference of the slave axis is the time (the value is then calculated by the master axis velocity and ΔT .)

The attribute X_2 cannot be edited if the step type is a FlexStep with a relative master axis range or if the motion law is an extended motion law with acceleration-limited motion trapezoid profile, with an acceleration-limited motion sinusoid profile or with a jerk-limited motion.

Minimum

- $X_2 \geq X_1 + \text{minimum increment}$

Maximum

- X_2 has an upper limit if a FlexStep with an absolute master axis end position follows and if X_2 would extend the focused step beyond the absolute master axis end position

- Y2** Y_2 is the **slave axis position at the end point** of the focused motion step in the slave axis unit.

This attribute cannot be edited if it is automatically calculated by the selected motion law or if Y_1 of the preceding step cannot be edited.

- V2** V_2 is the **velocity at the end point** of the focused motion step. The unit depends on the selected slave axis scaling.

This attribute cannot be edited if it is automatically calculated by the selected motion law or if V_1 of the preceding step cannot be edited.

A2	A_2 is the acceleration at the end point of the focused motion step. The unit depends on the selected slave axis scaling. This attribute cannot be edited if it is automatically calculated by the selected motion law or if Y_1 of the preceding step cannot be edited.
J2	J_2 is the jerk at the end point of the focused motion step. The unit depends on the selected slave axis scaling. This attribute cannot be edited if it is automatically calculated by the selected motion law or if Y_1 of the preceding step cannot be edited.
Maximum values Vmax	V_{max} is the maximum velocity of the focused motion step. The unit depends on the selected slave axis scaling. This attribute cannot be edited if it is automatically calculated by the motion law selected in the focused motion step.
Amax	A_{max} is the maximum acceleration of the focused motion step. The unit depends on the selected slave axis scaling. This attribute cannot be edited if it is automatically calculated by the motion law selected in the focused motion step.
Jmax	J_{max} is the maximum jerk of the focused motion step. The unit depends on the selected slave axis scaling. This attribute cannot be edited if it is automatically calculated by the motion law selected in the focused motion step.
Cmdyn	The drive torque course due to dynamic load by inertial forces depends on the product resulting from velocity and acceleration. Thus, the maximum values of this product are defined as dynamic maximum characteristic values: $C_{mdyn} = \text{Maximum value } (V * A)$ The unit depends on the selected slave axis scaling. This attribute can never be edited and is always calculated automatically.
Turning point displacement	The turning point displacement specifies at which point the curving behavior changes for a symmetrical motion law. The turning point displacement can either be changed with the slider or by entering a percentage value between 0 and 1. This attribute can be edited for all symmetric "Rest-in-rest" motion laws.
Description	The description includes brief user-defined information on the focused motion step. This attribute can always be edited.

5.2.5 Calculating the motion step

The cam is recalculated after each entry (changing to another input field or confirming by means of the <Enter> key). If the calculation is not possible, the incorrect input fields are highlighted and detailed information is provided. The motion step is only applied if all entries are correct.

By means of the "Undo motion step" function, all changes that have been made since the motion step was successfully calculated the last time can be undone.

If an action is to be performed, which requires the focused motion step in a calculated format, e.g. another motion step is highlighted in the table as an active motion step or a new motion step is to be inserted, the active motion step has to be error-free.

In case of incorrect entries, the last focused motion step remains active until all the inputs are correct or have been undone.

Editing and analyzing cams

5.2.6 Undo/redo editing

The **Edit ► Undo** menu allows the last 50 processes, which have been performed on the focused cam since the last save, to be undone.

Once editing has been undone, it can still be redone providing no further changes have been made to the cam.

5.2.7 Absolute editing of the slave axis position (Y-values)

If the Y-value or ΔY in a motion step is changed in the **"Absolute edit mode"**, only this individual value is changed and the rest of the position profile remains at the original position.



If the change to a motion step results in the limit values of the subsequent step no longer matching its motion law, the distance of the subsequent step is regarded as a fixed value and the motion law is sporadically set to a Polynomial 5th order.

In the following example, the distance of the 3rd motion step cannot be edited that. That is why the distance of the 4th motion step is adjusted.

Example:

Absolute editing of ΔY




Fig. 5-4: Absolute edit mode




Fig. 5-5: Changing ΔY in the second motion step by -50 degrees

5.2.8 Relative editing of the slave axis position (Y-values)

If the Y-value or ΔY in a motion step is changed in the **"Relative edit mode"**, the remainder of the position profile is displaced in the Y-direction by the value of the change.



If the change to a motion step results in the limit values of the subsequent step no longer matching its motion law, the distance of the subsequent step is regarded as a fixed value and the motion law is sporadically set to a Polynomial 5th order.

Example:

Relative editing of ΔY



Fig. 5-6: Relative edit mode




Fig. 5-7: Changing ΔY in the second motion step by -50 degrees

5.2.9 Absolute editing of the master axis range (X-values)

In case of changes to the master axis range (ΔX , ΔT , X_1 or X_2) of individual motion steps in the **"Absolute edit mode"**, the total length of the cam is retained. This means that the change to the length of an individual motion step changes the length of the preceding or subsequent motion step.

Editing and analyzing cams

This mode is recommended if, for example, a cam with a fixed length of 360 degrees is to be edited and a motion step in the cam has to be shortened or extended, but the total length of the cam has to be retained.

If, in the "Absolute edit mode", a (new) motion step extends in the X-direction beyond one or more subsequent steps, these steps are overwritten.

Example:

Absolute editing of ΔX or X_n




Fig. 5-8: Absolute edit mode




Fig. 5-9: Changing ΔX in the second motion step by +40 degrees

5.2.10 Relative editing of the master axis range (X-values)

The total length of the cam changes with a change to the master axis range (ΔX , ΔT , X_1 or X_2) of individual motion steps in the "Relative edit mode". The ΔX or ΔT values of the preceding and subsequent motion steps are not changed.

This mode is recommended if, for example, a cam is being created for the first time or if time-dependent motion steps have to be identified. If, for example, the duration of a motion step is shortened, the duration of the total cam is also shortened.

Example:

Relative editing of ΔX or X_n




Fig. 5-10: Relative edit mode




Fig. 5-11: Changing ΔX in the second motion step by +40 degrees

5.2.11 Editing the motion step cam table

If the focused motion step includes a cam table as motion law, in addition to selecting the motion law, a modal window can be opened via an interface for editing the cam table.




Fig. 5-12: Icon: Edit cam table

All **% values** of the cam table can be **edited** in this window.

Points can be **deleted**. In this case, the X-values are recalculated and the existing Y-values retain their values. At least 3 points have to remain.

New points will be **added** after the focused line, the X-values are recalculated and the existing Y-values retain their value. At least 3 and max. 1.024 points can be entered.

The X-values are always specified as a unit of the master axis and the Y-values are recorded as a percentage value. In the cam table, the first X-value always corresponds to the first master axis position of the motion step and the last X-value corresponds to the last master axis position of the motion step.

5.2.12 Adding a new step after the focused step

This function adds a new motion step at the end of the focused motion step and gives ΔX the default step size from the options and the motion law "General motion - Polynomial 5th order".

The limit values of the starting point of the new motion step are applied from the focused end point.

If the **"Relative edit mode"** is active, the total length of the cam increases.

Editing and analyzing cams

The limit values of the end point are, if available, applied by the starting point of the subsequent motion step. If there is no subsequent motion step, the limit values are assigned "0" values.

If the **"Absolute edit mode"** is active, the total length of the cam is retained.

The boundary values of the end point are assigned the values of the previous subsequent step at its point ($X_1 + \text{default step size}$) and the subsequent step is shortened by the default step size. If this is not possible, a clear and understandable message appears explaining why a step cannot be inserted at this position. If there is no subsequent motion step, the limit values are assigned "0" values.

The inserted motion step is activated following the insertion.

Example:




Fig. 5-13: Absolute edit mode




Fig. 5-14: A new step is added at the end of the 2nd motion step

Example:




Fig. 5-15: Relative edit mode




Fig. 5-16: A new step is added at the end of the 2nd motion step

5.2.13 Adding a new step before the focused step

The "Add before" function adds a new motion step before the focused motion step and gives ΔX the default step size and gives the motion law the Polynomial 5th order.

The limit values of the starting point of the new motion step are applied from the end point of the preceding step.

If the **"Relative edit mode"** is active, the total length of the cam increases.

All subsequent steps are displaced backwards by ΔX .

If the **"Absolute edit mode"** is active, the total length of the cam is retained. The limit values of the end point are assigned the values of the previous step focused at its point ($X_1 + \text{default step size}$) and the previous step is shortened by the default step size. If this is not possible, a clear and understandable message appears explaining why a step cannot be inserted at this position.

The new inserted step is activated after the insertion.

Example:



Fig. 5-17: Absolute edit mode

Editing and analyzing cams




Fig. 5-18: A new step is added at the end of the 2nd motion step

Example:



Fig. 5-19: Relative edit mode




Fig. 5-20: A new step is added at the start of the 2nd motion step

5.2.14 Deleting a focused motion step

A cam requires at least one motion step. If a cam consists of more than one motion step, the focused motion step can be deleted.

If the **"Relative edit mode"** is active, the total length of the cam decreases.

If the **"Absolute edit mode"** is active, the total length of the cam is retained.

The total length is retained by the subsequent motion step (if not available, by the preceding step), extended by ΔX of the step to be deleted. If this is not possible, the motion step cannot be deleted.

Example:



Fig. 5-21: Absolute edit mode




Fig. 5-22: Deleting motion step 2

Example:



Fig. 5-23: Relative edit mode

Editing and analyzing cams




Fig. 5-24: Deleting motion step 2

5.3 Event editor

5.3.1 Overview

The event editor is used to define events.

Call: Menu **View** ► **Other windows** ► **Event editor**




Fig. 5-25: Event editor - CamBuilder

The **FlexProfile** supports the event control. **Events** can be assigned to motion steps. Events consist of a **trigger** and an **action**. Bits of the AxisData structure can be set during the execution time of the FlexProfile via the action of an event. The PLC offers solutions to react to these events.

Add an event to a focused motion step via the toolbar in the CamBuilder.



Fig. 5-26: Icon: Add event

5.3.2 Attributes

- | | |
|--------------------|--|
| No. | The number is assigned automatically and serves to identify the event. |
| Motion step | Each event is assigned to a certain motion step (Selection option: All motion steps of the focused cam). |

Trigger	The trigger is the criteria when the event is triggered: • PLC signal The event is triggered if the PLC signal is set during execution of the assigned motion step. • Absolute slave axis position reached The event is triggered when the master axis position entered in the assigned motion step is reached. • Relative slave distance moved The event is triggered when the slave axis position entered in the assigned motion step is reached. • Absolute master axis position reached The event is triggered when the master axis position entered in the assigned motion step is reached. Similarly to a programmable limit switch, the current position of an axis can be monitored. If it crosses a specified position in the current motion step, the event occurs. • Relative master distance moved The event is triggered when the master axis position entered in the assigned motion step is reached. • Time elapsed The event is triggered when the time specified as value has lapsed during the execution of the assigned motion step.
Value	The value depends on the trigger (position, travel distance or time).
Unit	The unit is displayed depending on the selected trigger (position and travel distance, specified in the unit of the master or slave axis, time in s).
Bit	If the trigger criteria is fulfilled during the execution of the assigned motion step, the selected bit of the AxisData structure is set. (Selection options: Bit0 to Bit15).
Action	The action defines when the bit should be set: • Set bit immediately The selected bit is set immediately. • Set bit at the end of the motion step The selected bit is set after executing the selected motion step. • Set bit at the end of the profile The selected bit is set after executing the last motion step at the end of the profile. • Set bit immediately and immediately connect next motion step The selected bit is set immediately and the next motion step is executed. If the next motion is a FlexStep, the limit values can be applied dynamically during runtime and the transition can be started without jerks.



If one or more events are assigned to a motion step, they are displayed in the Graph editor in the lower right area as active lighting symbol. The event editor opens by clicking on the symbol.

If a cam with events is displayed in a preview, it is displayed at which time which bit is activated.

Editing and analyzing cams

5.3.3 Functionality

Creating a new event

Icon: 

A standard event is inserted at the end of the event list. (Motion Step: focused step; trigger: PLC signal; bit: Bit0; action: set immediately).

Editing

Events can be edited in this list.

Remove event

Icon: 

The event focused in the list is removed.

Undo

Icon: 

Undoes the most recent change.

Restore

Icon: 

If a change has been undone, this function restores it again.

Help

Icon: 

Opens the Event Editor chapter of the CamBuilder online help.



By downloading a cam, the events are written in the corresponding parameter.

If a cam contains events, they are generated using the PLC function block for the FlexProfile generation.

If a motion step number changes, as e.g. an additional step is inserted, events remain assigned to the originally assigned motion step. If a motion step is removed, the events belonging to the motion step are also removed.

5.4 Variable editor

5.4.1 Overview

The variable editor defines variables of a cam definition.

Call: Menu **View** ► **Other windows** ► **Variable editor - CamBuilder**

Variables can be used in formulas (see [chapter 5.5 "Formula editor" on page 57](#)) of the cam input fields. When generating a PLC function block to parameterize a FlexProfile, these variables are displayed as inputs at the block.




Fig. 5-27: Variable editor - CamBuilder

5.4.2 Attributes

Name The variable name has to be IEC-compliant and unique.

If a variable value is changed, all references to this variable are renamed.

Variables can also be defined as variable fields. For example: "Range[1]" and "Range[2]". When generating a PLC function block, only the variable field is displayed at the input of the block.

Value	The variable value can be defined user-specifically and is displayed as default value when generating a PLC function block.
References	The field "References" cannot be edited. All abbreviations of formula fields referencing the variable are listed.
Description	Variable descriptions are displayed as comment in the PLC function block when declaring the variable.

5.4.3 Functionality

Creating a new variable

Icon: 

A new variable is added to the variable list.

Editing

Variables can be edited in this list.

Remove variable

Icon: 

The variable focused in the list is removed unless it is not used anymore in the cam definition.

Undo

Icon: 

Undoes the most recent change.

Restore

Icon: 

If a change has been undone, this function restores it again.

Help

Icon: 

Opens the Variable Editor chapter of the CamBuilder online help.



If values are calculated using formulas or variables in a cam definitions, the relative editing mode is used for the recalculation.

5.5 Formula editor

5.5.1 Overview

The formula editor is used to enter formulas to calculate cam properties.




Fig. 5-28:

The use of formulas instead of constant input values when defining cams allows to variably define certain values of a cam definition. If a PLC function block is generated using the CamBuilder definition using a "variable" cam definition, different cam variants can be parameterized as FlexProfile via variable inputs using this block.

The formula editor opens automatically if an "=" character was entered in an input field.

Editing and analyzing cams

The following input fields support the input of a formula if they are not automatically calculated:

Motion step editor

- Distance of the slave axis (ΔY)
- Master axis range (ΔX)
- Duration of the motion step (ΔT)
- Velocity in the starting point of the motion step (V_1)
- Velocity in the end point of the motion step (V_2)
- Velocity limit value of motion step ($V_{\max}$)
- Acceleration in the starting point of the motion step (A_1)
- Acceleration in the end point of the motion step (A_2)
- Acceleration in the motion step ($A_{\max}$)
- Jerk in the starting point of the motion step (J_1)
- Jerk in the end point of the motion step (J_2)
- Jerk limit value of motion step ($J_{\max}$)

Event editor

- Motion step number
- Trigger value



If the motion step number of an event is calculated with a formula, the result is rounded as integer.

5.5.2 Functionality

Editing formula

Edit formulas via the formula text field.

Apply formula and close (OK)

Icon:

The formula is checked and if valid, the calculated formula result is applied to the cam definition. The formula editor is closed.

Applying the formula (refresh)

Icon:

The functionality is as described. Only the formula editor remains open.

Removing formula

Icon:

The formula of the current CamBuilder input field is removed and the last value is used as constant value of the input field instead.

Help

Icon:

Opens the "Formula editor" chapter of the CamBuilder online help.



Changes are not applied when clicking on <Esc> or closing the editor.

Click on <Enter> or exit the editor by selecting a different input field, the changes are applied.

If values are calculated with formulas in a cam definition, the relative editing mode is used for recalculation.

5.5.3 Keyword formula

Mathematical operators

+	Addition
-	Subtraction
*	Multiplication
/	Division
()	Brackets

Tab. 5-1: Formula editor, mathematical operators

Constants

E	Euler number e
PI	Pi

Tab. 5-2: Formula editor, constants

Mathematical functions

ABS(n)	Returns the absolute value of the transferred number
ACOS(n)	Returns an angle whose cosine is the specified number (radian)
ASIN(n)	Returns an angle whose sine is the specified number (radian)
ATAN(n)	Returns an angle whose tangent is the specified number (radian)
CEILING(n)	Returns the smallest integer number that is greater or equal to the specified number The return value for n = 7.03 is 8 The return value for n = 7.64 is 8 The return value for n = 0.12 is 1 The return value for n = -0.12 is 0 The return value for n = -7.1 is -7 The return value for n = -7.6 is -7
COS(n)	Returns the cosine of the specified angle (radian)
DEG_TO_RAD(n)	Converts an angle from degrees to radian
EXP(n)	Returns the specified power of e
EXPT(n1,n2)	Exponentiates a specified number with the specified exponent
FLOOR(n)	Returns the largest integer number that is smaller or equal to the specified number The return value for n = 7.03 is 7 The return value for n = 7.64 is 7 The return value for n = 0.12 is 0 The return value for n = -0.12 is -1 The return value for n = -7.1 is -8 The return value for n = -7.6 is -8
LN(n)	Returns the natural logarithm of a specified number
LOG(n)	Returns the logarithm for basis 10 of the specified number

Editing and analyzing cams

MAX(n1,n2)	Returns the greater number of two specified numbers
MIN(n1,n2)	Returns the smaller number of two specified numbers
RAD_TO_DEG(n)	Converts an angle from radian to degrees
SIGN(n)	Returns a value that specifies the sign of a number The return value is -1, if n is smaller than 0 The return value is 0, if n is equal to 0 The return value is 1, if n is greater than 0
SIN(n)	Returns the sine of the specified angle (radian)
SQRT(n)	Returns the square root of a specified number
TAN(n)	Returns the tangent of the specified angle (radian)
TRUNC(n)	Calculates the integer part of a number

Tab. 5-3: Formula editor, mathematical functions

Cam attributes

MASTERVELOCITY	Master axis velocity
DYn	Slave axis range of motion step n
DXn	Master axis range of motion step n
DTn	Duration of motion step n
Vn	Initial velocity of the motion step n or end velocity of the motion step n+1
An	Initial acceleration of the motion step n or end acceleration of the motion step n+1
Jn	Initial jerk of the motion step n or end jerk of the motion step n+1
VMAXn	Velocity limit value of motion step n
AMAXn	Acceleration limit value of motion step n
JMAXn	Jerk limit value of motion step n
EVENT_STEPn	Assigned motion step of the event n
EVENT_VALUEn	Trigger value of event n

Tab. 5-4: Formula editor, references to fields



References to cam properties that are defined by motion laws are not supported! Only references to editable cam properties can be used in formulas.

User-defined variables

Variable1	Sample variable (see chapter 5.4 "Variable editor" on page 56)
Variable2	Sample variable
ArrayVariable[1]	Sample variable array
ArrayVariable[2]	Sample variable array

Tab. 5-5: Formula editor, references to variables

5.6 Application-specific wizard

5.6.1 General information

Call: When creating a new cam in the "Application-specific wizard" dialog field

Depending on its type of application, an application-specific cam has a special wizard used to edit the entire cam.

The screenshot shows the 'Create new cam' dialog box with the 'General settings' tab selected. The 'Name' field is set to 'Cam1'. The 'Description' field is empty. The 'Application Specific Wizard' dropdown menu is open, showing a list of options: 'None', 'Cross cutter', 'Feeder', 'Print length correction', 'Flying Shear', and 'Position'. The 'Slave axis' section includes 'Scaling' (Rotary (degree)), 'Position' (deg), 'velocity' (rpm), 'Acceleration' (rad/sec²), and 'Jerk' (rad/sec³). The 'Identical velocity at start and end point (cyclic execution)' checkbox is checked. Buttons for 'Finish', 'Cancel', and 'Help' are at the bottom.

Fig. 5-29: Create new cam - Application-specific wizard

Re-edit single motion steps later at any time using the Motion Step Editor (see [chapter 5.2 "Motion step editor" on page 38](#)). However, as soon as a change has been made using the wizard, all Motion Step Editor changes are overwritten.

5.6.2 CrossCutter wizard

The CamBuilder provides a wizard for common requirements, such as the CrossCutter functionality, which supports the user in creating the cam. All requirements and unique features of the application are dialog-controlled.

Editing and analyzing cams




Fig. 5-30: Application-specific wizard - "CrossCutter"

The specific inputs for the CrossCutter functionality are:

- Format length
- Roll diameter (D)
- Cutting angle
- Velocity of the master axis

Another parameter is calculated by the wizard:

- CompControlGradientValue
Gradient in the synchronous range

5.6.3 Feed wizard

The CamBuilder provides a wizard for common requirements, such as the feed function, which supports the user in creating the cam. All requirements and special features of the application are set using dialog-controlled inputs.

Feeder1 - CamBuilder

Feeder

Product length (L): 100 mm

Roller position (P): 40 mm

Roll diameter (D): 30 mm

Distance between products (S): 5 mm

Acceleration distance (A): 30 mm

Master axis velocity: 1 rpm

☐ FeederControlAutoDecel

FeederControlMaxDecel: 0.05 rad/sec²

Production Unit

Synchronized To Master

Material

D Roller-diameter

P Roller-position

S Distance Between Products

A Acc. Distance

L Product Length

Apply Help

Motion step editor - Feeder1 Feeder1 - CamBuilder

Fig. 5-31: Application-specific wizard - "Feeder"

The specific inputs for the feed function are as follows:

- Product length (L)
- Roll diameter (D)
- Acceleration distance (A)
- Roller position (P)
- Distance between two products (S)
- Velocity of the master axis

To attain the feed configured in the CamBuilder, the distance factor during the download as points table has to be set equal to the distance factor for executing the application.

Editing and analyzing cams

5.6.4 Print length correction wizard

The CamBuilder provides a Wizard for common requirements, such as the print length correction that supports the user in creating the cam. All requirements and unique features of the application are dialog-controlled.




Fig. 5-32: Application-specific wizard - "Print length correction"

The specific inputs for the print length correction are as follows:

- CompControlDiameter
Diameter of the pressurized cylinder
- Format length
Length of the printing plate
- Correction value
- Velocity of the master axis

Another parameter is calculated by the wizard:

- CompControlGradientValue
Gradient in the synchronous range

5.6.5 FlyingShear wizard

The CamBuilder provides a Wizard for common requirements, such as the print length correction that supports the user in creating the cam. All the requirements and unique features of the application are dialog-controlled.




Fig. 5-33: Application-specific wizard - "FlyingShear"

Specific entries for the FlyingShear:

- Synchronous range - range within which the step is executed
- The motion law in the transition area - the modified sine curve, polynomial 3rd order, polynomial 5th order and polynomial 7th order motion laws are available.

Another parameter is calculated by the wizard:

- CompControlGradientValue
Gradient in the synchronous range

5.7 Cam table

The cam table is an overview of the complete behavior of the cam.

Call: If the cam is open, go to **View ▶ Other windows ▶ Cam table - CamBuilder** in the IndraWorks menu




Fig. 5-34: Cam table - CamBuilder

The user can specify the **number of data points** for the entire position profile. It is also possible to define with which **distance** the percentage values are to be calculated.

Specify the distribution of the points across the master axis range using the following option:

The last data point in the table belongs to X: 100% (Yes/No) (table format).

Assuming the number of data points is to be 1,024:

Yes:	The 100% are split to exactly 1,024 points for example		
	0.0000%	=	Point 1
	99.9023%	=	Point 1023
	100.0000%	=	Point 1024
No:	100% is divided between 1024 + 1 points		
	0.0000%	=	Point 1
	99.9024%	=	Point 1024
	100.0000%	=	Point 1

Tab. 5-6: The units in the columns depend on the master and slave axis units

The table is write-protected and has the following columns:


Number, Y [%], Master axis position, Slave axis position, Velocity, Acceleration, Jerk. The values refer to the master axis velocity defined in the motion step editor.

Copy the values of the table to the clipboard and apply them with "Insert".

5.8 Extreme values

The minimum and maximum values referred to the master axis velocity defined in the motion step editor for the entire cam are displayed in the extreme values list.

Call: If the cam is open, go to **View** ► **Other windows** ► **Extreme values - CamBuilder** in the IndraWorks menu



	Minimum	Maximum	Unit
Position	0,0000	120,0000	Positi...
Geschwindigkeit	-1,2500	1,2500	velocity
Beschleunigung	-0,0134	0,0134	Accel...
Ruck	-0,0047	0,0046	Jerk
Dynamischer Drehmoment	-0,0047	0,0046	Dyna...

Fig. 5-35: Extreme values - CamBuilder

The drive torque course due to dynamic load by inertial forces depends on the product resulting from velocity and acceleration. Thus, the maximum values of this product are defined as dynamic maximum characteristic values:

$$C_{\text{mdyn}} = \text{maximum value } (V_{\text{max}} * A_{\text{max}})$$

where V_{max} = maximum velocity and A_{max} = maximum acceleration.

5.9 Cam preview

Cams are graphically edited in the "GraphEditor" (see [chapter 5.1 "Graph editor" on page 35](#)).

To compare several cams with regard to a master axis, open the cams in a preview and analyze them.

A preview can be added to a "Cam Pool" in the Project Explorer.

Icon: 

Call: In the Project Explorer via the context menu of the "Cam Pool" node: **Add** ► **Preview** or via the IndraWorks library, tab CamBuilder > "Preview" using "drag and drop" (refer to [chapter 4.2 "Creating preview objects" on page 32](#)).



Depending on the selected operation mode in the application, differences to the preview can occur. Cam tables and MotionProfiles do not support any time-dependent steps or events.

Slave axis and master axis offset have to be explicitly specified when enabling the respective synchronous operation mode in the user program via function blocks. (e.g. MB_PhasingSlave, MB_Phasing for all operation modes or via the corresponding inputs at the ML_FlexProfile block)

Editing and analyzing cams

Preview window design




Fig. 5-36: Cams - Preview

A preview window consists of time-dependent position representation of a master axis and the optional time-dependent profile representations (position/velocity/acceleration/jerk) of the slave axes.

Move the individual positions in the preview window upwards or downwards via a system menu in the upper right corner of the respective preview. The previews can be distributed in the preview window and individual previews can also be closed.



Change the height of the individual previews with the mouse. The line between two previews is "held" using the mouse and the size is adjusted by moving the mouse.

If the <Ctrl> key is pressed when changing the size, the entire size of the preview can be adjusted.

Measuring function (1)

Move the measuring line in the selection mode (arrow) using the mouse. The measuring results are shown in the title bar of each preview. To measure another profile (position/velocity/acceleration/jerk), select it with the mouse. The measuring results refer to this profile.

Changing the view

Change the view using the same tools as the Graph Editor (see [chapter 5.1.4 "Changing the view" on page 36](#)).

The individual views of the previews are synchronized on the X axis. The same time range is always displayed.

Master axis properties (2)

Change the following attributes of the master axis representation using the link "Settings...":

- **Velocity**
The unit of the master axis velocity depends on the scaling
- **Preview time**
The unit of the preview time is milliseconds
- **Modulo**
Defines the overflow for the graphic representation

- **Scaling**
(rotary or translatory and unit)
- Properties of the slave axes (3)** Change the following attributes of the slave axis representation using the link "Settings..." of the slave axis:
 - **Modulo**
Defines the overflow for the graphic representation
 - **Master offset**
Defines the offset in the master axis range
 - **Slave offset**
Defines the offset in the slave axis range
 - **Execution mode**
Execution mode:
 - Cyclic
 - Cyclical with defined pause
The cyclic representation with a defined pause is used to preview cams started with the processing type "One-time execution" by cyclic events (e.g. of other cams) .
 - One-time
 - **Execution pause**
The master axis offset can either be entered in the master axis unit or in ms.

5.10 Preview of superimposed cams (XY)

Cams are graphically edited in the "GraphEditor" (see [chapter 5.1 "Graph editor" on page 35](#)).

To compare the superimposition of two translatory cams in x- and y-direction with regard to a master axis, open the cams in a preview and analyze them.

Icon: 

Call: In the Project Explorer via the context menu of the "Cam Pool" node: **Add ► Preview of superimposed cams (X/Y)** or via the IndraWorks library, tab CamBuilder > "Preview" using "drag and drop" (refer to [chapter 4.3 "Creating preview objects of superimposed cam motions" on page 32](#)).

The preview of the superimposed cams generally works like the simple cam preview (see [chapter 5.9 "Cam preview" on page 67](#)).

Editing and analyzing cams

Structure of the window




Fig. 5-37: Example: Preview of superimposed cams (X/Y)

The preview window consists of the representation of the master axis, the superimposed motion of the cams in x- and y-direction (3) and a representation of the resulting variables of the superimposed motion (velocity, acceleration and jerk).

The example shown above results from the cams shown below.

Die superimposed representation results in a triangular motion (3).

- (1) X-axis = Cam1
- (2) Y-axis = Cam2




Fig. 5-38:

Measuring function

Move the measuring line in the master axis representation or the representation of the resulting values Using the mouse in the selection mode (arrow). The measuring results are shown in the title bar of each preview.

Properties of the x- and y-axis

Change the following attributes of the axes using the links "X-axis..." and "Y-axis..." of the representation of the cam superimposition:

- **X-axis / Y-axis**

Selection of the translatable cam

- **Master axis offset**

Defines the offset in the master axis range of the selected cam

The master axis offset can either be entered in the master axis unit or in ms.

- **Slave axis offset**

Defines the offset in the slave axis range of the selected cam

- **Execution mode**

- Cyclic
- Cyclical with defined pause

The cyclic representation with a defined pause is used to preview cams started with the processing type "One-time execution" by cyclic events (e.g. of other cams) .

- One-time

6 Managing cams and preview objects in the IndraWorks project

General information	The CamBuilder manages cams and preview objects within the project and archives and restores them. They are managed in the Project Explorer below the "Cam Pool" node. Export a cam to use it outside the project as well. It is also possible to import existing cams into a project (refer to chapter 8 "Importing and exporting cams" on page 79). Cams can be downloaded or uploaded from the project to devices (refer to chapter 7 "Interacting with Bosch Rexroth devices" on page 75).
"Cam Pool" Create folder	Copy a "Cam Pool" folder from the IndraWorks library from the "CamBuilder" section to the project via drag&drop. Use the context menu of a "Cam Pool" node to create a new folder below this one. Cams and preview objects can also be created and edited in this folder. Rename or delete this folder via the context menu. A "Cam Pool" folder can be moved in the project. Several "Cam Pool" folders can exist in one project.
Opening a cam / Preview	Open a cam or a preview by double-clicking on the relevant symbol in the "Cam Pool" node in the Project Explorer. The relevant graphical view opens.
Saving a cam/Preview	Once a cam was edited in the project and is focused, changes can be permanently applied to the project via the menu item File ► Save (Ctrl+S). The menu item File ► Save all also saves changes to cams and preview objects currently not focused.
 If a preview is saved, all the cams in the preview are saved as well! When closing a project, all open documents are automatically saved (without confirmation)!	
Copying a cam/Preview	A cam or a preview can be copied in the Project Explorer. Select the cam to be copied. For the copying command, go to the context menu of the cam node or to the IndraWorks menu: Edit ► Copy.
Inserting a cam	A cam or a preview can also be re-inserted into the project after it has been copied. Select the target node in the "Cam Pool" of the Project Explorer. For the insertion command, go to the context menu of the "Cam Pool" node or to the IndraWorks menu: Edit ► Paste.
Renaming	Rename a Cam Pool, cam or preview clicking slowly twice on its name in the Project Explorer. Alternatively, highlight the object and rename it via the context menu. Another option is to access the "Properties" dialog via the cam context menu when the cam is open and to change the name.
Deleting	Delete a Cam Pool, cam or preview via the context menu by highlighting it in the Project Explorer. Alternatively, highlight the object and delete it with the key.

7 Interacting with Bosch Rexroth devices

7.1 Downloading cams to devices

7.1.1 General information

The CamBuilder supports communication to different devices in the IndraWorks project.

The devices either have to be in online or offline parameterization mode and require an interface to the CamBuilder in order to use the following functions.

The "Download cam" dialog is started via the context menu of a cam in the Project Explorer. The devices in the IndraWorks project, which are either in online or offline parameterization mode and support the download of cams, provide their cam parameters in an overview.

The parameters have different symbols for different operation modes:




Fig. 7-1: Device symbols for different operation modes

7.1.2 Downloading cams to cam table parameters

If the focused cam is to be downloaded to cam table parameters, a data point table - with percentage values of at least three and at maximum of the number of points supported by the device - is created for the complete course of the position profile.

The following information is required when downloading as cam table:

- **Number of data points**
- **Distance** - Factor to calculate the percentage values
- **Remove linear components of the cam**

This setting applies only to drives and removes the linear part of a cam.

This option is required if a gear reduction is parameterized in the drive and this gear reduction controls the linear forward motion and the cam controls only the compensating motion. This combination allows to quickly change the cams for the CrossCutter for example. For more information on the gear reduction, refer to the functional description of the device used.

- **The last data point in the table corresponds to X = 100%** - (Yes: 360° / No: 360° - dφ) (table format)

This setting only applies to drives. For control, the last data point always corresponds to X = 100%

To specify the calculation of the x-values, there are two different formats on the drive.

Assuming the number of data points is to be 1,024:

Historically:	The 100% are split to 1,024 + 1 point (Last table value for the master axis phase 360° - dφ)		
	0.0000%	=	Point 1
	99.9024%	=	Point 1024
	100.0000%	=	Point 1

Interacting with Bosch Rexroth devices

Current:	The 100% are split to exactly 1,024 points for example (Last table value for the master axis phase 360°)		
	0.0000%	=	Point 1
	99.9023%	=	Point 1023
	100.0000%	=	Point 1024



If the cam contains motion steps with time reference, the slave axis motion is calculated using the entered master axis velocity. The dynamic functionality is lost. The dynamics of the FlexSteps is also lost.

7.1.3 Downloading Cams to MotionProfile Parameters

To download a cam to MotionProfile parameters, it may only contain motion laws supported by the MotionProfile operation mode. The master axis range has to be rotatorily fixed at 360 degrees.

No further settings are required.



If the cam contains motion steps with time reference, the slave axis motion is calculated using the entered master axis velocity. The dynamic limit values are lost. The dynamics of the FlexSteps is also lost.

7.1.4 Downloading cams to FlexProfile parameters

To download a cam to FlexProfile parameters, it may only contain motion laws supported by the FlexProfile operation mode.

NOTICE

Cams start at a slave position $\neq 0$

If the cams start at a slave position $\neq 0$, the start value is always moved to 0 if the cam is loaded to a FlexProfile.

The required start value can be restored using the MB_PhasingSlave function block.

No further settings are required.

7.1.5 Downloading cams to a CF memory card

If an IndraMotion MLC/IndraLogic XLC is online in the project, cams can also be stored on its Compact Flash card.

Unlike as for parameters for cam tables, MotionProfiles and FlexProfiles, there is no predefined format for cams on the CF card. The user has to specify the desired format. The cam is then saved as file under its name specified in the CamBuilder. If the file already exists, a query is displayed prompting whether it should be overwritten.

7.2 Uploading cams from devices

The CamBuilder supports communication to different devices in the IndraWorks project.

The devices either have to be in online or offline parameterization mode and require an interface to the CamBuilder in order to use this function.

Interacting with Bosch Rexroth devices

The "Upload Cam" dialog is started via the context menu of a "Cam Pool" node in the Project Explorer via "Upload Cam from Device". The devices in the IndraWorks project that are either in online or offline parameterization mode and that support the cam upload, provide its cams ready for upload in an overview.

The parameters have different symbols for different operation modes:




Fig. 7-2: Device symbols for different operation modes

The process of uploading cams is identical for all cam types.

Only a specific name has to be entered when saving the cam in the IndraWorks project. The cam is then converted to the neutral CamBuilder format. Editing a cam is thus always identical in the CamBuilder, the format of the cam is only of significance when downloading it to a device.

7.3 Creating a PLC function block

A PLC code (in structured text) can be created for a function blocks using the CamBuilder. This function block writes the cam defined in the CamBuilder to the FlexProfile parameters of an IndraMotion MLC/IndraLogic XLC axis.

Create a PLC code for a cam via its context menu in the Project Explorer via the menu item "Create PLC function block". Alternatively, the code generation with open cam is started via the "PLC" button.



Fig. 7-3: Creating PLC function blocks

If a folder named "General module folder" (IndraLogic) is available in the current project, a new function block is automatically created for the selected "Cam1" under the name "ChangeFlexSet_Cam1" for example. The function block name consists of a prefix specified in the "Options" dialog (see [chapter 9.1 "CamBuilder options" on page 83](#)) and the cam name (non-IEC-compliant characters are replaced by the character "_").

If the folder "General module folder" does not exist in the current project, the generated PLC code is only displayed in an output window. From this window, the code text can be copied to the clipboard and can be used in other applications.



To create a variable function block, formulas with references to variables can be used in the CamBuilder instead of constant values for cam properties (see [chapter 5.5 "Formula editor" on page 57](#)).

Brief description of the function block

The created "ChangeFlexSet_Cam1" function block loads the motion steps and events of the cam defined in the CamBuilder to a FlexProfile of an IndraMotion MLC/IndraLogic XLC axis.

Interacting with Bosch Rexroth devices

Interface description




Fig. 7-4: "ChangeFlexSet_Cam1" function block

	Name	Type	Comment
VAR_IN_OUT	Axis	AXIS_REF	Contains information on the axis whose FlexProfile set is to be exchanged
VAR_INPUT	Execute	BOOL	Starts the action at a rising edge
	SetNumber	UINT	Selecting the FlexProfile (0 ... 3)
VAR_OUTPUT	Done	BOOL	Data was applied
	Active	BOOL	Processing of data after preprocessing running
	Error	BOOL	Indicates that an error occurred in the function block instance
	ErrorID	ERROR_CODE	Brief note on error cause
	ErrorIdent	ERROR_STRUCT	Detailed error information

Tab. 7-1: Interface of the "ChangeFlexSet_Cam1" function block



If formulas with variables are used in cam definitions (see [chapter 5.4 "Variable editor" on page 56](#)), the function block contains these as additional inputs of type "LREAL".

Signal-time diagram




Fig. 7-5: Signal-time diagram: ChangeFlexSet_Cam1

8 Importing and exporting cams

8.1 General information

Import or export cams from/to an IndraWorks project using the CamBuilder. The following formats are supported for these import/export functionalities:

- **CamBuilder file (*.XML)**
Internal CamBuilder format.
Enables an unrestricted further editing of the cam in other CamBuilder projects.
- **Parameter file (*.PAR)**
Parameter file for drives and controls (e.g. IndraDrive and IndraMotion MLC or IndraLogic XLC).
Enables parameter files to be uploaded to the target device using IndraWorks or DriveTop for example. The cam is converted into a cam table.
- **Cam table (*.CSV)**
The position values, velocity values, acceleration values and jerk values of the cam are saved in a file that can be read with Excel. This ensures that it can also be read via DriveTop. The cam is converted into a cam table.

8.2 Exporting cams

The export of a cam is started via the cam context menu in the "Cam Pool" node of the Project Explorer.

To further edit the cam in another project, export it as XML format and import it to the other project.

To analyze the cam with the **IndraSize** tool, export it to XML format and import it to IndraSize.

To transmit the cam to a drive using DriveTop for example, the PAR or CSV format can be used. The cam is exported and the exported file is read with DriveTop and the cam table is transmitted to the drive.

The CSV format is available to further analyze position values, velocity values, acceleration values and jerk values of a cam.

As CamBuilder file (*.xml)

Only the target location of the file has to be specified.

As parameter file (*.par)

Specify the following for an export as parameter file:

- **Device type** - The drive or control type on which the cam is to be stored
- **Cam table** - The parameter, to which the cam is to be saved, e.g. drives of the ECODRIVE family support two cams (P-0-0072 and P-0-0092)
- **Remove linear components of the cam**

Prerequisite: Device type = IndraDrive or EcoDrive

This setting applies only to drives and removes the linear part of a cam.

This option is required if a gear reduction is parameterized in the drive and this gear reduction controls the linear forward motion and the cam controls only the compensating motion. This combination allows to quickly change the cams for the CrossCutter for example. For more information on the gear reduction, refer to the functional description of the device used.

Importing and exporting cams

- **Address** - Address of the drive or control on which the cam is to be saved (limited between 0 - 100)
 - **The last data point in the table belongs to X: 100%**
Prerequisite: Device type = IndraDrive or EcoDrive
(Yes: 360° / No: 360° - dφ) (table format)
 - **Data for cam table**
 - **Number of data points** (limited from 3 to 1,024)
 - **Distance** - Factor to calculate the % values of the data point table
- As cam table (*.csv)** Specify the following when exporting the cam to **CSV format**:
- **Data format**
 - **Field separator**
Specifies the separator the values are exported with.
 - **Decimal separator**
Point or comma
 - **Field separator**
Comma or semicolon
 - **Backup in VisualMotion-8 format** (Option)
automatically exports in VisualMotion-8-csv-file format.
This setting automatically resets all other settings.
 - **Data for cam table**
 - **Number of data points** (limited from 3 to 1,024)
 - **Distance** - Factor to calculate the % values of the data point table
 - **The last data point in the table belongs to X: 100%**
(Yes: 360° / No: 360° - dφ) (table format)
 - **Remove linear components of the cam** - If this function is set, the data sent is modified. This functionality is only available for drives and also only for specific firmware versions. For more information refer to the functional description of the device used

This setting applies only to drives and removes the linear part of a cam.

This option is required if a gear reduction is parameterized in the drive and this gear reduction controls the linear forward motion and the cam controls only the compensating motion. This combination allows to quickly change the cams for the CrossCutter for example. For more information on the gear reduction, refer to the functional description of the device used.
 - **Additional data**
This setting enables the velocity profile, acceleration profile and the jerk profile to be exported as well
 - **Add information**
If this setting is not set, only the cam table is exported. Otherwise, the following information is added automatically:
 - Date created
 - CamBuilder version
 - User-defined name

- Column headings
- **Velocity**
- **Acceleration**
- **Jerk**

8.3 Importing cams

The import of a cam is started via the context menu of the "Cam Pool" node in the Project Explorer. Subsequently, the file to be imported has to be selected in the **Open file** dialog.

No further entries are required when importing the cam in XML format.

Sercos ASCII format files can include more than one parameter which contains a cam table. If a *.par file is selected for import and this file includes more than one cam table, the user gets all cam table parameters found for selection. The user can then select the cam table from this list.

The CamBuilder internally requires cam tables whose last y-data point corresponds to $X = 100\%$. To import a CSV file or a PAR file, specify the table format. If the last y-value equals 0.xxx % or +-99.xxx %, a last data point is automatically suggested in the input field.

9 CamBuilder options and cam properties

9.1 CamBuilder options

Call: IndraWorks menu **Tools** ► **Options** ► **CamBuilder**

Enter all general settings affecting the entire CamBuilder and all opened cams into the CamBuilder options.

Each change is permanently saved and thus preset at the CamBuilder restart.

The options are divided into two groups: "Settings" and "Graph":

CamBuilder settings




Fig. 9-1: CamBuilder - Options "Settings"



The defined default values are used when inserting new motion steps.

Setting options:

- **Default rotary motion step length (ΔX)**
 - Rotary motion step length
 - Translatory motion step length
- **Minimum rotary motion step length (ΔX)**

Minimum motion step lengths can be defined for the slave axis. When a change is applied to a motion step, it is checked whether the length of the focused step is greater than this setting.

 - Rotary motion step length
 - Translatory motion step length
- **PLC code generation**

FlexProfile function block name prefix

The name prefix is used to generate a PLC function block from a cam. The name of the function block consists of the prefix and the cam name.

CamBuilder options and cam properties

CamBuilder Graph - General




Fig. 9-2: CamBuilder - Options "Graph - General"

Setting options:

- **Mouse sensitivity**
 - **Snap radius**
Radius used around the mouse pointer to select objects (1-20 pixels, default 5).
 - ☒ **Snap to grid on editing**
If the option is enabled, it is snapped to the grid in the GraphEditor when a motion step is moved "manually" using a selection tool.
Click on the <Ctrl> key to disable this option while editing
- **Line type**
 - Focused profile thickness
 - Inactive profile thickness
 - Line type of the coordinate grid

CamBuilder options and cam properties

CamBuilder Graph - Colors




Fig. 9-3: CamBuilder - Options "Graph - Colors"

Predefined color schemes can be selected or changed:

Color presets

Color schemes of the GraphEditor:

- Default
- Light profiles - Dark background
- Dark profiles - Light background

Profile colors

Color specifications of the graph in the GraphEditor:

- Position (color of the position profile)
- Velocity (color of the velocity profile)
- Acceleration (color of the acceleration profile)
- Jerk (color of the jerk profile)

Other colors

Color specifications for further GraphEditor elements:

- Selected step
Color of the selected step (top and bottom)
- Background
Color of the graph background (top and bottom)
- Motion step borders
- Coordinate grid
- Measure cursor

9.2 Cam properties

Call: Via the context menu of the selected cam in the Project Explorer **properties**



Opening "Properties" automatically loads the corresponding cam.

CamBuilder options and cam properties

Properties - CamBuilder

Name: CamBuilder

Description:

Application Specific Wizard: None

Master axis

Scaling: Rotary (degree)

Position: deg

velocity: rpm

Slave axis

Scaling: Rotary (degree)

Position: deg

velocity: rpm

Acceleration: rad/sec²

Jerk: rad/sec³

☒ Identical velocity at start and end point (cyclic execution)

OK Cancel Apply Help

Fig. 9-4:

The properties to be edited correspond to those in the first step of the wizard for a new cam.

Refer to [chapter 4 "Creating cams and preview objects"](#) on page 31

10 Printing cams

The CamBuilder prints the different cams individually.

Select the following print settings via the "Print" context menu item in the Project Explorer:

- **Print the "Graphic representation" of the cam**
The current graphic output is printed. To enable this option, open a cam in the workspace
- **Print "Description" of the cam**
The cam description is printed. To enable this option, the cam has to include a description
- **Print "Application data" of the cam**
The application data is printed from the application wizard. To enable this option, the cam has to include an application wizard
- **Print "Motion Steps" of the cam**
Data of the individual motion steps (position, velocity, motion law, description, ...) is printed
- **Print "Extreme values" of the cam**
The content of the extreme values list is printed
- **Print "Cam table" of the cam**
Example: 1.024 percentage values of the slave axis position are printed

To print or to view a preview, select at least one of the options.

Motion laws

	Definition of the motion law at the input "MotionLaw" (ProfileStepAdr)		Travelling range		Boundary values left			Boundary value right			Max (not considered everywhere)			TPS possible	FlexStep possible	Operation modes
			Distance	Range	StVel	StAcc	StJerk	EndVel	EndAcc	EndJerk	MaxVel	MaxAcc	MaxJerk			
Polynomial 5th order	REST_IN_VELOCITY_P OLY5	512	*	*	0	0	=	*	0	=	=	=	=			CT, MP, FP
Polynomial 7th order	REST_IN_VELOCITY_P OLY7	768	*	*	0	0	0	*	0	0	=	=	=			CT, FP
Velocity-in-velocity																
Constant velocity	CONSTANT_VELOCITY	1536	*	*	=	0	0	=	0	0	=	=	=			CT, MP, FP
Polynomial 5th order	VELOCITY_IN_VELOCITY_P OLY5	1792	*	*	*	0	=	*	0	=	=	=	=			CT, MP, FP
Polynomial 7th order	VELOCITY_IN_VELOCITY_P OLY7	4096	*	*	*	0	0	*	0	0	=	=	=			CT, FP
Modified sinusoid	VELOCITY_IN_VELOCITY_MOD_SINE	4352	*	*	*	0	=	*	0	=	=	=	=			CT, FP
Velocity-in-rest																
Polynomial 5th order	VELOCITY_IN_REST_P OLY5	1024	*	*	*	0	=	0	0	=	=	=	=			CT, MP, FP
Polynomial 7th order	VELOCITY_IN_REST_P OLY7	1280	*	*	*	0	0	0	0	0	=	=	=			CT, FP
General motion																
Polynomial 2nd order	COMMON_POLY2	16896	*	*	*	=	=	=	=	=	=	=	=			CT
Polynomial 3rd order	COMMON_POLY3	17152	*	*	*	=	=	*	=	=	=	=	=			CT
Polynomial 4th order	COMMON_POLY4	17408	*	*	*	=	=	*	=	=	=	=	=	x		CT
Polynomial 5th order	COMMON_POLY5	16384	*	*	*	*	=	*	*	=	=	=	=		x	CT, FP
Polynomial 7th order	COMMON_POLY7	16640	*	*	*	*	*	*	*	*	=	=	=		x	CT, FP
Polynomial 8th order	COMMON_POLY8	17664	*	*	*	*	*	*	*	*	=	=	=			CT
Extended motion																
- Resulting distance																
Velocity 2nd Order (starting acceleration zero)	X_VEL_STARTACC	33280	=	*	*	0	=	*	=	=	=	=	=			CT

Motion laws

	Definition of the motion law at the input "MotionLaw" (ProfileStepAdr)		Trave rsing range		Boundar y values left			Boundar y value right			Max (not consider ed everywh ere)			TPS possi ble	FlexSt ep possibl e	Operati on modes
			Distance	Range	StVel	StAcc	StJerk	EndVel	EndAcc	EndJerk	MaxVel	MaxAcc	MaxJerk			
Velocity 2nd Order (end acceleration zero)	X_VEL_ENDACC	33280	=	*	*	=	=	*	0	=	=	=	=			CT
Linear velocity	X_LINEAR_VEL	33024	=	*	*	=	=	*	=	=	=	=	=			CT
Linear acceleration	X_LINEAR_ACC	32768	=	*	*	*	=	=	*	=	=	=	=			CT
- Resulting master axis range																
Acceleration start; motion (trapezoid profile)	X_FIT_VEL_TRAPEZE_ ALIM	7000	*	=	*	=	=	*	=	=	*	*	=			CT, FP
Acceleration start; sine curve	X_FIT_SINE_TRAPEZE _ALIM	28928	*	=	*	=	=	*	=	=	*	*	=			CT, FP
Jerk-lim. motion (trapezoid profile)	X_FIT_ACC_TRAPEZE _JLIM	29184	*	=	*	=	=	*	=	=	*	*	*			CT, FP
- Other																
Acceleration start, polynomial 5th order	X_MOTION_IN_MOTIO N_POLY5_VLIM	24576	*	*	*	*	=	*	*	=	*	=	=			CT, FP
Overshooting-free polynomial 5th order	X_MOTION_IN_MOTIO N_POLY5_SLIM	24832	*	*	*	0	=	*	0	=	=	=	=			CT, FP
Acceleration start (trapezoid profile)	X_VELOCITY_IN_VELO CITY_TRAPEZE_ALIM	20480	*	*	*	0	=	*	0	=	*	*	=			CT, FP
Point table																
Cam	CAMTABLE_1	1...99	*	*	=	=	=	=	=	=	=	=	=			CT, MP, FP

0

*

=

CT

MP

FP

Explicitly 0

User-defined

Calculated automatically

Cam table

MotionProfile

FlexProfile

Tab. 11-1: Boundary conditions of the FlexProfile motion laws

Note on distance for cam tables:**Cam tables with the same starting and end points:**

The complete cam table is scaled with the specified distance.

The starting point is moved to 0 by an addition constant. This procedure allows a smooth linking of multiple steps in one profile.

Motion laws




Fig. 11-1: Cam table, same starting and end point

Cam tables with different starting and end points:

The starting point is moved to 0 by an addition constant and the end point is scaled with the distance specified, thus ending at 100%.

The remaining cam table changed accordingly.

This procedure allows a smooth linking of multiple steps in one profile. Thus, only the sign of the distance indicates the direction of the distance to be traversed.

Negative cam tables are traversed in positive direction if the distance is positive.



This can cause a distortion/deformation of the cam, as the end does not have to be the point with the biggest distance.

Example: The following cam table is given (20% to 50%)




Fig. 11-2: Original cam table




Fig. 11-3: Result if distance is 360




Fig. 11-4: Result if distance is -360

11.2 Analytic functions

11.2.1 General information

The following motion laws enable a selection based on different criteria.

A high quality is achieved by reducing damaging oscillations and abrasion and noise are also minimized.

11.2.2 Rest-in-rest

There are twelve rest-in-rest motion laws available. These motion laws are only defined by the distance and the master axis range. Starting and end velocity are 0.

Rest-in-rest, standstill

(up to CamBuilder 08VRS: linear rest)

$$f(z) = 0$$

Fig. 11-5: Function: Rest-in-rest, standstill

Motion laws




Fig. 11-6: Graph: Rest-in-rest, standstill

Rest-in-rest, simple sine curve

Advantages

- Low velocity characteristic value
- Low acceleration characteristic value
- Low dynamic torque characteristic value

Disadvantages

- Acceleration jump
- Oscillations, noise, wear

$$f(z) = \frac{1}{2} [1 - \cos(\pi z)]$$

Fig. 11-7: Function: Rest-in-rest, simple sine curve




Fig. 11-8: Graph: Rest-in-rest, Sine curve (simple sine)

Rest-in-rest, inclined sine curve (Bestehorn sine)

Advantages

- Especially low jerk characteristic value
- Low oscillation, ideal for high speeds

Disadvantages

- Velocity characteristic value, acceleration characteristic value and dynamic torque characteristic value are higher than for the polynomial 5th order

$$f(z) = z - \frac{1}{2\pi} \sin(2\pi z)$$

Fig. 11-9: Function: Rest-in-rest, inclined sine curve (Bestehorn sine)

Motion laws




Fig. 11-10: Graph: Rest-in-rest, inclined sine curve (Bestehorn sinoide)

Rest-in-rest, acceleration-optimum inclined sine curve

$$f(z) = z - \frac{1}{2\pi} \sin(2\pi z)$$

$$g(z) = z - \frac{0.41}{2\pi} \sin(2\pi z)$$

Fig. 11-11: Function: Rest-in-rest, acceleration-optimum inclined sine curve

Motion laws




Fig. 11-12: Graph: Rest-in-rest, acceleration-optimum inclined sine curve

Rest-in-rest, moment-optimum inclined sine curve

$$f(z) = z - \frac{1}{2\pi} \sin(2\pi z)$$

$$g(z) = z - \frac{0.134}{2\pi} \sin(2\pi z)$$

Fig. 11-13: Function: Rest-in-rest, torque-optimum inclined sine curve

Motion laws




Fig. 11-14: Graph: Rest-in-rest, torque-optimum inclined sine curve

Rest-in-rest, sinoide of Gutman

$$f(z) = z - \frac{15}{32\pi} \sin(2\pi z) - \frac{1}{96\pi} \sin(6\pi z)$$

Fig. 11-15: Function: Rest-in-rest, Gutman sinoide




Fig. 11-16: Graph: Rest-in-rest, Gutman sinoide

Rest-in-rest, modified sine curve

Advantages

- Ideal for high speeds
- Low velocity characteristic value
- Low acceleration characteristic value
- Low dynamic torque characteristic value

Disadvantages

- Jerk characteristic value higher than for the inclined sine curve

$$\begin{aligned}
 0 \leq z \leq \frac{1}{8}: f(z) &= \frac{1}{4 + \pi} \left[\pi z - \frac{1}{4} \sin(4\pi z) \right] \\
 \frac{1}{8} \leq z \leq \frac{7}{8}: f(z) &= \frac{1}{4 + \pi} \left[2 + \pi z - \frac{4}{9} \sin\left(\frac{4\pi}{3} z + \frac{\pi}{3}\right) \right] \\
 \frac{7}{8} \leq z \leq 1: f(z) &= \frac{1}{4 + \pi} \left[4 + \pi z - \frac{1}{4} \sin(4\pi z) \right]
 \end{aligned}$$

Fig. 11-17: Function: Rest-in-rest, modified sine




Fig. 11-18: Graph: Rest-in-rest, modified sine

Rest-in-rest, modified acceleration trapezoid

Advantages

- Especially low acceleration characteristic value
- Low inertia forces

Disadvantages

- Jerk characteristic value higher than for the inclined sine curve

Motion laws

$$\begin{aligned}
 0 \leq z \leq \frac{1}{8}: f(z) &= \frac{1}{2+\pi} \left[2z - \frac{1}{2\pi} \sin(4\pi z) \right] \\
 \frac{1}{8} \leq z \leq \frac{3}{8}: f(z) &= \frac{1}{2+\pi} \left[-\frac{1}{2\pi} + 2z + 4\pi \left(z + \frac{1}{8} \right)^2 \right] \\
 \frac{3}{8} \leq z \leq \frac{1}{2}: f(z) &= \frac{1}{2+\pi} \left[-\frac{\pi}{2} + 2(1+\pi)z - \frac{1}{2\pi} \sin(4\pi z - \pi) \right] \\
 \frac{1}{2} \leq z \leq 1: f(z) &= 1 - f(1-z)
 \end{aligned}$$

Fig. 11-19: Function: Rest-in-rest, modified acceleration trapezoid




Fig. 11-20: Graph: Rest-in-rest, modified acceleration trapezoid

Rest-in-rest, quadratic parabola

$$\begin{aligned}
 0 \leq z \leq 0.5: f(z) &= 2z^2 \\
 0.5 \leq z \leq 1: f(z) &= 1 - 2(z-1)^2
 \end{aligned}$$

Fig. 11-21: Function: Rest-in-rest, quadratic parabola




Fig. 11-22: Graph: Rest-in-rest, quadratic parabola

Rest-in-rest, polynomial 5th order

Advantages

- Low velocity characteristic value
- Low acceleration characteristic value
- Low dynamic torque characteristic value
- Low forces and torques

Disadvantages

- Jerk characteristic value higher than for the inclined sine curve

$$f(z) = 6z^5 - 15z^4 + 10z^3$$

Fig. 11-23: Function: Rest-in-rest, polynomial 5th order

Motion laws




Fig. 11-24: Graph: Rest-in-rest, polynomial 5th order

Rest-in-rest, polynomial 7th order

$$f(z) = -20z^7 + 70z^6 - 84z^5 - 35z^4$$

Fig. 11-25: Function: Rest-in-rest, polynomial 7th order




Fig. 11-26: Graph: Rest-in-rest, polynomial 7th order

Rest-in-rest, polynomial 8th order

$$f(z) = A_8 z^8 + A_7 z^7 + A_6 z^6 + A_5 z^5 + A_4 z^4 + A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-27: Function: Rest-in-rest, polynomial 8th order




Fig. 11-28: Graph: Rest-in-rest, polynomial 8th order

11.2.3 Rest-in-velocity

Rest-in-velocity motion laws are used for impact-free and jerk-free transition from standstill to defined velocities.

Rest-in-velocity, polynomial 5th order

$$f(z) = A_5 z^5 + A_4 z^4 + A_3 z^3$$

Fig. 11-29: Function: Rest-in-velocity, polynomial 5th order




Fig. 11-30: Graph: Rest-in-velocity, polynomial 5th order

Rest-in-velocity, polynomial 7th order

Motion laws

$$f(z) = A_7 z^7 + A_6 z^6 + A_5 z^5 + A_4 z^4 + A_3 z^3$$

Fig. 11-31: Function: Rest-in-velocity, polynomial 7th order




Fig. 11-32: Graph: Rest-in-velocity, polynomial 7th order

11.2.4 Velocity-in-rest

Velocity-in-rest motion laws are used for impact-free and jerk-free transition from defined velocities to standstill.

Velocity-in-rest, polynomial 5th order

$$f(z) = A_5 z^5 + A_4 z^4 + A_3 z^3 + A_1 z$$

Fig. 11-33: Function: Velocity-in-rest, polynomial 5th order




Fig. 11-34: Graph: Velocity-in-rest, polynomial 5th order

Velocity-in-rest, polynomial 7th order

$$f(z) = A_7 z^7 + A_6 z^6 + A_5 z^5 + A_4 z^4 + A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-35: Function: Velocity-in-rest, polynomial 7th order




Fig. 11-36: Graph: Velocity-in-rest, polynomial 7th order

11.2.5 Velocity-in-velocity

Velocity-in-velocity motion laws are used for impact and jerk-free transition from defined velocities to other defined velocities.

Velocity-in-velocity, constant velocity

(up to CamBuilder 08VRS: Analytic G-G / linear interpolation)

The velocity is calculated using the specified distance and the given master axis range. Specify a constant velocity in the motion law "Extended, linear velocity" (see [chapter "Resulting distance" on page 112](#)).

$$f(z) = z$$

Fig. 11-37: Function: Velocity-in-velocity, Constant velocity




Fig. 11-38: Graph: Velocity-in-velocity, Constant velocity

Velocity-in-velocity, polynomial 5th order

$$f(z) = A_5 z^5 + A_4 z^4 + A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-39: Function: Velocity-in-velocity, polynomial 5th order

Motion laws




Fig. 11-40: Graph: Velocity-in-velocity, polynomial 5th order

Velocity-in-velocity, polynomial 7th order

$$f(z) = A_7 z^7 + A_6 z^6 + A_5 z^5 + A_4 z^4 + A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-41: Function: Velocity-in-velocity, polynomial 7th order




Fig. 11-42: Graph: Velocity-in-velocity, polynomial 7th order

Velocity-in-velocity, modified sine curve

$$\begin{aligned}
 0 \leq z \leq \frac{\lambda}{8}: f'(z) &= C_a \frac{\lambda}{2\pi} \left(z - \frac{\lambda}{2\pi} \sin \left(2\pi \frac{z}{\lambda} \right) \right) + f'(0)z \\
 \frac{\lambda}{8} \leq z \leq \lambda: f'(z) &= C_a \frac{\lambda}{2\pi} \left(z - \frac{9\lambda}{2\pi} \sin \left(2\pi \frac{z + \frac{\lambda}{2}}{3\lambda} \right) + \frac{4\lambda}{\pi} \right) + f'(0)z \\
 \lambda \leq z \leq 1 - \frac{1-\lambda}{4}: f'(z) &= C_b \frac{1-\lambda}{2\pi} \left(z - \frac{9(1-\lambda)}{2\pi} \sin \left(2\pi \frac{z + \frac{3-5\lambda}{3(1-\lambda)}}{3\lambda} \right) + \frac{4\lambda}{\pi} \right) \\
 &+ f'(1) + (f'(0) - f'(1)) \left(\frac{3}{4} - \frac{1}{\pi} \right) + \lambda \\
 1 - \frac{1-\lambda}{4} \leq z \leq 1: f'(z) &= -C_b \frac{1-\lambda}{2\pi} \left(z - \frac{1-\lambda}{2\pi} \sin \left(2\pi \frac{z + \lambda}{1-\lambda} \right) - 1 \right) \\
 &+ 1 + f'(1) + (z-1)
 \end{aligned}$$

Fig. 11-43: Function: Velocity-in-velocity, modified sine curve

Motion laws

11.2.6 General motion

Motion laws for general motion can always be used.

General motion, polynomial 2nd order

$$f(z) = A_2 z^2 + A_1 z$$

Fig. 11-44: Function: General motion, polynomial 2nd order




Fig. 11-45: Graph: General motion, polynomial 2nd order

General motion, polynomial 3rd order

$$f(z) = A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-46: Function: General motion, polynomial 3rd order




Fig. 11-47: Graph: General motion, polynomial 3rd order

General motion, polynomial 4th order

(Special case with turning point displacement 0.57735 up to CamBuilder 08VRS: Polynomial 4th order (S))

$$f(z) = A_4 z^4 + A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-48: Function: General motion, polynomial 4th order




Fig. 11-49: Graph: General motion, polynomial 4th order

Motion laws

General motion, polynomial 5th order

$$f(z) = A_5 z^5 + A_4 z^4 + A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-50: Function: General motion, polynomial 5th order




Fig. 11-51: Graph: General motion, polynomial 5th order

General motion, polynomial 7th order

$$f(z) = A_7 z^7 + A_6 z^6 + A_5 z^5 + A_4 z^4 + A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-52: Function: General motion, polynomial 7th order




Fig. 11-53: Graph: General motion, polynomial 7th order

General motion, polynomial 8th order

$$f(z) = A_8 z^8 + A_7 z^7 + A_6 z^6 + A_5 z^5 + A_4 z^4 + A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-54: Function: General motion, polynomial 8th order




Fig. 11-55: Graph: General motion, polynomial 8th order

Motion laws

11.2.7 Extended motion laws

Resulting distance

Extended, linear velocity

(up to CamBuilder 08VRS: V-CAM linear)

$$f(z) = A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-56: Function: Extended, linear velocity




Fig. 11-57: Graph: Extended, linear velocity

Extended, linear acceleration

(up to CamBuilder 08VRS: A-CAM linear)

$$f'(z) = A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-58: Function: Extended, linear acceleration




Fig. 11-59: Graph: Extended, linear acceleration

Extended, velocity 2nd order (starting acc. zero)

(up to CamBuilder 08VRS: V-CAM 2nd order (1))

$$f(z) = A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-60: Function: Extended, velocity 2nd order (starting acc. zero)




Fig. 11-61: Graph: Extended, velocity 2nd order (starting acc. zero)

Motion laws

Extended, velocity 2nd order (end acc. zero)

(up to CamBuilder 08VRS: V-CAM 2nd order (2))

$$f(z) = A_3 z^3 + A_2 z^2 + A_1 z$$

Fig. 11-62: Function: Extended, velocity 2nd order (end acc. zero)




Fig. 11-63: Graph: Extended, velocity 2nd order (end acc. zero)

Extended, resulting master axis range

These extended motion laws are special motion laws. They differ from the known motion laws from the VDI guidelines due to their new degrees of freedom. While a standard motion law is clearly defined by the details of its left-hand and right-hand limit values, the motion laws shown here enable even further different setting options such as a required maximum velocity. In this case, the master axis range of the motion step is not to be specified. Instead, this results from the parameterization of the motion law and the specification of characteristic values. Thus, for example, acceleration-limited motion allows the distance, starting and end velocity to be specified, but not the setting of a master axis range. The latter, and thus also the duration of the motion step, results from the maximum acceleration and maximum velocity values, which can also be specified.

Extended, acceleration-limited motion (trapezoid profile)

The trapezoid profile, often also known as a ramp profile, can be seen as the simplest form of path interpolation. If a path "s" should be traveled, it is accelerated up to a specified travel velocity in the first phase (acceleration phase) using a given acceleration value. In the second phase (constant phase), it is traveled with a constant velocity and finally, in the third phase (deceleration phase), it is decelerated with a predetermined delay. The function of the path interpolation is to calculate the starting and end points in time t_1 , t_2 and t_3 and the individual travel times T_1 , T_2 and T_3 from these specified acceleration values a_1 and a_3 as well as the desired velocity v_m and the distance to be traveled "s". In the variant shown, the required starting velocity v_0 and end velocity v_3 is also taken into consideration.

Extended, acceleration-limited motion (sine curve)

With the sine profile, the starting and end velocity can be unequal to "0" and have the different acceleration factors a_1 and a_3 for the acceleration and deceleration phase. Moreover, the special cases are also taken into consideration, in which the starting velocity v_0 is already greater than the required travel velocity v_m . The same also applies to the end velocity v_3 .




Fig. 11-64: Graph: Acceleration-limited motion (sine curve)

Extended, jerk-limited motion (trapezoid profile)

The acceleration with jerk limitation applies to many motion tasks, for example, to the transportation of fluids and to machines easily susceptible to vibration.

Motion laws




Fig. 11-65: Graph: Jerk-limited motion

Miscellaneous

Extended, velocity-limited polynomial 5th order

The polynomial 5th order, known from the VDI, allows no control of the maximum travel velocity. The motion law is subdivided into three sections to solve this problem. The middle section corresponds to a straight line with the required velocity. This is surrounded by two polynomials 5th order. This ensures a smooth transition from the starting to the travel velocity and from the travel to the end velocity. The intersecting points between the first and second and the second and third sections have to be determined. The points are selected in such a way that no turning point is set for the two polynomials.




Fig. 11-66: Graph: Velocity-limited polynomial 5th order

Extended, overshooting-free polynomial 5th order

The overshooting-free polynomial 5th order detects and prevents a possible polynomial overshoot. The kind of modification depends on the combination of the standardized boundary velocity values. Four cases result. This motion law cannot be used for combinations in which the normalized starting velocity V_1 and the normalized end velocity V_2 have different signs. This means that the motion path would have a bend at a limit point if it was not able to leave the standardized range of $0 \leq z \leq 1$ and $0 \leq f(z) \leq 1$.

- Case 1:
 $V_0 \leq 1$ and $V_1 \leq 1$




Fig. 11-67: Case 1

- Case 2:
 $V_0 \leq 1$ and $V_1 > 1$

Motion laws




Fig. 11-68: Case 2

- Case 3:
 $V_0 > 1$ and $V_1 \leq 1$




Fig. 11-69: Case 3

- Case 4:
 $V_0 > 1$ and $V_1 > 1$




Fig. 11-70: Case 4

11.3 Cam tables

The slave axis motion of a motion step can be defined by a cam table.




Fig. 11-71: Cam tables supported by the CamBuilder

To allocate a cam table to a motion step as a motion law using CamBuilder, the menu item **Cam Table ► Import Cam Table...** has to be selected as a motion law in the motion step editor or an existing imported table is selected. A new import dialog opens if a new table is to be imported.

There are three different options to select a cam table:

1. Importing a cam table from a cam of the current project

All the cams of the current project can be listed and selected in a selection dialog

Motion laws

2. Importing a cam table from a parameter file

3. Importing a cam table from a CSV file

With cams from the project, it is possible to state how many data points have to be created (at least 3, at most 1,024). Moreover, the distance to calculate the data points can be specified (if 0 is specified as distance factor, the CamBuilder automatically calculates a distance factor creating a point table with value 0% to 100%). Following the import, a memory space number has to be defined for the subsequent memory location on a device for this selected cam table.

It is distinguished between cams consists of one and cams consisting of multiple motion steps when handling cam tables in the CamBuilder.

Cams consisting of one motion step:

All cam table forms are supported here, that is cam tables whose end value is greater or less than the starting value. Starting values not equal to 0 are also allowed, as are cam tables with the same starting and end point (e.g. bell). The response is as for the MotionProfile, that is that points from the cam table are simply multiplied by the distance (no offset, no scaling).

Cams consisting of multiple motion steps:

Cam tables whose end point is greater than the starting point are scaled in such a way that they end at 100%. A starting point, which is not equal to 0%, is offset to 0%. Thus, the entire cam table is automatically adapted to the distance preset for the respective motion step. Cam tables with the same or smaller end point than the starting point are not supported.

12 Service and support

Our worldwide service network provides an optimized and efficient support. Our experts offer you advice and assistance should you have any queries. You can contact us **24/7**.

Service Germany Our technology-oriented Competence Center in Lohr, Germany, is responsible for all your service-related queries for electric drive and controls.

Contact the **Service Hotline** and **Service Helpdesk** under:

Phone: **+49 9352 40 5060**
Fax: **+49 9352 18 4941**
E-mail: service.svc@boschrexroth.de
Internet: <http://www.boschrexroth.com>

Additional information on service, repair (e.g. delivery addresses) and training can be found on our internet sites.

Service worldwide Outside Germany, please contact your local service office first. For hotline numbers, refer to the sales office addresses on the internet.

Preparing information To be able to help you more quickly and efficiently, please have the following information ready:

- Detailed description of malfunction and circumstances
- Type plate specifications of the affected products, in particular type codes and serial numbers
- Your contact data (phone and fax number as well as your e-mail address)

Index

A

A1, acceleration in the starting point.....	44
A2, acceleration in the end point.....	45
Abbreviations.....	13
About this documentation.....	5
Information representation.....	12
Validity of the documentation.....	5
Absolute editing of the master axis range (X-values).....	47
Absolute editing of the slave axis position (Y-values).....	46
Amax.....	45
Application-specific wizard.....	31, 61
Attributes.....	54

C

Calculate the motion step.....	45
Cam	
Analyze.....	25
Copy.....	73
Create.....	31
Create a variable cam and a PLC function block.....	27
Create and download.....	19
Delete.....	73
Insert.....	73
Open.....	73
Preview.....	67
Preview of superimposed cams (XY).....	69
Rename.....	73
Save.....	73
Cam Pool.....	73
Create.....	73
Cam properties.....	85
Cam table.....	66
Processing.....	49
CamBuilder	
Cam pool.....	18
Cams.....	18
Preview.....	18
Preview of superimposed cams (X/Y).....	18
CamBuilder features.....	15
CamBuilder options.....	83
Graph - Colors.....	85
Graph - General.....	84
Settings.....	83
Cmdyn.....	45
Compact Flash Card.....	76
Coordinate system.....	35
CrossCutter wizard.....	61
CSV.....	79

D

Default layout.....	37
Definition of terms.....	16

Delta X.....	41
Delta Y.....	40
Demo license.....	18
Description.....	45
Distance.....	16, 40
Documentation structure.....	5
Download cams to devices.....	75
Duration.....	41
Dynamic torque.....	45

E

Editing mode.....	40
End point.....	16, 44
Event.....	54
Export cams	
IndraSize.....	79
Extreme values.....	67

F

Feed wizard.....	62
First Steps – CamBuilder.....	17
FlyingShear Wizard.....	64
Formula.....	57

G

Graph editor.....	35
Graph Manager.....	37

H

Helpdesk.....	121
Hotline.....	121

I

Import and export cams.....	79
Import cams.....	81
Installation.....	17
Interact with Bosch Rexroth devices.....	75
Introduction.....	15

J

J1, jerk in the starting point.....	44
J2, jerk in the end point.....	45
Jmax.....	45

L

Library.....	18
Licensing.....	17

M

Master axis.....	16
Master axis section.....	41
Master axis velocity.....	40
Maximum values.....	45
Motion law.....	16, 42, 89

Index

A-CAM linear.....	112	Velocity-in-rest.....	104
Analytic.....	93	Velocity-in-rest, polynomial 5th order.....	104
Analytic G-G.....	105	Velocity-in-rest, polynomial 7th order.....	104
Cam tables.....	119	Velocity-in-velocity.....	105
Extended.....	112	Velocity-in-velocity, constant velocity.....	105
Extended, acceleration-limited motion (sine curve).....	115	Velocity-in-velocity, modified sine curve.....	106
Extended, acceleration-limited motion (trapezoid profile).....	114	Velocity-in-velocity, polynomial 5th order.....	105
Extended, jerk-limited motion (trapezoid profile).....	115	Velocity-in-velocity, polynomial 7th order.....	106
Extended, linear acceleration.....	112	Motion step.....	16, 35
Extended, linear velocity.....	112	Add after the focused step.....	49
Extended, overshooting-free polynomial 5th order.....	117	Add before focused step.....	51
Extended, resulting master axis range.....	114	Delete.....	53
Extended, velocity 2nd order (end acc. zero).....	114	Editor.....	38
Extended, velocity 2nd order (starting acc. zero).....	113	Motion step limits.....	35
Extended, velocity-limited polynomial 5th order.....	116	Move points.....	36
General motion.....	108	N	
General motion, polynomial 2nd order.....	108	Names.....	13
General motion, polynomial 3rd order.....	108	Names and abbreviations.....	13
General motion, polynomial 4th order.....	109	O	
General motion, polynomial 4th order (S)....	109	Operation modes.....	15
General motion, polynomial 5th order.....	110	P	
General motion, polynomial 7th order.....	110	PAR.....	79
General motion, polynomial 8th order.....	111	PLC code	
Linear interpolation.....	105	Function block.....	77
Linear rest.....	93	Preview	
Miscellaneous.....	116	Copy.....	73
Rest-in-rest.....	93	Create.....	32
Rest-in-rest, Acceleration-optimal in- clined sine curve.....	96	Delete.....	73
Rest-in-rest, inclined sine curve (Beste- horn sinoide).....	95	Insert.....	73
Rest-in-rest, modified acceleration trape- zoid.....	99	Open.....	73
Rest-in-rest, modified sine curve.....	99	Rename.....	73
Rest-in-rest, moment-optimum inclined sine curve.....	97	Save.....	73
Rest-in-rest, polynomial 5th order.....	101	Preview objects of superimposed cam motions	
Rest-in-rest, polynomial 7th order.....	102	Create.....	32
Rest-in-rest, polynomial 8th order.....	102	Print length correction wizard.....	64
Rest-in-rest, quadratic parabola.....	100	Printing cam.....	87
Rest-in-rest, simple sine curve.....	94	Product phases.....	5
Rest-in-rest, sinoide of Gutman.....	98	Profiles.....	35
Rest-in-rest, standstill.....	93	Program start.....	17
Rest-in-velocity.....	103	R	
Rest-in-velocity, polynomial 5th order.....	103	Range.....	16
Rest-in-velocity, polynomial 7th order.....	103	Redo.....	46
Resulting distance.....	112	Reference.....	40
Selection dialog.....	42	Master axis.....	40
V-CAM 2nd order (1).....	113	Time.....	40
V-CAM 2nd order (2).....	114	Relative editing of the master axis range (X- values).....	48
V-CAM linear.....	112	Relative editing of the slave axis position (Y- values).....	47
		S	
		Safety instructions.....	12
		Service hotline.....	121

Slave axis.....	16
Start wizard.....	31
Starting point.....	16, 43
Step type.....	41
Default step.....	41
FlexStep.....	41
Support.....	121
Symbols used.....	12
Synchronization modes.....	15

T

Target groups.....	5
Tool window	
Show.....	37
Turning point displacement.....	45

U

Undo.....	46
Upload cams from devices.....	76

V

V1, velocity in the starting point.....	44
V2, velocity in the end point.....	44
Variable.....	56
View	
Copy graph to clipboard.....	37
Pan.....	37
Selection.....	36
Show All.....	36
Zoom In.....	36
Vmax.....	45

X

X1.....	43
X2.....	44
XML.....	79

Y

Y1, slave axis position in the starting point.....	44
Y2, slave axis position in the end point.....	44

Notes

Notes

Bosch Rexroth AG

Electric Drives and Controls

P.O. Box 13 57

97803 Lohr, Germany

Bgm.-Dr.-Nebel-Str. 2

97816 Lohr, Germany

Phone +49 9352 18 0

Fax +49 9352 18 8400

www.boschrexroth.com/electrics



R911387570