TB = Tapped base pillow block WSTU = Wide slot take-up

HOW TO ORDER/ NOMENCLATURE





E-Z KLEEN Polymer and Stainless Steel Housed Mounted Bearings

HOW TO ORDER

There are two ways to specify DODGE polymer-housed ball bearings. Most of the product offerings have part numbers with listings shown throughout this brochure. Use of part numbers ensures accurate order processing.

When part numbers are not shown, the product may be specified by description or part name. This method is used when ordering units that include modifications or options. To order by description for options not covered by the nomenclature.

```
NOMENCLATURE
P2B - SCUEZ - 104S
                                 PCR
                                        Modification Or Feature:
                                            CR = Corrosion resistant insert
                                            LL = Low torque labyrinth seal
                                            MOD = Modified
                                            NL = No Lube (sealed for life)
                                            P = Polymer housing
                                            SH = Stainless Steel Housing
                            Shaft Size
                                Inches:
                                   First digit = Number of inches
                                   Second & third digits = Number of sixteenths of an inch
                                      104 = Indicates 1-4/16 or 1-1/4
                                   S = Next smaller ring size. E.g. 1-1/4 206 would be written as 104S
                                   L = Next larger ring size. E.g. 1/2 204 would be written as 008L
                                Metric:
                                   First two digits = number of millimeters
                                   M = Metric
                  Bearing Type:
                     SC = Wide inner ring, normal duty, 65o setscrew locking
                     DL = Wide inner ring, normal duty, concentric clamp collar
                     GT = Wide inner ring, normal duty, thin wall adapter locking
                     PS = Polymer Sleeve Insert
                     Suffixes to the above:
                        EZ = EZ-KLEEN (used with polymer or stainless steel housed units)
                        BEZ = Low backing height pillow block, EZ-KLEEN"
                        UEZ = higher back pillow block, EZ-KLEEN (for interchangeability with competitive pillow
                               blocks)
      Housina:
          F2B = 2 bolt flange
          F4B = 4 bolt flange
          FB = Flanged bracket
          INS = Insert
          P2B = Pillow block, 2 bolt base
```