

# ELECTRIC AND AIR POWERED RIVET DRIVING

## Safe, Fast Installation of Flexco® Rivet Fasteners with Powered Rivet Driving

Speed installation of occasional splicing as well as production splicing with a portable electric or air powered rivet driver. Not only reduce operator fatigue, but also ensure the creation of uniform splices, every time.

- Work with standard MSRT or MBRTA application tools
- No need for special guide blocks or rivets – standard MSRT and MBRTA guide blocks ensure proper rivet placement
- Use with Rapid Loader™ Collated Rivets to further speed installation time

### **Electric Powered Rivet Driver**

- Electric Powered Rivet Driver is ergonomically designed and balanced
- Requires Electric Powered Rivet Driver and custom Drive Rod
- Speed settings are adjustable for multiple rivet sizes
- Uses standard 110 volt electric

### **Air Powered Rivet Driver**

- Small, lightweight tool for easy use
- Requires Air Powered Rivet Driver and custom Drive Rod
- Ergonomic handle for added operator comfort
- Requires a minimum of 90 psi for operation



*Electric Powered Rivet Driver Installation*



*Air Powered Rivet Driver Installation*

# ELECTRIC AND AIR POWERED RIVET DRIVING

## Electric Powered Rivet Driver

- For use with standard 110 volt electric
- Works with standard MSRT or MBRTA application tool and guide block

Electric Powered Rivet Driver	
Description	Ordering Number
Standard Kit *	EPRDSSK-1
Straight Shank Replacement Drive Rod	EPRDSS-DR
Step Shank** Replacement Drive Rod	EPRDVS-DR

\*Kit includes Driver, two Custom Drive Rods, and Convenient Carrying Case.

\*\*For use with previous model: EPRDVS-1.



Electric Powered Rivet Driver

## Air Powered Rivet Driver

- Requires a minimum of 90 psi for operation
- Works with standard MSRT or MBRTA application tool and guide block

Air Powered Rivet Driver	
Description	Ordering Number
Air Powered Rivet Driver-Complete*	PTRDK
<b>Replacement Parts</b>	
Air Powered Rivet Driver	PTAH
Retaining Spring	PTRD-RS
Drive Rod with Hold Down Spring and Washer	PTRD-DR

\*Includes Air Powered Rivet Driver, Retaining Spring, and Drive Rod with Hold Down Spring and Washer.



Air Powered Rivet Driver

Authorized Distributor:



2525 Wisconsin Avenue • Downers Grove, IL 60515-4200 • USA  
Tel: (630) 971-0150 • Fax: (630) 971-1180 • E-mail: info@flexco.com

Visit [www.flexco.com](http://www.flexco.com) for other Flexco locations and products.

©2009 Flexible Steel Lacing Company. Flexco® is a registered trademark. 04-22-19. For Reorder: X2159

