## **Switched Disconnects and Enclosures**





HBLDS3RCP

## **Non-Metallic Replacement Covers**

Description	30 Amp	60 Amp	100 Amp
For disconnect switch.	HBLDS3RC	HBLDS6RC	HBLDS10RC
For disconnect switch with LEDs.	HBLDS3RCP	_	-
For disconnect switch with LEDs and Jog.	HBLDS3RCPJ	_	_
For disconnect with Jog switch.	HBLDS3RCJ	HBLDS6RCJ	_

**Stainless Steel Replacement Covers** 

Description	30 Amp	60 Amp	100 Amp
For square top disconnect switch.	HBLDS3SSRC	HBLDS60100SSRC	HBLDS60100SSRC
For square top disconnects with LEDs.	HBLDS3SSRCP	_	_
For square top disconnect with Jog switch.	HBLDS3SSRCJ	_	_
For sloped top disconnect switch.	HBLDS3SSRRC	HBLDS60100SSRRC	HBLDS60100SSRRC
For sloped top disconnect with LEDs.	HBLDS3SSRRCP	_	_
For sloped top disconnect with Jog switch.	HBLDS3SSRRCJ	_	_



Description	Catalog Number
For 30A switches.	HBL30RGB
For 60A and 100A switches.	HBL60100RGB

**Replacement Neutral Block** 

Description	Catalog Number
For 30A switches.	HBL30RNB
For 60A switches.	HBL60RNB
For 100A switches.	HBL100RNB

**Replacement Switches** 

Description	Catalog Number
For 30A switches.	HBLDS3RS
For 60A and 100A switches.	HBLDS60100RS
For HBLDS33ACNK.	HBLDS33ACRS

**Replacement Mounting Feet** 

Description	Catalog Number
For 30A non-metallic switches.	HBLRFT1 <sup>∆</sup>
For 60A and 100A non-metallic switches.	HBLRFT2 <sup>∆</sup>

Note: <sup>A</sup> Package of 10 feet and 10 screws.



HBLDS3RCJ



HBLDS3SSRC



HBLDS3SSRRC



HBLDS3SSRRCP



HBL30RGB



HBL30RNB



HBLDS3RS

