



Series B Pico Controller

Catalog Number

1760-L12AWA, 1760-L12AWA-NC, 1760-L12AWA-ND, 1760-L12BBB, 1760-L12BBB-ND, 1760-L12BWB, 1760-L12BWB-NC, 1760-L12BWB-ND, 1760-L12DWD, 1760-L12DWD-ND, 1760-L12NWN, 1760-L12NWN-ND, 1760-L18AWA-EX, 1760-L18AWA-EXND, 1760-L18BWB-EX, 1760-L18BWB-EXND, 1760-L18DWD-EX, 1760-L18DWD-EXND, 1760-L18NWN-EX, 1760-L18NWN-EXND, 1760-L20BBB-EX, 1760-L20BBB-EXND

Introduction

Read this document before using the Series B Pico controller. This release note contains important information about:

- software compatibility
- how to find the Series letter
- how to download software

Software Compatibility

If you are using programming software to program the Pico controller, be sure that you are using the correct software version.



IMPORTANT !

PicoSoft version 6.1 or higher must be used to for the Series B Pico controller. Earlier versions of PicoSoft can only be used with Series A Pico controllers.

Find the Series Letter


The Series letter is printed on the side of the housing as shown.

Download the Software

You can download a free copy of PicoSoft version 6.1 from our web site.

Go to <http://www.ab.com/picosoft6>.

For PicoSoft Pro, please contact your Allen-Bradley Distributor or Rockwell Automation representative.



www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846